


Cinterion[®] PLS8-X

AT Command Set

Version: 03.017
DocId: PLS8-X_ATC_V03.017



Document Name: **Cinterion® PLS8-X AT Command Set**

Version: **03.017**

Date: **May 26, 2016**

DocId: **PLS8-X_ATC_V03.017**

Status **Confidential / Released**

GENERAL NOTE

THE USE OF THE PRODUCT INCLUDING THE SOFTWARE AND DOCUMENTATION (THE "PRODUCT") IS SUBJECT TO THE RELEASE NOTE PROVIDED TOGETHER WITH PRODUCT. IN ANY EVENT THE PROVISIONS OF THE RELEASE NOTE SHALL PREVAIL. THIS DOCUMENT CONTAINS INFORMATION ON GEMALTO M2M PRODUCTS. THE SPECIFICATIONS IN THIS DOCUMENT ARE SUBJECT TO CHANGE AT DISCRETION OF GEMALTO M2M. GEMALTO M2M GMBH GRANTS A NON-EXCLUSIVE RIGHT TO USE THE PRODUCT. THE RECIPIENT SHALL NOT TRANSFER, COPY, MODIFY, TRANSLATE, REVERSE ENGINEER, CREATE DERIVATIVE WORKS; DISASSEMBLE OR DECOMPILE THE PRODUCT OR OTHERWISE USE THE PRODUCT EXCEPT AS SPECIFICALLY AUTHORIZED. THE PRODUCT AND THIS DOCUMENT ARE PROVIDED ON AN "AS IS" BASIS ONLY AND MAY CONTAIN DEFICIENCIES OR INADEQUACIES. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, GEMALTO M2M GMBH DISCLAIMS ALL WARRANTIES AND LIABILITIES. THE RECIPIENT UNDERTAKES FOR AN UNLIMITED PERIOD OF TIME TO OBSERVE SECRECY REGARDING ANY INFORMATION AND DATA PROVIDED TO HIM IN THE CONTEXT OF THE DELIVERY OF THE PRODUCT. THIS GENERAL NOTE SHALL BE GOVERNED AND CONSTRUED ACCORDING TO GERMAN LAW.

Copyright

Transmittal, reproduction, dissemination and/or editing of this document as well as utilization of its contents and communication thereof to others without express authorization are prohibited. Offenders will be held liable for payment of damages. All rights created by patent grant or registration of a utility model or design patent are reserved.

Copyright © 2016, Gemalto M2M GmbH, Gemalto Company

Trademark Notice

Gemalto, the Gemalto logo, are trademarks and service marks of Gemalto and are registered in certain countries.

Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. All other registered trademarks or trademarks mentioned in this document are property of their respective owners.

Contents

1.	Introduction.....	12
1.1	Scope of the document	12
1.2	Related documents	13
1.3	Document Conventions	15
1.3.1	Quick Reference Table	15
1.3.2	Superscript Notation for Parameters And Values	16
1.4	AT Command Interpreter.....	17
1.5	AT Command Syntax	18
1.5.1	Using Parameters	18
1.5.2	Concatenating AT Commands.....	18
1.6	Communication between Customer Application and PLS8-X	20
1.7	Supported character sets	21
1.7.1	GSM alphabet tables and UCS2 character values	23
1.7.2	UCS2 and GSM character coding and conversion	25
1.7.2.1	Output of SIM data (UE to TE).....	25
1.7.2.2	Input of SIM data (TE to UE)	26
1.8	Unsolicited Result Code Presentation.....	27
1.8.1	Common URCs.....	28
1.9	Errors and Messages	29
2.	Configuration Commands.....	30
2.1	AT&F Reset AT Command Settings to Factory Default Values	30
2.2	AT&V Display current Configuration.....	31
2.2.1	AT&V Response	31
2.3	AT&W Store AT Command Settings to User Defined Profile	32
2.4	ATQ Result Code Presentation Mode	33
2.5	ATV Result code format mode	34
2.5.1	Verbose and numeric result codes	34
2.6	ATX Result Code Selection.....	35
2.7	ATZ Restore AT Command Settings from User Defined Profile	36
2.8	AT+CMEE Error Message Format	37
2.8.1	CME/CMS Error Code Overview	38
2.9	AT+CSCS Character Set	42
2.10	AT+CFUN PLS8-X Functionality Level	43
2.11	AT+GCAP Capabilities List	45
2.12	AT^SMSO Switch Off PLS8-X.....	46
2.13	AT^SCFG Extended Configuration Settings	47
2.14	AT^SSRVSET Service Interface Configuration	73
3.	Status Control Commands	79
3.1	AT+CEER Extended Error Report.....	79
3.1.1	List of status codes for extended error report	80
3.2	AT^SIND Extended Indicator Control.....	88
3.3	AT+CPAS Activity Status	104
3.4	AT+WS46 Select wireless network	105

4.	Serial Interface Control Commands.....	106
4.1	ATQ Flow Control.....	106
4.2	AT&C Set Data Carrier Detect (DCD) line mode.....	107
4.3	AT&D Set Data Terminal Ready (DTR) line mode.....	108
4.4	AT&S Set Data Set Ready (DSR) line mode.....	109
4.5	ATE AT Command Echo.....	110
4.6	AT+IPR Bit Rate.....	111
4.7	AT+CMUX Multiplex mode.....	112
4.7.1	Restrictions while using Multiplex mode.....	113
4.8	AT^SQPORT Query Port Type.....	114
5.	Security Commands.....	115
5.1	AT+CPIN PIN Authentication.....	115
5.2	AT+CLCK Facility Lock.....	117
5.3	AT+CPWD Change Password.....	124
5.4	AT^SPIC Display PIN Counter.....	127
6.	Identification Commands.....	132
6.1	ATI Display product identification information.....	132
6.2	AT+CGMI Request manufacturer identification.....	134
6.3	AT+GMI Request manufacturer identification.....	134
6.4	AT+CGMM Request model identification.....	135
6.5	AT+GMM Request model identification.....	135
6.6	AT+CGMR Request revision identification of software status.....	136
6.7	AT+GMR Request revision identification of software status.....	136
6.8	AT+CGSN Request International Mobile Equipment Identity (IMEI).....	137
6.9	AT+GSN Request International Mobile Equipment Identity (IMEI).....	137
6.10	AT+CIMI Request International Mobile Subscriber Identity (IMSI).....	138
7.	Network Service Commands.....	139
7.1	AT+COPN Read operator names.....	139
7.2	AT+COPS Operator Selection.....	140
7.3	AT+CPOL Preferred Operator List.....	143
7.4	AT+CPLS Select Preferred Operator List.....	145
7.5	AT+CREG Network Registration Status.....	146
7.6	AT+CESQ Extended Signal Quality.....	149
7.7	AT+CSQ Signal Quality.....	151
7.8	AT+CTZU Automatic Time Zone Update.....	152
7.9	AT^SMONI Monitoring Serving Cell.....	154
7.9.1	AT^SMONI Responses.....	154
7.9.2	AT^SMONI Enhanced Responses.....	158
7.9.3	Service states.....	161
7.10	AT^SMONP Monitoring Neighbour Cells.....	163
7.10.1	AT^SMONP Responses.....	163
7.10.2	AT^SMONP Enhanced Responses.....	166
7.11	AT^SNMON Network Monitoring.....	170
7.12	AT^SNCSGLS Operator CSG lists on USIM.....	172
7.13	AT^SNCSGSC Closed Subscriber Group Network Scan.....	173
7.14	AT^SNRSRP Neighbour Reference Signal Received Power.....	175
7.15	AT^SNRSRQ Neighbour Reference Signal Received Quality.....	176

8.	USIM Application Toolkit (USAT) Commands.....	177
8.1	Usage of Remote-SAT	179
8.1.1	Automatic Response Mode (AR Mode)	179
8.1.2	Explicit Response Mode (ER Mode).....	179
8.1.3	Character Sets.....	179
8.1.4	USIM Update Initiated by the Network.....	180
8.1.5	Icon Handling.....	180
8.1.6	Using SMS Related AT Commands	180
8.2	Remote-SAT States	182
8.2.1	Remote-SAT State Transition Diagram	183
8.2.2	Remote-SAT State Transition Table.....	184
8.3	Remote-SAT Command Types	186
8.4	AT^SSTA Remote-SAT Interface Activation	187
8.5	^SSTN SAT Notification	189
8.6	AT^SSTGI SAT Get Information	191
8.7	AT^SSTGI SAT Get Information - Refresh (1)	192
8.8	AT^SSTGI SAT Get Information - Set Up Event List (5)	194
8.9	AT^SSTGI SAT Get Information - Set Up Call (16).....	195
8.10	AT^SSTGI SAT Get Information - Send SS (17).....	197
8.11	AT^SSTGI SAT Get Information - Send USSD (18)	198
8.12	AT^SSTGI SAT Get Information - Send Short Message (19)	199
8.13	AT^SSTGI SAT Get Information - Send DTMF (20)	200
8.14	AT^SSTGI SAT Get Information - Launch Browser (21).....	201
8.15	AT^SSTGI SAT Get Information - Play Tone (32).....	203
8.16	AT^SSTGI SAT Get Information - Display Text (33).....	205
8.17	AT^SSTGI SAT Get Information - Get Inkey (34)	207
8.18	AT^SSTGI SAT Get Information - Get Input (35)	209
8.19	AT^SSTGI SAT Get Information - Select Item (36).....	211
8.20	AT^SSTGI SAT Get Information - Set up Menu (37)	213
8.21	AT^SSTGI SAT Get Information - Set up Idle Mode Text (40).....	215
8.22	AT^SSTGI SAT Get Information - Language Notification (53).....	216
8.23	AT^SSTGI SAT Get Information - Open Channel (64).....	217
8.24	AT^SSTGI SAT Get Information - Close Channel (65)	218
8.25	AT^SSTGI SAT Get Information - Receive Data (66)	219
8.26	AT^SSTGI SAT Get Information - Send Data (67).....	220
8.27	AT^SSTR SAT Response	221
8.28	AT^SSTR SAT Response - Refresh (1)	223
8.29	AT^SSTR SAT Response - Set Up Event List (5).....	224
8.30	AT^SSTR SAT Response - Set Up Call (16)	225
8.31	AT^SSTR SAT Response - Send SS (17)	226
8.32	AT^SSTR SAT Response - Send USSD (18)	227
8.33	AT^SSTR SAT Response - Send Short Message (19).....	228
8.34	AT^SSTR SAT Response - Send DTMF (20)	229
8.35	AT^SSTR SAT Response - Launch Browser (21).....	230
8.36	AT^SSTR SAT Response - Play Tone (32)	231
8.37	AT^SSTR SAT Response - Display Text (33).....	232
8.38	AT^SSTR SAT Response - Get Inkey (34)	233
8.39	AT^SSTR SAT Response - Get Input (35).....	235
8.40	AT^SSTR SAT Response - Select Item (36).....	237

8.41	AT^SSTR	SAT Response - Set Up Menu (37)	238
8.42	AT^SSTR	SAT Response - Set Up Idle Mode Text (40)	239
8.43	AT^SSTR	SAT Response - Language Notification (53)	240
8.44	AT^SSTR	SAT Response - Open Channel (64)	241
8.45	AT^SSTR	SAT Response - Close Channel (65)	242
8.46	AT^SSTR	SAT Response - Receive Data (66)	243
8.47	AT^SSTR	SAT Response - Send Data (67)	244
8.48	AT^SSTR	SAT Event - Menu Selection (211)	245
8.49	AT^SSTR	SAT Event - User Activity (232)	246
8.50	AT^SSTR	SAT Event - Idle Screen Available (233)	247
8.51	AT^SSTR	SAT Event - Language Selection (235)	248
8.52	AT^SSTR	SAT Event - Browser Termination (236)	249
8.53	AT^SSTR	SAT Event - Terminate Command (254)	250
8.54		Examples for Using Remote-SAT	251
9.	Short Message Service (SMS) Commands		254
9.1		SMS parameters	254
9.2	AT+CMGC	Send an SMS command	258
9.3	AT+CMGD	Delete short message	259
9.4	AT+CMGF	Select SMS message format	260
9.5	AT+CMGL	List SMS messages from preferred store	261
9.6	AT+CMGR	Read SMS messages	263
9.7	AT+CMGS	Send Short Message	265
9.8	AT+CMGW	Write Short Messages to Memory	266
9.9	AT+CMSS	Send short messages from storage	267
9.10	AT+CNMA	New Message Acknowledgement to UE/TE	268
9.11	AT+CNMI	SMS Event Reporting Configuration	270
9.12	AT+CPMS	Preferred SMS message storage	274
9.13	AT+CSCA	SMS Service Center Address	276
9.14	AT+CSCB	Select Cell Broadcast Message Indication	277
9.15	AT+CSDH	Show SMS text mode parameters	279
9.16	AT+CSMP	Set SMS Text Mode Parameters	280
9.17	AT+CSMS	Select Message Service	282
9.18	AT^SMGL	List Short Messages from preferred store without setting status to REC READ	284
9.19	AT^SMGR	Read short message without setting status to REC READ	285
9.20	AT^SSDA	Set SMS Display Availability	286
10.	Internet Service Commands		287
10.1	AT^SICA	Internet Connection Activate or Deactivate	291
10.2	AT^SICS	Internet Connection Settings	292
10.3	AT^SIPS	Internet Profile Storage	294
10.4	AT^SISS	Internet Service Setup Profile	295
10.5	AT^SISI	Internet Service Information	303
10.6	AT^SISO	Internet Service Open	305
10.7	AT^SISC	Internet Service Close	308
10.8	AT^SISR	Internet Service Read Data	309
10.8.1		Example: Socket Host Reads Small Amounts of UDP Data Packets (URC Mode)	311
10.9	AT^SISW	Internet Service Write Data	312
10.9.1		Usage of parameter <eodFlag>	314
10.10	AT^SIST	Transparent Mode	315

10.11	AT^SISH Disconnect Remote Client	317
10.12	AT^SISX Internet Service Execution	318
10.13	AT^SISE Internet Service Error Report	321
10.14	Internet Service URC	322
10.14.1	Information Elements Related to the Service Application	323
10.14.2	Information Elements Related to FTP Service	326
10.14.3	Information Elements Related to HTTP Service	326
10.14.4	Information Elements Related to SMTP Service	326
10.15	Examples of how to Configure and Use Internet Service Profiles	328
10.15.1	Selecting URC Mode or Polling Mode	328
10.15.2	Configuring an Internet Connection Profile	328
10.15.3	Configuring Non-Transparent Listener	328
10.15.4	Configuring TCP Client for Calling a TCP Listener	329
10.15.5	Transparent TCP Listener: Accepting / Rejecting Incoming Remote Client	329
10.15.6	Transparent TCP Listener: Autoanswering Incoming Remote Client	331
10.15.7	Socket Client Sends Data via TCP Connection (Polling Mode)	332
10.15.8	Socket Client Sends Data via TCP Connection with URCS	332
10.15.9	UDP Scenario	333
10.15.10	Creating Transparent TCP Socket Client	335
10.15.11	Opening and Closing Transparent TCP Service	335
10.15.12	Transparent TCP Client Receives Data While in AT Command Mode	336
10.15.13	Remote Server Disconnects While Transparent TCP Service is in Transparent Access Mode	337
10.15.14	Server Disconnects While Transparent TCP Service is in AT Command Mode and Data is Pending	337
10.15.15	FTP Upload Single File (URC Mode)	339
10.15.16	HTTP Download Using TLS	340
10.15.17	HTTP Post	340
10.15.18	Ping	341
10.15.19	Resolving DNS Host Name to IP Address	342
11.	Supplementary Service Commands	343
11.1	ATD Dialing Supplementary Service Number	343
11.2	AT+CCFC Call forwarding number and conditions control	344
11.3	AT+CUSD Unstructured Supplementary Service Data	348
12.	Packet Domain Related Commands	350
12.1	AT+CGDCONT Define PDP Context	350
12.1.1	Attaching to LTE Networks	352
12.2	AT+CGATT PS Attach or Detach	354
12.3	AT+CGACT PDP Context Activate or Deactivate	355
12.4	AT+CGDATA Enter Data State	357
12.4.1	Automatic deactivation of PDP context during dial-up PPP	358
12.5	AT+CGPADDR Show PDP Address	359
12.6	AT+CGPIAF Select Printing IP address format	361
12.7	AT+CGEREP Packet Domain Event Reporting	363
12.8	AT+CGREG Packet Domain Network Registration Status	366
12.9	AT+CEREG EPS Network Registration Status	368
12.10	AT+CGCONTRDP PDP context read dynamic parameters	370
12.11	AT+CGEQOS Define EPS Quality of Service	372

12.12	AT+CGEQOSRDP	EPS Quality of Service Read Dynamic Parameters	374
12.13	AT+CGSMS	Select Service for MO Short Messages	376
12.14	AT+CNMPSD	No more PS data	377
12.15	ATD*99#	Request Packet Domain service	378
12.16	AT^SGAPN	Configure APN class settings	379
12.17	AT^SGAUTH	Set Type of Authentication for PDP-IP Connections	382
12.18	AT^SWWAN	PDP Context Activate or Deactivate	384
13.	USIM related Commands		386
13.1	AT+CRSM	Restricted USIM Access	386
13.2	AT+CSIM	Generic USIM Access	388
13.3	AT^SATR	Query SIM's Answer to Reset Data	390
13.4	AT^SCKS	Query USIM and Chip Card Holder Status	391
13.5	AT^SSET	USIM Data Ready Indication	393
13.6	AT^SCID	USIM Identification Number	394
14.	Phonebook Commands		395
14.1	AT+CPBS	Select phonebook memory storage	395
14.2	AT+CPBR	Read from phonebook	398
14.3	AT+CPBW	Write into phonebook	401
14.4	AT+CNUM	Read own numbers	404
15.	GNSS Commands		405
15.1	GNSS Sentences		406
15.2	GNSS Power Saving Considerations		407
15.3	^SGPSE	GNSS Event Notification	408
15.4	AT^SGPSC	GNSS Configuration	410
15.5	Examples of How to Configure and Use GNSS		417
15.5.1	Loading Xtra.Bin File and Activating A-GNSS Start Mode		417
15.5.2	Trying to Load Invalid XTRA File		418
15.5.3	Starting GNSS without Aiding		418
15.5.4	Cold Start		418
15.5.5	Using the GNSS Buffering Mechanism		419
16.	Audio Commands		421
16.1	AT^SAIC	Audio Interface Configuration	421
16.2	AT^SNFG	Generate Tone	424
16.3	AT^SNFI	Set microphone path parameters	426
16.4	AT^SNFO	Set audio output parameter (loudspeaker path)	427
16.5	AT^SNFS	Select audio hardware set	429
17.	Hardware related Commands		430
17.1	AT+CALA	Alarm Configuration	430
17.2	AT+CCLK	Real Time Clock	433
17.3	AT^SAD	Antenna Configuration	435
17.4	AT^SBV	Battery/Supply Voltage	437
17.5	AT^SCTM	Critical Operating Temperature Monitoring	438
17.5.1	Deferred shutdown		439
17.6	AT^SLED	LED Feature	441
17.7	AT^SRADC	Configure and Read A/D Converter	443

18. General Purpose I/O (GPIO) Pin related Commands.....	447
18.1 AT^SPIO GPIO Driver Open/Close.....	447
18.2 AT^SCPIN Pin Configuration	448
18.3 AT^SCPOL GPIO Level Polling Configuration	450
18.4 AT^SGIO Get IO state of a specified pin.....	451
18.5 AT^SSIO Set IO state of a specified pin	452
19. Miscellaneous Commands.....	453
19.1 A/ Repeat Previous Command Line	453
19.2 +++ Escape from Data Mode to AT Command Mode	454
19.3 AT^SBNR Binary Read	455
19.4 AT^SBNW Binary Write.....	457
19.5 AT^SFDL Enter Firmware Download Mode	461
20. Appendix	462
20.1 Star-Hash (*#) Network Commands.....	462
20.2 Available AT Commands and Dependency on SIM PIN	464
20.3 Availability of AT Commands Depending on Operating Mode of ME	470
20.4 AT Command Settings storable with AT&W.....	476
20.5 Factory Default Settings Restorable with AT&F	477
20.6 Summary of Unsolicited Result Codes (URC).....	479
20.7 AT Commands Supported Only on the Modem Interface	482
20.8 Alphabetical List of AT Commands	483

List of Tables

Table 1.1:	Symbols used to mark the type of parameters	16
Table 1.2:	Symbols used to indicate storage options or correlations with other commands	16
Table 1.3:	Symbols used to mark different types of default values of parameters	16
Table 1.4:	Types of AT commands and responses	18
Table 1.5:	Exemplary escape sequences generated by PLS8-X for its non-UCS2 output	22
Table 2.1:	AT&V Response	31
Table 2.2:	General "CME ERROR" Codes (3GPP TS 27.007)	38
Table 2.3:	GPRS related "CME ERROR" Codes (3GPP TS 27.007)	39
Table 2.4:	Enhanced "CME ERROR" Codes	39
Table 2.5:	SMS related "CMS ERROR" Codes (3GPP TS 27.005)	40
Table 2.6:	Validated and released Service/Device Mappings	73
Table 8.1:	State: RESET description	184
Table 8.2:	State: OFF description	184
Table 8.3:	State: IDLE description	184
Table 8.4:	State: PAC description	185
Table 8.5:	State: WAIT description	185
Table 8.6:	Command Type Table	186
Table 10.1:	Applicability of AT^SICS <conParmTag> values	292
Table 10.2:	Applicability of AT^SISS <srvParmTag> values	295
Table 17.1:	PLS8-X Status and Mode Indication via LED	441
Table 20.1:	Star-Hash (*#) Command Overview	462
Table 20.2:	Abbreviations of Codes and Parameters used in Table 20.1	462
Table 20.3:	Star-Hash Command Response Parameters	463
Table 20.4:	Star-Hash Commands for Supplementary Services	463
Table 20.5:	Available AT Commands and Dependency on SIM PIN	464
Table 20.6:	Availability of AT Commands Depending on Operating Mode of ME	470
Table 20.7:	Settings Stored to User Profile	476
Table 20.8:	Factory Default Settings Restorable with AT&F	477
Table 20.9:	Summary of Unsolicited Result Codes (URC)	479
Table 20.10:	AT Commands Supported Only on the Modem Interface	482
Table 20.11:	Alphabetical List of AT Commands	483

List of Figures

Figure 1.1:	Main character table of GSM 7 bit default alphabet.....	23
Figure 1.2:	Extension character table of GSM 7 bit default alphabet.....	24
Figure 8.1:	Remote-USAT Context Diagram	178
Figure 8.2:	Remote-SAT State Transition Diagram	183

1. Introduction

1.1 Scope of the document

This document presents the AT Command Set for
PLS8-X GSM/UMTS/LTE Mobile Engine, Release 03.017.

Before using the PLS8-X or upgrading to a new firmware version please read the latest product information provided in "[PLS8-X Release Notes, Version 03.017](#)".

More information is available at <http://m2m.gemalto.com/>.

DISCLAIMER:

AT commands or parameters not documented in this document are subject to change and reserved for future use. Gemalto M2M GmbH reserves the right to modify or even eliminate these options in later releases.

PLS8-X features packet switched (PS) data capability, but does not support circuit switched (CS) data transmission. However, for reasons of compatibility with other products, and for compliance with 3GPP TS specifications, some AT commands imply parameters or values related to CS data capability.

1.2 Related documents

1.2 Related documents

- [1] PLS8-X Release Notes, Version 03.017
- [2] PLS8-X Hardware Interface Description, Version 03.017
- [3] User's Guide: Getting Started with PLS8-X
- [4] Application Note 16: Updating PLS8-X Firmware
- [5] Application Note 37: GPS Antenna Integration for PLS8-X
- [6] Application Note 39: USB Interface Description for PLS8-X
- [7] Application Note 62: Transport Layer Security for Client TCP/IP Services
- [8] [3GPP TR 21.905](#) (descendant of 3GPP TR 01.04): Vocabulary for 3GPP Specifications
- [9] Multiplexer User's Guide
- [10] [3GPP TS 27.010](#) (descendant of 3GPP TS 07.10): Terminal Equipment to User Equipment (TE-UE) multiplexer protocol
- [11] Multiplex Driver Developer's Guide
- [12] Multiplex Driver Installation Guide
- [13] International Organization for Standardization (ISO): [ISO/IEC10646](#): Universal Multiple-Octet Coded Character Set (UCS) - Part 1: Architecture and Basic Multilingual Plane.
This international standard is [closely related](#) to the [Unicode Standard](#) published by the [Unicode Consortium](#)
- [14] The [Unicode Consortium](#): [Mapping of ETSI GSM 03.38 7-bit default alphabet characters into Unicode \[.TXT!\]](#)
- [15] [ITU-T V.24](#) List of definitions for interchange circuits between data terminal equipment (DTE) and data circuit-terminating equipment (DCE)
- [16] [ITU-T V.250](#) Serial asynchronous automatic dialling and control
- [17] [3GPP TS 11.11](#): Specification of the Subscriber Identity Module - Mobile Equipment (SIM - ME) interface
- [18] [3GPP TS 31.101](#): UICC-terminal interface; Physical and logical characteristics
- [19] [3GPP TS 31.102](#): Characteristics of the Universal Subscriber Identity Module (USIM) application
- [20] [ETSI TS 102 221](#): Smart Cards; UICC-Terminal interface; Physical and logical characteristics
- [21] [3GPP TS 11.14](#): Specification of the SIM Application Toolkit for the Subscriber Identity Module - Mobile Equipment (SIM - ME) interface
- [22] [3GPP TS 31.111](#): Universal Subscriber Identity Module (USIM) Application Toolkit (USAT)
- [23] [ETSI TS 102 223](#): Smart Cards; Card Application Toolkit (CAT)
- [24] [3GPP TS 31.124](#): Mobile Equipment (ME) conformance test specification - Universal Subscriber Identity Module Application Toolkit (USAT) conformance test specification
- [25] [3GPP TS 22.002](#) (descendant of 3GPP TS 22.02): Circuit Bearer Services (BS) supported by a Public Land Mobile Network (PLMN)
- [26] [3GPP TS 22.004](#) (descendant of 3GPP TS 02.04): General on supplementary services
- [27] [3GPP TS 22.030](#) (descendant of 3GPP TS 02.30): Man-Machine Interface (MMI) of the Mobile Station (MS)
- [28] [3GPP TS 22.060](#) (descendant of 3GPP TS 02.60): General Packet Radio Service (GPRS); Service description; Stage 1
- [29] [3GPP TS 23.060](#) (descendant of 3GPP TS 03.60): General Packet Radio Service (GPRS); Service description; Stage 2
- [30] [3GPP TS 22.081](#) (descendant of 3GPP TS 02.81): Line Identification Supplementary Services; Stage 1
- [31] [3GPP TS 22.082](#) (descendant of 3GPP TS 02.82): Call Forwarding (CF) Supplementary Services; Stage 1
- [32] [3GPP TS 22.083](#) (descendant of 3GPP TS 02.83): Call Waiting (CW) and Call Holding (HOLD); Supplementary Services; Stage 1
- [33] [3GPP TS 22.085](#) (descendant of 3GPP TS 02.85): Closed User Group (CUG) supplementary services; Stage 1
- [34] [3GPP TS 22.088](#) (descendant of 3GPP TS 02.88): Call Barring (CB) supplementary services; Stage 1
- [35] [3GPP TS 22.090](#) (descendant of 3GPP TS 02.90): Unstructured Supplementary Service Data (USSD);

1.2 Related documents

Stage 1

- [36] [3GPP TS 23.038](#) (descendant of 3GPP TS 03.38): Alphabets and language specific information
- [37] [3GPP TS 23.040](#) (descendant of 3GPP TS 03.40): Technical realization of the Short Message Service (SMS)
- [38] [3GPP TS 23.041](#) (descendant of 3GPP TS 03.41): Technical realization of Cell Broadcast Service (CBS)
- [39] [3GPP TS 23.107](#): Quality of Service (QoS) concept and architecture
- [40] [3GPP TS 24.011](#) (descendant of 3GPP TS 04.11): Point-to-Point (PP) Short Message Service (SMS) support on mobile radio interface
- [41] [3GPP TS 24.008](#) (descendant of 3GPP TS 04.08): Mobile radio interface Layer 3 specification; Core network protocols; Stage 3
- [42] [3GPP TS 24.080](#) (descendant of 3GPP TS 04.80): Mobile radio interface layer 3 supplementary services specification; Formats and coding
- [43] [3GPP TS 24.301](#) Non-Access-Stratum (NAS) protocol for Evolved Packet System (EPS)
- [44] [3GPP TS 25.133](#) Requirements for support of radio resource management
- [45] [3GPP TS 25.304](#) User Equipment (UE) procedures in idle mode and procedures for cell reselection in connected mode
- [46] [3GPP TS 25.331](#) Radio Resource Control (RRC)
- [47] [3GPP TS 27.005](#) (descendant of 3GPP TS 07.05): Use of Data Terminal Equipment - Data Circuit terminating Equipment (DTE - DCE) interface for Short Message Service (SMS) and Cell Broadcast Service (CBS)
- [48] [3GPP TS 27.007](#) (descendant of 3GPP TS 07.07): AT command set for User Equipment (UE)
- [49] [3GPP TS 27.060](#) (descendant of 3GPP TS 07.60): Mobile Station (MS) supporting Packet Switched Services
- [50] [3GPP TS 22.101](#) (descendant of 3GPP TS 02.07 and 3GPP TS 02.40): Service principles
- [51] [Common PCN Handset Specification \(CPHS\) v4.2 \[.ZIP!\]](#)
- [52] [3GPP TS 45.008](#) (descendant of GSM 05.08): Radio subsystem link control
- [53] [3GPP TS 36.133](#) Evolved Universal Terrestrial Radio Access (E-UTRA); Requirements for support of radio resource management
- [54] [Documents posted on website of USB Implementers Forum](#)
- [55] [USB Language Identifiers \(LANGIDs\) \[.PDF!\]](#)
- [56] USB Class Definitions for Communication Devices, Version 1.1 January 19, 1999

1.3 Document Conventions

Throughout this document PLS8-X is also referred to as GSM/UMTS/LTE Mobile Engine or short UE, ME (Mobile Engine), MS (Mobile Station) or Mobile Terminal (MT). In related documents the equivalent term DCE (Data Communication Equipment) may be found.

AT Commands are used to control the PLS8-X. The controlling device is referred to as Customer Application or short TE. Related documents may use the equivalent term DTE (Data Terminal Equipment).

All abbreviations and acronyms used throughout this document are based on GSM or 3GPP specifications. For additional definitions please refer to 3GPP TR 21.905 [8].

1.3.1 Quick Reference Table

Each AT command description includes a table similar to the example shown below. The table is intended as a quick reference to indicate the following functions:

PIN:	Is the AT command PIN protected? + Yes - No ± Usage is dependent on conditions specified for the command, or not all command types are PIN protected (for example write command PIN protected, read command not). Note: The table provided in Section 20.2, Available AT Commands and Dependency on SIM PIN uses the same symbols.
MDM:	Is the AT command supported on the Modem instance? + Yes - No
APP:	Is the AT command supported on the Application instance? + Yes - No
→	Is the AT command supported in AIRPLANE mode? + Yes - No ± In AIRPLANE mode, not all described functions are available. For example, the test or read command is usable, the write or execute command is not. Furthermore, only some of the listed parameters can be changed in AIRPLANE mode. A typical example is AT^SCFG that controls different features.
Last:	If commands are concatenated, this AT command must be the last one. + Yes - No Note: See also Section 1.5, AT Command Syntax for details on concatenated AT commands.

Example:

PIN	MDM	APP	→	Last
-	+	+	-	-

1.3.2 Superscript Notation for Parameters And Values

Table 1.1: Symbols used to mark the type of parameters

Parameter type	Meaning
<param> ^(num)	Parameter value must be numeric type
<param> ^(str)	Parameter value must be string type enclosed in quotation marks.
<param> ^(text)	Parameter value is a string according to selected character set. Not enclosed in double quotes.
<param> ^(u)	Unspecified, i.e. parameter value may be numeric or string type.

Table 1.2: Symbols used to indicate storage options or correlations with other commands

Parameter option	Meaning
<param> ^(+CSCS)	Parameter value has to be (is) coded according to current setting of <charSet> (see AT+CSCS for details)
<param> ^(&W)	Parameter value is stored to user profile in non-volatile memory after executing AT&W
<param> ^(&V)	Parameter value is displayed by AT&V
<param> ^(NV)	Parameter is stored in non-volatile memory.

Table 1.3: Symbols used to mark different types of default values of parameters

Value option	Meaning
[x]	Default value set if parameter is omitted.
x ^(&F)	Factory value restored by AT&F
x ^(P)	Powerup value of a parameter not stored in non-volatile memory.
x ^(D)	Delivery value of a parameter which may be overridden from non-volatile setting (refer to symbol ^(NV) and symbol ^(&W) above).

1.4 AT Command Interpreter

PLS8-X features two instances for processing AT commands: Application and Modem instances. Their assignment to the PLS8-X's devices is dependent on the setting of [AT^SSRVSET](#) and whether Multiplex mode is active or not. See in particular Table [2.6, Validated and released Service/Device Mappings](#).

Application instance:

Auxiliary AT command instance designed especially for controlling the PLS8-X, i.e. for entering AT commands, receiving URCs, or sending and receiving short messages. It is not recommended for data transmission.

This instance is referred to as "Application" if queried with [AT^SQPORT](#). In the quick reference tables it is named APP.

Modem instance:

Main AT command instance intended for data transmission.

All URCs are, by default, issued only on the Application instance, but call related URCs (RING, NO CARRIER) as well as the "[^SYSSTART](#)" URC are additionally issued on the Modem instance.

This instance is referred to as "Modem" if queried with [AT^SQPORT](#). In the quick reference tables it is named MDM.

Please note that URCs are normally issued only on the Application instance, no matter whether the Modem instance or the Application instance was used to send the AT commands for activating their presentation. This URC management scheme is the default configuration recommended for a typical PLS8-X application. For further detail on URCs please refer to Section [1.8, Unsolicited Result Code Presentation](#), and the configuration command [AT^SCFG](#), parameter `<urcDestIfc>`.

Bear in mind that Application and Modem instances are handled by the same AT command interpreter. As a result, AT commands entered on both instances are not executed in parallel but sequentially, one after the other. So, an AT command issued on one instance will be buffered on this instance to be executed after the other instance has completed processing earlier AT command(s).

When a data connection is established over the Modem instance, the Application instance can still be used for any control functions.

For further details on Multiplex mode refer to [AT+CMUX](#).

1.5 AT Command Syntax

The "AT" or "at" prefix must be set at the beginning of each command line. To terminate a command line enter <CR>. Commands are usually followed by a response that includes "<CR><LF><response><CR><LF>". Throughout this document, only the responses are presented, <CR><LF> are omitted intentionally.

Table 1.4: Types of AT commands and responses

AT command type	Syntax	Function
Test command	AT+CXXX=?	The mobile equipment returns the list of parameters and value ranges set with the corresponding Write command or by internal processes.
Read command	AT+CXXX?	This command returns the currently set value of the parameter or parameters.
Write command	AT+CXXX=<...>	This command sets user-definable parameter values.
Exec(ution) command	AT+CXXX	The execution command reads non-variable parameters determined by internal processes in the UE.

1.5.1 Using Parameters

- Multiple parameters are separated by commas. This applies to write commands, command responses, URCs and result codes. Please note that throughout this document spaces behind commas may be added for better readability.
- Optional parameters are enclosed in square brackets. If optional parameters are omitted, the current settings are used until you change them.
- Optional parameters or subparameters can be omitted unless they are followed by other parameters. If you want to omit a parameter in the middle of a string it must be replaced by a comma.
- A parameter value enclosed in square brackets represents the value that will be used if an optional parameter is omitted.
- When the parameter is a character string, e.g. <text> or <number>, the string must be enclosed in quotation marks, e.g. "Charlie Brown" or "+49030xxxx". Symbols in quotation marks will be recognized as strings.
- All spaces will be ignored when using strings without quotation marks.
- It is possible to omit the leading zeros of strings which represent numbers.
- If an optional parameter of a ITU-T V.250 command is omitted, its value is assumed to be 0.

1.5.2 Concatenating AT Commands

Concatenating AT commands on the same line is possible, though not recommended because of restrictions listed below (for more details see ITU-T V.250 [16]).

When concatenating AT commands you need to enter the "AT" or "at" prefix only once at the beginning of a command line. Basic commands (i.e., ITU-T V.250 commands) are concatenated without delimiter. Extended commands (i.e., commands starting with AT+ or AT^) use a semicolon as delimiter.

Disadvantages and restrictions:

- There is no way to control the minimum time to wait between finishing an AT command and sending the next one. Please refer to Section 1.6, [Communication between Customer Application and PLS8-X](#) for details about timing.
- The sequence of processing the AT commands may be different from the sequential order of command input.
- Many AT commands cannot be concatenated (see list below). Concatenating these commands might end up with an error result code, or leads to an unexpected order of responses.

AT command type	Comment
3GPP TS 27.007 commands	Cannot be concatenated with extended commands (prefix AT^S)
3GPP TS 27.005 commands (SMS)	To be used standalone
Commands starting with AT&	To be used standalone
AT+IPR	To be used standalone

1.6 Communication between Customer Application and PLS8-X

After power-up or restart ensure that the UE is in ready state before trying to send any AT command or data. For detailed information on timing conditions, signal states and particularly the startup behavior of the PLS8-X's signal lines refer to the Hardware Interface Description [2].

Leaving hardware flow control unconsidered the Customer Application (TE) is coupled with the PLS8-X (UE) via a receive and a transmit line.

Since both lines are driven by independent devices collisions may (and will) happen. For example, if the TE issues an AT command and the PLS8-X starts sending a URC. This will probably cause the TE to misinterpret the URC being part of the AT command's response. To avoid this conflict the following measures must be taken:

- If an AT command is finished (with "OK" or "ERROR") the TE shall always wait at least 100 ms before sending the next one.
The pause between two AT commands gives the PLS8-X the opportunity to the transmission of pending URCs and get necessary service.
- The TE shall communicate with the PLS8-X using activated echo ([ATE1](#)), i.e. the PLS8-X echoes characters received from the TE.
Hence, when the TE receives the echo of the first character "A" of the AT command just sent by itself it has control both over the receive and the transmit paths.

Using Backspace at command line:

- As the standard GSM alphabet does not provide a backspace functionality the PLS8-X is designed to use the character "08" (hex 0x08) as backspace for command line input. This allows the user to easily erase the last character when writing an AT command. On the other hand, this solution requires entering the escape sequence \08 for writing the "ò" character in GSM character string parameters.
- If command echo is enabled ([ATE1](#)) Backspace may cause 08 - 32 - 08 (decimal) character sequence or no echo, depending on serial interface and speed of character input.

1.7 Supported character sets

1.7 Supported character sets

PLS8-X supports three character sets: *GSM 7 bit*, also referred to as GSM alphabet or SMS alphabet (3GPP TS 23.038 [36]) *UCS2 16 bit* (ISO-10646 [13]), and *IRA* (International Reference Alphabet, ITU T T.50). See [AT+CSCS](#) for information about selecting the character set. Character tables can be found below.

Explanation of terms

- Escape Character

There are two types of escape sequences which lead to an alternative interpretation on subsequent characters by the UE:

- AT command interface
Escape sequences starting with character value 0x5C are used for the UE's non-UCS2 input and output.
- GSM 7 bit default alphabet
The escape sequence used within a text coded in the GSM 7 bit default alphabet is starting with character value 0x1B and needs to be correctly interpreted by the TE, both for character input and output. To the PLS8-X, an escape sequence appears like any other byte received or sent.

For SMS user data input after the prompt '>' in text mode ([AT+CMGF](#))=1 and [AT+CSCS](#)="GSM" the character 0x1A is interpreted as 'CTRL-Z'. The character 0x1B (interpreted as 'ESC') as well as the escape character 0x5C (is interpreted as 'Ö'), therefore both escape mechanisms are not supported in this case.

- TE Character Set

The character set currently used by the Customer Application is selected with [AT+CSCS](#). It is recommended to select UCS2 setting.

- Data Coding Scheme (DCS)

DCS is part of a short message and is saved on the SIM. When writing a short message to the SIM in text mode, the DCS stored with [AT+CSMP](#) is used and determines the coded character set.

- International Reference Alphabet (IRA)

The International Reference Alphabet is equivalent to ASCII (American Standard Code for Information Interchange) and ISO 646, i.e. it defines a 7-bit coded character set. The mapping can be obtained from the character set tables below (UCS2 values 0x0000 to 0x007F).

When you enter characters that are not valid characters of the supported alphabets the behavior is undefined. If GSM alphabet is selected, all characters sent over the serial line (between TE and UE) must be in the range from 0 to 127 (7 bit range).

Note: If the UE is configured for GSM alphabet, but the Customer Application (TE) uses ASCII, bear in mind that some characters have different code values, such as the following:

- "@" character with GSM alphabet value 0 is not displayable by an ASCII terminal program, e.g. Microsoft® Hyperterminal®.
- "@" character with GSM alphabet value 0 will terminate any C string! This is because value 0 is defined as C string end tag. Therefore, the GSM Null character will cause problems on application level when using 'C'-functions, e.g. "strlen()". Using an escape sequence as shown in the table below solves the problem. By the way, this may be the reason why even network providers sometimes replace '@' with "@=" in their SIM application.
- Some other characters of the GSM alphabet may be misinterpreted by an ASCII terminal program. For example, GSM "ö" (as in "Börse") is assumed to be "l" in ASCII, thus resulting in "B|rse". This is because in both alphabets there are different characters assigned to value 7C (hexadecimal).

If the TE sends characters differently coded or undefined in ASCII or GSM (e.g. Ä, Ö, Ü) it is possible to use escape sequences. The UE's input parser translates the escape sequence to the corresponding GSM character value.

Note:

The UE also uses escape sequences for its non-UCS2 output: Quotation mark (") and the escape character itself (\, respectively Ö in GSM alphabet) are converted, as well as all characters with a value below 32 (hexadecimal 0x20).

Hence, the input parser of the Customer Application needs to be able to translate escape sequences back to the corresponding character of the currently used alphabet.

Unsupported characters are shown as a space (hexadecimal 0x20).

1.7 Supported character sets

Table 1.5: Exemplary escape sequences generated by PLS8-X for its non-UCS2 output

Character Value	ASCII Character	GSM Character	UCS2 Character	Escape Sequence	Numeric Escape Sequence
0x5C	\	Ö	00D6	\5C	0x5C 0x35 0x43
0x22	"	"	0022	\22	0x5C 0x32 0x32
0x00	NULL	@	n/a	\00	0x5C 0x30 0x30

Usually terminal programs are not able to recognize escape sequences, and thus, handle them as normal characters.

To prevent misinterpretation of control characters or special characters it is recommended to always use UCS2 alphabet and PDU mode.

1.7 Supported character sets

1.7.1 GSM alphabet tables and UCS2 character values

This section provides tables for the GSM default alphabet (3GPP TS 23.038 [36]) supported by the PLS8-X. Below any GSM character find the corresponding two byte character value of the UCS2 alphabet. For details refer to "ETSI GSM 03.38 mapping into Unicode" [14].

Main character table of GSM 7 bit default alphabet				b7	0	0	0	0	1	1	1	1
				b6	0	0	1	1	0	0	1	1
				b5	0	1	0	1	0	1	0	1
b4	b3	b2	b1		0	1	2	3	4	5	6	7
0	0	0	0	0	@ 0040	Δ 0394	SP 0020	0 0030	i 00A1	P 0050	¿ 00BF	p 0070
0	0	0	1	1	£ 00A3	_ 005F	! 0021	1 0031	A 0041	Q 0051	a 0061	q 0071
0	0	1	0	2	\$ 0024	Φ 03A6	" 0022	2 0032	B 0042	R 0052	b 0062	r 0072
0	0	1	1		3	¥ 00A5	Γ 0393	# 0023	3 0033	C 0043	S 0053	c 0063
0	1	0	0	4	è 00E8	Λ 039B	* 00A4	4 0034	D 0044	T 0054	d 0064	t 0074
0	1	0	1		5	é 00E9	Ω 03A9	% 0025	5 0035	E 0045	U 0055	e 0065
0	1	1	0	6	ù 00F9	Π 03A0	& 0026	6 0036	F 0046	V 0056	f 0066	v 0076
0	1	1	1		7	ì 00EC	Ψ 03A8	' 0027	7 0037	G 0047	W 0057	g 0067
1	0	0	0	8	ò 00F2 ³⁾	Σ 03A3	(0028	8 0038	H 0048	X 0058	h 0068	x 0078
1	0	0	1	9	ç 00E7	Θ 0398) 0029	9 0039	I 0049	Y 0059	i 0069	y 0079
1	0	1	0	10 /A	LF [LF] ²⁾	Ξ 039E	* 002A	: 003A	J 004A	Z 005A	j 006A	z 007A
1	0	1	1	11 /B	∅ 00D8	¹⁾	+ 002B	; 003B	K 004B	Ä 00C4	k 006B	ä 00E4
1	1	0	0	12 /C	ø 00F8	Æ 00C6	, 002C	< 003C	L 004C	Ö 00D6	l 006C	ö 00F6
1	1	0	1	13 /D	CR [CR] ²⁾	æ 00E6	- 002D	= 003D	M 004D	Ñ 00D1	m 006D	ñ 00F1
1	1	1	0	14 /E	À 00C5	ß 00DF	. 002E	> 003E	N 004E	Ü 00DC	n 006E	ü 00FC
1	1	1	1	15 /F	á 00E5	É 00C9	/ 002F	? 003F	O 004F	Ş 00A7	o 006F	à 00E0

Figure 1.1: Main character table of GSM 7 bit default alphabet

- 1) This code is an escape to the following extension of the 7 bit default alphabet table.
- 2) This code is not a printable character and therefore not defined for the UCS2 alphabet. It shall be treated as the accompanying control character.
- 3) See Section 1.6 for further details on using backspace and "ò" character.

Extension character table of GSM 7 bit default alphabet				b7	0	0	0	0	1	1	1	1
				b6	0	0	1	1	0	0	1	1
				b5	0	1	0	1	0	1	0	1
b4	b3	b2	b1		0	1	2	3	4	5	6	7
0	0	0	0	0					 007C			
0	0	0	1	1								
0	0	1	0	2								
0	0	1	1	3								
0	1	0	0	4		^ 005E						
0	1	0	1	5						€ ²⁾ 20AC		
0	1	1	0	6								
0	1	1	1	7								
1	0	0	0	8			{ 007B					
1	0	0	1	9			} 007D					
1	0	1	0	10 /A	³⁾ [LF]							
1	0	1	1	11 /B		⁴⁾						
1	1	0	0	12 /C			[005B					
1	1	0	1	13 /D			~ 007E					
1	1	1	0	14 /E] 005D					
1	1	1	1	15 /F			\ 005C					

Figure 1.2: Extension character table of GSM 7 bit default alphabet

- 1) This code value is reserved for the extension to another extension table. On receipt of this code, a receiving entity shall display a space until another extension table is defined.
- 2) This code represents the EURO currency symbol. The code value is the one used for the character 'e'. Therefore a receiving entity which is incapable of displaying the EURO currency symbol will display the character 'e' instead.
- 3) This code is defined as a Page Break character and may be used for example in compressed CBS messages. Any mobile which does not understand the 7 bit default alphabet table extension mechanism will treat this character as Line Feed.

1.7 Supported character sets

If the Customer Application receives a code where a symbol is not represented in Figure 1.2, [Extension character table of GSM 7 bit default alphabet](#) it shall display the character shown in the main GSM 7 bit default alphabet table (see Figure 1.1, [Main character table of GSM 7 bit default alphabet](#)).

1.7.2 UCS2 and GSM character coding and conversion

This section provides basic information on how to handle input and output character conversion, e.g. for SMS text mode and Remote SAT, if the character representation of UE and Customer Application differ, i.e. if the Data Coding Scheme and the TE character set use different mappings.

1.7.2.1 Output of SIM data (UE to TE)

Used character set	DCS = 7 bit GSM	DCS = 8 bit Data	DCS = 16 bit UCS2
GSM	Case 1 GSM (1:1)	Case 2 8 bit to IRA (1:2)	Case 3 UCS2 to IRA (2:4)
UCS2	Case 4 GSM to IRA (1:4)	Case 5 8 bit to IRA (1:4)	Case 6 UCS2 to IRA (2:4)

Note: The ratio of SIM bytes to output bytes is given in parentheses.

Case 1

Every GSM character is sent to the TE as it is (8-bit value with highest bit set to zero).

Example: 47'H, 53'H, 4D'H → 47'H, 53'H, 4D'H, displayed as "GSM"

Case 2

Every data byte is sent to the TE as 2 IRA characters each representing a halfbyte.

Example: B8'H (184 decimal) → 42'H, 38'H, displayed as "B8"

Case 3

Every 16-bit UCS2 value is sent to the TE as 4 IRA characters.

Example: C4xA7'H (50343 decimal) → 43'H, 34'H, 41'H, 37'H, displayed as "C4A7"

Problem: An odd number of bytes leads to an error because there are always two bytes needed for each UCS2 character

Case 4

Every GSM character is sent to the TE as 4 IRA characters to show UCS2 in text mode.

Example: 41'H ("A") → 30'H, 30'H, 34'H, 31'H, displayed as "0041"

Case 5

Every data byte is sent to the TE as IRA representation of UCS2 (similar to case 4).

Example: B2'H → 30'H, 30'H, 42'H, 32'H, displayed as "00B2"

Case 6

Every 16-bit value is sent to the TE as IRA representation of it. It is assumed that number of bytes is even.

Example: C3x46'H → 43'H, 33'H, 34'H, 36'H, displayed as "C346"

1.7 Supported character sets

1.7.2.2 Input of SIM data (TE to UE)

Used character set	DCS = 7 bit GSM	DCS = 8 bit Data	DCS = 16 bit UCS2
GSM	Case 1 GSM (1:1)	Case 2 IRA to 8 bit (2:1)	Case 3 IRA to 16 bit (4:2)
UCS2	Case 4 UCS2 to GSM (4:1)	Case 5 UCS2 to 8 bit (4:1)	Case 6 UCS2 to 16 bit (4:2)

Note: The ratio between the number of input characters and bytes stored on the SIM is given in parentheses.

Case 1

Every character is sent from TE to UE as GSM character (or ASCII with standard terminal emulation, e.g. Hyperterminal®).

Character value must be in range from 0 to 127 because of 7-bit GSM alphabet.

To reach maximum SMS text length of 160 characters in 140 bytes space characters will be compressed on SIM. This must be set using the parameter `<dcsc>` of `AT+CSMP` (add 64).

Example: "ABCDEFGH" typed is sent and stored uncompressed as → 4142434445464748'H (stored compressed as 41E19058341E91'H)

Case 2

Every data byte is sent as 2 IRA characters.

Maximum text length is 280 IRA characters which will be converted into 140 bytes SMS binary user data

Example: "C8" typed is sent as 43'H, 38'H → stored as C8'H

Case 3

Every 16-bit value is sent as 4 IRA characters.

Maximum text length is 280 IRA characters which will be converted into 70 UCS2 characters (16-bit each)

Number of IRA characters must be a multiple of four because always 4 half bytes are needed for a 16-bit value

Example: "D2C8" typed is sent as 44'H, 32'H, 43'H, 38'H → stored as D2C8'H

Case 4

Every GSM character is sent as 4 IRA characters representing one UCS2 character.

Example: To store text "ABC" using UCS2 character set you have to type "004100420043".

This is sent as 30'H,30'H,34'H,31'H, 30'H,30'H,34'H,32'H, 30'H,30'H,34'H,33'H → detected as IRA representation of 3 UCS2 characters, converted to GSM character set and stored as 41'H, 42'H, 43'H.

Maximum input is 640 IRA characters representing 160 UCS2 characters when compression is active. These are converted to 160 GSM 7-bit characters.

Without compression only 140 GSM characters can be stored which are put in as 560 IRA characters.

Values of UCS2 characters must be smaller than 80'H (128 decimal) to be valid GSM characters.

Number of IRA characters must be a multiple of four. Problems:

- "41" → Error, there are four IRA characters (two bytes) needed
- "0000" → Error, not an UCS2 character
- "4142" → Error, value of UCS2 character > 7F'H
- "008B" → Error, value of UCS2 character > 7F'H

This affects the maximum input length of a string)

Case 5

Every UCS2 character is sent as 4 IRA characters and is converted into two 8-bit values. This means that the first two characters have to be '00'.

Example: UCS2 character 009F'H typed as "009F" is sent as 30'H,30'H,39'H,46'H → converted into 8-bit value 9F'H.

Maximum number of UCS2 characters is 140 which are represented by 560 IRA characters. Number of IRA characters must be a multiple of four.

Case 6

Every UCS2 character is sent as 4 IRA characters each and is converted into a 16-bit value again.

Example: UCS2 character 9F3A'H typed as "9F3A" is sent as 39'H,46'H,33'H,41'H → converted into 9F3A'H.

Maximum number of UCS2 characters is 70 which are represented by 280 IRA characters. Number of IRA characters must be a multiple of four.

Invalid UCS2 values must be prevented.

1.8 Unsolicited Result Code Presentation

URC stands for Unsolicited Result Code and is a report message issued by the PLS8-X without being requested by the TE, i.e. a URC is issued automatically when a certain event occurs. Hence, a URC is not issued as part of the response related to an executed AT command.

Typical events leading to URCs are incoming calls ("RING"), waiting calls, received short messages, changes in temperature, network registration etc. For most of these messages, the UE needs to be configured whether or not to send a URC. Descriptions of these URCs are provided with the associated AT command. Only the URCs related to automatic undervoltage and overvoltage shutdown are not user definable. These URCs are described in Section 1.8.1, [Common URCs](#). A summary of all URCs can be found in Section 20.6, [Summary of Unsolicited Result Codes \(URC\)](#).

As specified in Section 1.4, [AT Command Interpreter](#) the Modem interface is dedicated for data transmission (HSDPA, GPRS), whereas the Application interface is designed primarily for control functions. This implies that all URCs are issued on the Application interface, no matter which of the AT interfaces was used to send the AT command for activating their presentation. URCs related to data calls (RING, NO CARRIER) are additionally issued on the Modem interface to ensure compatibility with existing modem applications. The "[^SYSSTART](#)" URC and the "[^SYSSTART AIRPLANE MODE](#)" URC will also be output both on the Application and Modem interface.

Enabled by default when the UE is powered up, the above URC management scheme is the recommended approach for a typical PLS8-X application. However, as an alternative to this approach, [AT^SCFG](#), "URC/DstIfc", [<urcDestIfc>](#) provides the option to determine the interface used for URC output.

Important: If the interface used for URC output is reserved by an active data connection or a long running AT command, URCs are buffered internally and will be issued after the interface becomes idle again. A pending URC will be signaled on the URC output interface via RING line. For detailed information regarding configuration of URC signaling refer to [AT^SCFG](#), "URC/Ringline", [<urcRinglineCfg>](#).

1.8.1 Common URCs

This section contains all URCs not associated to a certain AT command. They cannot be defined by the user and appear automatically when the required conditions described below occur. Please refer to [2] for specifications regarding the minimum and maximum operating voltage limits. The automatic shutdown procedure is usually equivalent to the Power-down initiated with the `AT^SMSO` command, except when the voltage threshold is exceeded very quickly.

URC 1

`^SBC: Undervoltage`

The URC indicates that the UE is close to the undervoltage threshold. If undervoltage persists the UE keeps sending the URC several times before switching off automatically.

URC 2

`^SBC: Overvoltage Warning`

Supply voltage is close to overvoltage threshold. The URC is sent once.

URC 3

`^SBC: Overvoltage Shutdown`

Overvoltage threshold exceeded. Module switches off within 5 seconds after sending the URC.

1.9 Errors and Messages

The command result codes "+CME ERROR: <err>" and "+CMS ERROR: <err>" indicate errors related to mobile equipment or network functionality.

The format of <err> can be either numeric or verbose and is selectable via [AT+CMEE](#).

A result error code terminates the execution of the command and prevents the execution of all remaining commands that may follow on the same command line.

Using the wrong command syntax may result in errors: For example, using the execute command syntax although the command has no execute format, causes "ERROR" to be returned. Likewise, using the write command syntax although the command has no write format causes "+CME ERROR: <err>" to be returned.

See also:

- Section [2.8.1](#), [CME/CMS Error Code Overview](#)
- Section [2.5.1](#), [Verbose and numeric result codes](#)
- Section [3.1](#), [AT+CEER](#)

2. Configuration Commands

The AT Commands described in this chapter allow the external application to determine the PLS8-X's behaviour under various conditions.

2.1 AT&F Reset AT Command Settings to Factory Default Values

AT&F resets AT command settings to their factory default values. However, the command does not change the current bit rate of PLS8-X's asynchronous serial interface (UART). For a list of affected parameters refer to Section 20.5, [Factory Default Settings Restorable with AT&F](#).

Syntax

Exec Command				
AT&F[<value>]				
Response(s)				
OK				
PIN	MDM	APP	→	Last
-	+	+	+	-
Reference(s)				
ITU-T V.250 [16]				

Parameter Description

<value> ^(num)	
[0]	Reset parameters in Section 20.5, Factory Default Settings Restorable with AT&F to their factory default values.

2.2 AT&V Display current Configuration

[AT&V](#) returns the setting of several AT command parameters applicable to the current operating mode, including the single-letter AT command parameters which are not readable otherwise.

Syntax

```
Exec Command
AT&V
Response(s)
ACTIVE PROFILE:
... (see Section 2.2.1, AT&V Response)
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

2.2.1 AT&V Response

Table 2.1: AT&V Response

```
ACTIVE PROFILE:
E1 Q0 V1 X0 &C1 &D2 &S0 \Q3

+CMGF: 0
+CSDH: 0
+CNMI: 0,0,0,0,1
+IPR: 115200
+CMEE: 2
+CSMS: 0,1,1,1
^SCKS: 0,1
^SSET: 0
+CREG: 0,1
+COPS: 0[,<format>,<operator>,<rat>]
+CGSMS: 3
OK
```

2.3 AT&W Store AT Command Settings to User Defined Profile

AT&W stores the current AT command settings to a user defined profile in non-volatile memory of PLS8-X. The AT command settings will automatically be restored from the user defined profile during power-up or if **ATZ** is used. **AT&F** restores AT command factory default settings. Hence, until first use of **AT&W**, **ATZ** works as **AT&F**. A list of parameters stored to the user profile can be found at Section 20.4, [AT Command Settings storable with AT&W](#).

Syntax

Exec Command				
AT&W[<value>]				
Response(s)				
OK				
ERROR				
+CME ERROR: <err>				
PIN	MDM	APP	→	Last
-	+	+	+	-
Reference(s)				
V.250				

Parameter Description

<value> ^(num)	
[0]	User Profile Number

2.4 ATQ Result Code Presentation Mode

ATQ controls if the PLS8-X transmits any result code to the TE. Other information text transmitted as response is not affected.

Syntax

Exec Command				
ATQ[<n>]				
Response(s)				
If <n>=0:				
OK				
If <n>=1:				
(none)				
PIN	MDM	APP	→	Last
-	+	+	+	-
Reference(s)				
V.250				

Parameter Description

<n> ^{(num)(&V)(&W)}	
Result Code Presentation Mode. It is not recommended to change this value.	
[0] ^{(&F)(D)}	UE transmits result code.
1	Result codes are suppressed and not transmitted.

2.5 ATV Result code format mode

This command determines the contents of header and trailer transmitted with AT command result codes and information responses. Possible responses are described in Section 2.5.1, [Verbose and numeric result codes](#).

Syntax

Exec Command					Reference(s)	
ATV[<value>]					ITU-T V.250 [16]	
Response(s)						
OK						
ERROR						
PIN	MDM	APP	→	Last		
-	+	+	+	-		

Parameter Description

<value> ^{(num)(&V)(&W)}	
[0]	Information response: <text><CR><LF> Short result code format: <numeric code><CR>
1(&F)(D)	Information response: <CR><LF><text><CR><LF> Long result code format: <CR><LF><verbose code><CR><LF>

2.5.1 Verbose and numeric result codes

Verbose format	Numeric format	Meaning
OK	0	command executed, no errors
RING	2	ring detected
NO CARRIER	3	link not established or disconnected
ERROR	4	invalid command or command line too long
NO DIALTONE	6	no dial tone, dialling impossible, wrong mode
BUSY	7	remote station busy
NO ANSWER	8	no answer

2.6 ATX Result Code Selection

ATX determines whether or not the PLS8-X transmits particular result codes to the TE. **ATX** also controls whether or not the UE verifies the presence of a dial tone when it begins dialing, and if engaged tone (busy signal) detection is enabled.

Syntax

Exec Command					Reference(s)	
ATX[<value>]					ITU-T V.250 [16]	
Response(s)						
OK						
ERROR						
PIN	MDM	APP	→	Last		
+	+	+	+	-		

Parameter Description

<value> ^{(num)(&V)(&W)}	
[0] ^{(&F)(D)}	CONNECT result code returned. Dial tone and busy detection are disabled.
1	CONNECT <text> result code returned. Dial tone and busy detection are disabled.
2	CONNECT <text> result code returned. Dial tone detection is enabled, busy detection is disabled.
3	CONNECT <text> result code returned. Dial tone detection is disabled, busy detection is enabled.
4	CONNECT <text> result code returned. Dial tone and busy detection are both enabled.

2.7 ATZ Restore AT Command Settings from User Defined Profile

First [ATZ](#) resets the AT command settings to their factory default values, similar to [AT&F](#). Afterwards the AT command settings are restored from a user defined profile in non-volatile memory of PLS8-X, if one was stored with [AT&W](#) before. Any additional AT command on the same command line may be ignored. A delay of 300 ms is required before next AT command is sent.

However, [ATZ](#) does not change the current bit rate of PLS8-X's asynchronous serial interface (UART). [ATZ](#) does not change the PDP context profiles.

Syntax

Exec Command					
ATZ[<value>]					
Response(s)					
OK					
PIN	MDM	APP	→	Last	Reference(s)
+	+	+	+	-	V.250

Parameter Description

<value> ^(num)	
[0]	User Profile Number

2.8 AT+CMEE Error Message Format

AT+CMEE controls the format of error result codes that indicates errors related to PLS8-X functionality. Format can be selected between plain "ERROR" output, error numbers or verbose "+CME ERROR: <err>" and "+CMS ERROR: <err>" messages.

Possible error result codes are listed in Table 2.2, General "CME ERROR" Codes (3GPP TS 27.007), Table 2.3, GPRS related "CME ERROR" Codes (3GPP TS 27.007) and Table 2.5, SMS related "CMS ERROR" Codes (3GPP TS 27.005).

The AT+CMEE exec command performs a write command with factory default parameter setting.

Syntax

<p>Test Command</p> <p>AT+CMEE=?</p> <p>Response(s)</p> <p>+CMEE: (list of supported<errMode>s)</p> <p>OK</p>											
<p>Read Command</p> <p>AT+CMEE?</p> <p>Response(s)</p> <p>+CMEE: <errMode></p> <p>OK</p>											
<p>Exec Command</p> <p>AT+CMEE</p> <p>Response(s)</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>											
<p>Write Command</p> <p>AT+CMEE=<errMode></p> <p>Response(s)</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>-</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	-	+	+	+	-	<p>Reference(s)</p> <p>3GPP TS 27.007 [48], 3GPP TS 27.005 [47]</p>
PIN	MDM	APP	→	Last							
-	+	+	+	-							

Parameter Description

<errMode> ^{(num)(&V)(&W)}	Description
0	Disable result code, i.e. only "ERROR" will be displayed.
1	Enable error result code with numeric values.
2(&F)(D)	Enable error result code with verbose (string) values.

2.8.1 CME/CMS Error Code Overview

Table 2.2: General "CME ERROR" Codes (3GPP TS 27.007)

<err> Code	Text (if AT+CMEE=2)
0	phone failure
1	no connection to phone
2	phone adapter link reserved
3	operation not allowed
4	operation not supported
5	PH-SIM PIN required
6	PH-FSIM PIN required
7	PH-FSIM PUK required
10	SIM not inserted
11	SIM PIN required
12	SIM PUK required
13	SIM failure
14	SIM busy
15	SIM wrong
16	incorrect password
17	SIM PIN2 required
18	SIM PUK2 required
20	memory full
21	invalid index
22	not found
23	memory failure
24	text string too long
25	invalid characters in text string
26	dial string too long
27	invalid characters in dial string
30	no network service
31	network timeout
32	network not allowed - emergency calls only
40	network personalization PIN required
41	network personalization PUK required
42	network subset personalization PIN required
43	network subset personalization PUK required
44	service provider personalization PIN required
45	service provider personalization PUK required
46	corporate personalization PIN required
47	corporate personalization PUK required
100	unknown

Table 2.3: GPRS related "CME ERROR" Codes (3GPP TS 27.007)

<err> Code	Text (if AT+CMEE=2)
103	illegal MS
106	illegal ME
107	GPRS services not allowed
111	PLMN not allowed
112	location area not allowed
113	roaming not allowed in this location area
127	missing or unknown APN
132	service option not supported
133	requested service option not subscribed
134	service option temporary out of order
148	unspecified GPRS error
149	PDP authentication failure
150	invalid mobile class
273	minimum TFTs per PDP address violated
274	TFT precedence index not unique
275	invalid parameter combination

Table 2.4: Enhanced "CME ERROR" Codes

<err> Code	Text (if AT+CMEE=2)
256	operation temporary not allowed
257	network rejected request
258	retry operation
259	invalid deflected to number
260	deflected to own number
261	unknown subscriber
262	service not available
263	unknown class specified
264	unknown network message
300	resource limitation
301	subscription violation
302	TeleService not provisioned
303	error BearerService not provisioned
304	system failure
305	data missing
306	unknown alphabet
307	unexpected data value
308	unrecognized component
309	mistyped component
310	badly structured component
311	mistyped parameter
312	initiating release

<err> Code	Text (if AT+CMEE=2)
320	call barred
330	SMSC address unknown
331	network search aborted
332	could not camp on chosen cell
333	reselection to chosen cell failed
340	call index error
341	call state error
342	sys state error
343	parameters error
344	expired password
350	cancelled due to active call state
351	cancelled due to location update processing
352	cancelled due to packet transfer mode
353	cancelled due to radio resource connection establishment
354	cancelled due to ongoing SMS transfer
355	cancelled due to ongoing SS transaction
767	operation failed

Table 2.5: SMS related "CMS ERROR" Codes (3GPP TS 27.005)

<err> Code	Text (if AT+CMEE=2)
0	none
300	ME failure
301	SMS service of ME reserved
302	operation not allowed
303	operation not supported
304	invalid PDU mode parameter
305	invalid text mode parameter
310	SIM not inserted
311	SIM PIN required
312	PH-SIM PIN required
313	SIM failure
314	SIM busy
315	SIM wrong
316	SIM PUK required
317	SIM PIN2 required
318	SIM PUK2 required
321	invalid memory index
322	memory full
330	SMSC address unknown
331	no network service
332	network timeout
340	no +CNMA acknowledgement expected

<err> Code	Text (if AT+CMEE=2)
500	unknown error
512	user abort

2.9 AT+CSCS Character Set

AT+CSCS write command informs the PLS8-X which character set is used by the TE. This enables the UE to convert character strings correctly between TE and UE character sets. Please also refer to Section 1.7, [Supported character sets](#).

Syntax

<p>Test Command</p> <p>AT+CSCS=?</p> <p>Response(s)</p> <p>+CSCS: (list of supported<charSet>s)</p> <p>OK</p>											
<p>Read Command</p> <p>AT+CSCS?</p> <p>Response(s)</p> <p>+CSCS: <charSet></p> <p>OK</p>											
<p>Write Command</p> <p>AT+CSCS=<charSet></p> <p>Response(s)</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>-</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	-	+	+	+	-	<p>Reference(s)</p> <p>3GPP TS 27.007 [48]</p>
PIN	MDM	APP	→	Last							
-	+	+	+	-							

Parameter Description

<charSet> ^(str)	
"GSM" ^{(&F)(P)}	GSM default alphabet (3GPP TS 23.038 [36], subclause 6.2.1).
"UCS2"	16-bit universal multiple-octet coded character set (ISO/IEC10646 [32]). UCS2 character strings are converted to hexadecimal numbers in the range 0000 to FFFF; e.g. "004100620063" equates three 16-bit characters with decimal values 65, 98 and 99.
"IRA"	International reference alphabet (ITU T T.50).

2.10 AT+CFUN PLS8-X Functionality Level

AT+CFUN controls PLS8-X functionality levels "Normal Functionality Mode" and "Airplane Mode".
AT+CFUN can also be used to reset the UE.

In pure Airplane Mode (**AT+CFUN** parameter `<fun>=4`) the UE shuts down its radio interface (PA and receiver), what causes the UE to log off from network and disables all AT commands whose execution requires a radio connection. In extended Airplane Mode (`<fun>=0`) the UE shuts down its radio and USIM interfaces. The benefit of using Airplane Modes is that they allow to save power and, at locations where no RF emission is allowed (typically airplanes, hospitals etc.), the subscriber can continue network-independent activities rather than powering off the UE.

Syntax

Test Command	
AT+CFUN=?	
Response(s)	
+CFUN: (list of supported <code><fun>s</code>), (list of supported <code><rst>s</code>)	
OK	
ERROR	
+CME ERROR: <code><err></code>	
Read Command	
AT+CFUN?	
Response(s)	
+CFUN: <code><fun></code>	
OK	
ERROR	
+CME ERROR: <code><err></code>	
Write Command	
AT+CFUN= <code><fun></code> [, <code><rst></code>]	
Response(s)	
OK	
ERROR	
+CME ERROR: <code><err></code>	
PIN MDM APP → Last	Reference(s)
- + + + -	3GPP TS 27.007 [48]

Unsolicited Result Codes

URC 1

^SYSSTART

URC indicates that the UE is running in Normal Functionality level.

URC 2

^SYSSTART AIRPLANE MODE

URC indicates that the UE is running in Airplane Mode.

Parameter Description

<fun>^(num)

This parameter determines the functionality level of the UE.

It is possible to enable the UE to store the setting of this parameter persistently via `AT^SCFG="MEopMode/CFUN", <volacFUN>`.

- | | |
|------------------|--|
| 0 | Switch UE into Minimum Functionality level.
UE's RF (TX and RX) and USIM interfaces are shut down. Consequently, the UE logs off from network and enters extended Airplane Mode, which is indicated via " <code>^SYSSTART AIRPLANE MODE</code> " URC. All AT commands whose execution requires a radio connection or USIM access will return an error result code.
Direct switches between pure and extended Airplane Modes (and vice versa) are not supported.
To return to Normal Functionality level use <code>AT+CFUN=1</code> or <code>AT+CFUN=1,1</code> . After this, PIN authentication may be necessary if required by the USIM. |
| 1 ^(P) | Switch UE into Normal Functionality level, which is indicated via " <code>^SYSSTART</code> " URC. |
| 4 | Switch UE into pure Airplane Mode.
UE's RF-interface (TX and RX) is shut down whereby it logs off from the network and enters Airplane mode, which is indicated via " <code>^SYSSTART AIR-PLANE MODE</code> " URC. USIM remains accessible. All AT commands whose execution requires a radio connection will return an error result code.
Direct switches between pure and extended Airplane Modes (and vice versa) are not supported.
To return to Normal Functionality level use <code>AT+CFUN=1</code> or <code>AT+CFUN=1,1</code> . The UE may reregister to the network, e.g. if network service is available. |

<rst>^(num)

- | | |
|-----|--|
| [0] | UE switches to <fun> level without reset. |
| 1 | UE resets and restarts.
Restart is only possible with <fun>=1 which activates Normal Functionality level. |

2.11 AT+GCAP Capabilities List

[AT+GCAP](#) displays a list of basic capabilities supported by the PLS8-X. This allows the TE to determine which groups of extended-syntax AT commands can be used with the UE.

Syntax

Test Command	
AT+GCAP=?	
Response(s)	
OK	
Exec Command	
AT+GCAP	
Response(s)	
+GCAP: <name>	
OK	
PIN MDM APP → Last	Reference(s)
+ + + + -	ITU-T V.250 [16]

Parameter Description

<name> ^(str)
e.g. +GCAP: +CGSM

2.12 AT^SMSO Switch Off PLS8-X

[AT^SMSO](#) initiates PLS8-X's power-off procedure. Do not send any other AT command after this. For further detail please refer to [\[2\]](#).

Syntax

Test Command

```
AT^SMSO=?
```

Response(s)

```
OK
```

Exec Command

```
AT^SMSO
```

Response(s)

```
OK
```

```
ERROR
```

```
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	+

2.13 AT^SCFG Extended Configuration Settings

AT^SCFG can be used to query and configure various settings of the PLS8-X.

AT^SCFG read command returns a list of all supported parameters and their current values.

AT^SCFG write command queries a configuration parameter (if no value is entered) or sets its value(s).

Syntax

Test Command

AT^SCFG=?

Response(s)

```

^SCFG: "Audio/Loop", (list of supported <al>s)
^SCFG: "Audio/SvTone", (list of supported <toneoff>s)
^SCFG: "Call/ECC", (list of supported <ecc>s)
^SCFG: "GPIO/Mode/Antenna", (list of supported <ant>s)
^SCFG: "GPRS/Auth", (list of supported <gauth>s)
^SCFG: "GPRS/AutoAttach", (list of supported <gaa>s)
^SCFG: "MEopMode/CFUN", (list of supported <volacFUN>s)
^SCFG: "MEopMode/DTM/Mode", (list of supported <dtm>s)
^SCFG: "MEopMode/ExpectDTR", (list of supported <expdtr-set>s), (list of supported <expdtr-
port>s)
^SCFG: "MEopMode/NonBlock/Cops", (list of supported <com>s)
^SCFG: "MEopMode/PingRsp", (list of supported <pingv>s)
^SCFG: "MEopMode/PowerMgmt/LCI", (list of supported <lci>s), (list of supported <gpio>s)
^SCFG: "MEopMode/Prov/Cfg", (list of supported <provCfg>s)
^SCFG: "MEopMode/Prov/Iccid1", (list of supported <iccidAvail>s), (list of supported <provIccid1>s)
^SCFG: "MEopMode/Prov/Iccid2", (list of supported <iccidAvail>s), (list of supported <provIccid2>s)
^SCFG: "MEopMode/PwrSave", (list of supported <PwrSaveMode>s), (list of supported
<PwrSavePeriod>s), (list of supported <PwrSaveWakeup>s)
^SCFG: "MEShutdown/OnIgnition", (list of supported <msi>s)
^SCFG: "MEShutdown/Timer", (range of supported <shutdownRemainingTime>values)
^SCFG: "Misc/CId", (max. string length of <CIId>)
^SCFG: "Radio/Band", (list of supported <rba>s), (list of supported <rbe>s)
^SCFG: "Radio/CNS", (list of supported <cns>s)
^SCFG: "Radio/Mtpl", (list of supported <mode>s), (list of supported <profile>s), (list of supported
<band>s), (list of supported <limit>s), (list of supported <limit_psk>s)
^SCFG: "Radio/OutputPowerReduction", (list of supported <ropr>s)
^SCFG: "RemoteWakeUp/Event/ASC", (list of supported <RemWakeLine>s)
^SCFG: "RemoteWakeUp/Event/URC", (list of supported <RemWakeLine>s)
^SCFG: "RemoteWakeUp/Event/USB", (list of supported <RemWakeLine>s)
^SCFG: "RemoteWakeUp/Ports", (list of supported <RemWakePortSet>s), (list of supported
<RemWakePort>s)
^SCFG: "RemoteWakeUp/Pulse", (range of supported <RemWakePulse>s)
^SCFG: "SIM/CS", (list of supported <CS>s)
^SCFG: "SIM/Retry", (list of supported <SimReadRetry>s)
^SCFG: "Sms/AutoAck", (list of supported <SmsAcknl>s)
^SCFG: "Sms/Format", (list of supported <SmsFormat>s), (list of supported <SmsFormat3gpp2>s)
^SCFG: "Tcp/IPv6Priv", (list of supported <v6privacyv>s)
^SCFG: "Tcp/MR", (list of supported <tcpMr>)
^SCFG: "Tcp/OT", (list of supported <tcpOt>)
^SCFG: "Tcp/UnreachRsp", (list of supported <unreachv>s)
^SCFG: "Tcp/WithURCs", (list of supported <tcpWithUrc>)
^SCFG: "Tcp/Loop", (list of supported <loopback>s)
^SCFG: "Tcp/TLS/Version", (list of supported <TLS_min_version>s), (list of supported
<TLS_max_version>s)
^SCFG: "URC/DstIfc", (list of supported <urcDestIfc>s)

```

2.13 AT^SCFG

Test Command

(Continued)

AT^SCFG=?

Response(s)

^SCFG: "URC/Ringline", (list of supported <urcRinglineCfg>s)
 ^SCFG: "URC/Ringline/ActiveTime", (list of supported <urcRinglineDuration>s)
 OK

Read Command

AT^SCFG?

Response(s)

^SCFG: "Audio/Loop", <al>
 ^SCFG: "Audio/SvTone", <toneoff>
 ^SCFG: "Call/ECC", <ecc>
 ^SCFG: "GPIO/Mode/Antenna", <ant>
 ^SCFG: "GPRS/Auth", <gauth>
 ^SCFG: "GPRS/AutoAttach", <gaa>
 ^SCFG: "MEopMode/CFUN", <volaCFUN>, <storedCFUN>
 ^SCFG: "MEopMode/DTM/Mode", <dtm>
 ^SCFG: "MEopMode/ExpectDTR", "current"[, <expdtr-port>₁[, <expdtr-port>₂[, ...]]]
 ^SCFG: "MEopMode/ExpectDTR", "powerup"[, <expdtr-port>₁[, <expdtr-port>₂[, ...]]]
 ^SCFG: "MEopMode/NonBlock/Cops", <com>
 ^SCFG: "MEopMode/PingRsp", <pingv>
 ^SCFG: "MEopMode/PowerMgmt/LCI", <lci>[, <gpio>]
 ^SCFG: "MEopMode/Prov/Cfg", <provCfg>
 ^SCFG: "MEopMode/Prov/Iccid1", <iccidAvail>[, <provIccid1>]
 ^SCFG: "MEopMode/Prov/Iccid2", <iccidAvail>[, <provIccid2>]
 ^SCFG: "MEopMode/PwrSave", <PwrSaveMode>, <PwrSavePeriod>, <PwrSaveWakeup>
 ^SCFG: "MEShutdown/OnIgnition", <msi>
 ^SCFG: "MEShutdown/Timer", <shutdownRemainingTime>
 ^SCFG: "Misc/CId", <CId>
 ^SCFG: "Radio/Band", <rba>
 ^SCFG: "Radio/CNS", <cns>
 ^SCFG: "Radio/Mtp1", <mode>[, <profile>]
 ^SCFG: "Radio/OutputPowerReduction", <ropr>
 ^SCFG: "RemoteWakeUp/Event/ASC", <RemWakeLine>
 ^SCFG: "RemoteWakeUp/Event/URC", <RemWakeLine>
 ^SCFG: "RemoteWakeUp/Event/USB", <RemWakeLine>
 ^SCFG: "RemoteWakeUp/Ports", "current"[, <RemWakePort>₁[, <RemWakePort>₂[, ...]]]
 ^SCFG: "RemoteWakeUp/Ports", "powerup"[, <RemWakePort>₁[, <RemWakePort>₂[, ...]]]
 ^SCFG: "RemoteWakeUp/Pulse", <RemWakePulse>
 ^SCFG: "SIM/CS", <CS>
 ^SCFG: "SIM/Retry", <SimReadRetry>
 ^SCFG: "Sms/AutoAck", <SmsAcknl>
 ^SCFG: "Sms/Format", <SmsFormat>, <SmsFormat3gpp2>
 ^SCFG: "Tcp/IPv6Priv", <v6privacyv>
 ^SCFG: "Tcp/MR", <tcpMr>
 ^SCFG: "Tcp/OT", <tcpOt>
 ^SCFG: "Tcp/UnreachRsp", <unreachv>
 ^SCFG: "Tcp/WithURCs", <tcpWithUrc>
 ^SCFG: "Tcp/Loop", <loopback>
 ^SCFG: "Tcp/TLS/Version", <TLS_min_version>, <TLS_max_version>
 ^SCFG: "URC/DstIfc", <urcDestIfc>
 ^SCFG: "URC/Ringline", <urcRinglineCfg>
 ^SCFG: "URC/Ringline/ActiveTime", <urcRinglineDuration>
 OK

Write Command

Configure Audio Loop.

AT^SCFG="Audio/Loop"[, <al>]

Response(s)

^SCFG: "Audio/Loop", <al>

OK

ERROR

+CME ERROR: <err>

Write Command

Deactivation of supervisory tones.

AT^SCFG="Audio/SvTone"[, <toneoff>]

Response(s)

^SCFG: "Audio/SvTone", <toneoff>

OK

ERROR

+CME ERROR: <err>

Write Command

Query/Configure Emergency numbers for USIM without or empty ECC field.

AT^SCFG="Call/ECC"[, <ecc>]

Response(s)

^SCFG: "Call/ECC", <ecc>

OK

ERROR

+CME ERROR: <err>

Write Command

External Antenna Control Switch for 700 MHz.

AT^SCFG="GPIO/Mode/Antenna"[, <ant>]

Response(s)

^SCFG: "GPIO/Mode/Antenna", <ant>

OK

ERROR

+CME ERROR: <err>

Write Command

Configure PPP authentication.

AT^SCFG="GPRS/Auth"[, <gauth>]

Response(s)

^SCFG: "GPRS/Auth", <gauth>

OK

ERROR

+CME ERROR: <err>

Write Command

PS Domain auto attach.

AT^SCFG="GPRS/AutoAttach"[, <gaa>]

Response(s)

^SCFG: "GPRS/AutoAttach", <gaa>

OK

ERROR

+CME ERROR: <err>

Write Command

Control persistence of [AT+CFUN](#) parameter [<fun>](#).

```
AT^SCFG="MEopMode/CFUN", <volaCFUN>
```

Response(s)

```
^SCFG: "MEopMode/CFUN", <volaCFUN>, <storedCFUN>
```

OK

ERROR

+CME ERROR: [<err>](#)

Write Command

```
AT^SCFG="MEopMode/DTM/Mode", <dtm>
```

Response(s)

```
^SCFG: "MEopMode/DTM/Mode", <dtm>
```

OK

ERROR

+CME ERROR: [<err>](#)

Write Command

```
AT^SCFG="MEopMode/ExpectDTR", <expdtr-set>[, <expdtr-port>1[, <expdtr-port>2[, ...]]]
```

Response(s)

```
^SCFG: "MEopMode/ExpectDTR", "current"[, <expdtr-port>1[, <expdtr-port>2[, ...]]]
```

```
^SCFG: "MEopMode/ExpectDTR", "powerup"[, <expdtr-port>1[, <expdtr-port>2[, ...]]]
```

OK

ERROR

+CME ERROR: [<err>](#)

Write Command

```
AT^SCFG="MEopMode/NonBlock/Cops", <com>
```

Response(s)

```
^SCFG: "MEopMode/NonBlock/Cops", <com>
```

OK

ERROR

+CME ERROR: [<err>](#)

Write Command

Allow/block response on PING

```
AT^SCFG="MEopMode/PingRsp", <pingv>
```

Response(s)

```
^SCFG: "MEopMode/PingRsp", <pingv>
```

OK

ERROR

+CME ERROR: [<err>](#)

Write Command

Power Management control by Low Current Indicator (LC_IND line).

```
AT^SCFG="MEopMode/PowerMgmt/LCI", <lci>[, <gpio>]
```

Response(s)

```
^SCFG: "MEopMode/PowerMgmt/LCI", <lci>[, <gpio>]
```

OK

ERROR

+CME ERROR: [<err>](#)

Write Command

Provider modem software configuration.

```
AT^SCFG="MEopMode/Prov/Cfg", <provCfg>
```

Response(s)

```
^SCFG: "MEopMode/Prov/Cfg", <provCfg>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Provider specific ICCID configuration (AT&T).

```
AT^SCFG="MEopMode/Prov/Iccid1", <provIccid1>
```

Response(s)

```
^SCFG: "MEopMode/Prov/Iccid1", <iccidAvail>[, <provIccid1>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Provider specific ICCID configuration (VERIZON).

```
AT^SCFG="MEopMode/Prov/Iccid2", <provIccid2>
```

Response(s)

```
^SCFG: "MEopMode/Prov/Iccid2", <iccidAvail>[, <provIccid2>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Extended power saving control.

```
AT^SCFG="MEopMode/PwrSave", <PwrSaveMode>][, <PwrSavePeriod>][, <PwrSaveWakeup>
```

Response(s)

```
^SCFG: "MEopMode/PwrSave", <PwrSaveMode>, <PwrSavePeriod>, <PwrSaveWakeup>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Enable/disable shutdown by ignition line.

```
AT^SCFG="MESHUTDOWN/OnIgnition", <msi>
```

Response(s)

```
^SCFG: "MESHUTDOWN/OnIgnition", <msi>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Query/Configure the timer controlled shutdown.

```
AT^SCFG="MESHUTDOWN/Timer", <shutdownRemainingTime>
```

Response(s)

```
^SCFG: "MESHUTDOWN/Timer", <shutdownRemainingTime>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Query/Configure Customer Id.

```
AT^SCFG="Misc/CId"[, <CId>]
```

Response(s)

```
^SCFG: "Misc/CId", <CId>
```

OK

ERROR

```
+CME ERROR: <err>
```

Write Command

Enable/disable radio bands.

```
AT^SCFG="Radio/Band"[, <rba>][, <rbe>]
```

Response(s)

```
^SCFG: "Radio/Band", <rba>
```

OK

ERROR

```
+CME ERROR: <err>
```

Write Command

Enable/Disable Continuous Network Search

```
AT^SCFG="Radio/CNS"[, <cns>]
```

Response(s)

```
^SCFG: "Radio/CNS", <cns>
```

OK

ERROR

```
+CME ERROR: <err>
```

Write Command

Disable / enable / query / configure output power limitation for SAR (Specific Absorbtion Rate)

```
AT^SCFG="Radio/Mtpl"[, <mode>[, <profile>, <band>, <limit>[, <limit_psk>]]]
```

Response(s)

```
^SCFG: "Radio/Mtpl", <mode>[, <profile>, <band>, <limit>[, <limit_psk>]]
```

In case of <mode>=0

```
^SCFG: "Radio/Mtpl", <mode>
```

In case of <mode>=1 and <profile>

```
^SCFG: "Radio/Mtpl", <mode>, <profile>
```

In case of <mode>=2 and <profile> one profile configuration is printed out

```
^SCFG: "Radio/Mtpl", <mode>, <profile>, <band>, <limit>[, <limit_psk>]
```

```
^SCFG: ["Radio/Mtpl", <mode>, <profile>, <band>, <limit>[, <limit_psk>]]
```

```
^SCFG: ["Radio/Mtpl", ...]
```

In case of <mode>=2 full profile configuration (1-8) is printed out

```
^SCFG: "Radio/Mtpl", <mode>, <profile>, <band>, <limit>[, <limit_psk>]
```

```
^SCFG: ["Radio/Mtpl", <mode>, <profile>, <band>, <limit>[, <limit_psk>]]
```

```
^SCFG: ["Radio/Mtpl", <mode>, <profile>, <band>, <limit>[, <limit_psk>]]
```

```
^SCFG: ["Radio/Mtpl", ...]
```

In case of <mode>=3 and <profile>, <band>, <limit> [, <limit_psk>]

```
^SCFG: "Radio/Mtpl", <mode>[, <profile>]
```

OK

ERROR

```
+CME ERROR: <err>
```

Write Command

Radio output power reduction.

```
AT^SCFG="Radio/OutputPowerReduction"[, <ropr>]
```

Response(s)

```
^SCFG: "Radio/OutputPowerReduction", <ropr>  
OK  
ERROR  
+CME ERROR: <err>
```

Write Command

Configure line that shall be toggled when UE has data to be transferred to the TE while RTS is inactive.

```
AT^SCFG="RemoteWakeUp/Event/ASC"[, <RemWakeLine>]
```

Response(s)

```
^SCFG: "RemoteWakeUp/Event/ASC", <RemWakeLine>  
OK  
ERROR  
+CME ERROR: <err>
```

Write Command

Configure line that shall be toggled when a URC is issued.

```
AT^SCFG="RemoteWakeUp/Event/URC"[, <RemWakeLine>]
```

Response(s)

```
^SCFG: "RemoteWakeUp/Event/URC", <RemWakeLine>  
OK  
ERROR  
+CME ERROR: <err>
```

Write Command

Configure line that shall be toggled to wake up the TE when a Remote Wakeup Event occurs on USB.

```
AT^SCFG="RemoteWakeUp/Event/USB"[, <RemWakeLine>]
```

Response(s)

```
^SCFG: "RemoteWakeUp/Event/USB", <RemWakeLine>  
OK  
ERROR  
+CME ERROR: <err>
```

Write Command

Select ports for waking up the TE

```
AT^SCFG="RemoteWakeUp/Ports"[, <RemWakePortSet>[, <RemWakePort>_1[, <RemWakePort>_2[, ...]]]]
```

Response(s)

```
^SCFG: "RemoteWakeUp/Ports", "current"[, <RemWakePort>_1[, <RemWakePort>_2[, ...]]]  
^SCFG: "RemoteWakeUp/Ports", "powerup"[, <RemWakePort>_1[, <RemWakePort>_2[, ...]]]  
OK  
ERROR  
+CME ERROR: <err>
```

Write Command

Configure duration of Wakeup Event pulse.

```
AT^SCFG="RemoteWakeUp/Pulse"[, <RemWakePulse>]
```

Response(s)

```
^SCFG: "RemoteWakeUp/Pulse", <RemWakePulse>  
OK  
ERROR  
+CME ERROR: <err>
```

Write Command

Select the USIM to be used.

```
AT^SCFG="SIM/CS" [, <CS>]
```

Response(s)

```
^SCFG: "SIM/CS" , <CS>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Configure mode of reading unreadable or missing Elementary Files on (U)SIM

```
AT^SCFG="SIM/Retry" [, <SimReadRetry>]
```

Response(s)

```
^SCFG: "SIM/Retry" , <SimReadRetry>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Enable / disable automatic acknowledgement of a directly routed incoming SMS without entering AT+CNMA.

```
AT^SCFG="Sms/AutoAck" [, <SmsAcknl>]
```

Response(s)

```
^SCFG: "Sms/AutoAck" , <SmsAcknl>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Configure 3GPP or 3GPP2 SMS format mode.

```
AT^SCFG="Sms/Format" [, <SmsFormat> [, <SmsFormat3gpp2>]]
```

Response(s)

```
^SCFG: "Sms/Format" , <SmsFormat> , <SmsFormat3gpp2>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Enable/disable IPv6 privacy extensions for the IP stack

```
AT^SCFG="Tcp/IPv6Priv" [, <v6privacyv>]
```

Response(s)

```
^SCFG: "Tcp/IPv6Priv" , <v6privacyv>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Configuration of TCP parameter 'MaxRetransmissions'.

```
AT^SCFG="Tcp/MR" [, <tcpMr>]
```

Response(s)

```
^SCFG: "Tcp/MR" , <tcpMr>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Configuration of TCP parameter 'OverallTimeout'.

```
AT^SCFG="Tcp/OT"[, <tcpOt>]
```

Response(s)

```
^SCFG: "Tcp/OT", <tcpOt>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Enable/disable "destination unreachable response" for connect requests on non-opened TCP sockets (sockets with no listener running)

```
AT^SCFG="Tcp/UnreachRsp"[, <unreachv>]
```

Response(s)

```
^SCFG: "Tcp/UnreachRsp", <unreachv>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Configuration of Internet Service URCS:

```
AT^SCFG="Tcp/WithURCs"[, <tcpWithUrc>]
```

Response(s)

```
^SCFG: "Tcp/WithURCs", <tcpWithUrc>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Enables/disables loopback device for the IPoverAT services.

```
AT^SCFG="Tcp/Loop", <loopback>
```

Response(s)

```
^SCFG: "Tcp/Loop", <loopback>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Set a range of accepted TLS versions for the IPoverAT services.

```
AT^SCFG="Tcp/TLS/Version", <TLS_min_version>, <TLS_max_version>
```

Response(s)

```
^SCFG: "Tcp/TLS/Version", <TLS_min_version>, <TLS_max_version>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Subcommand controls which interface will be used for URC presentation.

```
AT^SCFG="URC/DstIfc"[, <urcDestIfc>]
```

Response(s)

```
^SCFG: "URC/DstIfc", <urcDestIfc>
```

OK

ERROR

+CME ERROR: <err>

Write Command

Subcommand controls the behavior of the RING line if it is selected for URC signalization.

AT^SCFG="URC/Ringline", <urcRinglineCfg>

Response(s)

^SCFG: "URC/Ringline", <urcRinglineCfg>
OK
ERROR
+CME ERROR: <err>

Write Command

Subcommand controls duration of active RING line if it is selected for URC signalization.

AT^SCFG="URC/Ringline/ActiveTime", <urcRinglineDuration>

Response(s)

^SCFG: "URC/Ringline/ActiveTime", <urcRinglineDuration>
OK
ERROR
+CME ERROR: <err>

PIN MDM APP → Last

- + + + -

Parameter Description

<a1>^(str)

Audio Loop Setting

This parameter can be used to start and stop an audio loop. The feature is intended for testing the audio path without SIM card inserted and without mobile network environment. It is not intended for normal operation. Before starting the audio loop, it is recommended to set the audio related AT commands for the audio functions to be tested.

"0" ^(P)	No audio loop active
"1"	Audio loop active

<toneoff>^{(str)(NV)}

Supervisory tone and other locally generated tones off

This parameter can be used to deactivate a supervisory and locally generated tone. The value range is "0"..."2047". To deselect certain tones calculate the sum of the values of all deactivated tones. For example, for RINGING "2" and CONGESTION "8" please enter the value "10".

"0" ^(D)	No tone is deactivated.
"1"	DIAL TONE deactivated.
"2"	RINGING deactivated.
"4"	BUSY deactivated.
"8"	CONGESTION deactivated.
"16"	DROPPED deactivated.
"32"	WAITING deactivated.
"64"	RADIO_ACK deactivated.
"128"	AUTHENTICATION deactivated.
"256"	UNOBTAINABLE deactivated.
"512"	ATTENTION deactivated.

“1024“ all other locally generated tones deactivated.
 “2047“ all supervisory tones and other locally generated tones are deactivated.

`<ecc>`^{(str)(NV)}

Emergency call numbers on non-ECC USIM

Setting specifies emergency call numbers on a USIM without or empty ECC field. It has no influence on the commonly used emergency numbers 112 and 911 which are always supported.

Also refer to Section ATD where you can find a list of emergency call numbers supported if no USIM is inserted. The value range of `<ecc>` is "0"..."255". To select or deselect an emergency number calculate the sum of the values of all desired numbers and use the resulting value. For example, for "08" (2) and "118" (8) please enter the value (10).

Setting takes effect after next UE restart or USIM insertion.

0 ^(D) ...255	Bitmask setting:
“0“	No additional emergency numbers
“1“	000
“2“	08
“4“	110
“8“	118
“16“	119
“32“	999
“64“	Reserved
“128“	Reserved
“255“	All additional emergency call numbers are supported.

`<ant>`^{(str)(NV)}

External Antenna Control Switch for 700 MHz

To support an external 700 MHz antenna for FDD LTE B13 and B17 the UE has to provide a control pin for external antenna switching. Setting can be used to enable or disable an external 700 MHz antenna using a fixed GPIO2 line. For details refer to "[PLS8-X Hardware Interface Description, Version 03.017](#)".

If the external antenna is enabled, GPIO2 is locked for other functions, such as GPIO handler (see [AT^SCPIN](#)) or [AT^SCFG="MEopMode/PowerMgmt/LCI"](#) or Remote Wakeup line (see [<RemWakeLine>](#)). For example, if GPIO2 is opened by [AT^SCPIN](#), then it cannot be configured as external antenna. Restart the UE for the change to take effect.

“off“ ^(D)	External antenna is disabled.
“on“	External antenna is enabled.

`<gauth>`^(str)

PPP authentication mechanism

Setting can be used to configure which authentication algorithm the [AT+CGDATA](#) or [ATD*99#](#) commands will apply, during the PPP startup phase, for PDP contexts not yet activated.

For contexts activated with [AT+CGACT](#) please use the AT command [AT^SGAUTH](#) to configure the authentication method.

“0“	CHAP only
“1“	PAP only
“2“ ^(P)	Try CHAP first, then PAP

<gaa>^{(str)(NV)}

PS Domain auto attach

Setting can be used to control whether or not the UE will perform a PS Domain attach immediately after power-up and registering to the network. If the setting is changed to "enabled" and the UE is not attached yet, it will not initiate an attach immediately but after the next restart and registration to the network. For LTE please see more information in Section 12.1.1, [Attaching to LTE Networks](#).

"disabled"	PS Domain auto attach is disabled
"enabled" ^(D)	PS Domain auto attach is enabled

<volaCFUN>^{(str)(NV)}

Volatile +CFUN Mode

Parameter determines whether [AT+CFUN](#) parameter <fun> is stored persistently.

"0"	Setting of AT+CFUN parameter <fun> is stored persistently.
"1" ^(D)	Setting of AT+CFUN parameter <fun> is volatile, i.e. changes are not reestablished after next UE restart.

<storedCFUN>^{(str)(NV)}

Stored +CFUN Mode

Indicates setting of [AT+CFUN](#) parameter <fun> which will be used for next UE restart.

<dtm>^{(str)(NV)}

DTM Mode

This parameter controls the Dual Transfer Mode.

"0"	DTM and EDTM are disabled.
"1" ^(D)	DTM is enabled and EDTM is disabled.
"2"	DTM and EDTM are enabled.

<expdtr-set>^(str)

Set of DTR configurations for power saving

"current"	The currently used configuration (volatile).
"powerup"	The configuration used after powerup or restart (non-volatile).

<expdtr-port>^(str)

Port

The [AT^SCFG](#) "MEopMode/ExpectDTR" subcommand is designed to ensure an efficient power saving scheme. This is necessary because power saving takes effect only if there is no data pending on any port.

The <expdtr-port> parameter specifies ports where the host application (TE or DTE) can indicate its readiness to receive data from the module (DCE or UE). The supported ports are reported by the [AT^SCFG](#) test command in the line for "MEopMode/ExpectDTR". By delivery default the "MEopMode/ExpectDTR" feature is activated for all ports.

On each configured port, the module transmits data and notifications only after the connected host has activated DTR, or has sent a "SetControlLineState(DTE present)" request to a USB CDC ACM port, or a "SetInterface(Alt-Set)" request to a USB CDC ECM port (WWAN or RmNet adapter). Transmission data becoming pending on such a port before the host has notified its readiness will be discarded, thus allowing for power saving even

2.13 AT^SCFG

though the port was never opened.

Ports not configured with [AT^SCFG](#) "MEopMode/ExpectDTR" are handled dependent on port-specific flow control. They must be opened and read until no more data is available. Otherwise, data buffered on an unattended port (e.g. a ^SYSSTART URC) would prevent the module from power saving.

"acm1" ^(D)	Refers to USB0 set with AT^SSRVSET , parameter <Device>
"acm2" ^(D)	Refers to USB1 set with AT^SSRVSET , parameter <Device>
"acm3" ^(D)	Refers to USB2 set with AT^SSRVSET , parameter <Device>
"acm4" ^(D)	Refers to USB3 set with AT^SSRVSET , parameter <Device> . USB3 is not set within preconfigured AT^SSRVSET Service Sets. But it may be set within a customized AT^SSRVSET Service Set <SetNum> ≥ 10. For preconfigured AT^SSRVSET Service Sets, "acm4" must be left enabled.
"rmnet0" ^(D)	WWAN adapter
"rmnet1" ^(D)	WWAN adapter
"asc0" ^(D)	Refers to ASC0 set with AT^SSRVSET , parameter <Device>

[<com>](#)^{(str)(NV)}

AT+COPS operation mode

Parameter determines whether to use the UE's standard AT+COPS write command (default) or the non-blocking AT+COPS write command. In non-blocking mode the AT+COPS write command immediately returns OK. In this mode, the AT command interface will not be blocked till the search is finished. The status of the search will be indicated by the "+CREG" URC.

"0" ^(D)	Normal mode The standard mode of AT+COPS write command.
"1"	Non-blocking mode AT+COPS write command immediately returns OK.

[<pingv>](#)^{(str)(NV)}

Enable ping response

Enable or disable response on PING. If module is connected to Internet and has valid IP address it will or will not respond to ICMP PING depending on this setting.

"0"	Disable response on PING
"1" ^(D)	Enable

[<lci>](#)^(str)

Low Current Indicator

Setting can be used to enable or disable the Low Current Indicator using the line specified with parameter [<gpio>](#). For details refer to "[PLS8-X Hardware Interface Description, Version 03.017](#)".

"disabled" ^(P)	Low Current Indicator is disabled.
"enabled"	Low Current Indicator is enabled.

[<gpio>](#)^(str)

Low Current Indicator GPIO

Parameter specifies the GPIO used as Low Current Indicator.

If Low Current Indicator is enabled with parameter [<lci>](#), the used GPIO cannot be assigned to other functions such as GPIO handler (see [AT^SCPIN](#)) or [AT^SCFG="GPIO/Mode/Antenna"](#) or Remote Wakeup line (see [<RemWakeLine>](#)) or GPIO1 configured as DR_SYNC line (see [AT^SGPSC](#), [<DRSyncVal>](#)). Vice versa, if assigned to another function a GPIO cannot be configured as Low Current Indicator.

GPIO1...[GPIO6]...GPIO10

<provCfg>^{(str)(NV)}

Provider configuration

This parameter controls the provider modem software configuration. It is not allowed to change manual the provider configuration when value is "on". It will be denied with result code "+CME ERROR: operation temporary not allowed".

Check the possible provider by using `AT^SCFG=?` test command. Possible and current modem software configuration summary can also be read by `ATI61`.

For manual selection setting takes effect after next restart.

"0" ^(D)	Use default modem software configuration. Check a possible provider configuration mismatch by URC presentation <code>AT^SIND="prov"</code> indicator. The +CIEV: "prov" indicator delivers the provider configuration mismatch status via URC and it is helpful to switch on the indicator using <code>AT^SIND="prov",1</code> and store it non-volatile with <code>AT&W</code> . It is the responsibility of the manufacturer to use a desired configuration. For flexibility there is no automatic switch to any provider configuration.
"1"	AT&T.
"2"	VERIZON.

<iccidAvail>^{(str)(NV)}

Provider ICCID configuration availability

This parameter is set to "1" if any additional ICCID entry is available.

"0" ^(D)	No ICCID entry is available.
"1"	ICCID entry is available.

<provIccid1>^{(str)(NV)}

Provider ICCID configuration (AT&T)

This parameter is used to add any provider specific ICCIDs. Setting takes effect after next restart or reinsert SIM card.

To add a single entry use AT command `AT^SCFG="MEopMode/Prov/Iccid1","12345"`

Adding more entries (here 3) use `AT^SCFG="MEopMode/Prov/Iccid1","7654321:121212:999999999"`

Always the full string (maximum is 120 characters) is necessary separated by a colon.

Known hardcoded values are:

89311180,89310410,89310150,89310170,89310380,89310560,89310680,89310070,89310980,89310090.

<provIccid2>^{(str)(NV)}

Provider ICCID configuration (VERIZON)

This parameter is used to add any provider specific ICCIDs. Setting takes effect after next restart or reinsert SIM card.

To add a single entry use AT command `AT^SCFG="MEopMode/Prov/Iccid2","654321"`

Adding more entries (here 2) use `AT^SCFG="MEopMode/Prov/Iccid2","5555:9876543210"`

Always the full string (maximum is 120 characters) is necessary separated by a colon.

Known hardcoded values are:

891433,891444,891483,891486,891487,891489,891808,891480.

<PwrSaveMode>^{(str)(NV)}

Power Save Mode

AT^SCFG "MeOpMode/PwrSave" settings allow to control the PLS8-X's power saving behavior. See also "PLS8-X Hardware Interface Description, Version 03.017" for additional advice on power saving requirements for USB.

The first parameter <PwrSaveMode> enables or disables power save mode.

"disabled" ^(D)	Power save mode is disabled. Under no circumstances the UE will enter its power save (SLEEP) state. <PwrSavePeriod> value is reset to zero.
"enabled"	Power save mode is enabled. This mode enables the UE to enter power save (SLEEP) state when no activity occurs on any port. For ASC0, also set the parameters <PwrSavePeriod> and <PwrSaveWakeup>. Power saving will take effect only if there is no data pending on any port. You have two options to prevent that data remains pending: <ul style="list-style-type: none"> • On each port, the connected TE must retrieve all data sent from the UE to the TE. • If a TE is not able to receive data you can use the AT^SCFG "MEopMode/ExpectDTR" subcommand. If enabled the subcommand ensures to discard data pending on a port before the connected TE has signalled its readiness to receive data. By default this behavior is enabled for all ports.

<PwrSavePeriod>^{(str)(NV)}

Maximum Power Save Period

This parameter is only effective for the UART, i.e. for the serial interface ASC0 (see AT^SSRVSET settings for ASC0).

If <PwrSaveMode> is "enabled" the <PwrSavePeriod> value specifies the maximum duration the UE is allowed to stay in power save (SLEEP) state.

0...52^(D)...600 Maximum power save period in 1/10 seconds. Tolerance = -0/+2 seconds.

In SLEEP state, the CTS0 line stays inactive, i.e. the AT command interface is not accessible. The UART wakes up from SLEEP state after one of the following events:

- cyclically after expiry of the specified <PwrSavePeriod>,
- sending a URC (incl. for incoming calls),
- toggling the RTS0 line (falling edge only),
- toggling the DTR0 line (both edges).

After a wakeup event, the UART stays awake (CTS0 line becomes active), at least for the time defined by the parameter <PwrSaveWakeup> (5 seconds by default).

Notes on DTR toggling:

- Do not use DTR0 toggling for wakeup in context of data call if AT&D2 is enabled.
- Be careful using DTR0 toggling while the AT^SCFG "MEopMode/ExpectDTR" subcommand is enabled for ASC0. It is sometimes possible (when RTS0 and DTR0 are inactive) that some data intended to be sent from the TE to the UE (e.g. a URC) is discarded.

<PwrSavePeriod> value "0" means that the UE is allowed to stay in power save (SLEEP) state for an unlimited duration, without cyclic wakeup if once fallen asleep. In this case, the UE wakes up only by sending a URC, or toggling either RTS0 or DTR0.

Especially for large <PwrSavePeriod> values, toggling RTS0 or DTR0 is an option to wake up the UE any time before the <PwrSavePeriod> expires. Values between 1 and 600 are recommended when the TE is not designed to toggle RTS0 or DTR0. A recommended value is retaining the delivery default

52, i.e. 5.2 seconds. However, depending on the requirements of the Customer Application other values may be more suitable.

If Multiplex mode is used on ASC0, the `<PwrSavePeriod>` value depends on whether or not the Multiplex driver allows for toggling RTS0 and/or DTR0. If not, then the `<PwrSavePeriod>` must be set to a value smaller than internal timeouts implemented in your own Multiplexer to wait for "Tx data transmission completed". The WinMux demo driver supplied by GEMALTO M2M does not support RTS0 or DTR0 toggling. Instead, due to internal timeouts implemented in the WinMux driver, `<PwrSavePeriod>` shall be set to max. 52 (= delivery default).

`<PwrSaveWakeup>`^{(str)(NV)}

Minimum awake time

This parameter is only effective for the UART, i.e. for the serial interface ASC0.

The `<PwrSaveWakeup>` value determines the minimum period the UART remains awake after the last activity occurred on the UART (e.g. the first character sent or received caused UART wakeup), or wakeup by RTS0 or DTR0 toggling.

1...50^(D)...36000 Minimum delay in 1/10 seconds before the UE enters power save mode (SLEEP) again after a wakeup event on the UART .

`<msi>`^{(str)(NV)}

Parameter determines the switching mode of the ignition line (IGT): The line may either be used only to switch on the UE, or to toggle it on and off. For details refer to "[PLS8-X Hardware Interface Description, Version 03.017](#)".

"on" Ignition line (IGT) can be used to switch on and off the UE.

"off"^(D) Ignition line (IGT) can be used to switch on the UE.

`<shutdownRemainingTime>`^(str)

Remaining time for timer controlled shutdown

Remaining time in minutes until PLS8-X is powered down automatically. The timer is based on the real time clock of the PLS8-X (see [AT+CCLK](#)).

Please note, that changing the real time clock using [AT+CCLK](#) influences the remaining time for an activated automatic shutdown timer. Setting the time into the past will increase the remaining time, setting the time into the future will decrease the remaining time. If the real time clock is set to a time later than the expiration time of the active automatic shutdown timer, then the automatic shutdown is disabled.

"off"^(P) Automatic shutdown is disabled

"0" Automatic shutdown within the next minute

1...525600 Automatic shutdown after specified number of minutes

`<CIId>`^{(str)(+CSCS)(NV)}

Customer Id

Setting allows customers to store an identification string. It is not used by the UE itself. The maximum length of the string is 290 characters (GSM or UCS2 or IRA depending on the setting of [AT+CSCS](#)). The delivery value is an empty string.

`<rba>`^{(str)(NV)}

Parameter determines frequency band usage of the UE.

Please note that the band selection implementation of PLS8-X is based on a single band group that includes all frequency bands it is capable to use. This enables the UE to easily find a suitable network in any country around the world, no matter which frequency bands or band combinations and access technologies are present in a particular area.

Factory default of `<rba>` is the combination of all available bands meaning that all supported bands are allowed. If [AT+COPS](#) equals "0" (automatic mode) this solution allows the subscriber to take advantage of a full-featured

automatic network selection when trying to register.

Therefore, changes to the band configuration are recommended only if the subscriber wishes to restrict the allowed bands to a specific band or band combination, in particular to speed up the network search, and thus, to reduce the power consumption. In such case, `<rba>` may be one of the supported single values listed below or the sum of the values of all desired bands. For example, for GSM 900 MHz (1) and GSM 1800 MHz (2) please enter the value 3.

When changing the `<rba>` value you can use the additional `<rbe>` parameter to make the changes take effect immediately without reboot being required (`<rbe>="1"`) or after reboot only (`<rbe>="0"`).

If you wish to configure a specific band or band configuration take care that the selected value complies with the `<rat>` value selected with `AT+COPS`. Otherwise, if the settings of `<rba>` and `<rat>` are incompatible all bands supported by PLS8-X will be enabled after power-up.

"1"	GSM 900
"2"	GSM 1800
"4"	GSM 850
"8"	GSM 1900
"32"	WCDMA 1900 (BC2)
"64"	WCDMA 850 (BC5)
"512"	WCDMA 1700 AWS (BC4)
"16384"	LTE 1900 (B2)
"65536"	LTE 1700 (B4)
"131072"	LTE 850 (B5)
"1048576"	LTE 700 (B17)
"4194304"	LTE 700 (B13)

`<rbe>`^(str)

Radio/Band: Set frequency band(s) immediately effective

The additional `<rbe>` parameter determines when a changed `<rba>` value becomes effective.

"0"	<code><rba></code> takes effect after next restart.
"1"	<code><rba></code> takes effect immediately and will also be effective after next restart. Setting a new <code><rba></code> value and <code><rbe>= 1</code> causes the UE to restart a network search and to deregister and re-register. If old and new <code><rba></code> are the same the command will be accepted without triggering a network search and without effect on the registration. <code><rbe>= 1</code> is not usable while the UE is set to <code>AT+CFUN=0</code> or 4 (TX and RX RF switched off). In this case, the <code>AT^SCFG</code> write command returns an ERROR message.

`<cns>`^(str)

Continuous Network Search Mode

This parameter can be used to influence the time the UE takes to register to the network.

"0" ^(P)	Normal When trying to register to a network the UE sleeps longer than in "Fast mode" before restarting a network scan.
"1"	Fast "Fast mode" reduces the time the UE sleeps before restarting a network scan when trying to register. Advantage: If the UE is out of network service it may take less time to find a network. Disadvantage: Higher current consumption while the UE is out of network service.

Note: To monitor the search process it may be useful to have the "+CREG" URC enabled.

2.13 AT^SCFG

`<mode>`^(str)

Power Limitation Mode

The `AT^SCFG` subcommand "Radio/Mtpl" can be used to instantly adapt the module's Specific Absorption Rate (SAR) by reducing its output power for specific or all bands in any operating mode.

8 profiles for instant RF output power limitation can be defined and stored to the NV memory. A profile contains all supported bands (`<band>`) and, for each single band, a parameter limiting the maximum RF output power (`<limit>`). For GSM, a second parameter, `<limit_psk>`, is required to set the RF output power limit for GSM 8 PSK. The RF output power limit for a GSM band is related to one transmit timeslot. If two/three/four timeslots are used for transmission the specified power limit is reduced by another 3 / 4.8 / 6 dB.

Changing limit values of a profile with `<mode>` 3 takes effect after UE restart only. Activating and deactivating power limitation with `<mode>` 1 or 0, takes effect instantly. The `<mode>` is volatile, therefore output power limitation is deactivated after UE restart.

For an example on how to configure and trigger instant power limitation see below *Example* section.

"0" ^(P)	Power limitation deactivated (no further parameters are possible).
"1"	Power limitation activated. <code><profile></code> parameter is mandatory for activation.
"2"	Query profile settings. The response shows the currently used limit values if instant power limitation is active, i.e. if <code><mode></code> = 1. Therefore, bear in mind that modified profile values will be visible only if you restart the UE and run a query before activating instant power limitation. You can read either all profiles, or a specific profile by adding a <code><profile></code> number.
"3"	Change profile. All parameters are mandatory. Remember to restart the UE after changing the output power limits of a profile.

`<profile>`^(str)

Power Limitation Profile

This parameter identifies a profile.

When no profile is activated `<mode>` "0" is returned and if any profile is activated `<mode>` "1" and `<profile>` "1" ... "8" is returned in read command.

1...8	Number of profile.
-------	--------------------

`<band>`^(str)

Radio Band

"1"	GSM 900
"2"	GSM 1800
"4"	GSM 850
"8"	GSM 1900
"32"	WCDMA 1900 (BC2)
"64"	WCDMA 850 (BC5)
"512"	WCDMA 1700 AWS (BC4)
"16384"	LTE 1900 (B2)
"65536"	LTE 1700 (B4)
"131072"	LTE 850 (B5)
"1048576"	LTE 700 (B17)
"4194304"	LTE 700 (B13)

`<limit>`^{(str)(NV)}

Power Limitation

This parameter is used to set the power limit.
Setting takes effect after next restart.

18...33	Power limit value in dBm for GSM low bands.
18...30	Power limit value in dBm for GSM high bands.
18...24	Power limit value in dBm for WCDMA bands.
18...24	Power limit value in dBm for LTE bands.

`<limit_psk>`^{(str)(NV)}

Power Limitation 8 PSK (only for GSM)

This parameter is used to set the power limit 8 PSK.
Setting takes effect after next restart.

18...27	Power limit value in dBm only for GSM 8 PSK low bands.
18...26	Power limit value in dBm only for GSM 8 PSK high bands.

`<ropr>`^{(str)(NV)}

Radio Output Power Reduction

According to 3GPP TS 45.005, it is permissible to reduce the the maximum (E)GPRS output power. The amount of the maximum (E)GPRS power reduction is configurable for the case of 4TX.
Setting takes effect after next restart.

"4" ^(D)	No power reduction with GMSK and 8PSK.
"5"	2 dB power reduction with GMSK (with 4 Tx), no power reduction for 8PSK.
"6"	4 dB power reduction with GMSK (with 4 Tx), no power reduction for 8PSK.
"7"	6 dB power reduction with GMSK (with 4 Tx), no power reduction for 8PSK.
"8"	Max. power reduction for GSMK and 8PSK (6dB for 4 Tx).

`<RemWakeLine>`^{(str)(NV)}

Remote Wakeup line

Parameter specifies the line(s) that shall be toggled in order to signalize following events to the TE:
- UE has data on the ASC0 interface to be transferred to the TE while RTS0 is inactive (e.g. due to Sleep state or Flow Control),
- a URC is issued,
- UE has data on a USB port to be transferred to the TE.

For each event type the `AT^SCFG` subcommands "RemoteWakeUp/Event/ASC", "RemoteWakeUp/Event/URC" and "RemoteWakeUp/Event/USB" can be used to assign Remote Wakeup lines. You have the choice to specify the same line or different lines for all three event types.

When using a GPIO keep in mind that it is locked for other functions, e.g. GPIO handler (see `AT^SCPIN`) or Low Current Indicator (see `AT^SCFG "MEopMode/PowerMgmt/LCI"` parameter `<lci>`) or GPIO1 configured as DR_SYNC line (see `AT^SGPSC, <DRSyncVal>`) or GPIO2 enabling 700 MHz antenna (see `AT^SCFG "GPIO/Mode/Antenna" <ant>`).

The pulse duration is configurable via `<RemWakePulse>`.

"none" ^(D)	In case of USB: The Remote Wakeup mechanism specified in "USB Specification Revision 2.0" is applicable.
GPIO1...GPIO10	GPIO toggles when the assigned Remote Wakeup Event occurs on the port(s) selected with <code><RemWakePort></code> . The GPIO is active high. Note that some other types of Gemalto M2M modules employ GPIO4 for Host Wakeup. For compatibility with these modules you may select GPIO4.

“RING0“ RING0 line toggles when the assigned Remote Wakeup Event occurs on the port(s) selected with [<RemWakePort>](#).
The RING0 line is active low.
If the RING0 line is not set with [<RemWakeLine>](#), the legacy options "URC/Ringline" (see [<urcRinglineCfg>](#)) and "URC/Ringline/ActiveTime" (see [<urcRinglineDuration>](#)) are applicable.

[<RemWakePortSet>](#)^{(str)(NV)}

Set of ports signaling Remote Wakeup Events

“current“ The currently used configuration (volatile).
“powerup“ The configuration used after powerup or restart (non-volatile).

[<RemWakePort>](#)^(str)

Port

Only ports listed with [<RemWakePort>](#) try to wake up the TE when an event configured with [AT^SCFG](#) subcommands "RemoteWakeUp/Event/ASC" or "RemoteWakeUp/Event/USB" occurs. The supported ports are reported by the [AT^SCFG](#) test command in the line for "RemoteWakeUp/Ports".

“acm1“^(D) Refers to USB0 set with [AT^SSRVSET](#), parameter [<Device>](#)
“acm2“^(D) Refers to USB1 set with [AT^SSRVSET](#), parameter [<Device>](#)
“acm3“^(D) Refers to USB2 set with [AT^SSRVSET](#), parameter [<Device>](#)
“acm4“^(D) Refers to USB3 set with [AT^SSRVSET](#), parameter [<Device>](#)
“rmnet0“^(D) WWAN adapter
“rmnet1“^(D) WWAN adapter
“asc0“^(D) Refers to ASC0 set with [AT^SSRVSET](#), parameter [<Device>](#)

[<RemWakePulse>](#)^{(str)(NV)}

Remote Wakeup Pulse Duration

Parameter specifies the pulse duration for a Remote Wakeup Event in 10ms steps.

1...10^(D)...100

[<CS>](#)^{(str)(NV)}

Card slot / USIM

The [AT^SCFG](#) subcommand "SIM/CS" specifies the (U)SIM interface currently used. Usage of this command depends on whether the host application is designed to include an additional second (U)SIM interface. Only one of the supported (U)SIM interfaces can be used at a time. For details on how to connect the first and the second (U)SIM interface please refer to ["PLS8-X Hardware Interface Description, Version 03.017"](#).

“NO_SIM“ No USIM is used, no matter whether a USIM is present in one of the slots.
“SIM_1“^(D) First (U)SIM slot is enabled regardless of whether a (U)SIM card is inserted.
Access to another (U)SIM inserted in slot 2 is deactivated.
“SIM_2“ Second (U)SIM slot is enabled regardless of whether a (U)SIM card is inserted.
Access to another (U)SIM inserted in slot 1 is deactivated.

To check the status of the (U)SIM and the (U)SIM interface you can take advantage of several URCs, such as [AT^SIND](#) "simstatus", [AT^SCKS](#), [AT^SSET](#).

When the configuration changes the UE tries to start the selected (U)SIM interface no matter whether a CCIN line is populated. Therefore, please note that the [AT^SIND](#) "simstatus" indicator and the [AT^SCKS](#) URCs will show up 3 times when the selected (U)SIM slot is empty. Both URCs will show a sequence of values 0, 1, 0 (e.g. "[^SCKS](#): 0", "[^SCKS](#): 1", "[^SCKS](#): 0" and "+CIEV: simstatus,0", "+CIEV: simstatus,1", "+CIEV: simstatus,0"). If a (U)SIM is inserted both URCs will show value 1.

<SimReadRetry>^{(str)(+CSCS)}

The **AT^SCFG** subcommand "SIM/Retry" is designed for reading Elementary Files (EF) on the (U)SIM which cannot be read or found for some reason, e.g. if a certain EF on a (U)SIM is corrupt, wrongly configured, or missing at all. In this case, the <SimReadRetry> parameter determines the number of attempts the UE will make to read such an EF on the (U)SIM.

- | | |
|---------------------|---|
| "off" | For each unreadable or missing EF, the UE makes one attempt to read this EF on the (U)SIM. |
| "on" ^(P) | For each unreadable or missing EF, the UE makes up to 3 attempts to read this EF on the (U)SIM. |

<SmsAcknl>^(str)

SMS auto acknowledge

Parameter activates or deactivates the ability to automatically acknowledge an incoming short message directly routed to the TE.

- | | |
|--------------------|---|
| "0" ^(P) | No automatic acknowledgement. |
| "1" | UE will automatically acknowledge an incoming short message directly routed to the TE / immediately displayed. This eliminates the need for the user to manually acknowledge such messages with AT+CNMA .
Please keep in mind that you may lose an incoming short message if the interface is blocked. |

<SmsFormat>^{(str)(NV)}

Only for AT&T provider configuration set with **AT^SCFG** subcommand "MEopMode/Prov/Cfg", see parameter <provCfg>:

Parameter determines the access technology (AcT) specific handling of short messages: either 3GPP or 3GPP2.

- 3GPP SMS format mode:
In 3GPP SMS format mode all SMS related AT commands operate according to the 3GPP specifications defined for GSM/UMTS/LTE networks. 3GPP formatted short messages may be sent in any 3GPP defined technology (GSM/GPRS/UMTS/LTE).
- 3GPP2 SMS format mode:
In 3GPP2 SMS format mode all SMS related AT commands operate according to the 3GPP2 specifications defined for CDMA2000 networks (refer to 3GPP2 C.S0015-A).

Due to the different code formats the used SMS memory is internally split into 3GPP and 3GPP2 sections, each with an own location index counter. As a result, a certain location number points either to a message in 3GPP format, or to a message in 3GPP2 format. Therefore, when switching back and forth between both "SMS/Format" types, users should be aware that same location numbers refer to different SMS content. In 3GPP2 SMS format mode only the storages "ME" and "MT" are available, the "SM" storage cannot be selected. For details see [AT+CPMS](#).

Short messages are received regardless of the selected SMS format mode. The URCs set with **AT+CNMI <mt>** report only short messages of the selected SMS format. Therefore, it is recommended to enable the "+CIEV: newsms" URC which reports all incoming stored short messages, and additionally indicates the AcT type and the storage location of each new incoming short message. This way, the URC notifies the user whether or not to change the SMS format in order to read or list received short messages. See **AT^SIND** for details.

- | | |
|-----------------------|--|
| "3GPP" ^(D) | Short messages are encoded / decoded in 3GPP format:
AT commands for listing, reading, deleting, writing, sending short messages, such as AT+CMGL , AT+CMGR , AT+CMGD , AT+CMGW , AT+CMGS use only the 3GPP section of the selected SMS memory.
URCs set with AT+CNMI <mt> will report only stored mobile terminated short messages encoded in 3GPP format. |
|-----------------------|--|

“3GPP2” Short messages are encoded / decoded in 3GPP2 format:
 At commands for listing, reading, deleting, writing, sending short messages, such as [AT+CMGL](#), [AT+CMGR](#), [AT+CMGD](#), [AT+CMGW](#), [AT+CMGS](#) use only the 3GPP2 section of the SMS "ME" or "MT" memory.
 URCs set with [AT+CNMI <mt>](#) will report only stored mobile terminated short messages encoded in 3GPP2 format.
[AT+CNMI](#) values [<mt>=2](#) and [<mt>=3](#) are disabled because phase 2+ compatibility ([AT+CSMS=1](#)) is not supported.
[AT+CNMI](#) value [<bm> 2](#) is disabled because Cell Broadcast ([AT+CSCB](#)) is not supported for 3GPP2.
 Manual SMS acknowledgement with [AT+CNMA](#) is not supported.

`<SmsFormat3gpp2>(str)(NV)`

Only for "Verizon" provider configuration set with [AT^SCFG](#) subcommand "MEopMode/Prov/Cfg", see parameter [<provCfg>](#):

Parameter determines the access technology (AcT) specific handling of short messages: either 3GPP or 3GPP2.

- 3GPP SMS format mode:
 In 3GPP SMS format mode all SMS related AT commands operate according to the 3GPP specifications defined for GSM/UMTS/LTE networks. For Verizon subscribers this option is only needed when roaming in networks other than Verizon to allow sending and receiving short messages in any 3GPP defined technology (GSM/GPRS/UMTS/LTE).
- 3GPP2 SMS format mode:
 In 3GPP2 SMS format mode all SMS related AT commands operate according to the 3GPP2 specifications defined for CDMA2000 networks (refer to 3GPP2 C.S0015-A).
 In Verizon Wireless networks 3GPP2 formatted short messages are sent/received only via IMS (IP Multimedia Subsystem). The UE registers to IMS only if registered to LTE, configured for IPV4 / IPV6 and if registered to the VzW IMS server "vzwims" via the dedicated APN1. If IMS is not available there is no possibility to send or receive such messages. In such case MT short messages cannot be received, and sending short messages with [AT+CMGS](#) will be denied with an error result code.

Due to the different code formats the used SMS memory is internally split into 3GPP and 3GPP2 sections, each with an own location index counter. As a result, a certain location number points either to a message in 3GPP format, or to a message in 3GPP2 format. Therefore, when switching back and forth between both "SMS/Format" types, users should be aware that same location numbers refer to different SMS content. In 3GPP2 SMS format mode only the storages "ME" and "MT" are available, the "SM" storage cannot be selected. For details see [AT+CPMS](#).

In Verizon Wireless networks received short messages are converted automatically to 3GPP2 SMS format. The URCs set with [AT+CNMI <mt>](#) can therefore report all MT short messages. The additional "+CIEV: newsms" URC provided by [AT^SIND](#) is not necessary.

“3GPP” Short messages are encoded / decoded in 3GPP format:
 AT commands for listing, reading, deleting, writing, sending short messages, such as [AT+CMGL](#), [AT+CMGR](#), [AT+CMGD](#), [AT+CMGW](#), [AT+CMGS](#) use only the 3GPP section of the selected SMS memory.
 URCs set with [AT+CNMI <mt>](#) will report only stored mobile terminated short messages encoded in 3GPP format.

“3GPP2“(D) Short messages are encoded / decoded in 3GPP2 format:
 AT commands for listing, reading, deleting, writing, sending short messages, such as [AT+CMGL](#), [AT+CMGR](#), [AT+CMGD](#), [AT+CMGW](#), [AT+CMGS](#) use only the 3GPP2 section of the SMS "ME" or "MT" memory.
[AT+CNMI](#) values [<mt>=2](#) and [<mt>=3](#) are disabled because phase 2+ compatibility ([AT+CSMS=1](#)) is not supported.
[AT+CNMI](#) value [<bm> 2](#) is disabled because Cell Broadcast ([AT+CSCB](#)) is not supported for 3GPP2.
 Manual SMS acknowledgement with [AT+CNMA](#) is not supported.

<v6privacyv>^{(str)(NV)}

Enable IPv6 privacy

Enable or disable IPv6 privacy extensions (RFC 4941) for the IP stack

"0"	Disable IPv6 privacy extensions
"1" ^(D)	Enable

<tcpMr>^{(str)(NV)}

Maximum Number of Retransmissions (MR)

1...10 ^{(&F)(D)} ...30	Setting determines the maximum number of times to retransmit TCP packets. The value set with <tcpMr> will be assumed as default for the <srvParm-Tag> "tcpMR" when a new service profile is created with AT^SISS. In each service profile, you can set another "tcpMR" value which has precedence over the global value set with AT^SCFG. Existing service profiles are not affected when you change the global value via AT^SCFG. Use of default value is recommended.
-------------------------------------	---

<tcpOt>^{(str)(NV)}

Overall TCP Timer for outstanding connections (tcpOT)

1...6000 ^{(&F)(D)}	Setting specifies the number of seconds to wait before closing a connection if TCP/IP packets are not acknowledged. Setting the maximum value is practically equivalent to deactivating the tcpOT mechanism because the maximum time would never be reached by the TCP/IP stack. The value set with <tcpOt> will be assumed as default for the <srvParm-Tag> "tcpOT" when a new service profile is created with AT^SISS. However, in each service profile, you can set another "tcpOT" value which has precedence over the global value set with AT^SCFG. Existing service profiles are not affected when you change the global value via AT^SCFG. Use of default value is recommended.
---------------------------------	---

<unreachv>^{(str)(NV)}

Enable unreach response

Enable or disable response for open (SYN) requests on non-opened TCP sockets (no service is running on this socket). Normally, a SYN request on such a port is answered with a TCP packet, having set the RST bit in its header. Depending on this setting, the responding TCP packet is sent or not.

"0"	Disable response on non-opened sockets
"1" ^(D)	Enable

<tcpWithUrc>^{(str)(NV)}

URC mode or polling mode for Internet service commands

This parameter enables or disables the presentation of the following URCs related to Internet service commands: "^SISR" URC, "^SISW" URC and "^SIS" URC for parameter <urcCause>=0 (Internet service events). "^SIS" URCs with <urcCause>=1 or 2 used to indicate incoming Socket connections are always enabled.

"on" ^(D)	Enable URCs related to Internet service commands. Throughout the Chapter "Internet Service AT Commands" the mode is also referred to as URC mode.
"off"	Disable URCs related to Internet service commands. This requires the TE to employ polling techniques when using the Internet service AT commands: The TE is responsible to retrieve all status information needed to control an Internet session. The method is referred to as polling mode.

<loopback>^(str)

IPOverAT loopback device

This parameter controls whether loopback device is enabled/disabled for IPOverAT services.

“disabled” ^(P)	Loopback device is disabled
“enabled”	Loopback device is enabled

<TLS_min_version>^{(str)(NV)}

Minimum TLS Version allowed

This parameter sets the accepted minimum TLS version for IPOverAT services.

“MIN” ^(D)	Automatic minimum
“0.9”	TLSv0.9 (SSLv3)
“1.0”	TLSv1
“1.1”	TLSv1.1
“1.2”	TLSv1.2
“MAX”	Automatic maximum

<TLS_max_version>^{(str)(NV)}

Maximum TLS version allowed

This parameter sets the accepted maximum TLS version for IPOverAT services. Must be equal or greater than [<TLS_min_version>](#).

“1.0”	TLSv1
“1.1”	TLSv1.1
“1.2”	TLSv1.2
“MAX” ^(D)	Automatic maximum

<urcDestIfc>^{(str)(NV)}

Parameter determines which interface will be used for URC presentation. Note that the recommended approach for a typical PLS8-X application is using the default configuration. If changing the configuration please carefully read Section 1.4, [AT Command Interpreter](#) and Section 1.8, [Unsolicited Result Code Presentation](#).

If the application port is not available, then it is not possible to select it.

If Multiplex mode is started with [AT+CMUX](#), then automatically the value "app" will be selected.

If the modem interface is used, keep in mind, that if the interface is blocked by an active data connection, this connection should be periodically suspended to check for pending URCs.

“mdm”	Use modem interface to output URCs.
“app” ^(D)	Use application interface to output URCs.

<urcRinglineCfg>^{(str)(NV)}

Parameter specifies the ring line to be used for signaling URCs both for idle interface and while interface is reserved, i.e. while busy on AT command execution or data transmission.

For details about URC presentation and related hardware signalization refer to Section 1.8, [Unsolicited Result Code Presentation](#). line to wake up the TE refer to ["PLS8-X Hardware Interface Description, Version 03.017"](#).

Note: Setting is local for every AT command instance, i.e. for Modem (MDM) and Application (APP) services; for details refer to Section 1.4, [AT Command Interpreter](#).

“off”	URCs do not activate a ring line.
-------	-----------------------------------

"local" ^(D)	Ring line will be activated on the same device where the URC appears: This is the RING0 line (active low) if the URC appears on ASC0 device and a virtual ring line if the URC appears on a USB related device.
"asc0"	RING0 line will be activated as Host Wakeup (low active).

`<urcRinglineDuration>`^{(str)(NV)}

Parameter determines how long the ring line shall be activated for URC signalization. The type of ring line depends on parameter `<urcRinglineCfg>`.
For details about URC presentation and related hardware signalization refer to Section 1.8, [Unsolicited Result Code Presentation](#).

"2" ^(D)	Ring line will be activated for about 1s.
"on"	Ring line is always activated.
"off"	Ring line is always deactivated.

Example

The example shows how to read, configure, activate and deactivate output power limitation using the `AT^SCFG "Radio/Mtpl"` subcommand. See parameters `<mode>`, `<profile>`, `<band>`, `<limit>`, `<limit_psk>`.

```

^SYSSTART
AT^SCFG="Radio/Mtpl"
^SCFG: "Radio/Mtpl", "0"
OK
AT^SCFG="Radio/Mtpl", 2, 1
^SCFG: "Radio/Mtpl", "2", "1", "1", "33", "27"
^SCFG: "Radio/Mtpl", "2", "1", "2", "30", "26"
^SCFG: "Radio/Mtpl", "2", "1", "4", "33", "27"
^SCFG: "Radio/Mtpl", "2", "1", "8", "30", "26"
^SCFG: "Radio/Mtpl", "2", "1", "32", "24"
^SCFG: "Radio/Mtpl", "2", "1", "64", "24"
^SCFG: "Radio/Mtpl", "2", "1", "512", "24"
^SCFG: "Radio/Mtpl", "2", "1", "16384", "24"
^SCFG: "Radio/Mtpl", "2", "1", "65536", "24"
^SCFG: "Radio/Mtpl", "2", "1", "131072", "24"
^SCFG: "Radio/Mtpl", "2", "1", "1048576", "24"
^SCFG: "Radio/Mtpl", "2", "1", "4194304", "24"
OK
AT^SCFG="Radio/Mtpl", 3, 1, 32, 23
^SCFG: "Radio/Mtpl", "0"
OK
AT^SCFG="Radio/Mtpl", 3, 1, 64, 23
^SCFG: "Radio/Mtpl", "0"
OK
AT^SCFG="Radio/Mtpl", 3, 1, 512, 23
^SCFG: "Radio/Mtpl", "0"
OK
AT^SCFG="Radio/Mtpl", 3, 1, 16384, 23
^SCFG: "Radio/Mtpl", "0"
OK
AT^SCFG="Radio/Mtpl", 3, 1, 65536, 23

```

Read "Radio/Mtpl" mode.
Instant power limitation is still disabled.

Read profile 1 settings. Delivery default settings are shown:

Profile 1: Change max. RF output power limit of WCDMA 1900 (BC2) band to 23dBm.
Instant power limitation is still disabled.

Profile 1: Change max. RF output power limit of WCDMA 850 (BC5) band to 23dBm.
Instant power limitation is still disabled.

Profile 1: Change max. RF output power limit of WCDMA 1700 AWS (BC4) band to 23dBm.
Instant power limitation is still disabled.

Profile 1: Change max. RF output power limit of LTE 1900 (B2) band to 23dBm.
Instant power limitation is still disabled.

Profile 1: Change max. RF output power limit of LTE 1700 (B4) band to 23dBm.

<pre>^SCFG: "Radio/Mtpl", "0" OK AT^SCFG="Radio/Mtpl", 3, 1, 131072, 23 ^SCFG: "Radio/Mtpl", "0" OK AT^SCFG="Radio/Mtpl", 3, 1, 1048576, 23 ^SCFG: "Radio/Mtpl", "0" OK AT^SCFG="Radio/Mtpl", 3, 1, 4194304, 23 ^SCFG: "Radio/Mtpl", "0" OK AT^SCFG="Radio/Mtpl", 2, 1 AT+CFUN=1, 1 OK ^SYSSTART AT^SCFG="Radio/Mtpl" ^SCFG: "Radio/Mtpl", "0" OK AT^SCFG="Radio/Mtpl", 2, 1 ^SCFG: "Radio/Mtpl", "2", "1", "1", "33", "27" ^SCFG: "Radio/Mtpl", "2", "1", "2", "30", "26" ^SCFG: "Radio/Mtpl", "2", "1", "4", "33", "27" ^SCFG: "Radio/Mtpl", "2", "1", "8", "30", "26" ^SCFG: "Radio/Mtpl", "2", "1", "32", "23" ^SCFG: "Radio/Mtpl", "2", "1", "64", "23" ^SCFG: "Radio/Mtpl", "2", "1", "512", "23" ^SCFG: "Radio/Mtpl", "2", "1", "16384", "23" ^SCFG: "Radio/Mtpl", "2", "1", "65536", "23" ^SCFG: "Radio/Mtpl", "2", "1", "131072", "23" ^SCFG: "Radio/Mtpl", "2", "1", "1048576", "23" ^SCFG: "Radio/Mtpl", "2", "1", "4194304", "23" OK AT^SCFG="Radio/Mtpl", 1, 1 ^SCFG: "Radio/Mtpl", "1", "1" OK AT^SCFG="Radio/Mtpl", 1, 2 ^SCFG: "Radio/Mtpl", "1", "2" OK AT^SCFG="Radio/Mtpl", 0 ^SCFG: "Radio/Mtpl", "0" OK</pre>	<p>Instant power limitation is still disabled.</p> <p>Profile 1: Change max. RF output power limit of LTE 850 (B5) band to 23dBm. Instant power limitation is still disabled.</p> <p>Profile 1: Change max. RF output power limit of LTE 700 (B17) band to 23dBm. Instant power limitation is still disabled.</p> <p>Profile 1: Change max. RF output power limit of LTE 700 (B13) band to 23dBm. Instant power limitation is still disabled.</p> <p>Read profile 1 settings. The response returns the old values as above (therefore omitted in this example). Restart UE to enable the profile 1 settings configured above.</p> <p>Read "Radio/Mtpl" mode. Instant power limitation is still disabled.</p> <p>Read profile 1 settings. Changed values are shown now.</p> <p>Activate Profile 1. Instant power limitation is now enabled with profile 1 and new limits as changed above.</p> <p>Switch profiles, and activate profile 2. Instant power limitation is now enabled with profile 2, still using delivery default values.</p> <p>Deactivate instant power limitation. Instant power limitation is now disabled.</p>
---	--

2.14 AT^SSRVSET Service Interface Configuration

PLS8-X offers numerous services such as two AT command instances MDM (Modem) and APP (Application) and NMEA streaming (see Chapter 15., [GNSS Commands](#)). For AT command instances MDM and APP refer to Section 1.4, [AT Command Interpreter](#) and [AT^SQPORT](#).

PLS8-X also offers numerous devices such as serial interface ASC0, USB related channels and Multiplex mode related channels. USB related channels are part of the UE's USB composition, which can be enabled or disabled. Hence, [AT^SSRVSET](#) serves to configure which service is mapped onto which device. These mappings are stored in Service Sets. A number of fixed (i.e. predefined) Service Sets and some customer configurable Service Sets are available.

Information provided by the active Service Set is evaluated during PLS8-X restart.

The UE does not support mapping of any available service to every device. Therefore, it is highly recommended to exclusively use the mappings specified in the following table. For every service the table determines the mapping for two scenarios: Normal mode after UE switch-on and for Multiplex mode activated via [AT+CMUX](#).

After changing the [AT^SSRVSET](#) configuration make sure that all device / interface relevant AT commands and settings match. For example, please check, and if needed, modify [AT^SCFG](#) subcommands "URC/Dstlfc", "URC/Ringline" and "MEopMode/ExpectDTR".

Table 2.6: Validated and released Service/Device Mappings

Service Set	MDM ^{*)}	APP	NMEA
<SetNum> 1 UART & USB	ASC0, MUX0 ^{**)}	USB1, MUX1	USB2, MUX2
<SetNum> 2 USB only	USB0, MUX0	USB1, MUX1	USB2, MUX2
<SetNum> 3 UART only	ASC0, MUX0	NONE, MUX1	NONE, MUX2
<SetNum>s ≥ 10 Customer Configurable	ASC0, MUX0	USB1 ^{***)} , MUX1	NONE, MUX2

*) Multiplex mode can be started on Modem interface (MDM) only. For details refer to [AT+CMUX](#).

**) Please note that the [AT^SSRVSET](#) command starts off counting the multiplex channels from 0, whereas other AT commands and descriptions start off from 1 (see e.g. [AT+CMUX](#)). This means MUX0 refers to multiplex channel 1, MUX1 to multiplex channel 2 etc.

***) Even if APP service is not used while UE is not in Multiplex mode, it is recommended to enable USB1 as a fallback solution to regain access to AT commands.

Syntax

```

Test Command
AT^SSRVSET=?
Response(s)
OK

Read Command
AT^SSRVSET?
Response(s)
^SSRVSET: <SetNum>, "usbcomp", <comp>, <usbLangId>, <usbVendorId>, <usbProductId>,
<usbManufacturer>, <usbProduct>, <usbSerialNo>
^SSRVSET: <SetNum>, "srvmap", <Service>, <Device>, <Mux-Device>
^SSRVSET: ...
OK
ERROR
+CME ERROR: <err>
    
```

Write Command

Determine or query the Service Set used during next UE restart. Only a valid Service Set can be activated, i.e. at least one AT command service (i.e. MDM or APP) mapping needs to be provided. Otherwise "actSrvSet" subcommand will return an `<SrvSetError>` code.

```
AT^SSRVSET="actSrvSet"[, <SetNum>]
```

Response(s)

In case of an error:

```
[^SSRVSET:"ERROR", <SrvSetError>]
```

OK

Write Command

Generate list of all devices available as part of a certain Service Set.

```
AT^SSRVSET="listSrvSetDev", <SetNum>
```

Response(s)

```
^SSRVSET:"fixDev", <SetNum>, <Device>[, <Device>, ... ]
```

```
^SSRVSET:"usbDev", <SetNum>, <Device>[, <Device>, ... ]
```

```
^SSRVSET:"muxDev", <SetNum>, <Mux-Device>[, <Mux-Device>, ... ]
```

Or in case of an error:

```
[^SSRVSET:"ERROR", <SrvSetError>]
```

OK

Write Command

Query details of service interface configuration currently used by the UE. The configuration data was initially taken from the Service Set database and cannot be changed without UE restart.

```
AT^SSRVSET="current"
```

Response(s)

```
^SSRVSET:"usbcomp", <comp>, <usbLangId>, <usbVendorId>, <usbProductId>, <usbManufacturer>, <usbProduct>, <usbSerialNo>
```

```
^SSRVSET:"srvmap", <Service>, <Device>, <Mux-Device>
```

```
^SSRVSET:...
```

Or in case of an error:

```
[^SSRVSET:"ERROR", <SrvSetError>]
```

OK

Write Command

Determine USB composition for a given customer configurable Service Set. This way a USB composition is to be used if the given Service Set is activated for next UE restart.

If parameter `<comp>` is set to "NONE", the service set does not use a USB composition. Hence, no USB related devices can be mapped to a service. If a device provided as part of a USB composition is used in any mapping of the given Service Set the "usbcomp" subcommand will return an `<SrvSetError>` code.

If no further parameters are provided this subcommand queries the USB composition used by the UE.

```
AT^SSRVSET="usbcomp"[, <SetNum>, <comp>]
```

Response(s)

In case of query of available USB composition:

```
[^SSRVSET:"usbcomp", <comp>, <usbLangId>, <usbVendorId>, <usbProductId>, <usbManufacturer>, <usbProduct>, <usbSerialNo>]
```

In case of an error:

```
[^SSRVSET:"ERROR", <SrvSetError>]
```

OK

2.14 AT^SSRVSET

Write Command

Determine a service - device mapping for a given customer configurable Service Set. This way connect a service to a device and a Multiplex mode related device if the given Service Set is used during UE restart. If last parameter `<Mux-Device>` is omitted "NONE" is used as default value, i.e. the service will remain usable on the given device during Multiplex mode.

If no devices are provided (i.e. both parameters `<Device>` and `<Mux-Device>` are set to "NONE"), a mapping of the service is deleted if one exists, if not the "srvmap" subcommand will return with `<SrvSetError>=3`.

It is not possible to map a `<Device>` or Multiplex mode related `<Mux-Device>` to more than one service. "srvmap" subcommand will return an `<SrvSetError>` code.

Take special care when changing the mapping of the currently active Service Set for use after next UE restart. It is not allowed to invalidate the active Service Set by deleting the last AT command service (i.e. MDM or APP) mapping. "srvmap" subcommand will return an `<SrvSetError>` code in this case.

```
AT^SSRVSET="srvmap", <SetNum>, <Service>, <Device>[, <Mux-Device>]
```

Response(s)

In case of an error:

```
[^SSRVSET:"ERROR", <SrvSetError>]
```

OK

Write Command

Dismiss all service - device mappings for a given customer configurable Service Set. If no further parameter is provided this subcommand clears all customer configurable Service Sets. However, it is not allowed to clear the mappings of the currently active Service Set, i.e. which will be used during next UE restart. "clear" subcommand will return an `<SrvSetError>` code in this case.

```
AT^SSRVSET="clear"[, <SetNum>]
```

Response(s)

In case of an error:

```
[^SSRVSET:"ERROR", <SrvSetError>]
```

OK

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

`<SetNum>`^{(num)(NV)}

Service Set Number

The Service Set number can be seen as an index into the Service Set database.

1 ^(D)	Service Set with fixed configuration for USB and UART access.
2	Service Set with fixed configuration for accessing USB only.
3	Service Set with fixed configuration for accessing UART only.
10...12	Customer configurable Service Sets.

<comp>^{(str)(NV)}

USB Composition Identification

Identification of USB composition.

“NONE” No USB composition dedicated to a Service Set. Hence, no USB related devices are available to be mapped to a service.

“0061” USB composition Identifier. This composition enumerates the following devices: 4*CDC-ACM (USB0..3), 1*CDC-ACM (USB4 only reserved) and 2*CDC-ECM (WWAN adapters).
For details refer to ["PLS8-X Hardware Interface Description, Version 03.017"](#) and [AT^SWWAN](#).

<usbLangId>^{(str)(NV)}

Language ID

Please refer to ["USB Language Identifiers \(LANGIDs\) \[.PDF!\]"](#) to find the language IDs currently defined for USB devices. If parameter <usbLangId> is not specified, the default value of the UE's standard USB Device Descriptor configuration applies (US English).

Parameter shall be given in HEX format, maximum 4 characters.

<usbVendorId>^{(str)(NV)}

Vendor ID

This parameter represents the Vendor ID obtained from the USB Implementers Forum. The Vendor ID will, together with the Product ID, be transmitted to the host during USB enumeration. If the parameter <usbVendorId> is not specified, the default value of the UE's standard USB Device Descriptor configuration applies.

Parameter shall be given in HEX format, maximum 4 characters.

<usbProductId>^{(str)(NV)}

Product ID

Product ID (PID) defined by the Customer Application manufacturer to identify the USB device. The Product ID will, together with the Vendor ID, be transmitted to the host during USB enumeration. If parameter <usbProductId> is not specified, the default value of UE's standard USB Device Descriptor applies.

Parameter shall be given in HEX format, maximum 4 characters.

<usbManufacturer>^{(str)(NV)}

Manufacturer name

Optional manufacturer string defined by the Customer Application manufacturer. If parameter <usbManufacturer> is not specified, the default value of the UE's standard USB Device Descriptor configuration applies. Parameter length: maximum 63 characters.

<usbProduct>^{(str)(NV)}

Product string

Optional product name defined by the Customer Application manufacturer. If parameter <usbProduct> is not specified, the default value of the UE's standard USB Device Descriptor configuration applies.

Parameter length: maximum 63 characters.

<usbSerialNo>^{(str)(NV)}

Device serial number

Optional serial number. Empty string if not used, like in the case of the UE's standard USB Device Descriptor configuration.

A serial number enables the host to assign the same virtual COM port to the USB device even though the device is connected to another USB port. This eliminates the need for the host to load the driver again.

Parameter length: maximum 4 characters.

<Service>^{(str)(NV)}

List of possible services provided by the UE.

“APP“	Application instance referred to as "Application" if queried with AT^SQPORT . In the quick reference tables it is named APP.
“MDM“	Modem instance referred to as "Modem" if queried with AT^SQPORT . In the quick reference tables it is named MDM.
“NMEA“	Interface dedicated for output of NMEA data.

<Device>^{(str)(NV)}

List of devices provided by the UE.

“NONE“	Special value which is used to indicate that there is no device mapping.
“ASC0“	
“USB0“	
“USB1“	
“USB2“	
“USB3“	Not used in preconfigured Service Sets <SetNum>, but can be selected in a customized Service Set (with <SetNum> ≥ 10). If not used, take care that AT^SCFG "MEopMode/ExpectDTR" feature remains activated for USB3. For details see parameter <expdtr-port>.

<Mux-Device>^{(str)(NV)}

Devices related to Multiplex mode. For details refer to [AT+CMUX](#)

[“NONE“]	No mapping to a <Mux-Device> during Multiplex mode, however, there may be a mapping to a <Device> at this time.
“MUX0“	Multiplex channel 1
“MUX1“	Multiplex channel 2
“MUX2“	Multiplex channel 3
“MUX3“	Multiplex channel 4. Not used in preconfigured Service Sets <SetNum>, but can be selected in a customized Service Set <SetNum> ≥ 10.

<SrvSetError>^(num)

Service Set Error
Error result codes.

1	Error cause unknown
2	Parameter out of range
3	Operation not supported
4	No AT command service would be accessible after UE restart
5	Invalid service name
6	Invalid device name
7	Invalid Multiplex mode related device name
8	Storage failure

Examples

EXAMPLE 1

Query details of service interface configuration currently used by the UE.

```
AT^SSRVSET="current"           For example, if Service Set 2 was active during last start-up of the UE
                                the following information will be provided.
^SSRVSET: "usbcomp", "0061", "", "1E2D", "0061", "Cinterion", "LTE Modem", ""
^SSRVSET: "srvmap", "MDM", "USB0", "MUX0"
^SSRVSET: "srvmap", "APP", "USB1", "MUX1"
^SSRVSET: "srvmap", "NMEA", "USB2", "MUX2"
OK
```

EXAMPLE 2

Configure the customer settings in last row of Table 2.6, [Validated and released Service/Device Mappings](#) into Service Set 10.

```
^SYSSTART                       After UE restart ...
AT^SSRVSET="actSrvSet"         ... assure to run a Service Set other than the one to configure
^SSRVSET: 10                   If not running the right Service Set ...
OK

AT^SSRVSET="actSrvSet", 2     ... switch to Service Set 2.
OK                             However, the new setting is activated after next UE restart only, ...

AT+CFUN=1, 1                  ... therefore, force UE restart.
OK

^SYSSTART                       The newly selected Service Set is now active.

AT^SSRVSET="usb-               Determine the USB composition "0061" to be used by Service Set 10.
comp", 10, "0061"
OK

AT^SSRVSET="srv-               MDM service is accessible via ASC0 device. After Multiplex mode is
map", 10, "MDM"                 started MDM service is accessible on MUX0 channel.
, "ASC0", "MUX0"
OK

AT^SSRVSET="srv-               APP service is accessible via USB1 device. After Multiplex mode is
map", 10, "APP"                 started APP service is accessible on MUX1 channel.
, "USB1", "MUX1"
OK

AT^SSRVSET="srv-               NMEA (i.e. GPS location data) service is only accessible during Multi-
map", 10, "NMEA", "NONE", "MUX  plex mode. After Multiplex mode is started NMEA service is accessible
2"                               on MUX2 channel.
OK

AT^SSRVSET="actSrvSet", 10     Activate the configured Service Set 10.
OK                             Consequently, it will be used after next UE restart.
```

3. Status Control Commands

The AT Commands described in this chapter allow the external application to obtain various status information from the PLS8-X.

3.1 AT+CEER Extended Error Report

AT+CEER returns an extended error report regarding the reason of the last

- call release
- failure to set up a call (both mobile originated or terminated)
- failure to modify a call by using Supplementary Services
- failed attempt to activate, register, query, deactivate or deregister a Supplementary Service
- unsuccessful PS attach or unsuccessful PDP context activation
- PS detach or PDP context deactivation

The release cause report `<report>` is a single line containing the cause information given by the network in textual format.

Syntax

Test Command

```
AT+CEER=?
```

Response(s)

```
OK
```

```
ERROR
```

```
+CME ERROR: <err>
```

Exec Command

```
AT+CEER
```

Response(s)

```
+CEER: <report>
```

```
OK
```

```
ERROR
```

```
+CME ERROR: <err>
```

Write Command

```
AT+CEER=<reset>
```

Response(s)

```
OK
```

```
ERROR
```

```
+CME ERROR
```

PIN	MDM	APP	→	Last
+	+	+	+	-

+	+	+	+	-
---	---	---	---	---

Reference(s)

3GPP TS 27.007 [48]

3GPP TS 24.008 [41]

Parameter Description

<report>^(str)

release cause report

Reason for the last call release or call failure. See Section 3.1.1, [List of status codes for extended error report](#). Both CS and PS domain call types are reported. Cause data is captured from Call Manager events and cached locally to later use by this command.

<reset>^(num)

0 Reset the extended error report to initial value.

3.1.1 List of status codes for extended error report

CS internal cause

No cause information available (default)

Phone is offline

No service available

Network release, no reason given

Received incoming call

Client ended call

UIM not present

Access attempt already in progress

Access failure, unknown source

Concur service not supported by network

No response received from network

GPS call ended for user call

SMS call ended for user call

Data call ended for emergency call

Rejected during redirect or handoff

Lower-layer ended call

Call origination request failed

Client rejected incoming call

Client rejected setup indication

Network ended call

No funds available

No service available

Full service not available

Maximum packet calls exceeded

Video connection lost

Video protocol closed after setup

Video protocol setup failure

Internal error

CS network cause
Unassigned/unallocated number
No route to destination
Channel unacceptable
Operator determined barring
Normal call clearing
User busy
No user responding
User alerting, no answer
Call rejected
Number changed
Non selected user clearing
Destination out of order
Invalid/incomplete number
Facility rejected
Response to status enquiry
Normal, unspecified
No circuit/channel available
Network out of order
Temporary failure
Switching equipment congestion
Access information discarded
Requested circuit/channel not available
Resources unavailable, unspecified
Quality of service unavailable
Requested facility not subscribed
Incoming calls barred within the CUG
Bearer capability not authorized
Bearer capability not available
Service/option not available
Bearer service not implemented
ACM >= ACM max
Requested facility not implemented
Only RDI bearer is available
Service/option not implemented
Invalid transaction identifier value
User not member of CUG
Incompatible destination
Invalid transit network selection
Semantically incorrect message
Invalid mandatory information
Message non-existent/not implemented

CS network cause

Message type not compatible with state

IE non-existent/not implemented

Conditional IE error

Message not compatible with state

Recovery on timer expiry

Protocol error, unspecified

Interworking, unspecified

CS network reject

IMSI unknown in HLR

Illegal MS

IMSI unknown in VLR

IMEI not accepted

Illegal ME

GPRS services not allowed

GPRS and non GPRS services not allowed

MS identity cannot be derived

Implicitly detached

PLMN not allowed

Location area not allowed

Roaming not allowed

GPRS services not allowed in PLMN

No suitable cells in location area

MSC temporary not reachable

Network failure

MAC failure

Synch failure

Congestion

GSM authentication unacceptable

Service option not supported

Requested service option not subscribed

Service option temporary out of order

Call cannot be identified

No PDP context activated

Semantically incorrect message

Invalid mandatory information

Message type non-existent

Message type not compatible with state

Information element non-existent

Message not compatible with state

RR release indication

RR random access failure

CS network reject
RRC release indication
RRC close session indication
RRC open session failure
Low level failure
Low level failure no redial allowed
Invalid SIM
No service
Timer T3230 expired
No cell available
Wrong state
Access class blocked
Abort message received
Other cause
Timer T303 expired
No resources
Release pending
Invalid user data

PS internal cause
Invalid connection identifier
Invalid NSAPI
Invalid primary NSAPI
PDP establish timeout
Invalid field
SNDCP failure
RAB setup failure
No GPRS context
PDP activate timeout
PDP modify timeout
PDP inactive max timeout
PDP lowerlayer error
PDP duplicate
Access technology change
PDP unknown reason

PS network cause
LLC or SNDCP failure
Insufficient resources
Missing or unknown APN
Unknown PDP address or PDP type
User authentication failed
Activation rejected by GGSN

PS network cause

Activation rejected, unspecified
Service option not supported
Requested service option not subscribed
Service option temporary out of order
NSAPI already used (not sent)
Regular deactivation
QoS not accepted
Network failure
Reactivation required
Feature not supported
Semantic error in the TFT operation
Syntactical error in the TFT operation
Unknown PDP context
PDP context without TFT already activated
Semantic errors in packet filter
Syntactical errors in packet filter
Invalid transaction identifier
Semantically incorrect message
Invalid mandatory information
Message non-existent/not implemented
Message type not compatible with state
IE non-existent/not implemented
Conditional IE error
Message not compatible with state
Protocol error, unspecified

Other release cause

Call barred

PS lte cause

Operator Determined Barring
Insufficient resources
Unknown or missing APN
Unknown PDN type
User authentication failed
Request rejected by Serving GW or PDN GW
Request rejected, unspecified
Service option not supported
Requested service option not subscribed
Service option temporarily out of order
PTI already in use
Regular deactivation

PS lte cause
EPS QoS not accepted
Network failure
Reactivation required
Feature not supported
Semantic error in the TFT operation
Syntactical error in the TFT operation
Invalid EPS bearer identity
Semantic errors in packet filter(s)
Syntactical errors in packet filter(s)
EPS bearer context without TFT already activated
PTI mismatch
Last PDN disconnection not allowed
PDN type IPV4 only allowed
PDN type IPV6 only allowed
Single address bearers only allowed
ESM information not received
PDN connection does not exist
Multiple PDN connection for given APN not allowed
Collision with network initiated request
Unsupported QCI value
Invalid PTI value
Symantically invalid message
Invalid mandatory information
Message type non-existent or not implemented
Message type not compatible with the protocol state
Information element non-existent or not implemented
Conditional IE error
Message not compatible with the protocol state
Protocol error, unspecified
APN restriction value incompatible with active EPS bearer context
No Failure
PS lte local cause
IMSI unknown in HSS
Illegal UE
IMEI not accepted
Illegal ME
EPS services not allowed
EPS services and non-EPS services not allowed
UE identity cannot be derived by the network
Implicitly Detached
PLMN not allowed

PS lte local cause
Tracking area not allowed
Roaming not allowed in this tracking area
EPS services not allowed in this PLMN
No Suitable cells in tracking area
MSC temporarily not reachable
Network failure
CS Domain Not available
ESM failure
MAC failure
Synch failure
Congestion
UE security capabilities mismatch
Security mode rejected, unspecified
Not Authorized for this CSG
Non-EPS authentication unacceptable
CS fallback call EST not allowed
CS domain temporarily not allowed
No EPS bearer context activated
Unknown EPS bearer context
Semantically incorrect message
Invalid mandatory information
Message type non-existent or not implemented
Message type not compatible with the protocol state
Information element non-existent or not implemented
Conditional IE error
Message not compatible with the protocol state
Protocol error, unspecified
Released AT RRC
Signal Connection Released
EMM detached
EMM attach failed
EMM attach started
NAS service request failed
ESM activate dedicated bearer reactivater by network
Lower layer failure
ESM sync up with network
Network activater dedicated bearer with ID of deffered bearer
BAD OTA message
DS rejected the call
Context transferred due to IRAT
DS explicit deactivation
ESM MSGR failure

PS lte local cause
Local Cause not Available
Rejected due to connected state
Nas Service request failed, no throttle
EMM T3417 expired
EMM T3417 ext expired
Nas LRRc UL data CNF failure TXN
Nas LRRc UL data CNF failure HO
Nas LRRc UL data CNF failure CONN release
Nas LRRc UL data CNF failure RLF
Nas LRRc UL data CNF failure control Not CONN
NAS LRRc connection EST success
NAS LRRc connection EST failure
NAS LRRc connection EST failure, aborted
NAS LRRc connection EST failure, access barrer
NAS LRRc connection EST failure, CELL resel
NAS LRRc connection EST failure, config failure
NAS LRRc connection EST failure, timer expired
NAS LRRc connection EST failure, link failure
NAS LRRc connection EST failure, not camped
NAS LRRc connection EST failure, SI failure
NAS LRRc connection EST failure, CONN reject
NAS LRRc connection release normal
NAS LRRc connection release RLF
NAS LRRc connection release CRE failure
NAS LRRc connection release QOS during CRE
NAS LRRc connection release aborted
NAS LRRc connection release SIB read error
NAS LRRc connection release aborted IRAT Success
Nas Reject LRRc radio link failure
Nas service request failure, LTE network reject
Nas detach with reattach, LTE network detach
NAS detach without reattach, LTE network detach

3.2 AT^SIND Extended Indicator Control

AT^SIND controls the presentation of indicator event URCs. You can enable or disable URCs to be issued by the PLS8-X each time the value of the related indicator changes, you can request the current status of all indicators, and you can also query the status of a single indicator.

Syntax

Test Command

AT^SIND=?

Response(s)

^SIND: (<indDescr>, list of supported <indValue>s)[, (<indDescr>, list of supported <indValue>s)[, ...]], (list of supported <mode>s)
OK

Read Command

AT^SIND?

Response(s)

^SIND: <indDescr>, <mode>[, <indValue>]
[^SIND: <indDescr>, <mode>[, <indValue>]]
...

In case of <indDescr>="eons"

^SIND: eons, <mode>, <indValue>, <eonsOperator>, <servProvider>, <servProviderType>

In case of <indDescr>="nitz"

^SIND: nitz, <mode>, <nitzUT>, <nitzTZ>[, <nitzDST>]

In case of <indDescr>="steerroam"

^SIND: steerroam, <mode>

In case of <indDescr>="lsta"

^SIND: lsta, <mode>, <lstaLevel>

In case of <indDescr>="ceer"

^SIND: ceer, <mode>, <ceerRelCauseGroup>[, <ceerRelCauseGroupList>]

In case of <indDescr>="simlocal"

^SIND: simlocal, <mode>, <indValue>_{slot_1}, <indValue>_{slot_2}

In case of <indDescr>="newsms"

^SIND: newsms, <mode>[, <newsmsact>, <newsmsmem>, <newsmsindex>]

In case of <indDescr>="simread"

^SIND: simread, <mode>, <simreadEfBitMask>

In case of <indDescr>="is_cert"

^SIND: is_cert, <mode>[, <srvProfileId>, <issuer>, <serialNumber>, <subject>, <signatureAlgorithm>, <thumbprintAlgorithm>, <thumbprint>]

In case of <indDescr>="omadm"

^SIND: omadm, <mode>, <OmaDmAction>[, <OmaDmStatus>]

In case of <indDescr>="orpc"

^SIND: orpc, <mode>[, <containerid>, <mccmnc>, <clength>, <container>]

Read Command (Continued)

AT^SIND?

Response(s)

In case of <indDescr>="ltebot"

^SIND: ltebot, <mode>, <ltebotTimerstat>, <ltebotReason>, <APN>[, <ltebotReasonTxt>]

In case of <indDescr>="prov"

^SIND: prov, <mode>, <provMm>, <provCur>

OK

ERROR

+CME ERROR: <err>

Write Command

AT^SIND=<indDescr>, <mode>

Response(s)

^SIND: <indDescr>, <mode>[, <indValue>]

In case of: <indDescr>="eons" and <mode>=2

^SIND: eons, <mode>, <indValue>, <eonsOperator>, <servProvider>, <servProviderType>

In case of: <indDescr>="nitz" and <mode>=2

^SIND: nitz, <mode>, <nitzUT>, <nitzTZ>[, <nitzDST>]

In case of: <indDescr>="newsms" and <mode>=2

^SIND: newsms, <mode>[, <newsmsact>, <newsmsmem>, <newsmsindex>]

In case of: <indDescr>="orpc" and <mode>=2

^SIND: orpc, <mode>, <containerid>, <mccmnc>, <clength>, <container>

In case of: <indDescr>="ltebot" and <mode>=2

^SIND: ltebot, <mode>, <ltebotTimerstat>, <ltebotReason>, <APN>[, <ltebotReasonTxt>]

In case of: <indDescr>="is_cert" and <mode>=1 or 2:

^SIND: is_cert, <mode>[, <srvProfileId>, <issuer>, <serialNumber>, <subject>, <signatureAlgorithm>, <thumbprintAlgorithm>, <thumbprint>]

OK

ERROR

+CME ERROR: <err>

Write Command

AT^SIND="lsta", <mode>[, <lstaLevel>]

Response(s)

^SIND: lsta, <mode>[, <lstaLevel>]

OK

ERROR

+CME ERROR: <err>

Write Command

AT^SIND="ceer", <mode>[, <ceerRelCauseGroup>]

Response(s)

^SIND: ceer, <mode>, <ceerRelCauseGroup>[, <ceerRelCauseGroupList>]

OK

ERROR

+CME ERROR: <err>

Write Command

```
AT^SIND="simread", <mode>[, <simreadEf>]
```

Response(s)

```
^SIND: simread, <mode>, <simreadEfBitMask>
```

OK

ERROR

```
+CME ERROR: <err>
```

Write Command

```
AT^SIND="omadm", <mode>
```

Response(s)

```
^SIND: omadm, <mode>, <OmaDmAction>[, <OmaDmStatus>]
```

OK

ERROR

```
+CME ERROR: <err>
```

Write Command

```
AT^SIND="prov", <mode>
```

Response(s)

```
^SIND: prov, <mode>, <provMm>, <provCur>
```

OK

ERROR

```
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Unsolicited Result Codes

URC 1

Format of the standard indicator:

```
+CIEV: <indDescr>, <indValue>
```

Value of an indicator has changed.

URC 2

Format of the "simdata" indicator follows the AT^SSTGI response:

```
+CIEV: <indDescr>, <cmdType>, <commandDetails>[, <pathLen>, <fileNum>, <fileList>[, <status>, <statAddInfo>]]
```

This URC is issued if PLS8-X is in Remote-USAT Autoresponse mode (AT^SSTA) and the USIM sent a USAT REFRESH command (i.e. <cmdType>=1) indicating that the content of one or more Elementary Files has been changed.

Additionally, independent of Remote-USAT modes, a "+CIEV: "simdata"" URC is issued if REFRESH command processing fails. The reason may derived from <status> and <statAddInfo> values.

The UE holds a limited storage available to keep numerous "simdata" events received while AT^SIND setting was not enabled or UE-TE link was reserved, e.g. in online data mode. In case of storage overflow a special URC "+CIEV: simdata,1,254" will be issued.

URC 3

Format of the "eons" indicator:

```
+CIEV: <indDescr>, <indValue>, <eonsOperator>, <servProvider>, <servProviderType>
```

One URC is issued for each new LAI (Location Area Information) broadcast by the network.

URC 4

Format of the "nitz" indicator:

+CIEV: <indDescr>, <nitzUT>, <nitzTZ>[, <nitzDST>]

URC 5

Format of the "steer roam" indicator:

+CIEV: <indDescr>

URC 6

Format of the "lsta" indicator:

In case <indValue> equals "0" or <indValue> equals "2".

+CIEV: <indDescr>, <indValue>, <lstaEdvs>, <lstaRssi>

The URC is issued for every radio link error. It provides the error downcounter value corresponding to number of consecutive errors on downlink and the RSSI of the serving cell.

Error downcounter value of 11 corresponds to first error occurred on downlink, 0 corresponds to last before cell loss.

URC 7

In case <indValue> equals "1".

+CIEV: <indDescr>, <indValue>, <lstaNo>, <lstaMin>, <lstaMax>, <lstaMean>, <lstaVar>

After the error downcounter reaches the value 0 the URC provides some statistic parameters of signal strength distribution across the band.

URC 8

Format of the "ceer" indicator:

+CIEV: <indDescr>, <ceerRelCauseGroup>, <ceerReport>

URC 9

Format of the "simlocal" indicator:

+CIEV: <indDescr>, <indValue>_{slot_1}, <indValue>_{slot_2}

URC 10

Format of the "newsms" indicator:

+CIEV: <indDescr>[, <newsmsact>, <newsmsmem>, <newsmsindex>]

URC 11

Format of the "is_cert" indicator:

+CIEV: <indDescr>, <srvProfileId>, <issuer>, <serialNumber>, <subject>, <signatureAlgorithm>, <thumbprintAlgorithm>, <thumbprint>

The URC is issued after opening a secure Internet connection with AT^SISO.

URC 12

Format of the "omadm" indicator:

+CIEV: <indDescr>, <OmaDmAction>[, <OmaDmStatus>]

URC 13

Format of the "orpc" indicator:

+CIEV: <indDescr>, <containerid>, <mccmnc>, <clength>, <container>

URC 14

Format of the "simread" indicator:

+CIEV: <indDescr>, <simreadEf>

The URC indicates that the UE has finished reading one of the Elementary Files on the (U)SIM specified in the <simreadEfBitMask> parameter. For each Elementary File type one single URC will be issued.

URC 15

Format of the "ltebot" indicator:

+CIEV: <indDescr>, <ltebotTimerstat>, <ltebotReason>, <APN>[, <ltebotReasonTxt>]

URC 16

Format of the "prov" indicator:

+CIEV: <indDescr>, <provMm>, <provCur>

Parameter Description

<indDescr>^(str)

This section describes <indDescr> values and their associated <indValue> ranges. For command input on the AT^SIND write command line <indDescr> values are handled as string type. In responses and URCs <indDescr> values are output without quotation marks.

"signal"	Channel bit error rate of the signal received: The parameter is always set to value 99. See also AT+CSQ .
"service"	Service availability: 0 Not registered to any network. 1 Registered to home network or, if "roam"=1 then registered to another network.
"sounder"	Sounder activity: Reports every event that causes the UE to generate a tone. 0 Tone generator not active. 1 Tone generator active.
"message"	Unread short message at memory location <mem1>. Refer to AT+CPMS . 0 No unread message(s) available. 1 Unread message(s) available.
"roam"	Roaming indicator: 0 Registered to home network or not registered. 1 Registered to other network.
"smsfull"	Capacity of storage for received short messages: 0 The short message memory location <mem3> is still free or has just become free again. Refer to AT+CPMS . 1 All memory locations of <mem3> are used up.
"audio"	Activity of the built-in audio unit: 0 Audio unit not active. 1 Audio unit is active.
"simdata"	Notification of changes to Elementary File(s) data on the (U)SIM: All data provided by the USIM is stored in one of many of its so-called Elementary Files. This data can be queried by the TE directly via AT+CRSM or implicitly via many AT commands presented by this document. For instance the USIM's international mobile subscriber identity (IMSI) can be queried via AT+CIMI , but actually is stored in EF _{IMSI} , as defined in 3GPP TS 11.11 [17], 3GPP TS 31.101 [18], 3GPP TS 31.102 [19]. However, be aware that this Elementary File data can be changed at any time

by the network provider or an application running on the USIM. For details refer to [USAT](#) feature "Data Download to USIM" in 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23]. If this happens the TE urgently needs to refresh its internal representation (i.e. copy) of the changed data to ensure its safe and consistent use!

Therefore, a "+CIEV: "simdata"" URC is issued if PLS8-X is in [Remote-USAT](#) Autoresponse mode ([AT^SSTA](#)) and the USIM sent a [USAT](#) REFRESH command indicating that the content of one or more Elementary Files has been changed.

Additionally a "+CIEV: "simdata"" URC is issued in both [Remote-USAT](#) modes (Autoresponse mode and Explicit Response mode), if the REFRESH command processing fails. This might happen due to an ongoing call or an inappropriate USIM (PIN) status.

“eons“

Enhanced Operator Name String (EONS):

The Enhanced Operator Name String indicator feature allows the PLS8-X to output various operator names for different PLMN identities. It also allows the output of a different operator name based on a subset of the registered network by using a range of Location Area Codes (LACs) or a single LAC. See also 3GPP TS 22.101 [50].

The EONS tables are stored in the USIM and will be read after SIM PIN authentication.

Following USIM Elementary Files are affected by the EONS feature:

EF_{SST} (USIM Service Table) - describes which features are active.

EF_{OPL} (Operator PLMN List) - contains the PLMN identification and location ID together with the index of the corresponding PNN record

EF_{PNN} (PLMN Network Name) - contains the full and short form version of the network name for the registered PLMN

The name displayed by the [<eonsOperator>](#) parameter depends on various sources of information prioritized in the list below. The highest priority has option 1. If an option is not available the next lower option from the list determines the displayed name. The priority is indicated by the [<indValue>](#) parameter.

Prioritized sources determining the name displayed by [<eonsOperator>](#):

- [<indValue>](#) 0 Not registered.
- [<indValue>](#) 1 Operator name from EF_{OPL} and EF_{PNN} in alphanumeric format.
- [<indValue>](#) 2 Operator name in long or short format according to Common PCN Handset Specification (CPHS) [51] depending on availability and content of EF_{ONString} (Operator Name String) and EF_{OPShort} (Operator Name Short form).
- [<indValue>](#) 3 Operator name received over the network via NITZ service in long and short alphanumeric format.
- [<indValue>](#) 4 Operator name found in the UE's [AT+COPN](#) list, given in alphanumeric format.
- [<indValue>](#) 5 Broadcast MCC-MNC (numeric format which consists of a 3-digit country code plus a 2- or 3-digit network code).
- [<indValue>](#) 6 CSG (Closed Subscriber Group) Lookup.

“nitz“

Network Identity and Time Zone:

This indicator shows the time relevant information elements of an MM Information (MMI) or GMM Information (GMMI) message received from the network (see 3GPP TS 24.008 [41], ch. 9.2.15a and 9.4.19).

The [AT^SIND](#) test command indicates the maximum length of the "nitz" [<indValue>](#). The network usually sends a NITZ indicator when the mobile attaches to the network, when it enters a location area with different time zone or when a daylight change occurs.

A NITZ indicator may consist of the following parameters: Universal Time (UT), local Time Zone (TZ), Daylight Saving Time (DST). All information elements of MMI/GMMI are optional and therefore, the presentation of the parameters

<nitzUT>, <nitzTZ>, <nitzDST> varies with the network. For example, the network may send all three parameters UT, TZ, DST, or only UT and TZ or only TZ.

UT is indicated in usual date/time format and represents the current world time (GMT) at the moment when sent.

TZ is given as a positive (east) or negative (west) offset from UT in units of 15 minutes.

DST shows the number of hours added to the local TZ because of daylight saving time (summertime) adjustment. Usually DST is 1 hour but it can be also 2 hours in certain locations.

Example for time and time zone with DST:

+CIEV: nitz,"04/07/23,13:39:20",-28,1

In this example TZ is -28, showing a time offset of -7 hours (west) to Universal Time/GMT (which never changes for DST). DST is 1 which indicates that one hour was added to TZ because of Daylight Saving Time. If a network does not send the DST parameter the TZ value would be -32 (8 hours west) as would be done in winter:

+CIEV: nitz,"04/11/23,13:39:20",-32

Please be aware that although the last NITZ value can be looked up again via "AT^SIND=nitz,2" the returned values may be out of date. Especially the UT value is obsolete because there is no internal NITZ clock and therefore no continuation of UT.

NITZ values are lost when the UE detaches from network. Also when a manual network selection fails and the UE automatically falls back to the previous network the NITZ values cannot be recalled. Nevertheless an indicated time zone is valid until a new MMI/GMMI will trigger another NITZ indication.

"simstatus"

USIM status:

- 0 USIM removed.
 Note: Another way to verify the USIM connection is the "^scks" URC enabled with AT^SCKS.
- 1 USIM inserted.
- 3 USIM PIN required - USIM locked. USIM PIN must be entered to enable PLS8-X to register to the network.
- 4 Personalization info ready - CHV (Card Holder Verification) data have been verified (if required).
- 5 USIM initialization completed - UE has finished reading USIM data.

"simlocal"

Availability of the physically connected USIM:

- 0 USIM removed.
- 1 USIM inserted.

The availability of the (U)SIM is shown for the (U)SIM interfaces configurable with AT^SCFG="SIM/CS" parameter <CS>.

"psinfo"

Packet Switched status:

"psinfo" indicates the status of the UE related to packet switched data calls. Please consider that some providers don't support the indication of HSDPA/HSUPA.

- 0 GPRS/EGPRS not available in currently used cell
- 1 GPRS available in currently used cell
- 2 GPRS attached
- 3 EGPRS available in currently used cell
- 4 EGPRS attached
- 5 camped on WCDMA cell
- 6 WCDMA PS attached
- 7 camped on HSDPA capable cell
- 8 PS attached in HSDPA capable cell
- 9 camped on HSDPA/HSUPA capable cell

- 10 PS attached in HSDPA/HSUPA capable cell
- 16 camped on EUTRAN capable cell
- 17 attached in EUTRAN capable cell

“Ista”

Link Stability indication (for GSM only):

The Link Stability indicator feature allows the PLS8-X to output radio link errors and statistic parameters of signal strength distribution across the band via URC.

- 0 Radio link error.
- 1 Radio link signal strength distribution.
- 2 Radio link error during voice call.

The presentation of the "Ista" indicator is determined by the radio link spectrum shape. For example, each time a radio link error appears the URC indicates an Error Downcounter value and the RSSI of the serving cell to provide some kind of warning. Every consecutive error decrements the Error Downcounter value and successful downlink signal reception resets it to start value of 11. The Error Downcounter value is only available in IDLE mode. It will not be presented during PS connections.

The factor on which Error Downcounter is decremented depends on network settings.

Error Downcounter value 0 means that the UE has lost the cell and will start the cell reselection process. In this case the URC is enhanced and includes the following statistic parameters of signal strength distribution across the band.

These are:

- Number of reported channels,
- Maximal signal strength value,
- Minimal signal strength value,
- Mean value of signal strength across frequency band and
- Variance of signal strength across frequency band.

To avoid that radio link error URCs are output too often, when radio conditions are bad, you can select a lower warning level with `<lstaLevel>`.

“pacsp”

PLMN mode bit status::

"pacsp" indicates the parsed PLMN mode bit value of the USIM Elementary File EF_{CSP} (Customer Service Profile) according to Common PCN Handset Specification (CPHS) [51].

- 0 CSP PLMN mode bit off
- 1 CSP PLMN mode bit on
- 99 CSP PLMN mode bit not defined or USIM Elementary File EF_{CSP} not accessible

The contents of the USIM Elementary File EF_{CSP} may be changed by the network in the background at any time via [USIM Application Toolkit \(USAT\)](#) procedure "Data download to USIM". For a detailed description please refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].

Please note, that URC presentation `<mode>` for this indicator is stored to non-volatile memory with `AT&W`, restored with `ATZ` and reset to '0' (disabled) by `AT&F`.

“steerroam”

Steering-of-roaming:

The "steerroam" indicator supports so called "steering-of-roaming" ("SOR") techniques of some providers.

If a UE roaming within a certain country tries to register to a VPLMN (visited PLMN), the VPLMN will ask the HLR of the subscribers home operator for authorization credentials of the subscriber. Steering-of-roaming means that instead of sending those credentials, the HLR sends back an error message which will make the VPLMN send back a location update reject to the UE. This location updating procedure is described in 3GPP TS 24.008 [41] chapter 4.4.4.9.

When UE is attempting to register into a PLMN and get updating rejected with reject cause 17 then UE stays in limited service on the configured network, UE may reattempt network registration four times, and after that UE will inform the TE via Steering-of-roaming indication URC +CIEV: "steerroam" that the registration attempt has failed.

When the UE is in manual PLMN selection mode (see [AT+COPS](#)) the TE has to start a new manual PLMN search to select a different network or switch to automatic PLMN selection mode.

When UE is in automatic PLMN selection mode (see [AT+COPS](#)) UE itself attempts a PLMN search to select a different network.

"iccid"	<p>USIM identification number: "iccid" indicator shows the USIM identification number stored in the USIM Elementary File EF_{ICCID}. The AT^SIND test command indicates the maximum length of the "iccid" <indValue>. Please note, that URC presentation <mode> for this indicator is stored to non-volatile memory with AT&W, restored with ATZ and reset to '0' (disabled) by AT&F.</p>														
"euiccid"	<p>USIM embedded identification number: "euiccid" indicator shows the USIM embedded identification number stored in the USIM Elementary File EF_{EUICCID}. The AT^SIND test command indicates the maximum length of the "euiccid" <indValue>.</p>														
"imsi"	<p>International Mobile Subscriber Identity: The "imsi" indicator shows the IMSI stored in the USIM Elementary File EF_{IMSI}. The AT^SIND test command indicates the maximum length of the "imsi" <indValue>. Please note, that URC presentation <mode> for this indicator is stored to non-volatile memory with AT&W, restored with ATZ and reset to '0' (disabled) by AT&F.</p>														
"pagingcoord"	<p>Paging coordination: Paging coordination is a network feature which allows the network to page (alert) the UE about incoming CS calls while the UE is receiving PS data transmissions The indicator notifies the UE of the capabilities currently present in the network, i.e. it can show one of the single values listed below or the sum of some of them.</p> <table><tr><td>0</td><td>No coordination</td></tr><tr><td>1</td><td>WCDMA</td></tr><tr><td>2</td><td>NMO 1</td></tr><tr><td>4</td><td>DTM support</td></tr><tr><td>8</td><td>BSS PAGING COORD</td></tr><tr><td>16</td><td>LTE</td></tr><tr><td>99</td><td>Undefined e.g. transitional state or PS data not supported by the network</td></tr></table>	0	No coordination	1	WCDMA	2	NMO 1	4	DTM support	8	BSS PAGING COORD	16	LTE	99	Undefined e.g. transitional state or PS data not supported by the network
0	No coordination														
1	WCDMA														
2	NMO 1														
4	DTM support														
8	BSS PAGING COORD														
16	LTE														
99	Undefined e.g. transitional state or PS data not supported by the network														
"ceer"	<p>Extended Error Report: "ceer" delivers an extended error / release cause report as a single line containing the cause information given by the network in textual format. The URC "CIEV: ceer,<ceerRelCauseGroup>,<ceerReport>" shows the same information as the standard command AT+CEER. If enabled the indicator will show up each time when a release cause is detected, whereas AT+CEER only polls the release cause of the latest event. The major benefit is that "ceer" URCs can be used for better analysis and tracing.</p>														
"newsms"	<p>AcT specific SMS notification: The UE is able to detect whether incoming short messages are coded in 3GPP or 3GPP2 format, and stores them to access technology (AcT) specific memory spaces of the memory selected with AT+CPMS. For details on both formats see also AT^SCFG "SMS/Format" parameter <SmsFormat>. The "newsms" indicator informs about new received and stored short messages by displaying</p>														

the following parameters:

- `<newsmsact>` showing the AcT specific coding type of the short message,
- `<newsmsmem>` showing the used memory,
- `<newsmsindex>` showing the used index inside the memory.

“is_cert“

Report details of the server certificate used for a secure Internet connection opened with `AT^SISO`.

The following certificate details are listed: `<srvProfileId>`, `<issuer>`, `<serialNumber>`, `<subject>`, `<signatureAlgorithm>`, `<signatureAlgorithm>`, `<thumbprintAlgorithm>`, `<thumbprint>`

Detailed guidelines for managing the required certificates can be found in [7]. See also AT commands `AT^SISS`, `AT^SBNR` and `AT^SBNW`.

“omadm“

Indication of OMA-DM session progress or errors:

+CIEV: omadm,"START" - indicates start of the execution of the OMA-DM process.

+CIEV: omadm,"PROGRESS", `<OmaDmStatus>` - describes a progress and current a state of the process.

+CIEV: omadm,"FINISHED", `<OmaDmStatus>` - describes a final result after an execution of the process.

+CIEV: omadm,"ERROR", `<OmaDmStatus>` - in case of an error indicates the result with extended error code.

“orpc“

Indication of new Operator Reserved Protocol Configuration Options:

"orpc" delivers the indication of a new "Operator Reserved PCO" received from the network.

“simread“

Notification of end of reading Elementary Files on the (U)SIM:

If enabled the URC "CIEV: simread, `<simreadEf>`" indicates that the UE has completed reading and verifying the accessibility of a specific Elementary File (EF) on the (U)SIM.

The purpose of this URC is that the access to selected Elementary Files will be reported earlier than the access to the entire (U)SIM as indicated by the "`^SSIM READY`" URC (see `AT^SSET`). The resulting time advantage can be used, for example, to cut the time until the UE is able to set up an emergency call.

“ltebot“

Status of LTE back-off timer:

The "ltebot" indicator shows up each time when the T3402 timer starts (`<ltebotTimerstat>` 1) and expires (`<ltebotTimerstat>` 0). It notifies the user whether the UE is backing off from LTE. For details on the T3402 timer please refer to see 3GPP TS 24.301 [43], table 10.2.

The duration of the timer is 12 minutes. During this period the UE will not try to attach to LTE unless a manual `AT+CGATT=0` and `AT+CGATT=1` is performed. Yet, before the timer expires, it is possible that the UE registers with UMTS or GSM UMTS instead of LTE.

The "ltebot" indicator is almost exclusively triggered by a wrong APN (in case of no LTE rights on the subscription or no LTE coverage, it is not started).

The indicator includes the following parameters: `<ltebotTimerstat>`, `<ltebotReason>`, `<APN>`, `<ltebotReasonTxt>`. The values of `<ltebotReason>` and the content of `<ltebotReasonTxt>` are operator dependent.

Examples for wrong APN given with `AT+CGDCONT`:

+CIEV: ltebot,1,33,"invalid name","Requested service option not subscribed"

+CIEV: ltebot,1,27,"invalid name","Unknown or missing APN"

In addition to the "ltebot" indicator, you can activate the "ceer" indicator that also shows the reason when the the UE fails to attach to the LTE.

Example for wrong APN given with `AT+CGDCONT`:

+CIEV: ceer,7,"Unknown or missing APN"

3.2 AT^SIND

"prov"
 Provider configuration mismatch:
 The "prov" indicator delivers the provider configuration mismatch status via URC.
 +CIEV: prov,<provMm>,<provCur>
 For provider configuration details see [ATI61](#).
 The change of provider configuration is done by [AT^SCFG](#) parameter "MEop-Mode/Prov/Cfg" (see [<provCfg>](#)).
 Please note, that URC presentation [<mode>](#) for this indicator is stored to non-volatile memory with [AT&W](#), restored with [ATZ](#) and reset to '0' (disabled) by [AT&F](#).

[<indValue>](#)^(num)

Integer type value as specified above for the corresponding [<indDescr>](#).

[<mode>](#)^(num)

Set or query URC presentation mode of a specific indicator [<indDescr>](#).
 Please note, that some indicator types allow the [<mode>](#) to be stored to non-volatile memory with [AT&W](#), restored with [ATZ](#) and reset to '0' (disabled) by [AT&F](#). See indicator descriptions whether or not [AT&W](#), [AT&F](#) and [ATZ](#) are effective.

0 ^(P)	Disables the presentation of a specific URC.
1	Enables the presentation of a specific URC. The URC will be buffered in the UE when the UE-TE link is reserved (e.g. in online data mode), and flushed to the TE when the UE-TE link is free again. Otherwise, the URC will be forwarded directly to the TE.
2	Requests the presentation mode of the URC status and the current value of a single indicator type.

[<eonsOperator>](#)^{(str)(+CSCS)}

Operator name determined by the source of information. The source is indicated as [<indValue>](#). All possible sources ([<indValue>](#)) are listed in the description of the "eons" indicator.

[<servProvider>](#)^{(str)(+CSCS)}

Service Provider Name according to the status settings (USIM Service No. 17) in the USIM Service Table (SST) of the USIM.
 Service Provider Name (SPN) will be read from EF_{SPN}. Service Provider Display Information (SPDI) will be read from EF_{SPDI} list.

[<servProviderType>](#)^(num)

Service Provider Type according to Registered Public Land Mobile Network (RPLMN) and Home Public Land Mobile Network (HPLMN).

0	Service Provider Name will not be displayed (EF _{SPN} is empty or not available).
1	Service Provider Name will be displayed. RPLMN is the HPLMN.
2	Service Provider Name will be displayed. One entry of SPDI list is equal to the RPLMN.

[<nitzUT>](#)^{(str)(+CSCS)}

Universal Time delivered as part of the "nitz" Indicator. Refer to [<indDescr>](#).

[<nitzTZ>](#)^(num)

Time Zone delivered as part of the "nitz" Indicator. Refer to [<indDescr>](#).

<nitzDST>^(num)

Adjustment for Daylight Saving Time as part of the "nitz" Indicator. Displayed only when received from network. Refer to <indDescr>.

<lstaLevel>^(num)

Warning Level

0-11 User value to limit the indication of radio link errors.

Refer to <indDescr>.

<lstaEdvs>^(num)

EDVS (0-11)

Error Downcounter value scaled. Refer to <indDescr>.

<lstaRssi>^(num)

Value in dBm

Received signal strength indication value. Refer to <indDescr>.

<lstaNo>^(num)

Number of reported channels. Refer to <indDescr>.

<lstaMin>^(num)

Value in dBm

Minimal received signal strength value. Refer to <indDescr>.

<lstaMax>^(num)

Value in dBm

Maximal received signal strength value. Refer to <indDescr>.

<lstaMean>^(num)

Value in dBm

Mean value of received signal strength across frequency. Refer to <indDescr>.

<lstaVar>^(num)

Variance of signal strength across frequency. Refer to <indDescr>.

<ceerRelCauseGroup>^(num)

Release Cause Group.

To enable the URC "CIEV: ceer,<ceerRelCauseGroup>,<ceerReport>" activate <mode> "1", and either select single <ceerRelCauseGroup> values, or choose value "99" for all release causes. For each single <ceerRelCauseGroup> value the AT^SIND write command needs to be executed, but the AT^SIND read command response lists all activated values (see <ceerRelCauseGroupList>). <ceerRelCauseGroup> value "0" can be used to clear all activated values. Setting <mode> "0" also clears all values and restores default <ceerRelCauseGroup> "0".

- | | |
|------------------|---|
| 0 ^(P) | Clear activated <ceerRelCauseGroup> values. |
| 1 | CS Internal Cause. |
| 2 | CS Network Cause. |
| 3 | CS Network Reject. |
| 4 | PS Internal Cause. |

5	PS Network Cause.
6	Other Release Cause.
7	PS LTE Cause.
8	PS LTE Local Cause.
99	All Release Causes. Note that if value "99" is set selecting a single release causes will have no effect. Before activating single release cause values first set <code><ceerRelCauseGroup></code> "0".

`<ceerRelCauseGroupList>`^(num)

In the `AT^SIND` read command response: List of `<ceerRelCauseGroup>`s currently activated, each separated by comma.

The `<ceerRelCauseGroupList>` is only displayed if several single `<ceerRelCauseGroup>`s were activated before. If only one `<ceerRelCauseGroup>` or value 99 was activated, the read command response contains just this one value, and no `<ceerRelCauseGroupList>`.

Example: after activating `<ceerRelCauseGroup>`s 1, 4, 5 and 6 the read command returns:

`^SIND: ceer,1,1,4,5,6`

`<ceerReport>`^(str)

Release cause information given by the network in textual format.

`<newsmsact>`^(str)

Access technology specific coding type of new received and stored short message.

"3GPP"	Coding type 3GPP
"3GPP2"	Coding type 3GPP2

`<newsmsmem>`^(str)

Memory storage of new received and stored short message corresponding to technology, please see `AT+CPMS` parameter `<mem3>`s).

""	No new stored short message received
"ME"	ME storage of received and stored short message
"SM"	Only for 3GPP

`<newsmsindex>`^(num)

Storage index of received and stored short message, please see `AT+CNMI` parameter `<index>`

`<srvProfileId>`^(num)

Internet service profile identifier. Refer to `AT^SISS`, `<srvProfileId>`.

`<issuer>`^(str)

Certificate's issuer. Refer to `<indDescr>`.

`<serialNumber>`^(str)

Certificate's serial number. Refer to `<indDescr>`.

`<subject>`^(str)

Certificate's subject. Refer to `<indDescr>`.

<signatureAlgorithm>^(str)

Certificate's signature algorithm. Refer to <indDescr>.

<thumbprintAlgorithm>^(str)

Certificate's thumbprint algorithm. Refer to <indDescr>.

<thumbprint>^(str)

Certificate's thumbprint. Refer to <indDescr>.

<OmaDmAction>^(str)

OMA-DM action current state delivered as part of "omadm" indicator. Refer to <indDescr>.

"IDLE"

"START"

"PROGRESS"

"FINISHED"

"ERROR"

<OmaDmStatus>^(num)

OMA-DM action status delivered as part of "omadm" indicator. Refer to <indDescr>.

0	No error
1	Bearer error
2	Error in WAP Push message
3	Error in OMA-DM session
101	WAP Push message received
103	Bearer connected
104	Bearer disconnected
105	Session established
106	Session closed
107	IPV6 failed, fallback to IPV4

<containerid>^(num)

Container Id of Operator Reserved Protocol Configuration Options.

65280...65535 Container ID of received orpco

<mccmnc>^(str)

Mobile country and network code

<clength>^(num)

Length of received orpco

<container>^(str)

Provider specific Hex output of the received orpco

3.2 AT^SIND

`<simreadEf>(num)`

This parameter determines the type of Elementary Files (EF) verified on the (U)SIM.

As part of the `AT^SIND` write command, the `<simreadEf>` parameter determines the type(s) of EF to be read when the UE is reading data from the (U)SIM. You may set the value of a specific EF type, or sum up the values of the EF types you may want to be reported.

As part of the URC CIEV: `simread,<simreadEf>` the parameter reports a specific EF type that the UE has just read. For each Elementary File type one single URC will be issued.

0	No USIM Elementary File.
1	USIM Elementary File EF _{SMS} .
2	USIM Elementary File EF _{FDN} .
4	USIM Elementary File EF _{SDN} .
255	All USIM Elementary Files listed above. This value can be set only in the write command, it will not be reported in the URC "CIEV: <code>simread,<simreadEf></code> ".

`<simreadEfBitMask>(num)`

Bit Mask of the Elementary File(s) to be verified on the (U)SIM, created from the `<simreadEf>` value set by the write command `AT^SIND="simread",<mode>,<simreadEf>`.

`<ltebotTimerstat>(num)`

Status of LTE back-off timer.

0	LTE back-off timer is not running, UE is using LTE (if available).
1	LTE back-off timer (12 minute T3402 timer) is running. The UE will not try to attach to LTE until it expires.

`<ltebotReason>(num)`

Rejection cause value given from the network that caused the module to back-off from LTE. Value is dependent on the operator. Value is 0 if attached to LTE.

`<APN>(str)`

Last APN attempted for LTE attachment, successful or otherwise.

`<ltebotReasonTxt>(str)`

Rejection cause value `<ltebotReason>` in text form. Displayed only if text form is available. Text is dependent on operator.

`<provMm>(num)`

Provider configuration mismatch.

0	No provider mismatch.
1	Provider mismatch.

`<provCur>(str)`

Current provider.

"0"	No provider list member, either AT&T or VERIZON.
"1"	AT&T provider list member.
"2"	VERIZON provider list member.

Notes

- If the AT^SIND indicator "Ista" URC's <indValue> equals "1" and <IstaNo> is low, the following assumptions are possible:
 - Low <IstaMean> indicates out of coverage
 - High <IstaVar> indicates industrial interference
 - High (or middle depending on distance from jammer) <IstaMean> and low <IstaVar> indicates jamming.
- If the AT^SIND indicator "Ista" URC's <indValue> equals "1" and <IstaNo> is high, the following assumption is possible:
 - High <IstaMean> and low <IstaVar> indicates jamming.

3.3 AT+CPAS Activity Status

AT+CPAS execute command queries PLS8-X's activity status.

Syntax

Test Command

AT+CPAS=?

Response(s)

+CPAS: (list of supported<pas>s)

OK

Exec Command

AT+CPAS

Response(s)

+CPAS: <pas>

OK

PIN	MDM	APP	→	Last
-	+	+	+	-

Reference(s)

3GPP TS 27.007 [48]

Parameter Description


<pas>^(num)

0	Ready
3	Incoming call (ringing)
4	Call in progress

3.4 AT+WS46 Select wireless network

The [AT+WS46](#) command is intended for reading the current status of the network selection. The write command has no effect. To select the network please use the [AT+COPS](#) command.

Syntax

Test Command	
AT+WS46=?	
Response(s)	
+WS46: (list of supported<n>s)	
OK	
Read Command	
AT+WS46?	
Response(s)	
+WS46: <n>	
OK	
Write Command	
AT+WS46=<n>	
Response(s)	
OK	
ERROR	
+CME ERROR: <err>	
PIN MDM APP  Last	Reference(s)
- + + + -	3GPP TS 27.007 [48]

Parameter Description

<n> ^(num)	
12	GSM digital cellular (GERAN only)
22	UTRAN only
25	3GPP Systems (GERAN, UTRAN and E-UTRAN)
28	E-UTRAN only
29	GERAN and UTRAN

4. Serial Interface Control Commands

The AT Commands described in this chapter allow the external application to determine various settings related to the PLS8-X's serial interface.

4.1 AT\Q Flow Control

[AT\Q](#) allows to configure flow control on the PLS8-X's asynchronous serial interface ASC0 (UART).

The [AT\Q](#) setting is always common for all interfaces and can be changed, for compatibility reasons, on each interface, but is only applicable to the ASC0 interface. [AT\Q](#) settings have no effect on the USB ports because the USB protocol integrates a flow control mechanism of its own.

Syntax

Exec Command					
AT\Q[<n>]					
Response(s)					
OK					
PIN	MDM	APP	→	Last	
-	+	+	+	-	

Parameter Description

<n>	(num)(&V)(&W)
3(&F)(D)	RTS/CTS hardware flow control

Note

- For compatibility reasons, [AT\Q](#) can be used in Multiplex mode ([AT+CMUX](#)), though the settings will not take effect. However, be aware that whenever you use the [AT\Q](#) write command in Multiplex mode and then save the current configuration to the user profile with [AT&W](#), the changed [AT\Q](#) setting will become active after restart.

4.2 AT&C Set Data Carrier Detect (DCD) line mode

AT&C controls the behavior of the UE's DCD line.

Syntax

```
Exec Command
AT&C[<value>]
Response(s)
OK
```

PIN	MDM	APP	→	Last
+	+	+	+	-

Parameter Description

<value> ^{(num)(&V)(&W)}	
[0]	DCD line shall always be on.
1(&F)(D)	DCD line shall be on only when data carrier signal is present.
2	<p>DCD line shall be on when Internet service profiles are in state "Connecting" or "Up" as described below. For details on the various service states refer to AT^SISI, parameter <srvState> or AT^SISO, parameter <srvState>.</p> <ul style="list-style-type: none">• Transparent TCP or Transparent UDP client, SOCKET, HTTP, SMTP: DCD shall be on when <srvState>="Connecting" or "Up".• Transparent TCP Listener: DCD shall be on when <srvState>="Connected".• FTP: DCD shall be on when data channel is connected, i.e. <srvState>="Up".

4.3 AT&D Set Data Terminal Ready (DTR) line mode

[AT&D](#) determines how the UE responds if DTR line is changed from ON to OFF state during data mode.

Syntax

```
Exec Command
AT&D[<value>]
Response(s)
OK
```

PIN	MDM	APP	→	Last
+	+	-	+	-

Parameter Description

<value> ^{(num)(&V)(&W)}	
[0]	ME ignores status of DTR line.
2 ^{(&F)(D)}	ON->OFF on DTR: Disconnect data call or PPP and change to command mode. In Transparent Access Mode set up with AT^SIST DTR ON-OFF transition changes to command mode. For more details see AT^SISS and AT^SIST .

4.4 AT&S Set Data Set Ready (DSR) line mode

AT&S determines how the UE sets the DSR line depending on its communication state.

Syntax

Exec Command				
AT&S[<value>]				
Response(s)				
OK				
PIN	MDM	APP	→	Last
-	+	-	+	-
Reference(s)				V.250

Parameter Description

<value> ^{(num)(&V)(&W)}	
[0] ^{(&F)(D)}	DSR line is always ON
1	ME in command mode: DSR is OFF. ME in data mode: DSR is ON.

4.5 ATE AT Command Echo

ATE controls if the PLS8-X echoes characters received from TE during AT command state.

Syntax

Exec Command				
ATE[<value>]				
Response(s)				
OK				
PIN	MDM	APP	→	Last
-	+	+	+	-
				Reference(s)
				V.250

Parameter Description

<value> ^{(num)(&V)(&W)}	
0	Echo mode off
[1] ^{(&F)(D)}	Echo mode on

4.6 AT+IPR Bit Rate

AT+IPR allows to query and set the bit rate of the PLS8-X's asynchronous serial interface (UART).
The test command returns the values of supported fixed bit rates.
The read command returns the currently set `<rate>` value.
The write command determines the bit rate to be used for the interface.

A selected fixed bit rate takes effect after the write command returns "OK" and is stored in the non-volatile memory.

When using **AT+IPR** on a USB channel or on a Multiplex mode related channel(**AT+CMUX**) the **AT+IPR** write command responds with "OK", but will not have any effect. However, the **AT+IPR** read command always returns the current setting dedicated to the UART channel.

It is highly recommended to use **AT+IPR** as a standalone AT command, i.e. better do not combine with other commands on the same AT command line.

The current setting of **AT+IPR** will be preserved after firmware download (i.e. a firmware update does not restore the factory setting) or in the event of power failure.

Syntax

Test Command					
AT+IPR=?					
Response(s)					
+IPR: () , (list of supported selectable <code><rate></code> s)					
OK					
Read Command					
AT+IPR?					
Response(s)					
+IPR: <code><rate></code>					
OK					
Write Command					
AT+IPR= <code><rate></code>					
Response(s)					
OK					
ERROR					
+CME ERROR: <code><err></code>					
PIN	MDM	APP	→	Last	Reference(s)
-	+	+	+	-	V.250

Parameter Description

<code><rate></code> ^{(num)&(V)(NV)}
Bit rate per second (bps)
115200 ^(D)
230400
460800
921600

4.7 AT+CMUX Multiplex mode

Multiplex mode according to 3GPP TS 27.010 [10] enables a serial interface to be partitioned into virtual channels. It can be used either on PLS8-X's USB interface or its asynchronous serial interface ASC0.

Multiplex mode can be started only on the Modem interface. This may be either the virtual modem port of the USB composite device or the ASC0 interface. In either case the Modem interface will be mapped to the first multiplex channel, and the Application interface will be mapped to the second multiplex channel. As a result, the functions of the first and second multiplex channels are the same as described in Section 1.4, [AT Command Interpreter](#) for the Modem and Application interfaces. The third multiplex channel is dedicated to GPS and will be used if NMEA output is switched on with [AT^SGPSC](#) while Multiplex mode is active. Multiplex channels 5 and 6 are dedicated for the Transparent TCP/IP service and can be used for data exchange with [AT^SIST](#). For more details on number and usage of multiplex channels refer to "[Multiplexer User's Guide](#)".

PLS8-X offers an internal multiplexer and thus integrates all functionality needed to implement full-featured multiplex solutions. For the application on top, customers have the flexibility to create their own multiplex programs conforming to the multiplexer protocol. To help system integrators save the time and expense of designing multiplexer applications, Gemalto M2M GmbH offers WinMux, a ready-to-use multiplex driver for Windows XP, Windows Vista, Windows 7. Another approach is to develop customized solutions based on the sources of the WinMux driver.

Refer to "[Multiplexer User's Guide](#)" which provides a detailed description of the multiplex architecture and step-by-step instructions of how to install and configure the Multiplex mode. The WinMux driver and its source files can be supplied on request. Please contact your local distributor to obtain the latest installation software and user's guide.

[AT+CMUX](#) write command is used to enter Multiplex mode. Setup of the logical channels is initiated by the TE, i.e. the TE acts as initiator. This means that the TE shall ensure that logical channels are established before any further actions on the channels can be started. There is a timeout of five seconds, if the multiplexer protocol is enabled but no multiplexer control channel is established. Afterwards PLS8-X returns to AT command mode. The parameter maximum frame size (N1) according to 3GPP TS 27.010 [10] is implemented as 98 bytes by default. All other parameters are not available. Refer to "[Multiplexer User's Guide](#)" for further details regarding frame size.

Syntax

Test Command

```
AT+CMUX=?
```

Response(s)

```
+CMUX: (list of supported<mode>s)  
OK
```

Read Command

```
AT+CMUX?
```

Response(s)

```
+CMUX: <mode>  
OK  
ERROR  
+CME ERROR: <err>
```

Write Command

```
AT+CMUX=<mode>
```

Response(s)

```
OK  
ERROR  
+CME ERROR: <err>
```


PIN	MDM	APP	→	Last
-	+	-	+	+

Reference(s)
3GPP TS 27.007 [48]
3GPP TS 27.010 [10]

Parameter Description

<mode> ^(num)	
Enable Multiplex mode.	
0	Basic option

4.7.1 Restrictions while using Multiplex mode

If Multiplex mode is used on ASC0 interface:

1. Using [AT+IPR](#) write command on a Multiplex mode related channel command has no effect but always responds with "OK".
2. It is recommended to set hardware flow control ([AT\Q3](#)) before starting Multiplex mode.

4.8 AT^SQPORT Query Port Type

[AT^SQPORT](#) enables the Customer Application to query the type of AT command instance it is connected to. Further details on AT command instances and the different types of PLS8-X devices can be found in [Section 1.4, AT Command Interpreter](#) and [AT^SSRVSET](#).

Syntax

Test Command
AT^SQPORT=?
Response(s)
OK
Read Command
AT^SQPORT?
Response(s)
^SQPORT: <type>
OK
Exec Command
AT^SQPORT
Response(s)
^SQPORT: <type>
OK
PIN MDM APP → Last
- + + + -

Parameter Description

<type> ^(str)	
“Modem“	Main AT command instance, mainly intended for data transmission.
“Application“	Auxiliary AT command instance. It is recommended that this instance be used for controlling the PLS8-X, e.g. for entering AT commands, receiving URCs, or sending and receiving short messages. For further details on URCs please refer to Section 1.8, Unsolicited Result Code Presentation .

5. Security Commands

The AT Commands described in this chapter allow the external application to determine various security related settings.

5.1 AT+CPIN PIN Authentication

The [AT+CPIN](#) read command returns an alphanumeric string indicating whether or not network authentication is required.

The write [AT+CPIN](#) command allows the PLS8-X to store the entered password. This may be for example the SIM PIN1 to register to a GSM/UMTS/LTE network, or the SIM PUK1 to replace a disabled SIM PIN1 with a new one, or the PH-SIM PIN if the client has taken precautions for preventing damage in the event of loss or theft etc.

If SIM PIN1 authentication was successful and no SIM PIN1 request is pending the [AT+CPIN?](#) read command returns "READY", but the next [AT+CPIN=<pin>](#) write command request refers to SIM PIN2. As a result, whilst SIM PIN2 has not been given, each attempt to enter SIM PIN1 again leads to "+CME ERROR: incorrect password", thus decreasing the SIM PIN2 counter. Therefore, you are advised to check which password is requested by using the read command [AT^SPIC?](#) and the execute command [AT^SPIC](#).

Syntax

Test Command AT+CPIN=? Response(s) OK											
Read Command AT+CPIN? Response(s) +CPIN: <code> OK ERROR +CME ERROR: <err>											
Write Command AT+CPIN=<pin>[, <new pin>] Response(s) OK ERROR +CME ERROR: <err>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>-</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	-	+	+	+	-	Reference(s) 3GPP TS 27.007 [48]
PIN	MDM	APP	→	Last							
-	+	+	+	-							

Parameter Description

<pin> ^(str) Password (string type), usually SIM PIN1. If the requested password was a PUK, such as SIM PUK1 or PH-FSIM PUK or another password, then <pin> must be followed by <new pin>.
--

5.1 AT+CPIN

`<new pin>(str)`

If the requested code was a PUK: specify a new password or restore the former disabled password.

`<code>(text)`

SIM PIN authentication

READY	PIN has already been entered. No further entry needed.
SIM PIN	UE is waiting for SIM PIN1.
SIM PUK	UE is waiting for SIM PUK1 if PIN1 was disabled after three failed attempts to enter PIN1.
SIM PIN2	UE is waiting for PIN2.
SIM PUK2	UE is waiting for PUK2 to unblock a disabled PIN2.
Phone security locks set by client or factory	
PH-SIM PIN	UE is waiting for phone-to-SIM card password if "PS" lock is active and the client inserts other USIM, card than the one used for the lock. ("PS" lock is also referred to as phone or antitheft lock).
PH-FSIM PIN	UE is waiting for phone-to-very-first-SIM card password. Necessary when "PF" lock was set. When powered up the first time, UE locks itself to the first USIM card put into the card holder. As a result, operation of the mobile is restricted to this one USIM card (unless the PH-FSIM PUK is used as described below).
PH-FSIM PUK	UE is waiting for phone-to-very-first-USIM card unblocking password to be given. Necessary when "PF" lock is active and other than first USIM card is inserted.
PH-NET PIN	UE is waiting for network personalisation password
PH-NET PUK	UE is waiting for network personalisation unblocking password
PH-NETSUB PIN	UE is waiting for network subset personalisation password
PH-NETSUB PUK	UE is waiting for network subset unblocking password
PH-SP PIN	UE is waiting for service provider personalisation password
PH-SP PUK	UE is waiting for service provider personalisation unblocking password
PH-CORP PIN	UE is waiting for corporate personalisation password
PH-CORP PUK	UE is waiting for corporate personalisation un-blocking password

Notes

- Successful PIN authentication only confirms that the entered PIN was recognized and correct. The output of the result code OK does not necessarily imply that the mobile is registered to the desired network. Typical example: PIN was entered and accepted with OK, but the UE fails to register to the network. This may be due to missing network coverage, denied network access with currently used USIM card, no valid roaming agreement between home network and currently available operators etc. PLS8-X offers various options to verify the present status of network registration: For example, the [AT+COPS](#) command indicates the currently used network. With [AT+CREG](#) you can also check the current status and activate an unsolicited result code which appears whenever the status of the network registration changes (e.g. when the UE is powered up, or when the network cell changes).
- `<pin>` and `<new pin>` can also be entered in quotation marks (e.g. "1234").
- See [AT+CPWD](#) for information on passwords.
- See [AT+CLCK](#) for information on lock types.
- See [AT+CPBS](#) for information on write access to the FD phonebook with PIN2

5.2 AT+CLCK Facility Lock

AT+CLCK can be used to lock, unlock or interrogate a network or UE *<facility>*. The command can be aborted when network facilities are being set or interrogated.

Syntax

<p>Test Command</p> <p>AT+CLCK=?</p> <p>Response(s)</p> <p>+CLCK: list of supported <i><facility></i>s</p> <p>OK</p>											
<p>Write Command</p> <p>AT+CLCK=<i><facility></i>, <i><mode></i> [, <i><password></i>] [, <i><class></i>] [, <i><data></i>]</p> <p>Response(s)</p> <p>If <i><mode></i> is 0 or 1 and command successful:</p> <p>+CLCK: <i><mode></i></p> <p>OK</p> <p>If <i><mode></i>= 2 and command successful:</p> <p>+CLCK: <i><status></i> [, <i><class></i>]</p> <p>[+CLCK: <i><status></i> [, <i><class></i>]]</p> <p>[+CLCK: ...]</p> <p>OK</p> <p>If <i><mode></i>= 3 and no Customer Lock has been programmed yet:</p> <p>+CLCK: <i><password></i></p> <p>If <i><mode></i>= 3 and Customer Lock is set:</p> <p>+CLCK: ERROR</p> <p>If <i><mode></i>= 4 and no Network Lock is set:</p> <p>+CLCK: ""</p> <p>If <i><mode></i>= 4 and Network Lock is effective:</p> <p>+CLCK: <i><data></i> [: <i><data></i>: <i><data></i>: ...]</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <i><err></i></p>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>±</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	±	-	<p>Reference(s)</p> <p>3GPP TS 27.007 [48], 3GPP TS 22.004 [26], 3GPP TS 22.088 [34], 3GPP TS 23.088, 3GPP TS 24.088</p>
PIN	MDM	APP	→	Last							
+	+	+	±	-							

Parameter Description

<facility>^(str)

Phone security locks set by client or factory:

Primarily intended for the client to take safety precautions, "SC" can be configured individually.

Parameter *<class>* is not applicable to security locks.

See examples below for further details.

<p>"SC"</p>	<p>SIM (lock SIM card). SIM requests password upon UE power-up and when this lock command is issued. <i><password></i>: SIM PIN1.</p>
-------------	---

“PS“	<p>PH SIM (lock PHone to SIM/UICC card). UE asks for <code><password></code> when other than current SIM/UICC card is inserted. <code><password></code>: PH-SIM PIN. This 8-digit code is unique for each device. The PH-SIM PIN is necessary to lock the UE to a SIM/UICC. To find out the PH-SIM PIN it is necessary to execute the AT+CLCK write command with <code><facility>="PS"</code>, <code><mode>=3</code>. Keep in mind that if a lock is set, reading the <code><password></code> with <code><mode>=3</code> is no longer possible. Parameter <code><class></code> is not applicable. To allow for any later changes, it is the responsibility of the manufacturer to hold a database with the module specific passwords. To avoid unauthorized use, the PH-SIM PIN should not be provisioned to end users.</p>
“FD“	<p>SIM Fixed Dialing Phonebook lock. If "FD" lock is enabled numbers or public MMI *# codes can be used only if they start with matching numbers or characters stored in the "FD" phonebook. Numbers stored to the "FD" phonebook must not contain the call modifiers "I", "i", "*31#", "#31#". The capacity of the "FD" phonebook is depending on the SIM card. <code><password></code>: SIM PIN2 is mandatory for <code><mode>=0</code> (unlock) or <code><mode>=1</code> (lock). Any attempt to dial a string not specified in the "FD" phonebook will be denied, causing an error result code. The type of result code varies depending on the type of service: "+CME ERROR: call barred" for voice calls, packet switched connections and *# codes for Supplementary Services and USSD. "+CMS ERROR: operation not allowed" for SMS.</p> <p>If "FD" lock is enabled the following applies:</p> <ul style="list-style-type: none">• Handling of AT+CCFC: The "FD" lock is effective only for AT+CCFC <code><mode> 3</code> (registering the CF destination number). All other functions provided by AT+CCFC are not restricted by the "FD" lock.• Handling of USSD: Access to Unstructured Supplementary Services is possible with ATD if the ATD dial string starts with a matching *# code stored in the "FD" phonebook. The USSD command AT+CUSSD, however, is not barred by an "FD" lock.
“PN“	<p>Network Personalization. This feature allows application manufacturers to lock a mobile to specific operators by activating a Network Personalization ("PN"). If the lock is enabled the mobile will accept only SIM/UICC cards from the given operators. The lock is activated by specifying the mobile country codes and mobile networks codes on command line. The Customer SIM Lock feature is protected by depersonalization key. UE asks for <code><password></code> when other than specified operator SIM/UICC card is inserted. <code><password></code>: PH-NET PIN. This 8-digit code is unique for each device. To allow for any later changes, it is the responsibility of the manufacturer to hold a database with the module specific passwords. To avoid unauthorized use, the PH-NET PIN should not be provisioned to end users. Parameter <code><class></code> is not applicable.</p>

Supplementary Service Call Barring:

Supplementary Service "Call Barring" allows to specify conditions under which calls will be disallowed by the network.

The availability of the Supplementary Services varies with the network. To benefit from call barring the client will need to subscribe them, though a limited number of call barring types may be included in the basic tariff package.

When you attempt to set a `<facility>` or `<class>` which is not provisioned, not yet subscribed to, or not sup-

ported by the module, the setting will not take effect regardless of the response returned. The responses in these cases vary with the network (for example "OK", "+CME ERROR: operation not allowed", "+CME ERROR: operation not supported" etc.). To make sure check the extended error response with [AT+CEER](#) and the lock status with `<mode>=2`.

`<password>`: Network password supplied from the provider or operator. Usually there is one password which applies to all call barring options. For details contact your provider.

"AO"	BAOC (Bar All Outgoing Calls)
"OI"	BOIC (Bar Outgoing International Calls)
"OX"	BOIC-exHC (Bar Outgoing International Calls except to Home Country)
"AI"	BAIC (Bar All Incoming Calls)
"IR"	BIC-Roam (Bar Incoming Calls when Roaming outside the Home Country)
"AB"	All Barring services (applicable only for <code><mode>=0</code>)
"AG"	All outGOing barring services (applicable only for <code><mode>=0</code>)
"AC"	All inCOming barring services (applicable only for <code><mode>=0</code>)

`<mode>`^(num)

0	Unlock (parameter <code><password></code> is mandatory).
1	Lock (parameter <code><password></code> is mandatory).
2	Query status.
3	Request the PH-SIM PIN, allowed if phone lock to SIM card <code><facility></code> "PS" has not already been programmed. Otherwise returns "+CLCK: ERROR". Required parameters: <code><facility>="PS",<mode>=3</code> .
3	Request the PH-NET PIN, allowed if phone lock to Network <code><facility></code> "PN" has not already been programmed. Otherwise returns "+CLCK: ERROR". Required parameters: <code><facility>="PN",<mode>=3</code> .
4	Request Customer Network lock status. Required parameters: <code><facility>="PN",<mode>=4</code> .
5	Set Customer Network lock into prepared state (Autolock). In this case, the Network lock data will be read from the first inserted SIM card and stored. Required parameters: <code><facility>="PN",<mode>=5,<password></code> .

`<status>`^(num)

0	Lock is inactive
1	Lock is active

`<password>`^(str)

Password string used to lock and to unlock a `<facility>`. Length and authority for passwords depend on the `<facility>` in question and are therefore listed in the section on parameter `<facility>`. Passwords which can be modified see [AT+CPWD](#).

`<class>`^(num)

Integer or sum of integers each representing a class of information, i.e. a bearer service, telecommunication service or bearer service group as defined in 3GPP TS 22.004 [26]. Values related to data connectivity are listed for compatibility reasons, but are not supported by PLS8-X.

1	Voice
---	-------

5.2 AT+CLCK

2	Class 2 ("Data") comprises all those individual data classes between 16 and 128, that are supported both by the network and the MS. This means, a setting made for class 2 applies to all individual data classes (if supported). In addition, you can assign a different setting to a specific class. For example, you can activate Call Forwarding for all data classes, but deactivate it for data class 64, "dedicated packet access".
4	Fax (only for compatibility reasons, not supported by PLS8-X)
8	SMS
16	Data circuit sync
32	Data circuit async
64	Dedicated packet access
128	Dedicated PAD access
1...[7]...255	Combination of some of the above classes. For example, the default setting 7 represents the sum of the integers 1, 2 and 4 for voice, data and fax (fax only for compatibility reasons) . The value 255 covers all classes. If parameter "class" is omitted, the default value 7 is used.

`<data>`^(str)

Data of the allowed network operators. Parameter is mandatory for Network Personalization ("PN"). Each operator code consists of the "Mobile Country Code" MCC and the "Mobile Network Code" MNC, both separated by a dot, e.g. MCC1.MNC1 . If more than one operator is entered on the same line, then a colon must be set between each operator code, e.g. MCC1.MNC1:MCC2.MNC2:MCC3.MNC3 . For example, for the three operators T-Mobile D1, Vodafone D2 and E-Plus you would enter the following data: 262.01:262.02:262.03
New operator entries will not be added to an existing list. If you need to add new operator entries please unlock the old one and send the complete list once again.

Notes

- The **AT+CLCK** command offers the full range of `<class>` parameters according to the 3GPP Technical Specifications. However, when you attempt to use a service option which is not provisioned or not yet subscribed to, the setting will not take effect regardless of the response returned. The responses in these cases vary with the network (for example "OK", "Operation not allowed", "Operation not supported" etc.). To make sure check the extended error response with **AT+CEER** and the lock status with `<mode>=2`.
- The command has been implemented with the full set of `<class>` parameters according to 3GPP TS 27.007 [48]. For actual applicability of a desired Call barring service to a specific service or service group (a specific `<class>` value) please consult table A.1 of 3GPP TS 22.004 [26].
- If an outgoing Data Call is rejected due to an active `<facility>="FD"` barring supplementary service, the call will be terminated with result code NO CARRIER. Under the same conditions, an outgoing Voice call will be terminated with result code NO DIALTONE.
- If the user tries to set a lock although it is already active or, the other way round, tries to unlock an inactive lock, the response will be OK, but the `<password>` will not be checked or verified.
- In the airplane mode the write command version for the network related `<facility>` (AO, OI, OX, AI, IR, AB, AG and AC) is not supported. For remaining facilities the command is fully functional then.
- As stated above `<class>` 2 is intended only to send the data classes 16/32/64/128 to the network. However, the responses returned when the subscriber sets or queries the lock refer only to the status of the data classes received from the network. This means that the responses will display only those data classes between 16 and 128 which are supported by the network and currently activated. There will be no output for class 2, nor for classes which are not supported or not set.
- The parameter `<class>` will not be sent to the network if `<mode>=2`. Therefore it may happen that the response of the query command contains information about classes which were not requested, or it shows only the inactive status of the class 1 or 255. This means that the status is valid for all classes.
- Upper-case and lower-case characters cannot be used together for the `<facility>` parameter. For example, you can write either "FD" or "fd", but not "Fd".

- Parameter `<class>` is also allowed by `<mode>=2`.

Examples

EXAMPLE 1

Lock SIM card (`<facility>="SC"`)

```
AT+CLCK="SC",1,"9999"    The "SC" parameter enables or disables the SIM PIN authentication (PIN1) when you power up the UE
OK                        SIM card locked. As a result, SIM PIN1 must be entered to enable UE to register to the network.
```

```
AT+CLCK="SC",0,"9999"    Unlocks SIM card.
OK                        When powered up, UE registers to the network without requesting SIM PIN1.
                           Note: Depending on the services offered by the provider, this feature is not supported by all SIM card types. If so, the command returns "ERROR" when you attempt to unlock the card.
```

To query the status of the SIM card lock:

```
AT+CLCK="SC",2           Query the status of SIM card lock.
+CLCK: 1                 SIM card is locked. SIM PIN1 must be entered to enable UE to register to the network.
OK
```

EXAMPLE 2

Phone locked to SIM card (`<facility>="PS"`):

```
AT+CPIN?                 Make sure that PIN1 authentication is valid.
+CPIN: READY
OK
```

To lock the UE to the currently inserted SIM card, first read the password for `<facility> "PS"`:

```
AT+CLCK="PS",3           Read the <facility> "PS" password.
+CLCK: 55555555
OK
```

Then, activate the phone locked to SIM card:

```
AT+CLCK="PS",1,"55555555" Locks the UE to the current SIM card.
OK
```

Optionally, query the status of the phone locked to SIM card:

```
AT+CLCK="PS",2
+CLCK: 1
OK
```

To operate the UE with the SIM card for which "PS" lock was activated:

```
AT+CPIN?
+CPIN: SIM PIN
OK
AT+CPIN="9999"
OK                        No additional password is required for operation (SIM recognized by UE).
```

To operate the UE with other SIM card than the one used for the "PS" lock:
Enter PH-SIM PIN of present card, followed by "PS" lock password.

```
AT+CPIN?
+CPIN: SIM PIN
OK
AT+CPIN="1111"
OK                        PIN authentication accepted.
AT+CPIN?
```

```
+CPIN: PH-SIM PIN          "PS" phone lock password is required.
OK
AT+CPIN="55555555"
OK                          "PS" phone lock password has been accepted. UE is fully operational
                              now.
```

To deactivate the phone locked to SIM card:

```
AT+CLCK="PS",0,"55555555"  "PS" phone lock password has to be provided again.
OK                          Now the UE can be used with any SIM card, without the need of the
                              phone lock password.
```

EXAMPLE 3

Phone locked to Network (<facility>="PN"):

```
AT+CPIN?                    Make sure that PIN1 authentication is valid.
+CPIN: READY
OK
```

To lock the UE to Network, first read the password for <facility> "PN":

```
AT+CLCK="PN",3              Read the <facility> "PN" password.
+CLCK: 66666666
OK
```

Then, activate the phone locked to Network:

```
AT+CLCK="PN",1,"66666666", Locks the UE to Network "262.01".
, "262.01"
OK
```

Optionally, query the status of the phone locked to Network:

```
AT+CLCK="PN",2
+CLCK: 1
OK
```

Optionally, query the status of the locked Network (string is empty when no Network locked):

```
AT+CLCK="PN",4
+CLCK: "262.01"
OK
```

Optionally, activate the phone locked to Network using Autolock:

```
AT+CLCK="PN",5,"66666666"  Locks the UE to current Network.
OK
```

To operate the UE with the Network for which "PN" lock was activated:

```
AT+CPIN?
+CPIN: NET PIN
OK
AT+CPIN="9999"
OK                          No additional password is required for operation (SIM recognized by
                              UE).
```

To operate the UE with other Network than the one used for the "PN" lock:
Enter PH-NET PIN of present card, followed by "PN" lock password.

```
AT+CPIN?
+CPIN: NET PIN
OK
AT+CPIN="1111"
OK                          PIN authentication accepted.
AT+CPIN?
+CPIN: PH-NET PIN          "PN" phone lock password is required.
OK
```

```
AT+CPIN="66666666"
```

```
OK
```

```
"PN" phone lock password has been accepted. UE is fully operational now.
```

To deactivate the phone locked to Network:

```
AT+CLCK="PN",0,"66666666"
```

```
OK
```

```
"PN" phone lock password has to be provided again.  
Now the UE can be used with any SIM card, without the need of the phone lock password.
```

5.3 AT+CPWD Change Password

AT+CPWD allows to define a new password for a password protected `<facility>` lock function. Each password is a string of digits, the length of which varies with the associated `<facility>`. The test command returns a list of pairs which represent the available facilities and the maximum length of the associated password. See AT command [AT+CLCK](#) for more information on the various lock features.

To delete a password use the following syntax: `at+cpwd=<facility>,<old password>`

Syntax

<p>Test Command</p> <pre>AT+CPWD=?</pre> <p>Response(s)</p> <pre>+CPWD: list of supported (<facility>, <password length>) OK</pre>											
<p>Write Command</p> <pre>AT+CPWD=<facility>, <old password>[, <new password>]</pre> <p>Response(s)</p> <pre>New password has been registered for the facility lock function. OK If parameter <old password> was not correct: +CME ERROR: 16 (+CME ERROR: incorrect password) If the password for the selected <facility> has been invalidated due to too many failed attempts: +CME ERROR: ... If the network provider or network operator doesn't supply the Network Password: +CME ERROR: 258 (+CME ERROR: retry operation) If error is related to ME functionality: +CME ERROR: <err></pre>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>±</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	±	-	<p>Reference(s)</p> <p>3GPP TS 27.007 [48]</p>
PIN	MDM	APP	→	Last							
+	+	+	±	-							

Parameter Description

`<facility>`^(str)

Phone security locks set by client or factory:

Primarily intended for the client to take safety precautions, passwords "SC" (SIM PIN) and "P2" (SIM PIN2) are usually predefined, but can be configured individually.

<p>"SC"</p>	<p>SIM PIN. SIM requests password upon ME power-up and when this lock command is issued. If incorrectly entered three times, the SIM PUK is required to perform authentication. Input of the SIM PUK password is possible only with AT command AT+CPIN. <code><password length></code>: 4 to 8 digits.</p>
<p>"P2"</p>	<p>SIM PIN 2, e.g. required for authentication with facility lock "FD" (cf. AT+CLCK). If incorrectly entered three times, the SIM PUK 2 is required to perform authentication. Input of the SIM PUK 2 password is possible only with AT command AT+CPIN. <code><password length></code>: 4 to 8 digits.</p>

Supplementary Service Call Barring:

The call barring supplementary service allows to specify conditions under which calls will be disallowed by the network.

The availability of the supplementary services varies with the network. To benefit from call barring the client will need to subscribe them, though a limited number of call barring types may be included in the basic tariff package.

`<password length>`: ThenNetwork password needs to be supplied from the network provider or network operator. Usually there is one 4 digit password which applies to all call barring options. For details contact your provider.

"AO"	BAOC (Bar All Outgoing Calls)
"OI"	BOIC (Bar Outgoing International Calls)
"OX"	BOIC-exHC (Bar Outgoing International Calls except to Home Country)
"AI"	BAIC (Bar All Incoming Calls)
"IR"	BIC-Roam (Bar Incoming Calls when Roaming outside the home country)
"AB"	All Barring services
"AG"	All outGoing barring services
"AC"	All inComing barring services

`<password length>`^(num)

4...8 Length of password. The range of permitted length for a password depends on the associated `<facility>`. It is available from the test command response, or in the description of parameter `<facility>`. If the entered password is longer then the maximum password length it will be stripped to the maximum length and the remaining digits will be ignored.

`<old password>`^(str)

Password specified for the facility.

Parameter `<old password>` can be ignored if no old password was allocated to the facility.

Take into account that a password may have already been set by factory, or that the service is subject to a password issued by the provider. See notes above or contact provider.

`<new password>`^(str)

New password. Mandatory, if `<old password>` was an unblocking key (PUK).

Notes

- In the airplane mode the write command version for the network related `<facility>` (AO, OI, OX, AI, IR, AB, AG and AC) is not supported. For remaining facilities the command is fully functional then.
- As stated above there is usually a one 4-digit password for all call barring facilities. To change the password please use only the "AB" `<facility>` (All Barring services).

Examples

EXAMPLE 1

To change PIN2

```
AT+CPWD="P2","0000","8888" (where "0000" = old PIN2 and "8888" = new PIN2)
OK PIN2 password has been changed to "8888"
```

EXAMPLE 2

To set the password used to enable or disable Call Barring:

```
AT+CPWD="AB", "0000", "3333"
```

```
OK
```

Requests the network to change the password for the call barring supplementary service. Even though issued for "AB" only the request applies to all other call barring services, too.

5.4 AT^SPIC Display PIN Counter

The `AT^SPIC` command can be used to find out whether the ME is waiting for a password and, if so, how many attempts are left to enter the password.

The execute command returns the number of attempts still available for entering the currently required password, for example the SIM PIN, SIM PUK, PH-SIM PIN etc.

The read command `AT^SPIC?` indicates which password the number of attempts stated by the execute command actually refers to. Also, the write command may be used to query the counter for a specific password. It indicates the number of attempts still available for entering the password identified by `<facility>`, for example the SIM PIN, SIM PIN2, PH-SIM PIN etc. .

To check whether or not you need to enter a password use the read commands `AT+CPIN?` or `AT^SPIC?` . If the response to `AT+CPIN?` is "READY" the counter of the execute command `AT^SPIC` relates to PIN2. See [last example](#). If PIN and PIN2 (e. g. `AT+CPBS="FD","PIN2"`) are entered successfully no password is currently required and `AT^SPIC` read and execute commands return only OK.

If no USIM card is inserted the `AT^SPIC` read, execute and write commands return "+CME ERROR: SIM not inserted".

Syntax

Test Command

```
AT^SPIC=?
```

Response(s)

```
OK
```

Read Command

```
AT^SPIC?
```

Response(s)

```
^SPIC: <code>
```

```
OK
```

Exec Command

```
AT^SPIC
```

Response(s)

```
[^SPIC: <counter>]
```

```
OK
```

Write Command

```
AT^SPIC=<facility>[, <pin_puk>]
```

Response(s)

```
^SPIC: <counter>
```

```
OK
```

```
ERROR
```

```
+CME ERROR: <err>
```

PIN MDM APP → Last

```
- + + + -
```

Parameter Description

`<counter>`^(num)

Number of attempts left to enter the currently required password. This number will be counted down after each failure.

`<facility>`^(str)

Password for which the corresponding PIN counter is to be displayed.

“SC”	SIM PIN if parameter <code><pin_puk></code> is omitted or set to 0. SIM PUK if parameter <code><pin_puk></code> is set to 1.
“PS”	PH-SIM PIN if parameter <code><pin_puk></code> is omitted or set to 0. PH-SIM PUK if parameter <code><pin_puk></code> is set to 1. For details see AT command <code>AT+CLCK</code> .
“P2”	SIM PIN2 if parameter <code><pin_puk></code> is omitted or set to 0. SIM PUK2 if parameter <code><pin_puk></code> is set to 1.
“PN”	Network Personalisation. PH-NET PIN if parameter <code><pin_puk></code> is omitted or set to 0. PH-NET PUK if parameter <code><pin_puk></code> is set to 1.

`<pin_puk>`^(num)

[0]	Show PIN counter for given <code><facility></code> .
1	Show PUK counter for given <code><facility></code> .

`<code>`^(text)

Identification of the currently required password.

SIM PIN	ME is waiting for SIM PIN1.
SIM PUK	ME is waiting for SIM PUK1 if PIN1 was disabled after three failed attempts to enter PIN1.
SIM PIN2	ME is waiting for PIN2, when the attempt to access PIN2 requiring features was acknowledged with "+CME ERROR: SIM PIN2 required" (e.g. if the user attempts to edit the FD phonebook by using <code>AT+CPBS="FD","PIN2"</code>).
SIM PUK2	ME is waiting for PUK2 to unblock a disabled PIN2. Necessary if preceding command was acknowledged with "+CME ERROR: SIM PUK2 required".
PH-SIM PIN	ME is waiting for 8-digit code to unlock the UE to a SIM/UICC if "PS" lock is active and user inserts other SIM card than the one used for the lock. For details see <code>AT+CLCK="PS"</code> .
PH-SIM PUK	ME is waiting for 8-digit code to unblock the UE, if the "PS" lock password was incorrectly entered 10 times.
PH-NET PIN	ME is waiting for Network Personalisation.
PH-NET PUK	ME is waiting for Network Personalisation unblocking password.

Notes

- Whenever the required password changes, `<counter>` changes to reflect that change. Please refer to the examples below.
- See also chapters `AT+CLCK`, `AT+CPIN` and `AT+CPWD` for further information on locks and passwords.

Examples

EXAMPLE 1

The user fails to provide a correct SIM PIN three times. The counter decreases each time. After the counter reaches zero, the SIM PUK is required. After each failure to enter a correct SIM PUK, the counter decreases.

```
at+cpin?
+CPIN: SIM PIN
OK
at^spic?
Currently required password is PIN1.
```



```

^SPIC: SIM PIN
OK                               Currently required password is PIN1.
at^spic
^SPIC: 3
OK                               3 attempts left.
at+cpin="9999"
+CME ERROR: incorrect password
at^spic
^SPIC: 2
OK                               2 attempts left.
at+cpin="9999"
+CME ERROR: incorrect password
OK
at^spic
^SPIC: 1
OK                               1 attempt left.
at+cpin="9999"
+CME ERROR: incorrect password
at+cpin?
+CPIN: SIM PUK
OK                               Now required password is PUK1.
at^spic
^SPIC: 10
OK                               10 attempts left for PUK1.
at+cpin="01234567","1234"
+CME ERROR: incorrect password
at^spic
^SPIC: 9
OK                               9 attempts left for PUK1.

```

EXAMPLE 2

Though a mobile is locked to Network Personalisation ("PN"), the user attempts to operate it with another SIM card. The user correctly enters the SIM PIN of the SIM card currently inserted, but then fails to give the "PN" unblock password (PH-NET PUK):

```

at+cpin="9999"
OK
at+cpin?
+CPIN: PH-NET PIN                ME is waiting for the Network Personalisation password.

OK
at^spic
^SPIC: 10                       10 attempts left.
OK
at+cpin="11110000"
+CME ERROR: incorrect password
at^spic?
^SPIC: 9                         9 attempts left.
OK
at+cpin="11111111"
+CME ERROR: incorrect password
and so on ...
at^spic
^SPIC: 1                         1 attempt left.
OK
at^spic?
^SPIC: PH-NET PIN                Displayed counter refers to Network Personalisation password.

```

```
OK

at+cpin="11119999"
+CME ERROR: incorrect password
at^spic
^SPIC: 32
OK
at^spic?
^SPIC: PH-NET PUK
```

Displayed counter refers to Network Personalisation unblock password.

```
OK
at+cpin="22220000"
+CME ERROR: incorrect password
at^spic
^SPIC: 31
OK
```

EXAMPLE 3

This example shows that after successful SIM PIN1 authentication the counter of the `AT^SPIC` execute and read command refers to SIM PIN2, i.e. it does not reflect the status of SIM PIN1. This may be a problem if the user enters a wrong PIN1 and is not aware that the number of attempts left to enter SIM PIN1 is counted down.

```
+CREG: 0
at+cpin="1234"
OK
+CREG: 2

+CREG: 1
at+cpin?
+CPIN: READY

at^spic
^SPIC: 3

OK
AT^SPIC?

^SPIC: SIM PIN2
OK
at+clck="SC",0,"456789"
+CME ERROR: incorrect password
at^spic
^SPIC: 3

at+clck="SC",0,"456789"
+CME ERROR: incorrect password
at^spic
^SPIC: 3

at+clck="SC",0,"456789"
+CME ERROR: incorrect password

+CREG: 0
```

The mobile ist properly registered to the network.

The `AT+CPIN?` read command confirms that SIM PIN1 authentication was successful.

As SIM PIN1 authentication was successful, the counter relates to SIM PIN2 and correctly indicates that the user has 3 attempts to enter SIM PIN2.

Likewise, the read command notifies that the ME is waiting for SIM PIN2.

First attempt to enter a wrong SIM PIN1.

SIM PIN1 authentication is still valid, and the counter relates to SIM PIN2.

Second attempt to enter a wrong SIM PIN1.

SIM PIN1 authentication is still valid, and the counter relates to SIM PIN2.

Third attempt to enter a wrong SIM PIN1.

SIM PIN1 authentication is no longer valid.

```
at^spic  
^SPIC: 10
```

This time, after the SIM PIN1 code has been disabled, the counter indicates the status of SIM PIN1 and notifies that 10 attempts are left to enter the SIM PUK.

To avoid conflicts we recommend to use the [AT^SPIC](#) read and write commands rather than the execute command only. The read command clearly states the currently required password, and the write command may be used to get the counter for a specific [<facility>](#), in this case for example "P2".

6. Identification Commands

The AT Commands described in this chapter allow the external application to obtain various identification information related to the PLS8-X and linked entities.

6.1 ATI Display product identification information

The [ATI](#) execute command delivers a product information text.

Syntax

```
Exec Command
ATI
Response(s)
Cinterion
PLS8-X
REVISION xx.yyy
OK
```

```
Exec Command
ATI1
Response(s)
Cinterion
PLS8-X
REVISION xx.yyy
A-REVISION xx.zzz.cc
OK
```

```
Exec Command
ATI2
Response(s)
UICC Application Identification <applId>
OK
ERROR
+CME ERROR: <err>
```

```
Exec Command
ATI3
Response(s)
L-REVISION xx.zzz.cc
OK
```

```
Exec Command
ATI61
Response(s)
[<provCfg> <mdmSwVer>]
[<provCfg> <mdmSwVer>]
[...]
xxx.<cProvCfg>
MIMG <mdmImage>
OK
```

6.1 ATI

Exec Command					Reference(s)	
ATI176					ITU-T V.250 [16]	
Response(s)						
<imeisv_number>						
OK						
PIN	MDM	APP	→	Last		
±	+	+	+	-		

Parameter Description**<applId>**^(num)

UICC application types. A single value or a combination of the following values is possible. For example, the response value 0x03 represents the sum of the integers 0x01 and 0x02 (GSM application and USIM application).

0x01	GSM application
0x02	USIM application
0x04	ISIM application

<provCfg>^(text)

Possible provider configuration.
The change of provider configuration is done by `AT^SCFG` parameter "MEopMode/Prov/Cfg" (see **<provCfg>**).

<mdmSwVer>^(text)

Modem software version number.

<cProvCfg>^(text)

Current provider configuration.

<mdmImage>^(text)

Modem image.

<imeisv_number>^(num)

IMEISV (International Mobile station Equipment Identity and Software Version number) conforming to the format: <IMEI>.<SVN>. For information on IMEISV refer to 3GPP TS 23.003 and 3GPP TS 27.007 [48].

Notes

- The "Revision" information consists of the following parts: Version xx and variant yyy of software release.
- "A-REVISION xx.zzz.cc" information consists of the following parts:
 - Application Revision Number 'xx' as an assignment to customer application. '01' indicates no customer application.
 - Application Revision Version 'zzz' as an assignment to changes in customer application.
 - 'cc' as an additional number, e.g. defined by customer.

6.2 AT+CGMI Request manufacturer identification

[AT+CGMI](#) returns a manufacturer identification text. See also: [AT+GMI](#).

Syntax

Test Command	
AT+CGMI=?	
Response(s)	
OK	
Exec Command	
AT+CGMI	
Response(s)	
Cinterion	
OK	
PIN MDM APP → Last	Reference(s)
- + + + -	3GPP TS 27.007 [48]

6.3 AT+GMI Request manufacturer identification

[AT+GMI](#) returns a manufacturer identification text. See also: [AT+CGMI](#).

Syntax

Test Command	
AT+GMI=?	
Response(s)	
OK	
Exec Command	
AT+GMI	
Response(s)	
Cinterion	
OK	
PIN MDM APP → Last	Reference(s)
- + + + -	ITU-T V.250 [16]

6.4 AT+CGMM Request model identification

[AT+CGMM](#) returns a product model identification text. Command is identical with [AT+GMM](#).

Syntax

Test Command					
AT+CGMM=?					
Response(s)					
OK					
Exec Command					
AT+CGMM					
Response(s)					
PLS8-X					
OK					
PIN	MDM	APP	→	Last	Reference(s)
-	+	+	+	-	3GPP TS 27.007 [48]

6.5 AT+GMM Request model identification

[AT+GMM](#) returns a product model identification text. Command is identical with [AT+CGMM](#).

Syntax

Test Command					
AT+GMM=?					
Response(s)					
OK					
Exec Command					
AT+GMM					
Response(s)					
PLS8-X					
OK					
PIN	MDM	APP	→	Last	Reference(s)
-	+	+	+	-	ITU-T V.250 [16]

6.6 AT+CGMR Request revision identification of software status

[AT+CGMR](#) delivers a product firmware version identification. Command is identical with [AT+GMR](#).

Syntax

Test Command					
AT+CGMR=?					
Response(s)					
OK					
Exec Command					
AT+CGMR					
Response(s)					
REVISION <xx.yyy>					
OK					
PIN	MDM	APP	→	Last	Reference(s)
-	+	+	+	-	3GPP TS 27.007 [48]

Parameter Description

<xx.yyy> ^(text)
Version xx and variant yyy of software release.

6.7 AT+GMR Request revision identification of software status

[AT+GMR](#) delivers a product firmware version identification. Command is identical with [AT+CGMR](#).

Syntax

Test Command					
AT+GMR=?					
Response(s)					
OK					
Exec Command					
AT+GMR					
Response(s)					
REVISION <xx.yyy>					
OK					
PIN	MDM	APP	→	Last	Reference(s)
-	+	+	+	-	ITU-T V.250 [16]

Parameter Description

<xx.yyy> ^(text)
Version xx and variant yyy of software release.

6.8 AT+CGSN Request International Mobile Equipment Identity (IMEI)

[AT+CGSN](#) returns the International Mobile Equipment Identity (IMEI). Command is identical with [AT+GSN](#).

Syntax

Test Command					
AT+CGSN=?					
Response(s)					
OK					
Exec Command					
AT+CGSN					
Response(s)					
<sn>					
OK					
PIN	MDM	APP	→	Last	Reference(s)
-	+	+	+	-	3GPP TS 27.007 [48]

Parameter Description

<sn> ^(text)
IMEI used to identify mobile equipment when used on a mobile network.

6.9 AT+GSN Request International Mobile Equipment Identity (IMEI)

[AT+GSN](#) returns the International Mobile Equipment Identity (IMEI). Command is identical with [AT+CGSN](#).

Syntax

Test Command					
AT+GSN=?					
Response(s)					
OK					
Exec Command					
AT+GSN					
Response(s)					
<sn>					
OK					
PIN	MDM	APP	→	Last	Reference(s)
-	+	+	+	-	ITU-T V.250 [16]

Parameter Description

<sn> ^(text)
IMEI used to identify mobile equipment when used on a mobile network.

6.10 AT+CIMI Request International Mobile Subscriber Identity (IMSI)

AT+CIMI delivers the International Mobile Subscriber Identity (IMSI). The IMSI permits the TE to identify the individual SIM attached to the UE.

Syntax

Test Command	
AT+CIMI=?	
Response(s)	
OK	
Exec Command	
AT+CIMI	
Response(s)	
<imsi>	
OK	
ERROR	
+CME ERROR: <err>	
PIN MDM APP → Last	Reference(s)
+ + + + -	3GPP TS 27.007 [48]

Parameter Description

<imsi> ^(text)
International Mobile Subscriber Identity

7. Network Service Commands

The AT Commands described in this chapter are related to various network services.

7.1 AT+COPN Read operator names

The `AT+COPN` command returns the list of operator names from the UE. Each operator code `<numericn>` that has an alphanumeric equivalent `<alphan>` in the UE memory is returned.

Syntax

Test Command					
AT+COPN=?					
Response(s)					
OK					
ERROR					
+CME ERROR: <code><err></code>					
Exec Command					
AT+COPN					
Response(s)					
+COPN: <code><numericn></code> , <code><alphan></code>					
[+COPN: ...]					
OK					
ERROR					
+CME ERROR: <code><err></code>					
PIN	MDM	APP	→	Last	Reference(s)
+	+	+	+	-	3GPP TS 27.007 [48]

Parameter Description

<code><numericn></code> ^(str)
Operator in numeric format
<code><alphan></code> ^{(str)(+CSCS)}
Operator in long alphanumeric format

7.2 AT+COPS Operator Selection

AT+COPS queries the present status of the PLS8-X's network registration and allows to determine whether automatic or manual network selection shall be used.

Three operator selection modes are available with **AT+COPS**:

- **Automatic**
PLS8-X searches for the home operator automatically. If successful the PLS8-X registers to the home network. If the home network is not found, PLS8-X goes on searching. If a permitted operator is found, PLS8-X registers to this operator.
If no operator is found the PLS8-X remains unregistered.
- **Manual**
Desired operator can be determined using the **AT+COPS** write command. If the operator is found, PLS8-X registers to it immediately. If the selected operator is forbidden, the PLS8-X remains unregistered.
- **Manual/automatic**
The UE first tries to find the operator determined via **AT+COPS** write command. If the UE fails to register to this operator, then it starts to select another (permitted) operator automatically.

The **AT+COPS** test command lists sets of five parameters, each representing an operator present in the network. A set consists of

- an integer indicating the availability of the operator,
- long alphanumeric format of the operator's name,
- short alphanumeric format of the operator's name,
- numeric format representation of the operator and
- an integer indicating the access technology of the operator.

Any of the parameters may be unavailable and will then be an empty field (,). The list of operators comes in the following order: Home network, networks referenced in SIM and other networks.

The operator list is followed by a list of the supported **<mode>**s and **<format>**s. These lists are delimited from the operator list by two commas.

The response to the **AT+COPS** test command is independent of the settings made with **<mode>** and **<rat>**. The **AT+COPS** test command will return a list of operators with the supported **<rat>**s.

Under certain conditions the UE has not enough resources to perform a network scan in the background. In such case, the **AT+COPS** test command is denied with error, for example during location update, data traffic in PS connections etc.

The response to the **AT+COPS** read command depends on the registration status. If the UE is not registered, the read command returns only the current **<mode>**. If the UE is registered the response returns the currently selected operator, the currently set format and the currently used **<rat>**.

The **AT+COPS** write command forces an attempt to select and register to a network operator. If the selected operator is not available, no other operator will be selected (except **<mode>=4**). The selected operator name **<format>** will apply to further read commands, too.

The **AT+COPS** exec command returns OK and has no effect on the current **<mode>**.

Syntax

Test Command

```
AT+COPS=?
```

Response(s)

```
+COPS: [list of supported (<opStatus>, long alphanumeric <opName>, short alphanumeric <opName>, numeric <opName>, <rat>)s ], , (list of supported <mode>s), (list of supported <format>s)
```

```
OK
```

```
ERROR
```

```
+CME ERROR:<err>
```

Read Command		Reference(s)			
AT+COPS?					
Response(s)					
+COPS: <mode>[, <format>[, <opName>][, <rat>]]					
OK					
ERROR					
+CME ERROR: <err>					
Write Command					
AT+COPS=<mode>[, <format>[, <opName>][, <rat>]]					
Response(s)					
OK					
ERROR					
+CME ERROR: <err>					
PIN	MDM	APP	→	Last	
+	+	+	-	-	
					3GPP TS 27.007 [48]

Parameter Description

<opStatus> ^(num)	
Operator Status	
0	Unknown
1	Operator available
2	Current operator
3	Operator forbidden
<opName> ^{(str)(+CSCS)(&V)}	
Operator Name	
If test command: Operator name in long alphanumeric format, short alphanumeric format and numeric format.	
If read command: Operator name as per <format>.	
If write command: Operator name in numeric format.	
<mode> ^{(num)(&V)(NV)}	
Only Parameter values 0 and 1 are stored in the non-volatile memory of the PLS8-X.	
0 ^(D)	Automatic mode; <opName> field is ignored.
1	Manual operator selection The AT+COPS write command requires <opName> in numeric format, i.e. <format> shall be 2. <opName> can be omitted when changing only the <rat> parameter and retaining the network already manually selected. When using this mode keep in mind that only the <mode> parameter is non-volatile, but not the selected <opName>. After restarting the UE the network will be selected according to the priority order specified in 3GPP TS 23.122: "Last Registered PLMN", "Home PLMN", "Preferred PLMN" (related USIM elementary files are EF_LOCI, EF_IMSI, EF_PLMNwAcT). The same priority order applies when swapping the USIM during operation.
2	Manually deregister from network and remain unregistered until <mode>=0 or 1 or 4 is selected. After setting command AT+COPS=2 wait for <regStatus> 0, e.g. indicated by the "+CREG: 0" URC before executing any further network service related AT commands.

- 3 Set only `<format>` (for `AT+COPS` read command).
- 4 Manual / automatic selection; if manual selection fails, automatic mode (`<mode>=0`) is entered (`<opName>` field will be present).

`<rat>`^{(num)(&V)(NV)}

Radio Access Technology (RAT)

By delivery default, the `<rat>` parameter is set to an automatic selection mode which enables the UE to select either UTRAN (UMTS) or GSM or E-UTRAN, depending on the network coverage. This automatic mode for selecting `<rat>` remains enabled until you explicitly set either 0 for GSM or 2 for UTRAN or 7 for E-UTRAN. This means, setting the `<rat>` parameter is a restriction, i.e. it forces the UE to select either UTRAN only or GSM only or 7 for E-UTRAN. The selected `<rat>` value 0 or 2 or 7 will be stored in the non-volatile memory. If the selected `<rat>` is not available, the UE cannot register to a network.

The automatic `<rat>` selection mode can be restored any time by executing the `AT+COPS` write command without choosing a specific `<rat>`, i.e. simply by omitting the `<rat>` value. When you do so, it does not matter, which value(s) you select for other `AT+COPS` parameters. For example, an easy way is setting `AT+COPS=0`, which means both PLMN and RAT are automatically selected. Another way is giving the `AT+COPS` write command with any `<mode>`, `<format>`, or `<opName>`, but `<rat>` omitted.

Please consider that the `AT+COPS?` read command does not reflect whether `<rat>` was omitted or explicitly set. This is because the response to the `AT+COPS?` read command will always indicate the currently used `<rat>`. Values 3, 4 and 6 occur only in read command responses and are not intended for the `AT+COPS` write command.

If you wish to modify `<rat>` and also the `<rba>` parameter of `AT^SCFG` take care that both values are compatible.

- 0 GSM
- 2 UTRAN
- 3 GSM w/EGPRS
- 4 UTRAN w/HSDPA
- 6 UTRAN w/HSDPA and HSUPA
- 7 E-UTRAN

`<format>`^{(num)(&V)(&W)}

- 0^(D) Long alphanumeric format of `<opName>`.
- 1 Short alphanumeric format of `<opName>`.
- 2 Numeric format of `<opName>`. This is the Location Area Identification (LAI) number, which consists of the 3-digit Mobile Country Code (MCC) plus the 2- or 3-digit Mobile Network Code (MNC).

Note

- `AT+COPS=?` shows PLMNs as available (`<opStatus>=1`) as long as a location update was not rejected and the PLMNs are not written to the forbidden PLMN list (SIM EF-FPLMN).

7.3 AT+CPOL Preferred Operator List

AT+CPOL read command queries the list of the preferred operators.
AT+CPOL write command allows to edit the list of the preferred operators.
 The response of **AT+CPOL** read command also depends on the setting of **AT+CPLS**.
 If **<index>** is given but **<operator>** is left out, the entry is deleted.

Syntax

<p>Test Command</p> <p>AT+CPOL=?</p> <p>Response(s)</p> <p>+CPOL: (list of supported <index>s), (list of supported <format>s)</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>											
<p>Read Command</p> <p>AT+CPOL?</p> <p>Response(s)</p> <p>+CPOL: <index>, <format>, <operator>[, <gsm>, <gsm_compact>, <utran>, <e-utran>]</p> <p>+CPOL: ...</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>											
<p>Write Command</p> <p>AT+CPOL=[<index>][[, <format>][[, <operator>][[, <gsm>, <gsm_compact>, <utran>, <e-utran>]]]</p> <p>Response(s)</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	+	-	<p>Reference(s)</p> <p>3GPP TS 27.007 [48]</p>
PIN	MDM	APP	→	Last							
+	+	+	+	-							

Parameter Description

<index> ^(num)	
The order number of the operator in the SIM preferred operator list.	
<format> ^(num)	
0	Long alphanumeric format <operator>
1	Short alphanumeric format <operator>
2	Numeric format <operator>
<operator> ^(str)	
The operator in the format specified in <format> .	

<gsm>^(num)

0	AcT GSM disabled
1	AcT GSM enabled

<gsm_compact>^(num)

0	AcT GSM Compact disabled
---	--------------------------

<utran>^(num)

0	AcT UTRAN disabled
1	AcT UTRAN enabled

<e-utran>^(num)

0	AcT E-UTRAN disabled
1	AcT E-UTRAN enabled

Note

- The Access Technology selection parameters <gsm>, <gsm_compact>, <utran>, <e-utran> are required for SIM cards or UICCs containing PLMN selector with Access Technology.

7.4 AT+CPLS Select Preferred Operator List

AT+CPLS is used to select a preferred PLMN list defined in Elementary Files of the SIM card or active application of the USIM. The setting takes effect for the **AT+CPOL** command.

Syntax

<p>Test Command</p> <p>AT+CPLS=?</p> <p>Response(s)</p> <p>+CPLS: (list of USIM supported <plmn-selector>s)</p> <p>OK</p>											
<p>Read Command</p> <p>AT+CPLS?</p> <p>Response(s)</p> <p>+CPLS: <plmn-selector></p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>											
<p>Write Command</p> <p>AT+CPLS=<plmn-selector></p> <p>Response(s)</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>✈</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>-</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	✈	Last	+	+	+	-	-	<p>Reference(s)</p> <p>3GPP TS 27.007 [48]</p>
PIN	MDM	APP	✈	Last							
+	+	+	-	-							

Parameter Description

<plmn-selector> ^(num)	Description
0 ^(P)	User controlled PLMN with EF _{PLMNwAcT} /EF _{PLMNsel}
1	Operator controlled PLMN selector with EF _{OPLMNwAcT}
2	HPLMN selector with EF _{HPLMNwAcT}

7.5 AT+CREG Network Registration Status

AT+CREG serves to monitor the PLS8-X's network registration status. Information can be reported by the AT+CREG? read command and by +CREG: URCs.

Syntax

<p>Test Command</p> <p>AT+CREG=?</p> <p>Response(s)</p> <p>+CREG: (list of supported<urcMode>s)</p> <p>OK</p>											
<p>Read Command</p> <p>AT+CREG?</p> <p>Response(s)</p> <p>+CREG: <urcMode>, <regStatus>[, <netLac>, <netCellId>[, <AcT>]]</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>											
<p>Write Command</p> <p>AT+CREG=<urcMode></p> <p>Response(s)</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>-</td> <td>+</td> <td>+</td> <td>-</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	-	+	+	-	-	<p>Reference(s)</p> <p>3GPP TS 27.007 [48]</p>
PIN	MDM	APP	→	Last							
-	+	+	-	-							

Unsolicited Result Codes

URC 1

If <urcMode>=1 and there is a change in the UE's network registration status:

+CREG: <regStatus>

URC 2

If <urcMode>=2 and there is a change of the UE's network registration status or at least one of the additional network information elements:

+CREG: <regStatus>[, <netLac>, <netCellId>[, <AcT>]]

Parameter Description

<urcMode> ^{(num)(&V)(&W)}	
[0] ^(&F)	Disable +CREG URC.
1	Enable URC +CREG:<regStatus> to report status of network registration.
2	Enable URC +CREG:<regStatus>[,<netLac>,<netCellId>][, <AcT>]] to report status of network registration including location information. Parameters <netLac>, <netCellId> and <AcT> will only be displayed if available.

<regStatus>^(num)(&V)

- | | |
|---|---|
| 0 | Not registered, UE is currently not searching for new operator. There is a technical problem. User intervention is required. Yet, emergency calls can be made if any network is available. Probable causes: <ul style="list-style-type: none">• no SIM card available• no PIN entered• no valid Home PLMN entry found on the SIM |
| 1 | Registered to home network. |
| 2 | Not registered, but UE is currently searching for a new operator. UE searches for an available network. Failure to log in until after more than a minute may be due to one of the following reasons: <ul style="list-style-type: none">• No network available or insufficient Rx level.• UE has no access rights to the networks available.• Networks from the SIM list of allowed networks are around, but login fails due to one of the following reasons:<ul style="list-style-type: none">- #11 ... PLMN not allowed- #12 ... Location area not allowed- #13 ... Roaming not allowed in this location area After this, the search will be resumed (if automatic network search is enabled). <ul style="list-style-type: none">• The Home PLMN or an allowed PLMN is available, but login is rejected by the cell (reasons: Access Class or LAC). If at least one network is available, emergency calls can be made. |
| 3 | Registration denied <ul style="list-style-type: none">• If automatic network search is enabled:
Authentication or registration fails after Location Update Reject due to one of the following reasons:<ul style="list-style-type: none">- #2 ... IMSI unknown at HLR- #3 ... Illegal MS- #6 ... Illegal UE Either the SIM or the UE are unable to log into any network. User intervention is required. Emergency calls can be made, if any network is available. <ul style="list-style-type: none">• Only if manual network search is enabled:
Manual registration fails after Location Update Reject due to the following reasons:<ul style="list-style-type: none">- #2 ... IMSI unknown at HLR- #3 ... Illegal MS- #6 ... Illegal UE- #11 ... PLMN not allowed- #12 ... Location area not allowed- #13 ... Roaming not allowed in this location area No further attempt is made to search or log into a network. Emergency calls can be made if any network is available. |
| 4 | Unknown, e.g. out of GSM/UMTS/LTE coverage. |
| 5 | Registered, roaming.
UE is registered at a foreign network (national or international network) |

<netLac>^(str)

Two byte location area code in hexadecimal format (e.g. "00C1" equals 193 in decimal).

<netCellId>^(str)

Cell ID in hexadecimal format:

- 16 bit for 2G
- 28 bit for 3G or 4G

<AcT>^(num)

Radio access technology

0	GSM
2	UTRAN
3	GSM w/EGPRS
4	UTRAN w/HSDPA
6	UTRAN w/HSDPA and HSUPA
7	E-UTRAN

Example

AT+CREG=1	Activate URC mode.
OK	
AT+COPS=0	Force UE to automatically search a network operator.
OK	
+CREG: 2	URC reports that UE is currently searching.
+CREG: 1	URC reports that operator has been found.

7.6 AT+CESQ Extended Signal Quality

The `AT+CESQ` command returns received signal quality parameters. If the current serving cell is not a GERAN cell, `<rxlev>` and `<ber>` are set to value 99. If the current serving cell is not a UTRA FDD or UTRA TDD cell, `<rscp>` is set to 255. If the current serving cell is not a UTRA FDD cell, `<ecno>` is set to 255. If the current serving cell is not an E-UTRA cell, `<rsrq>` and `<rsrp>` are set to 255.

Syntax

<p>Test Command</p> <p>AT+CESQ=?</p> <p>Response(s)</p> <p>+CESQ: (list of supported <code><rxlev></code>s), (list of supported <code><ber></code>s), (list of supported <code><rscp></code>s), (list of supported <code><ecno></code>s), (list of supported <code><rsrq></code>s), (list of supported <code><rsrp></code>s)</p> <p>OK</p>											
<p>Exec Command</p> <p>AT+CESQ</p> <p>Response(s)</p> <p>+CESQ: <code><rxlev></code>, <code><ber></code>, <code><rscp></code>, <code><ecno></code>, <code><rsrq></code>, <code><rsrp></code></p> <p>OK</p> <p>ERROR</p>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>-</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	-	-	<p>Reference(s)</p> <p>3GPP TS 27.007 [48]</p>
PIN	MDM	APP	→	Last							
+	+	+	-	-							

Parameter Description

<code><rxlev></code> ^(num)	
Received signal strength level (see 3GPP TS 45.008 [52] subclause 8.1.4). For 2G networks only	
0	$\text{rssi} < -110 \text{ dBm}$
1	$-110 \text{ dBm} \leq \text{rssi} < -109 \text{ dBm}$
2	$-109 \text{ dBm} \leq \text{rssi} < -108 \text{ dBm}$
...	
61	$-50 \text{ dBm} \leq \text{rssi} < -49 \text{ dBm}$
62	$-49 \text{ dBm} \leq \text{rssi} < -48 \text{ dBm}$
63	$-48 \text{ dBm} \leq \text{rssi}$
99	not known or not detectable
<code><ber></code> ^(num)	
Channel bit error rate (in percent). For 2G networks only	
0..7	as RXQUAL values in the table in 3GPP TS 45.008 [52] subclause 8.2.4
99	not known or not detectable
<code><rscp></code> ^(num)	
Received signal code power (see 3GPP TS 25.133 [44] subclauses 9.1.1.3 and 9.1.1.1.3) For 3G networks only	
0	$\text{rscp} < -120 \text{ dBm}$
1	$-120 \text{ dBm} \leq \text{rscp} < -119 \text{ dBm}$
2	$-119 \text{ dBm} \leq \text{rscp} < -118 \text{ dBm}$

...	
94	$-27 \text{ dBm} \leq \text{rscp} < -26 \text{ dBm}$
95	$-26 \text{ dBm} \leq \text{rscp} < -25 \text{ dBm}$
96	$-25 \text{ dBm} \leq \text{rscp}$
255	not known or not detectable

<ecno>^(num)

Ratio of the received energy per PN chip to the total received power spectral density (see 3GPP TS 25.133 [44] subclause 9.1.2.3) For 3G networks only

0	$\text{Ec/lo} < -24 \text{ dB}$
1	$-24 \text{ dB} \leq \text{Ec/lo} < -23.5 \text{ dB}$
2	$-23.5 \text{ dB} \leq \text{Ec/lo} < -23 \text{ dB}$
...	
47	$-1 \text{ dB} \leq \text{Ec/lo} < -0.5 \text{ dB}$
48	$-0.5 \text{ dB} \leq \text{Ec/lo} < 0 \text{ dB}$
49	$0 \text{ dB} \leq \text{Ec/lo}$
255	not known or not detectable

<rsrq>^(num)

Reference signal received quality (see 3GPP TS 36.133 [53] subclause 9.1.7). For 4G networks only

0	$\text{rsrq} < -19.5 \text{ dB}$
1	$-19.5 \text{ dB} \leq \text{rsrq} < -19 \text{ dB}$
2	$-19 \text{ dB} \leq \text{rsrq} < -18.5 \text{ dB}$
...	
94	$-4 \text{ dB} \leq \text{rsrq} < -3.5 \text{ dB}$
95	$-3.5 \text{ dB} \leq \text{rsrq} < -3 \text{ dB}$
96	$-3 \text{ dB} \leq \text{rsrq}$
255	not known or not detectable

<rsrp>^(num)

Reference signal received power (see 3GPP TS 36.133 [53] subclause 9.1.4). For 4G networks only

0	$\text{rsrp} < -140 \text{ dBm}$
1	$-140 \text{ dBm} \leq \text{rsrp} < -139 \text{ dBm}$
2	$-139 \text{ dBm} \leq \text{rsrp} < -138 \text{ dBm}$
...	
95	$-46 \text{ dBm} \leq \text{rsrp} < -45 \text{ dBm}$
96	$-45 \text{ dBm} \leq \text{rsrp} < -44 \text{ dBm}$
97	$-44 \text{ dBm} \leq \text{rsrp}$
255	not known or not detectable

7.7 AT+CSQ Signal Quality

The `AT+CSQ` execute command indicates the received signal strength `<rssi>` and the channel bit error rate `<ber>`.

Syntax

<pre>Test Command AT+CSQ=? Response(s) +CSQ: (list of supported <rssi>s), (list of supported<ber>s) OK</pre>	<pre>Exec Command AT+CSQ Response(s) +CSQ: <rssi>,<ber> OK</pre>												
<table border="1"> <tr> <td>PIN</td> <td>MDM</td> <td>APP</td> <td>→</td> <td>Last</td> </tr> <tr> <td>+</td> <td>+</td> <td>+</td> <td>-</td> <td>-</td> </tr> </table>	PIN	MDM	APP	→	Last	+	+	+	-	-	<table border="1"> <tr> <td>Reference(s)</td> </tr> <tr> <td>3GPP TS 27.007 [48]</td> </tr> </table>	Reference(s)	3GPP TS 27.007 [48]
PIN	MDM	APP	→	Last									
+	+	+	-	-									
Reference(s)													
3GPP TS 27.007 [48]													

Parameter Description

<code><rssi></code> ^(num)	
0	-113 dBm or less
1	-111 dBm
2..30	-109... -53 dBm
31	-51 dBm or greater
99	not known or not detectable

According to 3GPP TS 27.007 [48], the `<rssi>` value is not applicable to 3G and 4G networks. Please use `AT+CESQ` instead, or `AT^SMONI`.

Note for 3G only: With a view to employing `AT+CSQ` also for 3G networks the PLS8-X has been designed to show a `<rssi>` value derived from the 3G specific RSCP parameter shown by `AT^SMONI`. Nevertheless, please consider that connection quality in 3G networks is depending on further factors. For example, despite good `<rssi>` or RSCP values for signal quality, data throughput may vary depending on the number of subscribers sharing the same cell. It is therefore recommended to use also `AT^SMONI` which delivers additional information, in particular the values RSCP, EC/n0, SQual and SRxLev RX level.

<code><ber></code> ^(num)	
0..7	as RXQUAL values in the table in 3GPP TS 45.008 [52], section 8.2.4 (for GSM network only).
99	not known or not detectable.

7.8 AT+CTZU Automatic Time Zone Update

The [AT+CTZU](#) command enables and disables automatic time zone update via NITZ (if supported by the network).

When [AT+CTZU](#) is set to 1, the Real Time Clock (RTC) on the UE is constantly updated with the network time. Any changes to the RTC using the command [AT+CCLK](#) will be wiped out by the network time.

When [AT+CTZU](#) is set to 0, [AT+CCLK](#) can be used to set the RTC. The newly set time will not be overwritten by the network time.

The [AT^SIND](#) command can also be used to get NITZ information, for details see "nitz" indicator. Unlike [AT+CTZU](#), [AT^SIND](#) settings have no effect for the RTC.

Syntax

<p>Test Command</p> <p>AT+CTZU=?</p> <p>Response(s)</p> <p>+CTZU: (list of supported <n>s)</p> <p>OK</p>											
<p>Read Command</p> <p>AT+CTZU?</p> <p>Response(s)</p> <p>+CTZU: <n></p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>											
<p>Write Command</p> <p>AT+CTZU=<n></p> <p>Response(s)</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>-</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	-	+	+	+	-	<p>Reference(s)</p> <p>3GPP TS 27.007 [48]</p>
PIN	MDM	APP	→	Last							
-	+	+	+	-							

Unsolicited Result Code

Format of the unsolicited result code:

+CTZU:<nitzUT>, <nitzTZ> [, <nitzDST>]

The URC indicates the time relevant information elements of the NITZ message.

Parameter Description

<n>^(num)	
0(&F)	Suppress unsolicited result codes
1	Output unsolicited result codes
<nitzUT>^(str)	
Universal Time delivered as part of the NITZ message.	

<nitzTZ>^(num)

Time Zone delivered as part of the NITZ message.

<nitzDST>^(num)

Adjustment for Daylight Saving Time as part of the NITZ message. Displayed only when received from network.

7.9 AT^SMONI Monitoring Serving Cell

The `AT^SMONI` command supplies information of the serving cell.

Syntax

Test Command
<code>AT^SMONI=?</code>
Response(s)
OK
Exec Command
<code>AT^SMONI</code>
Response(s)
See: Section 7.9.1, AT^SMONI Responses
OK
Write Command
<code>AT^SMONI=255</code>
Response(s)
See: Section 7.9.2, AT^SMONI Enhanced Responses
OK
ERROR
+CME ERROR: <code><err></code>
PIN MDM APP → Last
- + + - -

Notes

- The parameters LAC and cell are presented as hexadecimal digits, the remaining parameters are composed of decimal digits.
- If the BS supports frequency hopping during a connection, the dedicated channel (ARFCN) is not stable. This mode is indicated by `chann = 'h'`.
- It may happen for a short time that following parameters have no values after an inter-system change from GSM to UMTS: EC/n0, RSCP, SQual and SRxLev. In this case these parameter values are displayed with the "-" character.
- The service state 'SEARCH' (Searching) could mean a PLMN search or a cell search. This can also happen for a short time when UE is leaving connected mode.
- The value of the TransportCh field is valid only for the moment, and can change frequently.

7.9.1 AT^SMONI Responses

UE is not connected:

- UE is camping on a GSM (2G) cell:

```
Syntax:
^SMONI: ACT,ARFCN,BCCH,MCC,MNC,LAC,cell,C1,C2,NCC,BCC,GPRS,ARFCN,TS,timAdv,dBm,Q,ChMod
Example:
^SMONI: 2G,71,-61,262,02,0143,83BA,33,33,3,6,G,NOCONN
```

- UE is camping on a UMTS (3G) cell:

Syntax:

```
^SMONI: ACT, UARFCN, PSC, EC/n0, RSCP, MCC, MNC, LAC, cell, SQual, SRxLev, CSGid, TransportCh, SF, Slot, EC/n0, RSCP, ComMod, HSUPA, HSDPA
```

Example:

```
^SMONI: 3G,10564,296,-7.5,-79,262,02,0143,00228FF,-92,-78,--,NOCONN
```

- UE is camping on a LTE (4G) cell:

Syntax:

```
^SMONI: ACT, EARFCN, Band, DL bandwidth, UL bandwidth, Mode, MCC, MNC, TAC, Global Cell ID, Physical Cell ID, Srxlev, RSRP, RSRQ, Conn_state
```

Example:

```
^SMONI: 4G,6300,20,10,10,FDD,262,02,BF75,0345103,350,33,-94,-7,NOCONN
```

- UE is searching and could not (yet) find a suitable GSM (2G) cell:

Syntax:

```
^SMONI: ACT, ARFCN, BCCH, MCC, MNC, LAC, cell, C1, C2, NCC, BCC, GPRS, ARFCN, TS, timAdv, dBm, Q, ChMod
```

Example:

```
^SMONI: 2G,SEARCH,SEARCH
```

- UE is searching and could not (yet) find a suitable UMTS (3G) cell:

Syntax:

```
^SMONI: ACT, UARFCN, PSC, EC/n0, RSCP, MCC, MNC, LAC, cell, SQual, SRxLev, CSGid, TransportCh, SF, Slot, EC/n0, RSCP, ComMod, HSUPA, HSDPA
```

Example:

```
^SMONI: 3G,SEARCH,SEARCH
```

- UE is searching and could not (yet) find a suitable LTE (4G) cell:

Syntax:

```
^SMONI: ACT, EARFCN, Band, DL bandwidth, UL bandwidth, Mode, MCC, MNC, TAC, Global Cell ID, Physical Cell ID, Srxlev, RSRP, RSRQ, Conn_state
```

Example:

```
^SMONI: 4G,SEARCH
```

- UE is camping on a GSM cell but not registered to the network (only emergency call allowed):

Syntax:

```
^SMONI:
```

```
ACT, ARFCN, BCCH, MCC, MNC, LAC, cell, C1, C2, NCC, BCC, GPRS, PWR, RXLev, ARFCN, TS, timAdv, dBm, Q, ChMod
```

Example:

```
^SMONI: 2G,673,-89,262,07,4EED,A500,16,16,7,4,G,5,-107,LIMSRV
```

- UE is camping on a UMTS cell but not registered to the network (only emergency call allowed):

Syntax:

```
^SMONI: ACT, UARFCN, PSC, EC/n0, RSCP, MCC, MNC, LAC, cell, SQual, SRxLev, CSGid, TransportCh, SF, Slot, EC/n0, RSCP, ComMod, HSUPA, HSDPA
```

Example:

```
^SMONI: 3G,10564,96,-7.5,-79,262,02,0143,00228FF,-92,-78,--,LIMSRV
```

- UE is camping on a LTE (4G) cell but not registered to the network (only emergency call allowed):

Syntax:

```
^SMONI: ACT, EARFCN, Band, DL bandwidth, UL bandwidth, Mode, MCC, MNC, TAC, Global Cell ID, Physical Cell ID, Srxlev, RSRP, RSRQ, Conn_state
```

Example:

```
^SMONI: 4G,6300,20,10,10,FDD,262,02,BF75,0345103,350,33,-94,-7,LIMSRV
```

UE has a dedicated channel (for example call in progress):

- GSM (2G) cell:

Syntax:

`^SMONI: ACT,ARFCN,BCCH,MCC,MNC,LAC,cell,C1,C2,NCC,BCC,GPRS,ARFCN,TS,timAdv,dBm,Q,ChMod`

Example:

`^SMONI: 2G,673,-80,262,07,4EED,A500,35,35,7,4,G,643,4,0,-80,0,S_FR`

- UMTS (3G) cell:

Syntax:

`^SMONI: ACT,UARFCN,PSC,EC/n0,RSCP,MCC,MNC,LAC,cell,SQual,SRxLev,CSGid,TransportCh,SF,Slot,EC/n0,RSCP,ComMod,HSUPA,HSDPA`

Example:

`^SMONI: 3G,10737,131,-5,-93,260,01,7D3D,C80BC9A,21,11,--,EDCH,256,4,-5,-93,0,01,06`

- LTE (4G) cell:

Syntax:

`^SMONI: ACT,EARFCN,Band,DL bandwidth,UL bandwidth,Mode,MCC,MNC,TAC,Global Cell ID,Physical Cell ID,TX_power,RSRP,RSRQ,Conn_state`

Example:

`^SMONI: 4G,6300,20,10,10,FDD,262,02,BF75,0345103,350,90,-94,-7,CONN`

Columns for GSM (2) Serving Cell parameters:

Column	Description
ACT	Access Technology
ARFCN	ARFCN (Absolute Radio Frequency Channel Number) of the BCCH carrier
BCCH	Receiving level of the BCCH carrier in dBm (level is limited from -110dBm to -47dBm)
MCC	Mobile Country Code (first part of the PLMN code)
MNC	Mobile Network Code (second part of the PLMN code)
LAC	Location Area Code
cell	Cell ID
C1	Coefficient for base station selection
C2	Coefficient for base station selection
NCC	PLMN colour code
BCC	Base station colour code
GPRS	GPRS state

Columns for UMTS (3G) Serving Cell parameters:

Column	Description
ACT	Access Technology
UARFCN	UARFCN (UTRAN Absolute Radio Frequency Channel Number) of the BCCH carrier
PSC	Primary Scrambling Code
EC/n0	Carrier to noise ratio in dB = measured Ec/Io value in dB. Please refer to 3GPP 25.133, section 9.1.2.3, Table 9.9 for details on the mapping from EC/n0 to Ec/Io.
RSCP	Received Signal Code Power in dBm
MCC	Mobile Country Code (first part of the PLMN code)
MNC	Mobile Network Code (second part of the PLMN code)

Column	Description
LAC	Location Area Code
cell	Cell ID
SQual	Quality value for base station selection in dB (see 3GPP 25.304)
SRxLev	RX level value for base station selection in dB (see 3GPP 25.304)
CSGid	Closed Subscriber Group id

Columns for GSM (2G) Dedicated Channel parameters:

Column	Description
ARFCN	ARFCN (Absolute Radio Frequency Channel Number) of the BCCH carrier
TS	Timeslot number
timAdv	Timing advance in bits
dBm	Receiving level of the traffic channel carrier in dBm
Q	Receiving quality (0-7)
ChMod	Channel mode (--: Signalling, S_HR: Half rate, S_FR: Full rate, S_EFR: Enhanced Full Rate, A_HR: AMR Half rate, A_FR: AMR Full rate)

Columns for UMTS (3G) Dedicated Channel parameters:

Note: Transport channels in downlink are considered.

Column	Description
TransportCh	Transport Channel Type (DPCH, FDPCH, HSDSCH, EDCH)
SF	Spreading Factor (4,8,16,32,64,128,256,512)
Slot	Slot Format for DPCH (0-16) (see 3GPP TS 25.211 V7.10.0 Table 11) Slot Format for FDPCH (0-9) (see 3GPP TS 25.211 V7.10.0 Table 16C)
EC/n0	Carrier to noise ratio in dB
RSCP	Received Signal Code Power in dBm
ComMod	Compressed Mode (0-1) (indicates valid transmission gap pattern)
HSUPA	HSUPA Status (a.k.a. E-DCH Status) indicated by xy: x = Cell Capability Indicator: 0 - HSUPA capability not indicated, 1 - HSUPA Capable Cell. Please consider that some providers/MNOs don't support this flag and that it is provided "for display indication only", see 3GPP TS 25.331 [46] (later than version 6.9.0) section 10.2.48.8.8. y = UE Call Status: 0 - HSUPA inactive, 1 - HSUPA active
HSDPA	HSDPA Status (a.k.a. HSDSCH Status) indicated by xy: x = Cell Capability Indicator: 0 - HSDPA capability not indicated, 1 - HSDPA Capable Cell. Please consider that some providers/MNOs don't support this flag and that it is provided "for display indication only", see 3GPP TS 25.331 [46] (later than version 6.8.0), section 10.2.48.8.8. y = UE Call Status: 0 - HSDPA inactive, 1 - HSDPA suspended, 2 - HSDPA active, 6 - HSDPA+ active

Columns for LTE (4G) Serving Channel parameters:

Column	Description
EARFCN	E-UTRA Absolute Radio Frequency Channel Number
Band	E-UTRA frequency band (see 3GPP 36.101)
DL bandwidth	DL bandwidth
UL bandwidth	UL bandwidth
Mode	FDD or TDD
MCC	Mobile Country Code (first part of the PLMN code)
MNC	Mobile Network Code (second part of the PLMN code)
TAC	Tracking Area Code (see 3GPP 23.003 Section 19.4.2.3)
Global Cell ID	Global Cell ID
Physical Cell ID	Physical Cell ID
Srxlev	RX level value for base station selection in dB (see 3GPP 25.304)
RSRP	Reference Signal Received Power (see 3GPP 36.214 Section 5.1.1.)
RSRQ	Reference Signal Received Quality (see 3GPP 36.214 Section 5.1.2.)
TX power	Used Uplink Power
Conn_state	Connection state. Can be one of following: CONN, LIMSRV, NOCONN or SEARCH

7.9.2 AT^SMONI Enhanced Responses

The `AT^SMONI=255` write command supplies information of the serving and dedicated cell.

UE is not connected:

- UE is camping on a GSM (2G) cell and registered to the network:

```
Syntax:
^SMONI:
ACT, ARFCN, BCCH, MCC, MNC, LAC, cell, C1, C2, NCC, BCC, GPRS, PWR, RXLev, ARFCN, TS, timAdv, dBm, Q, ChM
od
Example:
^SMONI: 2G,990,-75,262,03,0139,02C9,28,28,3,0,G,0,-104,NOCONN
```

- UE is camping on a UMTS (3G) cell and registered to the network:

```
Syntax:
^SMONI: ACT, UARFCN, PSC, EC/n0, RSCP, MCC, MNC, LAC, cell, SQual, SRxLev, CSGid, TransportCh,
SF, Slot, EC/n0, RSCP, ComMod, HSUPA, HSDPA
Example:
^SMONI: 3G,10737,131,-7.5,-103,260,01,7D3D,C80BC9A,21,11,--,NOCONN
```

- UE is camping on a LTE (4G) cell and registered to the network:

```
Syntax:
^SMONI: ACT, EARFCN, Band, DL bandwidth, UL bandwidth, Mode, MCC, MNC, TAC, Global Cell ID, Phys-
ical Cell ID, Srxlev, RSRP, RSRQ, Conn_state
Example:
^SMONI: 4G,6300,20,10,10,FDD,262,02,BF75,0345103,350,33,-94,-7,NOCONN
```

- UE is searching and could not (yet) find a suitable cell:
See Section 7.9.1, [AT^SMONI Responses](#).
- UE is camping on a GSM cell but not registered to the network (only emergency call allowed):

```
Syntax:
^SMONI:
ACT,ARFCN,BCCH,MCC,MNC,LAC,cell,C1,C2,NCC,BCC,GPRS,PWR,RXLev,ARFCN,TS,timAdv,dBm,Q,ChM
od
Example:
^SMONI: 2G,673,-89,262,07,4EED,A500,16,16,7,4,G,5,-107,LIMSRV
```

- UE is camping on a UMTS cell but not registered to the network (only emergency call allowed):

```
Syntax:
^SMONI: ACT,UARFCN,PSC,EC/n0,RSCP,MCC,MNC,LAC,cell,SQual,SRxLev,CSGid,TransportCh,
SF,Slot,EC/n0,RSCP,ComMod,HSUPA,HSDPA
Example:
^SMONI: 3G,10564,96,-7.5,-79,262,02,0143,00228FF,-92,-78,--,LIMSRV
```

- UE is camping on a LTE (4G) cell but not registered to the network (only emergency call allowed):

```
Syntax:
^SMONI: ACT,EARFCN,Band,DL bandwidth,UL bandwidth,Mode,MCC,MNC,TAC,Global Cell ID,Phys-
ical Cell ID,Srxlev,RSRP,RSRQ,Conn_state
Example:
^SMONI: 4G,6300,20,10,10,FDD,262,02,BF75,0345103,350,33,-94,-7,LIMSRV
```

UE has a dedicated channel (for example call in progress):

- GSM (2G) cell:

```
Syntax:
^SMONI:
ACT,ARFCN,BCCH,MCC,MNC,LAC,cell,C1,C2,NCC,BCC,GPRS,PWR,RXLev,ARFCN,TS,timAdv,dBm,Q,ChM
od
Example:
^SMONI: 2G,852,-80,262,03,4E2D,6C2D,28,32,3,5,E,0,-104,816,1,3,-71,0,A_FR
```

- UMTS (3G) cell:

```
Syntax:
^SMONI: ACT,UARFCN,PSC,EC/n0,RSCP,MCC,MNC,LAC,cell,SQual,SRxLev,CSGid,TransportCh,
SF,Slot,EC/n0,RSCP,ComMod,HSUPA,HSDPA
Example:
^SMONI: 3G,10737,131,-5,-93,260,01,7D3D,C80BC9A,21,11,--,DPCH,256,4,-5,-93,0,00,00
```

- LTE (4G) cell:

```
Syntax:
^SMONI: ACT,EARFCN,Band,DL bandwidth,UL bandwidth,Mode,MCC,MNC,TAC,Global Cell ID,Phys-
ical Cell ID,TX_power,RSRP,RSRQ,Conn_state
Example:
^SMONI: 4G,6300,20,10,10,FDD,262,02,BF75,0345103,350,90,-94,-7,CONN
```

Columns for GSM (2G) Serving Cell parameters:

Column	Description
ACT	Access Technology
ARFCN	ARFCN (Absolute Radio Frequency Channel Number) of the BCCH carrier
BCCH	Receiving level of the BCCH carrier in dBm (level is limited from -110dBm to -47dBm)
MCC	Mobile Country Code (first part of the PLMN code)
MNC	Mobile Network Code (second part of the PLMN code)

Column	Description
LAC	Location Area Code
cell	Cell ID
C1	Coefficient for base station selection
C2	Coefficient for base station selection
NCC	PLMN colour code
BCC	Base station colour code
GPRS	GPRS state
PWR	Maximal power level used on RACH channel in dBm
RxLev	Minimal receiving level (in dBm) to allow registration

Columns for UMTS (3G) Serving Cell parameters:

Column	Description
ACT	Access Technology
UARFCN	UARFCN (UTRAN Absolute Radio Frequency Channel Number) of the BCCH carrier
PSC	Primary Scrambling Code
EC/n0	Carrier to noise ratio in dB = measured Ec/Io value in dB. Please refer to 3GPP 25.133, section 9.1.2.3, Table 9.9 for details on the mapping from EC/n0 to EC/Io.
RSCP	Received Signal Code Power in dBm
MCC	Mobile Country Code (first part of the PLMN code)
MNC	Mobile Network Code (second part of the PLMN code)
LAC	Location Area Code, see note
cell	Cell ID
SQual	Quality value for base station selection in dB (see 3GPP 25.304)
SRxLev	RX level value for base station selection in dB (see 3GPP 25.304)
CSGid	Closed Subscriber Group id

Columns for GSM (2G) Dedicated Channel parameters:

Column	Description
ARFCN	ARFCN (Absolute Radio Frequency Channel Number) of the BCCH carrier
TS	Timeslot number
timAdv	Timing advance in bits
dBm	Receiving level of the traffic channel carrier in dBm
Q	Receiving quality (0-7)
ChMod	Channel mode (--: Signalling, S_HR: Half rate, S_FR: Full rate, S_EFR: Enhanced Full Rate, A_HR: AMR Half rate, A_FR: AMR Full rate)

Columns for UMTS (3G) Dedicated Channel parameters:
Note: Transport channels in downlink are considered.

Column	Description
TransportCh	Transport Channel Type (DPCH, FDPCH, HSDSCH, EDCH)
SF	Spreading Factor (4,8,16,32,64,128,256,512)
Slot	Slot Format for DPCH (0-16) (see 3GPP TS 25.211 V7.10.0 Table 11) Slot Format for FDPCH (0-9) (see 3GPP TS 25.211 V7.10.0 Table 16C)
EC/n0	Carrier to noise ratio in dB
RSCP	Received Signal Code Power in dBm
ComMod	Compressed Mode (0-1) (indicates valid transmission gap pattern)
HSUPA	HSUPA Status (a.k.a. E-DCH Status) indicated by xy: x = Cell Capability Indicator: 0 - HSUPA capability not indicated, 1 - HSUPA Capable Cell. Please consider that some providers/MNOs don't support this flag and that it is provided "for display indication only", see 3GPP TS 25.331 [46] (later than version 6.9.0) section 10.2.48.8.8. y = UE Call Status: 0 - HSUPA inactive, 1 - HSUPA active
HSDPA	HSDPA Status (a.k.a. HSDSCH Status) indicated by xy: x = Cell Capability Indicator: 0 - HSDPA capability not indicated, 1 - HSDPA Capable Cell. Please consider that some providers/MNOs don't support this flag and that it is provided "for display indication only", see 3GPP TS 25.331 [46] (later than version 6.8.0), section 10.2.48.8.8. y = UE Call Status: 0 - HSDPA inactive, 1 - HSDPA suspended, 2 - HSDPA active, 6 - HSDPA+ active

Columns for LTE (4G) Serving Channel parameters:

Column	Description
EARFCN	E-UTRA Absolute Radio Frequency Channel Number
Band	E-UTRA frequency band (see 3GPP 36.101)
DL bandwidth	DL bandwidth
UL bandwidth	UL bandwidth
Mode	FDD or TDD
MCC	Mobile Country Code (first part of the PLMN code)
MNC	Mobile Network Code (second part of the PLMN code)
TAC	Tracking Area Code (see 3GPP 23.003 Section 19.4.2.3)
Global Cell ID	Global Cell ID
Physical Cell ID	Physical Cell ID
Srxlev	RX level value for base station selection in dB (see 3GPP 25.304)
RSRP	Reference Signal Received Power (see 3GPP 36.214 Section 5.1.1.)
RSRQ	Reference Signal Received Quality (see 3GPP 36.214 Section 5.1.2.)
TX power	Used Uplink Power
Conn_state	Connection state. Can be one of following: CONN, LIMSRV, NOCONN or SEARCH

7.9.3 Service states

Depending on the service state, an additional textual output is generated (refer also to the response examples):

- "SEARCH" (Searching) - The MS is searching, but could not (yet) find a suitable cell. This output appears

after restart of the MS or after loss of coverage.

- "NOCONN" (No connection) - The MS is camping on a cell and registered to the network. The service state is 'idle', i.e. there is no connection established or a dedicated channel in use.
- "LIMSRV" (Limited Service) - The MS is camping on a cell but not registered to the network. Only emergency calls are allowed. The MS enters this state, for example, when
 - no SIM card is inserted, or PIN has not been given,
 - neither Home PLMN nor any other allowed PLMN are found,
 - registration request was not answered or denied by the network (use [AT+CREG](#) [AT+CEREG](#) to query the registration status),
 - authentication failed.

7.10 AT^SMONP Monitoring Neighbour Cells

The `AT^SMONP` supplies information of active cells and all neighbour cells. The active cell information will be delivered additively because an UE can be situated in Soft Handover or Softer Handover.

Syntax

Test Command
<code>AT^SMONP=?</code>
Response(s)
OK
Exec Command
<code>AT^SMONP</code>
Response(s)
See: Section 7.10.1, AT^SMONP Responses
OK
Write Command
<code>AT^SMONP=255</code>
Response(s)
See: Section 7.10.2, AT^SMONP Enhanced Responses
OK
ERROR
+CME ERROR: <err>
PIN MDM APP → Last
- + + - -

Notes

- Due to the fact that not all necessary information of the neighbour cells can be decoded during a connection, there are several constraints to be considered:
 - Only neighbour cells that have already been visible in IDLE mode will be further updated, as long as they are still included in the list.
 - Though new neighbour cells can be added to the list (e.g. due to handover), their C1 and C2 parameters cannot be displayed until the connection is released. In this case "-" is presented for C1 and C2.
- The neighbour cells have the same PLMN as the serving cell. In case of searching for a network the serving cell can change and the UE shows different sets of neighbour cells depending on the PLMN of the serving cell.
- Parameters for which no values are available are shown as "-".

7.10.1 AT^SMONP Responses

Responses of `AT^SMONP` execute command:

- In case of a GSM (2G) serving cell:

```
Syntax:
2G:
ARFCN1, rs1, dBm1, MCC1, MNC1, NCC1, BCC1, C11, C21, LAC1, cell1
ARFCN2, rs2, dBm2, MCC2, MNC2, NCC2, BCC2, C12, C22, LAC2, cell2
...
ARFCNn, rsn, dBmn, MCCn, MNCn, NCCn, BCCn, C1n, C2n, LACn, celln
3G:
```

```
UARFCN1, PSC1, EC/n01, RSCP1  
UARFCN2, PSC2, EC/n02, RSCP2  
...  
UARFCNn, PSCn, EC/n0n, RSCPn
```

```
4G:  
EARFCN1, RSRQ1, RSRP1, PCI1  
EARFCN2, RSRQ2, RSRP2, PCI2  
...  
EARFCNn, RSRQn, RSRPn, PCIn
```

Example:

```
2G:  
658,50,-61,262,07,7,4,45,45,4EED,08B8  
666,48,-63,262,07,7,1,43,43,4EED,A500  
1006,39,-72,262,07,7,4,34,34,4EED,----  
1021,36,-75,262,07,7,1,31,21,4EED,08B2  
702,32,-79,262,07,7,3,27,27,4EED,A4F0  
654,30,-81,262,07,7,5,25,25,4EED,1C3A  
3G:  
-----,---,-----,---  
4G:  
-----,-----,-----,---  
OK
```

- In case of a UMTS (3G) serving cell:

Syntax:

```
3G:  
UARFCN1, PSC1, EC/n01, RSCP1, SQual1, SRxLev1  
UARFCN2, PSC2, EC/n02, RSCP2, SQual2, SRxLev2  
...  
UARFCNn, PSCn, EC/n0n, RSCPn, SQualn, SRxLevn
```

```
2G:  
ARFCN1, RSSI1, NCC1, BCC1, SRxLev1  
ARFCN2, RSSI2, NCC2, BCC2, SRxLev2  
...  
ARFCNn, RSSIn, NCCn, BCCn, SRxLevn
```

```
4G:  
EARFCN1, RSRQ1, RSRP1, Srxlev1, PCI1  
EARFCN2, RSRQ2, RSRP2, Srxlev2, PCI2  
...  
EARFCNn, RSRQn, RSRPn, Srxlevn, PCIn
```

Example:

```
3G:  
10786,49,-5.5,-78,25,34  
10786,161,-24.0,-121,0,0  
10786,54,-24.0,-121,0,0  
10786,51,-24.0,-121,0,0  
10786,62,-24.0,-121,0,0  
10786,159,-24.0,-121,0,0  
2G:  
-----,-----,-----,---
```

```
4G:
-----,-----,-----,-----,-----
OK
```

- In case of a LTE (4G) serving cell:

```
Syntax:
4G:
EARFCN1,RSRQ1,RSRP1,Srxlev1,PCI1,RSSI1
EARFCN2,RSRQ2,RSRP2,Srxlev2,PCI2,RSSI2
...
EARFCNn,RSRQn,RSRPn,Srxlevn,PCIn,RSSIn

2G:
ARFCN1,RSSI1,NCC1,BCC1,SRxLev1
ARFCN2,RSSI2,NCC2,BCC2,SRxLev2
...
ARFCNn,RSSIn,NCCn,BCCn,SRxLevn

3G:
UARFCN1,PSC1,EC/n01,RSCP1,SQual1,SRxLev1
UARFCN2,PSC2,EC/n02,RSCP2,SQual2,SRxLev2
...
UARFCNn,PSCn,EC/n0n,RSCPn,SQualn,SRxLevn

Example:
4G:
1830,-11.7,-91,38,368,-61
1830,-11.6,-93,36,262,-72
1830,-11.7,-95,35,329,-74
1830,-14.3,-95,34,261,-72
1830,-18.4,-105,24,248,-74
2G:
-----,-----,-----,-----,-----
3G:
-----,-----,-----,-----,-----
OK
```

Columns for GSM (2G) parameters:

Column	Description
ARFCN	Absolute Radio Frequency Channel Number of the BCCH carrier
rs	RSSI value 0 - 63 (RSSI = Received signal strength indication)
dBm	Receiving level in dBm
MCC	Mobile Country Code (first part of the PLMN code)
MNC	Mobile Network Code (second part of the PLMN code)
NCC	Network colour Code
BCC	Base Station colour code
C1	cell selection criterion
C2	cell reselection criterion
LAC	Location area code
cell	Cell identifier

Columns for UMTS (3G) parameters:

Column	Description
UARFCN	UTRAN Absolute Radio Frequency Channel Number of the BCCH carrier
PSC	Primary Scrambling Code
EC/n0	Carrier to noise ratio in dB = measured Ec/Io value in dB. Please refer to 3GPP 25.133, section 9.1.2.3, Table 9.9 for details on the mapping from EC/n0 to EC/Io.
RSCP	Received Signal Code Power in dBm
SQual	Quality value for base station selection in dB (see 3GPP 25.304)
SRxLev	RX level value for base station selection in dB (see 3GPP 25.304)

Columns for LTE (4G) parameters:

Column	Description
EARFCN	E-UTRA Absolute Radio Frequency Channel Number
RSRQ	Reference Signal Received Quality as measured by L1 in dB (see ETSI TS 136 214 version 10.1.0 Section 5.1.3.)
RSRP	Reference Signal Received Power as measured by L1 in dBm (see ETSI TS 136 214 version 10.1.0 Section 5.1.1.)
Srxlev	RX level value for base station selection in dB (see 3GPP 25.304)
PCI	Physical Cell ID
RSSI	Received Signal Strength Indication as measured by L1 in dBm

7.10.2 AT^SMONP Enhanced Responses

Responses of write command `AT^SMONP=255:`

- In case of a GSM (2G) serving cell:

```
Syntax:
2G:
UARFCN1, rs1, dBm1, MCC1, MNC1, NCC1, BCC1, C11, C21, LAC1, cell1, C311, C321
UARFCN2, rs2, dBm2, MCC2, MNC2, NCC2, BCC2, C12, C22, LAC2, cell2, C312, C322
...
UARFCNn, rsn, dBmn, MCCn, MNCn, NCCn, BCCn, C1n, C2n, LACn, celln, C31n, C32n
3G:
UARFCN1, PSC1, EC/n01, RSCP1
UARFCN2, PSC2, EC/n02, RSCP2
...
UARFCNn, PSCn, EC/n0n, RSCPn
4G:
EARFCN1, RSRQ1, RSRP1, PCI1
EARFCN2, RSRQ2, RSRP2, PCI2
...
EARFCNn, RSRQn, RSRPn, PCIn
```

Example:

```
2G:
658,51,-60,262,07,7,4,46,46,4EED,08B8,0,0
666,47,-64,262,07,7,1,42,42,4EED,A500,0,0
1006,37,-74,262,07,7,4,32,32,4EED,----,0,0
1021,36,-75,262,07,7,1,31,21,4EED,08B2,0,0
702,33,-78,262,07,7,3,28,28,4EED,A4F0,0,0
654,32,-79,262,07,7,5,27,27,4EED,1C3A,0,0
3G:
-----,-----,-----
4G:
-----,-----,-----
OK
```

- In case of a 3G serving cell:

Syntax:

```
3G:
UARFCN1,PSC1,EC/n01,RSCP1,SQual1,SRxLev1,set1,rank1
UARFCN2,PSC2,EC/n02,RSCP2,SQual2,SRxLev2,set2,rank2
...
UARFCNn,PSCn,EC/n0n,RSCPn,SQualn,SRxLevn,setn,rankn

2G:
ARFCN1,RSSI1,NCC1,BCC1,SRxLev1,rank1
ARFCN2,RSSI2,NCC2,BCC2,SRxLev2,rank2
...
ARFCNn,RSSIn,NCCn,BCCn,SRxLevn,rankn

4G:
EARFCN1,RSRQ1,RSRP1,Srxlev1,PCI1,TDD1
EARFCN2,RSRQ2,RSRP2,Srxlev2,PCI2,TDD2
...
EARFCNn,RSRQn,RSRPn,Srxlevn,PCIn,TDDn
```

Example:

```
3G:
10786,49,-7.0,-75,22,37,AS,-9
10786,161,-24.0,-121,0,0,--,0
10786,54,-24.0,-121,0,0,--,0
10786,51,-24.0,-121,0,0,--,0
10786,62,-24.0,-121,0,0,--,0
10786,159,-24.0,-121,0,0,--,0
2G:
-----,-----,-----
4G:
-----,-----,-----
OK
```

- In case of a 4G serving cell:

Syntax:

```
4G:
EARFCN1,RSRQ1,RSRP1,Srxlev1,PCI1,RSSI1,Cell ID1,MCC1,MNC1,TAC1
EARFCN2,RSRQ2,RSRP2,Srxlev2,PCI2,RSSI2,Cell ID2,MCC2,MNC2,TAC2
...
EARFCNn,RSRQn,RSRPn,Srxlevn,PCIn,RSSIn,Cell IDn,MCCn,MNCn,TACn
```

```

2G:
ARFCN1, RSSI1, NCC1, BCC1, SRxLev1, rank1
ARFCN2, RSSI2, NCC2, BCC2, SRxLev2, rank2
...
ARFCNn, RSSIn, NCCn, BCCn, SRxLevn, rankn

3G:
UARFCN1, PSC1, EC/n01, RSCP1, SQual1, SRxLev1, set1, rank1
UARFCN2, PSC2, EC/n02, RSCP2, SQual2, SRxLev2, set2, rank2
...
UARFCNn, PSCn, EC/n0n, RSCPn, SQualn, SRxLevn, setn, rankn
    
```

Example:

```

4G:
1830, -12.6, -91, 38, 368, -60, 368, 262, 03, C463
1830, -11.7, -93, 36, 262, -72, 368, 262, 03, C463
1830, -10.9, -93, 36, 329, -73, 368, 262, 03, C463
1830, -15.1, -96, 33, 261, -72, 368, 262, 03, C463
2G:
-----,-----,-----,--
3G:
-----,-----,-----,--
OK
    
```

Columns for GSM (2G) parameters:

Column	Description
ARFCN	Absolute Radio Frequency Channel Number of the BCCH carrier
rs	RSSI value 0 - 63 (RSSI = Received signal strength indication)
dBm	Receiving level in dBm
MCC	Mobile Country Code (first part of the PLMN code)
MNC	Mobile Network Code (second part of the PLMN code)
NCC	Network colour Code
BCC	Base Station colour code
C1	cell selection criterion
C2	cell reselection criterion
LAC	Location area code
cell	Cell identifier
C31	cell reselection criterion
C32	cell reselection criterion
SRxLev	RX level value for base station selection in dB (see 3GPP 25.304)
rank	Rank of this cell as neighbor for inter-RAT cell reselection

Columns for UMTS (3G) parameters:

Column	Description
UARFCN	UTRAN Absolute Radio Frequency Channel Number of the BCCH carrier
PSC	Primary Scrambling Code
EC/n0	Carrier to noise ratio in dB = measured Ec/Io value in dB. Please refer to 3GPP 25.133, section 9.1.2.3, Table 9.9 for details on the mapping from EC/n0 to EC/Io.
RSCP	Received Signal Code Power in dBm
SQual	Quality value for base station selection in dB (see 3GPP 25.304)
SRxLev	RX level value for base station selection in dB (see 3GPP 25.304)
set	3G neighbour cell set (AS: ASET, SN: Sync Nset, AN: Async Nset)
rank	Rank of this cell as neighbor for inter-RAT cell reselection

Columns for LTE (4G) parameters:

Column	Description
EARFCN	E-UTRA Absolute Radio Frequency Channel Number
RSRQ	Reference Signal Received Quality as measured by L1 in dB (see ETSI TS 136 214 version 10.1.0 Section 5.1.3.)
RSRP	Reference Signal Received Power as measured by L1 in dBm (see ETSI TS 136 214 version 10.1.0 Section 5.1.1.)
Srxlev	RX level value for base station selection in dB (see 3GPP 25.304)
PCI	Physical Cell ID
RSSI	Received Signal Strength Indication as measured by L1 in dBm
Cell ID	LTE Serving cell ID
MCC	Mobile Country Code
MNC	Mobile Network Code
TAC	Tracking Area Code (see 3GPP 23.003 Section 19.4.2.3)

7.11 AT^SNMON Network Monitoring

The [AT^SNMON](#) command can be used to monitor various network information.

Syntax

<p>Test Command</p> <pre>AT^SNMON=?</pre> <p>Response(s)</p> <pre>^SNMON: "PDM", (list of supported <action>s), (list of supported <ta>s), (list of supported <nom>s), (list of supported <rac>s), (list of supported <dsac_avail>s), (list of supported <dsac_cs>s), (list of supported <dsac_ps>s), (list of supported <tac_avail>s), (range of supported <tac>s) OK ERROR +CME ERROR: <err></pre>	<p>Write Command</p> <p>Start Packet Data Monitor. <action> shall be 2.</p> <pre>AT^SNMON="PDM", <action></pre> <p>Response(s)</p> <pre>[^SNMON: "PDM", <reserved>, <ta>, <nom>, <rac>, <dsac_avail>, <dsac_cs>, <dsac_ps>, <tac_avail>, <tac>] OK ERROR +CME ERROR: <err></pre>										
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>-</td> <td>+</td> <td>+</td> <td>-</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	-	+	+	-	-	<p>Reference(s)</p> <p>3GPP TS 45.008 [52]</p>
PIN	MDM	APP	→	Last							
-	+	+	-	-							

Parameter Description

<action>^(num)	
This parameter determines the action to be taken for the monitoring command.	
0	Reset values
1	Set values
2	Query values
<reserved>^(num)	
0	Value returned in scan output responses. Value has no meaning and can be ignored.
<tac>^(num)	
Tracking Area Code (see 3GPP 23.003 Section 19.4.2.3)	
<ta>^(num)	
Timing Advance (TA)	
-1 ^(P)	Information is not available
0...63	

<nom>^(num)

Network Operation Mode (NOM)

-1 ^(P)	Information is not available
1	NOM1
2	NOM2
3	NOM3

<rac>^(num)

Routing Area Code (RAC)

-1	Information is not available
0...255	

<dsac_avail>^(num)

Domain Specific Access Control (DSAC) availability

0	DSAC not available
1	DSAC available

<dsac_cs>^(num)

Cell access status for CS domain

-1 ^(P)	Information is not available
1	Normal access
2	Emergency calls only
3	No calls allowed
4	All calls allowed

<dsac_ps>^(num)

Cell access status for PS domain

-1 ^(P)	Information is not available
1	Normal access
2	Emergency calls only
3	No calls allowed
4	All calls allowed

<tac_avail>^(num)

Tracking Area Code (TAC) availability

0	TAC not available
1	TAC available

<tac>^(num)

Tracking Area Code (TAC)

Hexadecimal encoded Tracking Area Code (see 3GPP 23.003 Section 19.4.2.3)

0000

7.12 AT^SNCSGLS Operator CSG lists on USIM

The `AT^SNCSGLS` command supplies the CSG (Closed Subscriber Group) lists from USIM EF_{OCSGL}.

Syntax

Test Command

```
AT^SNCSGLS=?
```

Response(s)

```
OK
```

```
ERROR
```

```
+CME ERROR: <err>
```

Exec Command

```
AT^SNCSGLS
```

Response(s)

```
^SNCSGLS: <mcc>,<mnc>,<csgId>,<cti>
```

```
[^SNCSGLS: ...]
```

```
OK
```

```
ERROR
```

```
+CME ERROR: <err>
```

PIN	MDM	APP	✈	Last
+	+	+	+	-

Parameter Description

<mcc>^(str)

Mobile Country Code

<mnc>^(str)

Mobile Network Code

<csgId>^(str)

CSG ID belonging to the Operator CSG lists

<cti>^(num)

CSG type indicator

7.13 AT^SNCSGSC Closed Subscriber Group Network Scan

[AT^SNCSGSC](#) queries the present status of the PLS8-X's CSG networks registration and allows to register to a specific macro cell as well as query the current used macro cell.

The [AT^SNCSGSC](#) test command lists sets of six parameters, each representing a macro cell present in the network.

A set consists of

- numeric format representation of the operator country code
- numeric format representation of the operator network code
- an hexadecimal number indicating the macro cell id.
- an integer indicating the access technology of the operator.
- an integer indicating the access properties of the macro cell.
- an integer indicating the signal strength.

Response to [AT^SNCSGSC](#) read command depends on the registration status. If the UE is registered the response returns the currently registered status. Any of the parameters may be unavailable and will then be an empty field (-). The [<mcc>](#), [<mnc>](#), [<netLac>](#), [<netCellId>](#), [<rat>](#) are valid if module is registered or camped to network. If [<csGId>](#) is not empty (-) it means that current serving cell is a femtocell with CSG support.

The [AT^SNCSGSC](#) write command forces an attempt to select and register to a manual selected macro cell. This result does not mean that registration to CSG cell is done with success or not. In order to get information if registration to CSG was done, it is needed to set the command [AT+CREG= 2](#) before CSG registration. After executing the [AT^SNCSGSC](#) write command wait for URC with information that ME is registered to new cell. After that, it can be checked if this cell is CSG via [AT^SNCSGSC](#) read command. The network name can be checked via [AT+COPS](#) command.

Syntax

Test Command

```
AT^SNCSGSC=?
```

Response(s)

```
^SNCSGSC: [list of supported (<mcc>, <mnc>, <csGId>, <rat>, <cat>, <rssi>)]
```

```
OK
```

```
ERROR
```

```
+CME ERROR:<err>
```

Read Command

```
AT^SNCSGSC?
```

Response(s)

```
^SNCSGSC:<mcc>, <mnc>, <csGId>, <rat>, <netLac>, <netCellId>
```

```
OK
```

```
ERROR
```

```
+CME ERROR:<err>
```

Write Command

```
AT^SNCSGSC=<mcc>, <mnc>, <csGId>, <rat>
```

Response(s)

```
OK
```

```
ERROR
```

```
+CME ERROR:<err>
```

PIN	MDM	APP	✈	Last
-	+	+	-	-

Parameter Description

<rat>^(num)

0	GSM
1	UMTS
2	LTE

<cat>^(num)

0	Unknown CSG list
1	Allowed CSG list
2	Operator CSG list

7.14 AT^SNRSRP Neighbour Reference Signal Received Power

The `AT^SNRSRP` command returns neighbour 4G cell info: PCI, EARFCN, and RSRP.

Syntax

Test Command

```
AT^SNRSRP=?
```

Response(s)

```
OK
```

Read Command

```
AT^SNRSRP?
```

Response(s)

```
in 4G network:
```

```
^SNRSRP: <pci>, <earfcn>, <rsrp>
```

```
OK
```

```
ERROR
```

```
no network or not 4G:
```

```
^SNRSRP:
```

```
OK
```

```
ERROR
```

PIN	MDM	APP	✈	Last
+	+	+	-	-

Parameter Description

<pci>^(num)

Physical Cell ID

<earfcn>^(num)

E-UTRA Absolute Radio Frequency Channel Number

<rsrp>^(num)

Reference Signal Received Power (in dBm). See 3GPP 36.214 section 5.1.1

7.15 AT^SNRSRQ Neighbour Reference Signal Received Quality

The [AT^SNRSRQ](#) command returns neighbour 4G cell info: PCI, EARFCN, and RSRQ.

Syntax

Test Command

```
AT^SNRSRQ=?
```

Response(s)

```
OK
```

Read Command

```
AT^SNRSRQ?
```

Response(s)

in 4G network:

```
^SNRSRQ: <pci>, <earfcn>, <rsrq>
```

```
OK
```

```
ERROR
```

no network or not 4G:

```
^SNRSRQ:
```

```
OK
```

```
ERROR
```

PIN	MDM	APP	✈	Last
+	+	+	-	-

Parameter Description

<pci>^(num)

Physical Cell ID

<earfcn>^(num)

E-UTRA Absolute Radio Frequency Channel Number

<rsrq>^(num)

Reference Signal Received Quality (in dB). See 3GPP 36.214 section 5.1.2

8. USIM Application Toolkit (USAT) Commands

This chapter describes AT commands and responses related to the PLS8-X's [USIM Application Toolkit \(USAT\)](#) implementation.

[USAT](#) is a technology that allows an application running on the USIM to control the GSM/UMTS/LTE Mobile Engine (UE); it is specified in 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].

[Remote USIM Application Toolkit](#), or short [Remote-USAT](#), provides a link between an application running on the USIM and the Customer Application (TE). The purpose of [Remote-USAT](#) is to allow the TE to send AT commands to the [USAT](#) interface and to display dedicated [USAT](#) activity on the user interface of the TE. The overall scenario is illustrated in the context diagram below.

Following types of data are exchanged between the PLS8-X and the application running on the USIM:

- Proactive commands (PACs) are sent from the USIM application to the UE. Some PAC types are executed by the UE itself, comparable with AT commands. Other PAC types are immediately forwarded to the TE, e.g. "DISPLAY TEXT".
- Terminal Response is the UE's answer to the last PAC, sometimes to be provided by the TE.
- Envelope commands are sent from the UE or TE to the USIM Application, such as "MENU SELECTION".




Figure 8.1: Remote-USAT Context Diagram

8.1 Usage of Remote-SAT

8.1 Usage of Remote-SAT

If USAT functionality is delivered by the USIM provider, the related USAT commands have to be handled. Otherwise other USIM functionality may not working correctly (e.g. SMS-PP downloads). Therefore two possible modes are available.

8.1.1 Automatic Response Mode (AR Mode)

If the UE operates in this (default) mode, usage of any Remote-USAT AT commands is not necessary. In this case, all commands and responses are exchanged automatically between the UE and the USIM application. The type of Terminal Response (TR) to a USAT Proactive Command issued by the USIM application used in AR mode is listed at Table 8.6, [Command Type Table](#), column "Auto Terminal Response". However, even while using AR Mode it is crucial to react on USAT REFRESH Proactive Commands, indicating that data read from the USIM has been changed!

Additionally the a "+CIEV: "simdata"" URC is issued if a Refresh is rejected (<status> and <statAddInfo> are visible).

This URC is independent from [Remote-USAT](#) modes (Autoresponse mode and Explicit Response mode). This can happen if it is not possible to refresh an EF (e.g. EF_IMSI during a call). In this case the customer have to cancel all Calls as soon as possible and wait for the next Refresh command from the SIM card.

If the Refresh will not occur again, please restart the module to complete the Refresh request.

Therefore, enable handling of [AT^SIND](#), using parameter <indDescr>="simdata" to get informed about USAT REFRESH events.

Furthermore it is recommended to activate the [AT^SCKS](#) URC, because for USAT REFRESH Type SIM RESET the same internally functionality as for physical remove and insertion of the USIM is done.

To take full advantage of Remote-USAT the ER mode has to be enabled using [AT^SSTA=1](#). This setting is stored in the non-volatile memory and takes effect after next switch-on of the UE.

8.1.2 Explicit Response Mode (ER Mode)

As a Wireless Modem does not have an MMI, Remote-USAT differs from a phone implementation of USAT. It uses a special set of AT commands to pass data, e.g. a list of menu items, to the TE and to receive responses, e.g. a selected menu item.

The TE is required to monitor the status of an ongoing USAT Proactive Command (PAC) and, if required, sends appropriate AT commands, depending upon users input.

The "+CIEV: "simdata"" URC is issued if a Refresh is rejected (<status> and <statAddInfo> are visible).

This can happen if it is not possible to refresh an EF (e.g. EF_IMSI during a call). In this case the customer have to cancel all Calls as soon as possible and wait for the next Refresh command from the SIM card.

If the Refresh will not occur again, please restart the module to complete the Refresh request.

8.1.3 Character Sets

Strings are passed as UCS2 characters, but using the GSM alphabet is also possible. Use of GSM alphabet is not recommended since a USIM can contain text which might be not displayable, e.g. Greek characters. Use the [AT^SSTA](#) command to select the type of alphabet both for input and output. UCS is specified in ISO/IEC 10646. There are 2 and 4 octet versions available, of which only the 2-octet variant is used, known as UCS2. The 65536 positions in the 2-octet form of UCS are divided into 256 rows, each with 256 cells. The first octet of a character representation gives the row number, the second the cell number. The first row, row 0, contains exactly the same characters as ISO/IEC 8859-1. The first 128 characters are thus the ASCII characters. The octet representing an ISO/IEC 8859-1 character is easily transformed to the representation in UCS by putting a 0 octet in front of it. UCS includes the same control characters as ISO/IEC 8859 which are located in row 0.

8.1 Usage of Remote-SAT

8.1.4 USIM Update Initiated by the Network

If a Customer Application (TE) uses data of the USIM card please consider that the contents of all elementary files are subject to change at any time. This happens because the network can change the USIM data in the background via the [USIM Application Toolkit \(USAT\)](#) procedure "Data download to USIM". For a detailed description refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23]. In order to receive the information that an elementary file has been changed the TE has to activate Remote-USAT and needs to look for the USAT Proactive Command "REFRESH", Section 8.7, [SAT Get Information - Refresh \(1\)](#).

8.1.5 Icon Handling

Several USAT Proactive commands may provide an icon identifier. Icons are intended to enhance the MMI by providing graphical information to the user. The display of icons is optional for the UE. The USIM indicates to the UE whether the icon replaces an alpha identifier or text string, or whether it accompanies it (icon qualifier).

If both an alpha identifier or text string, and an icon are provided with a proactive command, and both are requested to be displayed, but the UE is not able to display both together on the screen, then the alpha identifier or text string takes precedence over the icon.

If the USIM provides an icon identifier with a proactive command, then the UE shall inform the USIM if the icon could not be displayed by sending the response "Command performed successfully, but requested icon could not be displayed" (via AT^SSTR).

Icon data can be fetched directly from the USIM using the [AT+CRSM](#) command, for details please refer to 3GPP TS 11.11 [17], 3GPP TS 31.101 [18], 3GPP TS 31.102 [19]. Icon data can be read from the USIM on system start then cached.

8.1.6 Using SMS Related AT Commands

UE activities triggered by USAT often end in sending or receiving short messages. Usually, a short message containing a service request is sent to the network, for example a request to send the latest news. Subsequently, the network returns a short message containing the requested information. This short message needs to be read by the Customer Application.

Set SMS text mode

[AT+CMGF=1](#)

Activate the display of a URC on every received SMS

[AT+CNMI=1,1](#)

If needed activate extended SMS text mode parameter output

[AT+CSDH=1](#)

This is useful in order to obtain more detailed header information along with the incoming SMS (e.g. SMS class). Please refer to 3GPP TS 23.038 [36] for details.

As a result, a URC will be output each time a short message is received

["+CMTI"](#): "MT", 1 where

- the first parameter "MT" specifies the storage type of the SMS
- the second parameter contains a unique location number.

In the given example, the short message was stored to the memory type "MT" at location number 1.

The short message storage "MT" is a logical storage. For more detailed information please refer to [AT+CPMS](#).

To read the SMS data use

[AT+CMGR=<location>](#)

where <location> is the location number of the received SMS, e.g. 1 in the example above.

To list all stored short messages use
`AT+CMGL="ALL"`

To delete a certain SMS after reading use
`AT+CMGD=<location>`

8.2 Remote-SAT States

In order to communicate with the SIM Application Toolkit it is necessary to use AT commands which are explained in detail in the following chapters. In general, the type of AT command which should be issued depends on the current state of the Remote-SAT interface.

The current state of Remote-SAT is determined by

1. the Remote-SAT operating mode (AR or ER mode),
2. the application running on the SIM,
3. the Customer Application (in case of ER mode only), and
4. internal actions of the UE (especially SAT and Call Control).

8.2.1 Remote-SAT State Transition Diagram




Figure 8.2: Remote-SAT State Transition Diagram

8.2 Remote-SAT States

8.2.2 Remote-SAT State Transition Table

The following table outlines which AT commands can be issued during certain states. However, the test and read AT commands are available at any time. This way it is possible to determine the current state of the interface via [AT^SSTA?](#).

Meaning of options usable in column "M/O/X" of the following tables:

M: The TE has to issue the AT command to get Remote-SAT service (mandatory).

O: Usage of AT command is optional.

X: Usage of AT command is not allowed or not useful at this time and may cause an error message.

Table 8.1: State: RESET description

RESET: State after power on the UE.		
AT command	M/O/X	Description
^SSTA=0,n	O	Enable AR Mode (with alphabet type <n>)
^SSTA=1,n	O	Enable ER Mode (with alphabet type <n>)
^SSTGI=<pac>	X	
^SSTR=<pac>	X	
^SSTR=<event>	X	

Table 8.2: State: OFF description

OFF: UE is in Auto Response Mode.		
AT command	M/O/X	Description
^SSTA=0,n	O	Enable AR Mode (with alphabet type <n>)
^SSTA=1,n	O	Enable ER Mode (with alphabet type <n>)
^SSTGI=<pac>	X	
^SSTR=<pac>	X	
^SSTR=<event>	X	

Table 8.3: State: IDLE description

IDLE: UE is in Explicit Response Mode.		
AT command	M/O/X	Description
^SSTA=0,n	O	Enable AR Mode (with alphabet type <n>)
^SSTA=1,n	O	Enable ER Mode (with alphabet type <n>)
^SSTGI=<pac>	O	Show PAC information
^SSTR=<pac>	X	
^SSTR=<event>	O	

Table 8.4: State: PAC description

PAC ¹ : SIM application has issued a proactive command. This event is signalled to the TE via ^SSTN: <cmdType>.		
AT command	M/O/X	Description
^SSTA=0,n	O	Enable AR Mode (with alphabet type <n>)
^SSTA=1,n	O	Enable ER Mode (with alphabet type <n>)
^SSTGI=<pac>	M	Show PAC information
^SSTR=<pac>	X	
^SSTR=<event>	X	

Table 8.5: State: WAIT description

WAIT ¹ : SIM application is waiting for the response to the ongoing proactive command.		
AT command	M/O/X	Description
^SSTA=0,n	O	Enable AR Mode (with alphabet type <n>)
^SSTA=1,n	O	Enable ER Mode (with alphabet type <n>)
^SSTGI=<pac>	O	Show PAC information
^SSTR=<pac>	M	
^SSTR=<event>	X	

1) To limit the time Remote-SAT is kept in states PAC or WAIT, any ongoing (but unanswered) PAC will be aborted after 5 minutes automatically. For details refer to [AT^SSTA](#), parameter <userTOut>.

8.3 Remote-SAT Command Types

The Command Type value (cmdType) identifies the type of command or associated response passed between the TE and the UE.

cmdType is the parameter that comes first in AT commands, in responses to `AT^SSTGI` and `AT^SSTR` commands, and in the `^SSTN` URC. Also, the cmdType values may be used as Next Action Indicator for the SETUP MENU and for SELECT ITEM.

USAT implementation supports SAT class 3 (as specified by 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23] Release 99, letter class "c").

Table 8.6: Command Type Table

Proactive Toolkit commands vs. Terminal Responses			
Proactive Toolkit command (<code>AT^SSTR=<cmd-Type></code>)	Terminal Response in Automatic Response Mode (see <code>AT^SSTA=0</code>)	Terminal Response user choices in Explicit Response Mode (see <code>AT^SSTR=<cmd-Type>,<status></code>)	Terminal Response after user timeout in Explicit Response Mode (see URC <code>^SSTN: <cmdTerminateValue></code>)
REFRESH (1)	0	0	0
SET UP EVENT LIST (5)	0	0, 32, 48, 132	132
SET UP CALL (16)	48	0, 4, 16, 20, 32, 34, 35, 48, 132	132
SEND SS (17)	48	0, 4, 20, 32, 48, 132	132
SEND USSD (18)	48	0, 4, 20, 32, 48, 132	132
SEND SHORT MESSAGE (19)	48	0, 4, 32, 48, 132	132
SEND DTMF (20)	48	0, 4, 16, 32, 48, 132	132
LAUNCH BROWSER (21)	48	0, 4, 32, 34, 38, 48, 132, 138, 238, 239	132
PLAY TONE (32)	48	0, 4, 16, 32, 48, 132	132
DISPLAY TEXT (33)	0	0, 4, 16, 17, 18, 32, 48, 132	132
GET INKEY (34)	48	0, 4, 16, 17, 18, 19, 32, 48, 132	18
GET INPUT (35)	48	0, 4, 16, 17, 18, 19, 32, 48, 132	18
SELECT ITEM (36)	48	0, 4, 16, 17, 18, 19, 32, 48, 132	18
SET UP MENU (37)	0	0, 4, 32, 48, 132	132
SET UP IDLE MODE TEXT (40)	0	0, 4, 32, 48, 132	132
LANGUAGE NOTIFICATION (53)	0	0	0
OPEN CHANNEL (64)	48	0, 4, 16, 32, 48, 132	132
CLOSE CHANNEL (65)	48	0, 4, 16, 32, 48, 132	132
RECEIVE DATA (66)	48	0, 4, 16, 32, 48, 132	132
SEND DATA (67)	48	0, 4, 16, 32, 48, 132	132

8.4 AT^SSTA Remote-SAT Interface Activation

AT^SSTA write command can be used to determine the Remote-SAT activation mode <mode> and, if Explicit Response mode is enabled, to activate the Remote-SAT interface. Removing and inserting the SIM does not affect the activation status.

SAT commands which are not using the AT interface (non-MMI related SAT commands, e.g. PROVIDE LOCAL INFORMATION) are executed without activating Remote-SAT.

The read command can be used to request the current operating status and the used alphabet of the Remote-SAT interface.

Syntax

```

Test Command
AT^SSTA=?
Response(s)
^SSTA: (list of supported <state>s), (list of supported <Alphabet>s)
OK

Read Command
AT^SSTA?
Response(s)
^SSTA: <state>, <Alphabet>, <allowedInstance>, <SatProfile>, <userTOut>, <AppType>
OK

Write Command
AT^SSTA=<mode>[, <Alphabet>]
Response(s)
OK
    
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<state> ^(num)	
UE Remote-SAT interface states	
0	RESET
1	OFF
2	IDLE
3	PAC
4	WAIT

<Alphabet> ^{(num)(NV)}	
Setting becomes effective after restarting the UE.	
0 ^(D)	GSM character set Input of a character requests one byte, e.g. "Y".
1	UCS2 To display the 16 bit value of characters represented in UCS2 alphabet a 4 byte string is required, e.g. "0059" is coding the character "Y". For details please refer to ISO/IEC 10646.

<allowedInstance>^(num)

Remote-SAT handling (i.e. "^SSTN" URC, AT^SSTGI and AT^SSTR sequence) is only usable via the serial channel on which the Explicit Response (ER) mode was activated.

To change the serial channel execute AT^SSTA=1 on the desired channel and perform a restart.

0	Not applicable
1	SAT may be started on this instance via the write version of this command.

<SatProfile>^(str)

SAT or USAT Terminal Profile according to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23]. UE supports different profiles for 2G SIM and 3G USIM applications. The type of profile issued by AT^SSTA read command depends on the inserted SIM or USIM.

In case of no SIM is inserted the SAT Terminal Profile will be issued.

The profile tells the SIM Application which features (e.g. Proactive Commands) are supported by the SIM Application Toolkit implementation of the UE.

<userTOut>^(num)

PAC user timeout in seconds.

To limit the time Remote-SAT is kept in states PAC or WAIT, any ongoing (but unanswered) proactive command will be aborted automatically after 5 minutes. In this case, the terminal response is either "ME currently unable to process command", or if applicable, "No response from user". In addition a URC "Terminate Proactive Command" will be sent to the external application.

<AppType>^(num)

SIM Application type.

This parameter shows the type of SIM application currently running.

0	(U)SIM not inserted
1	2G Application (SAT)
2	3G Application (USAT)

<mode>^{(num)(NV)}

Select Remote-SAT activation mode.

Setting becomes effective after restarting the UE. Removing and inserting the SIM does not affect the activation status.

0 ^(D)	Automatic Response (AR) mode. All commands and responses are exchanged automatically between the UE and the SIM application. This eliminates the need to enter any Remote-SAT commands including the AT^SSTA command. If AR mode is enabled the UE enters the OFF state (<state>=1) after restart.
1	Explicit Response (ER) mode. This mode is intended for use with an MMI. If ER mode is enabled the MMI is required to handle, via UE's Remote-SAT interface, all commands and responses transmitted to or from the SIM or USIM. If ER mode is enabled the UE enters the IDLE state (<state>=2) after reboot.

8.5 ^SSTN SAT Notification

Unsolicited Result Codes

URC 1

Proactive command notification

^SSTN: <cmdType>

Every time the SIM Application issues an MMI relevant proactive command, via the UE, the TE will receive a notification. This indicates the type of proactive command issued.

AT^SSTGI must then be used by the TE to request the parameters of the proactive command from the UE. Upon receiving the ^SSTGI response from the UE, the TE must send AT^SSTR to confirm the execution of the proactive command and provide any required user response, e.g. a selected menu item.

URC 2

Terminate proactive command notification

^SSTN: <cmdTerminateValue>

When the SIM Application has issued a proactive command to the UE, it is possible that this command will be terminated later. URC "^SSTN" is sent with a different proactive command type number (added terminate offset 100) to indicate the termination of the specified command.

The state changes to idle. Therefore the TE should avoid sending any further commands related to the terminated proactive command, e.g. AT^SSTGI or AT^SSTR.

URC 3

Notification to the TE when the SIM Application has finished a command cycle and does not issue a subsequent proactive command.

^SSTN: 254

The TE does not need to respond directly, i.e. AT^SSTR is not required. The next action is left as an implementation decision to the manufacturer of the Customer Application (TE). Examples:

- If a Toolkit menu "^SSTN: 37" (SET UP MENU) proactive command was received at startup, the customer application can return to this Toolkit menu again after receiving the "^SSTN: 254" URC.
- In a Windows Mobile environment, the ToolkitUI application can be closed after receiving this URC.

Important notes:

- The Idle Mode text transferred with the SET UP IDLE MODE TEXT proactive command should not be removed as a result of this URC.
- If the text transferred with the DISPLAY TEXT proactive command is coded with an immediate response object set to "1" (see parameter <immediateResponse> of the AT^SSTGI=33 command), the text should not be removed as a result of this URC.

URC 4

SIM reset notification

^SSTN: 255

Notification to the TE indicating that the SIM is lost, e.g. if a proactive command "REFRESH - SIM Reset" has been issued by the SIM Application, please refer to AT^SSTGI=1.

This URC should be used to set the Customer Application to its initial state since the SIM Application will start from the beginning, too.

The TE does not need to respond directly, i.e. related AT^SSTGI and AT^SSTR are neither required nor allowed.

After reset SIM PIN authentication is required.

Parameter Description

<cmdType>^(num)

Proactive Command number

`<cmdTerminateValue>`^(num)

Defined as `<cmdType>` + terminate offset. The terminate offset equals 100.

8.6 AT^SSTGI SAT Get Information

This command shall be used upon receipt of a URC "[^SSTN](#)" to request the parameters of the Proactive Command.

Then the TE is expected to acknowledge the [AT^SSTGI](#) response with [AT^SSTR](#) to confirm that the Proactive Command has been executed. [AT^SSTR](#) will also provide some user information, e.g. a selected menu item. The Proactive Command type value specifies to which "[^SSTN](#)" the command is related.

Syntax

<p>Test Command</p> <p>AT^SSTGI=?</p> <p>Response(s)</p> <p>^SSTGI : (list of supported <state>s), (list of supported <cmdType>s)</p> <p>OK</p>										
<p>Read Command</p> <p>AT^SSTGI?</p> <p>Response(s)</p> <p>^SSTGI : <state>, <cmdType></p> <p>OK</p>										
<p>Write Command</p> <p>AT^SSTGI=<cmdType></p> <p>Response(s)</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>										
<table border="1"> <tr> <td>PIN</td> <td>MDM</td> <td>APP</td> <td>→</td> <td>Last</td> </tr> <tr> <td>-</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </table>	PIN	MDM	APP	→	Last	-	+	+	+	-
PIN	MDM	APP	→	Last						
-	+	+	+	-						

Parameter Description

<state> ^(num)	
PLS8-X Remote-SAT interface states	
0	RESET
1	OFF
2	IDLE
3	PAC
4	WAIT

[<cmdType>](#)^(num)

Related Proactive Command

8.7 AT^SSTGI SAT Get Information - Refresh (1)

The `AT^SSTGI=1` command shall be used after receiving the URC "`^SSTN: 1`". This URC notifies the TE that one or more Elementary Files on the USIM have been changed as a result of a USIM application activity, usually caused by the network provider. The response to the `AT^SSTGI=1` command indicates what type of USIM refresh has occurred. The change requires that the Elementary Files of the USIM be synchronized with the equivalent information (if any) stored inside the TE. Depending on the type of USIM refresh the TE may need to use the `AT+CRSM` command to read out the Elementary Files and store the refreshed information.

The response parameters `<pathLen>`, `<fileNum>` and `<fileList>` are mandatory if `<commandDetails>` equals 1 or 2. In all other cases they are optional and can be ignored.

Syntax

```
Write Command
AT^SSTGI=1

Response(s)
^SSTGI: <cmdType>, <commandDetails>[, <pathLen>, <fileNum>, <fileList>]
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

`<cmdType>`^(num)

1	Proactive command ID, see Section 8.3, Remote-SAT Command Types and Table 8.6.
---	--

`<commandDetails>`^(num)

For every return value of `<commandDetails>` other than 4 (USIM Reset) the TE shall complete the proactive command cycle using `AT^SSTR=1,0`.

0	USIM Initialization and Full File Change Notification
1	File Change Notification
2	USIM Initialization and File Change Notification
3	USIM Initialization
4	Value "4" means USIM Reset, but the value itself never appears. This is because value "4" is mapped to the URC " <code>^SSTN: 255</code> " which will be sent when a USIM reset occurs. In this case, the TE does not need to respond, i.e. the USIM Refresh commands <code>AT^SSTGI</code> and <code>AT^SSTR</code> are neither required nor allowed. Instead, as the USIM application restarts, the Toolkit application inside the TE should also return to initial state after receiving the URC " <code>^SSTN: 255</code> ". For more information on USIM reset and the URC " <code>^SSTN: 255</code> " refer to Section 8.5, ^SSTN SAT Notification .
5...255	Reserved values

`<pathLen>`^(num)

Number of bytes coded in `<fileList>`

<fileNum>^(num)

Number of updated Elementary Files (EF) with path given in <fileList>

<fileList>^(str)

String containing Elementary File paths. Each path contains at least two file entries; each file entry (MF, EF or DF) consists of two bytes, e.g. '3F002FE2' or '3F007F206FAD'. Every path in the file description begins with the Master File (MF). There can be any number of Dedicated File (DF) entries between Master File and Elementary File.

Example

In general, the TE only needs to take care of USIM content synchronization if it is permanently interested in the latest contents of one or more specific USIM files, e.g. because the TE has its own cache for specific USIM information. In this case, the TE needs to know exactly the paths and file IDs of these specific USIM files. Paths and file IDs can be found in 3GPP TS 11.11 [17], 3GPP TS 31.101 [18], 3GPP TS 31.102 [19] and ETSI TS 102 221 [20].

When <commandDetails> equals 0, 2 or 3 or the "^SSTN: 255" notification is received (refer to Section 8.5, ^SSTN SAT Notification), the TE shall synchronize its own cache for USIM information in any case.

When <commandDetails> equals 1, reloading the USIM information is only necessary if the TE finds that an important file is included in the Refresh <fileList>. For example, assuming that the TE is always interested in the latest contents of the "FD" (Fixed Dialing) phonebook, it has to know that EF_FDN is located at path "3F00\7F10\6F3B". Then, during normal operation, the TE should always check the Refresh <fileList>, if it includes the path and file ID of EF_FDN. An example is given below:

^SYSSTART	UE has been started.
AT+CLCK="FD", 2	Request "FD" lock state.
+CLCK: 1	"FD" lock is enabled.
OK	
AT+CPBS="FD"	Select the "FD" phonebook.
OK	
AT+CPBR=1	Read first "FD" phonebook entry.
+CPBR: 1, "123", 129, "ABC"	This is the "FD" phonebook content before Refresh.
OK	
^SSTN: 1	Indicates that a SIM Refresh has occurred.
AT^SSTGI=1	Request type of SIM Refresh.
^SSTGI: 1, 1, 6, 1, "3F007F106F3B"	The Refresh <fileList> includes path and file ID 3F00\7F10\6F3B which corresponds to EF_FDN, indicating that its contents may have changed.
OK	
AT^SSTR=1, 0	Terminate the proactive command.
OK	
^SSTN: 254	Session finished.
AT+CPBR=1	Read first "FD" phonebook entry.
+CPBR: 1, "0123456789", 129, "ABC"	This is the "FD" phonebook content after the Refresh.
OK	

Please keep in mind that this process is only necessary if the TE has its own cache for SIM/USIM information (e.g. SIM/USIM phonebook is cached inside the TE). If the TE does not have a cache for USIM information (e.g. USIM phonebook is read by the TE only at the user's request, directly from the USIM), it is not necessary to synchronize the content. The TE USIM content synchronization is not required for a proper operation of the UE. As long as the TE answers the "^SSTN: 1" notification with the commands AT^SSTGI=1 and AT^SSTR=1,0, the UE will use the latest USIM contents and will continue to work flawlessly, regardless of a possible TE USIM content synchronization.

8.8 AT^SSTGI SAT Get Information - Set Up Event List (5)

This command shall be used after receiving the URC ^SSTN: 5.

However, please refer to the note below.

The response informs the TE of the events that it must monitor within itself. If any of these events occur the TE must report them to the UE.

Syntax

```
Write Command
AT^SSTGI=5
Response(s)
^SSTGI: <cmdType>, <commandDetails>, <eventList>
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cmdType>^(num)
5 Proactive command ID, see Table 8.6, Command Type Table.

<commandDetails>^(num)
This byte is RFU.

<eventList>^(num)
The event list tells the TE which events have to be reported to the UE via the related commands AT^SSTR=(232, 233, 235, 236)

0...65535	Used as bit field
bit 1-4	RFU
bit 5	0: User Activity not in Event List 1: Any user activity (keyboard press) has to be signaled to the UE
bit 6	0: Idle Screen Available not in Event List 1: Any idle screen available event has to be signaled to the UE.
bit 7	RFU
bit 8	0: Language Selection not in Event List 1: Language Selection events have to be signaled to the UE.
bit 9	0: Browser Termination not in Event List 1: Browser Termination events have to be signaled to the UE
bit 10-16	RFU

Note

- It is possible to issue AT^SSTGI during states IDLE, PAC and WAIT for this proactive command without previously receiving a URC ^SSTN:<cmdType>, see AT^SSTGI.

8.9 AT^SSTGI SAT Get Information - Set Up Call (16)

This command shall be used after receiving the URC ^SSTN: 16. If the SIM Application attempts to set up a call it uses this response to inform the TE of the call parameters.

The sequence of events is as follows:

1. After the Remote-SAT notification 16 was issued the TE has to request the command parameter using AT^SSTGI=16.
2. If the SIM Application does not supply a confirmation text or icon parameter, the TE gives other information to the user, e.g. the telephone number. In this case refer to step 4.
3. If the SIM Application supplies a non empty confirmation text or icon parameter, the TE uses only these to ask the user whether or not he wishes to set up the call.
4. If the user confirms to set up the call, the response AT^SSTR=16,0 shall be sent.
5. If the user denies to set up the call, the response AT^SSTR=16,34 shall be sent.
6. After confirmation phase the TE may present a dialing animation on the screen until a mandatory parameter line ^SSTR: 16, <TermQualifier>, <TerminationCauseText> is issued.
7. If <TermQualifier> is not equal to 0 the call setup process has not been successfully. If <TerminationCauseText> is not an empty string, this text shall be shown to the user for an appropriate time, e.g. 2 seconds. The text contains information regarding the dial termination cause, e.g. call barring through Call Control by SIM mechanism. If <TerminationCauseText> is an empty string, the TE shall give an own indication to the user.
8. If <TermQualifier> is equal to 0, the call setup process has been started: If <TerminationCauseText> is not an empty string, this text shall be used to inform the user during the call setup. If <TerminationCauseText> is an empty string, <callSetupText> and/or <confirmationIconId> shall be used to inform the user during call setup. However, if <callSetupText> contains no data, too, no indication shall be shown.
9. The TE shall give the user an opportunity to end an ongoing call, set up by the Proactive Command. In this case the TE shall send an AT command to hang up the call.

Syntax

```
Write Command
AT^SSTGI=16
Response(s)
^SSTGI: <cmdType>, <commandDetails>, <confirmationText>, <calledNumber>,
<callSetupText>, <confirmationIconQualifier>, <confirmationIconId>,
<callSetupIconQualifier>, <callSetupIconId>
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cmdType> ^(num)	
16	Proactive command ID, see Table 8.6, Command Type Table.
<commandDetails> ^(num)	
0	Set up call, but only if not currently busy on another call
1	Set up call, but only if not currently busy on another call, with redial
2	Set up call, putting all other calls (if any) on hold
3	Set up call, putting all other calls (if any) on hold, with redial
4	Set up call, disconnecting all other calls (if any)

5	Set up call, disconnecting all other calls (if any), with redial
6...255	Reserved Values

<confirmationText>^(str)

String for user confirmation stage

<calledNumber>^(num)

String containing called number

<callSetupText>^(str)

String for call set up stage

<confirmationIconQualifier>^(num)

0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU

<confirmationIconId>^(num)

0...255	
0	No Icon

<callSetupIconQualifier>^(num)

0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU

<callSetupIconId>^(num)

0...255	
0	No Icon

Note

- If the Fixed Dialling Number service is enabled, the number included in the SET UP CALL proactive command shall not be checked against those of the FDN list.

8.10 AT^SSTGI SAT Get Information - Send SS (17)

This command shall be used after receiving the URC ^SSTN: 17
 The module is sending a supplementary service request to the network, and is alerting the user of this. Text and an icon identifier shall be passed to the TE to display to the user.

Syntax

```

Write Command
AT^SSTGI=17
Response(s)
^SSTGI: <cmdType>[, <commandDetails>][, <text>], <iconQualifier>, <iconId>
OK
ERROR
+CME ERROR: <err>
    
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cmdType>^(num)	
17	Proactive command ID, see Table 8.6, Command Type Table .
<commandDetails>^(num)	
This byte is RFU.	
<text>^(str)	
String to provide the user with information. If the string is provided by the SIM, the TE shall use it to inform the user. This is also an indication that the TE should not give any other information to the user on the fact that the UE is sending an SS request. If the alpha identifier is not provided by the SIM, the UE may give information to the user concerning what is happening.	
<iconQualifier>^(num)	
0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU
<iconId>^(num)	
0...255	
0	No Icon

8.11 AT^SSTGI SAT Get Information - Send USSD (18)

This command shall be used after receiving the URC ^SSTN: 18
 The module is sending an unstructured supplementary service request to the network, and is alerting the user of this.

Text and an icon identifier shall be passed to the TE to display to the user.

Syntax

```
Write Command
AT^SSTGI=18
Response(s)
^SSTGI: <cmdType>[, <commandDetails>][, <text>], <iconQualifier>, <iconId>
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cmdType>^(num)
 18 Proactive command ID, see Table 8.6, [Command Type Table](#).

<commandDetails>^(num)
 This byte is RFU.

<text>^(str)
 String to provide the user with information.
 If the string is provided by the SIM, the TE shall use it to inform the user. This is also an indication that the TE should not give any other information to the user on the fact that the UE is sending a USSD request.
 If the alpha identifier is not provided by the SIM, the UE may give information to the user concerning what is happening.

<iconQualifier>^(num)

0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU

<iconId>^(num)

0...255	
0	No Icon

8.12 AT^SSTGI SAT Get Information - Send Short Message (19)

This command shall be used after receiving the URC ^SSTN: 19
The SIM Application is sending a Short Message and the TE is informed of this. The user can be passed a string containing information to display.

Syntax

```
Write Command
AT^SSTGI=19
Response(s)
^SSTGI: <cmdType>, <commandDetails>, <textInfo>, <iconQualifier>, <iconId>
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cmdType>^(num)	
19	Proactive command ID, see Table 8.6, Command Type Table .
<commandDetails>^(num)	
This byte is RFU.	
<textInfo>^(str)	
String to provide the user with information. If the string is provided by the SIM, the TE shall use it to inform the user. This is also an indication that the TE should not give any other information to the user on the fact that the UE is sending a short message. If the alpha identifier is not provided by the SIM, the UE may give information to the user concerning what is happening.	
<iconQualifier>^(num)	
0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU
<iconId>^(num)	
0...255	
0	No Icon
1	An icon is provided by the SIM, the icon indicated in the command may be used by the UE to inform the user, in addition to, or instead of the alpha identifier, as indicated with the icon qualifier.

8.13 AT^SSTGI SAT Get Information - Send DTMF (20)

This command shall be used after receiving the URC ^SSTN: 20

The SIM Application is sending DTMF tones to the network, and can provide the TE with some information about this.

Text and an icon identifier can be passed to the TE to display to the user.

Syntax

```
Write Command
AT^SSTGI=20
Response(s)
^SSTGI: <cmdType>, <commandDetails>, <text>, <iconQualifier>, <iconId>
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cmdType>^(num)
20 Proactive command ID, see Table 8.6, [Command Type Table](#).

<commandDetails>^(num)
This byte is RFU.

<text>^(str)
String to provide the user with information.
If the string is provided by the SIM, the TE shall use it to inform the user. This is also an indication that the TE should not give any other information to the user on the fact that the UE is performing a SEND DTMF command. If the alpha identifier is not provided by the SIM, the UE may give information to the user concerning what is happening.

<iconQualifier>^(num)
0...255 Used as bit field
bit 1 0: Icon is self explanatory and replaces text
1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8 RFU

<iconId>^(num)
0...255
0 No Icon

8.14 AT^SSTGI SAT Get Information - Launch Browser (21)

This command shall be used after receiving the URC ^SSTN: 21.

If the SIM Application attempts to start an Internet Browser, it uses this response to inform the TE of the launch parameters.

The sequence of events is as follows:

1. After the Remote-SAT notification 21 was issued the TE shall ask for the command parameters via AT^SSTGI=21.
2. The UE shall ask the user for confirmation using the Alpha Identifier/Icon Identifier (user confirmation phase) if present, when it receives a LAUNCH BROWSER command which requests to connect the existing browser session to a new URL or to terminate a browser session.
3. If the user confirms to start the browser, the response AT^SSTR=21,0 shall be sent.
4. If the user rejects to start the browser, the response AT^SSTR=21,34 shall be sent.
5. The SIM Application will end the proactive session.
6. The UE shall request content using the given URL. However, if no URL string is supplied a default URL shall be used.
7. If the response AT^SSTR=21,0 was issued, the browser session may still be active while a next proactive command is issued. Therefore the end of the browser session shall be reported to the UE via browser termination event command asynchronously if determined by the event list.

For details please refer to [AT^SSTR](#).

Syntax

```
Write Command
AT^SSTGI=21
Response(s)
^SSTGI: <cmdType>, <commandDetails>, <confirmationText>,
<confirmationIconQualifier>, <iconId>, <browserIdentity>, <url>, <bearerList>,
<fileRefList>, <gatewayIdentity>
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cmdType> ^(num)	
21	Proactive command ID, see Remote-SAT Command Types
<commandDetails> ^(num)	
This byte is RFU.	
<confirmationText> ^(str)	
String for user confirmation stage	
<confirmationIconQualifier> ^(num)	
0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text

1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).

bit 2-8 RFU

<iconId>^(num)

0...255

0 No Icon

<browserIdentity>^(num)

0...255

Browser to be used

0 Default Browser shall be used.

1...255 RFU

<url>^(str)

String containing URL to be used by the TE to request content. The way the UE requests content using the URL is out of the scope of the present document. This is specified in RFC 1738 Annex K for example.

<bearerList>^(str)

"00" SMS

"01" CSD

"02" USSD

"03" GPRS

FF...04 RFU

<fileRefList>^(str)

String containing full path to the provisioning file. The first byte contains the number of files. Every comma separated path is the concatenation of file identifiers starting from the Master File (e.g. 3F007F206FX). The file contains a single unambiguous set of parameters required to make the connection. The content of the file is expected to be consistent with the format defined for provisioning information for the requested type of browser.

<gatewayIdentity>^(str)

String containing the Gateway/Proxy Identity which gives to the mobile the name/identity of the Gateway/Proxy to be used for connecting to the URL. This Gateway/Proxy identity is required when the bearer data object is present.

8.15 AT^SSTGI SAT Get Information - Play Tone (32)

This command shall be used after receiving the URC ^SSTN: 32.
The UE has been instructed to generate an audible tone, and may pass to the TE some information to support this.

Syntax

```
Write Command
AT^SSTGI=32
Response(s)
^SSTGI: <cmdType>, <commandDetails>, <infoText>, <tone>, <durationUnit>, <duration>,
<iconQualifier>, <iconId>
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cmdType>^(num)
32 Proactive command ID, see [Remote-SAT Command Types](#)

<commandDetails>^(num)
This byte is RFU.

<infoText>^(str)
String to accompany tone

<tone>^(str)
Tone generated by the UE

01...08	Standard supervisory tones:
“01“	Dial tone
“02“	Called subscriber busy
“03“	Congestion
“04“	Radio path acknowledge
“05“	Radio path not available / Call dropped
“06“	Error / Special information
“07“	Call waiting tone
“08“	Ringing tone
16...18	UE proprietary tones:
“16“	General beep
“17“	Positive acknowledgement tone
“18“	Negative acknowledgement or error tone

<durationUnit>^(num)

0	Minutes
1	Seconds
2	Tenth of Seconds

<duration>^(num)

1...255	Duration of tone, expressed in units
---------	--------------------------------------

<iconQualifier>^(num)

0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU

<iconId>^(num)


0...255	
0	No Icon

8.16 AT^SSTGI SAT Get Information - Display Text (33)

This command shall be used after receiving the URC ^SSTN: 33. The TE gets a message to be displayed to the user. The message can have different display characteristics.

Syntax

```
Write Command
AT^SSTGI=33
Response(s)
^SSTGI: <cmdType>, <commandDetails>, <text>, <immediateResponse>, <iconQualifier>,
<iconId>
OK
ERROR
+CME ERROR: <err>
```



Parameter Description

<cmdType>^(num)
33 Proactive command ID, see Section 8.3, [Remote-SAT Command Types](#) and Table 8.6.

<commandDetails>^(num)
0...255 Used as bit field
bit 1 0: Normal priority (see note).
1: High priority (see note).
bit 2-7 RFU
bit 8 0: Clear message after a delay.
1: Wait for user to clear message.

<text>^(str)
String to be displayed

<immediateResponse>^(num)
This parameter indicates whether the UE should sustain the display beyond sending the TERMINAL RESPONSE.
0 Send TERMINAL RESPONSE when text is cleared from screen.
1 Send TERMINAL RESPONSE immediately and continue to display the text until one of the following events occurs:

- A subsequent proactive command is received, containing display data.
- A short delay notified with **<commandDetails>** has expired.
- User intervention.

- A higher priority event occurs, e.g. a mobile terminated call.

No further TERMINAL RESPONSE shall be sent when the UE removes the text from the display, regardless of the cause.

If the `<immediateResponse>` parameter equals "1" the subsequent "`^SSTN: 254`" URC should not be used to clear the text from the screen - in this case the text should remain on the screen until one of the above events occurs.

`<iconQualifier>`^(num)

0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text. 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU

`<iconId>`^(num)

0...255	
0	No Icon

Notes

- The MMI shall reject normal priority text commands if the screen is currently used for more than its normal standby display, e.g. if the MMI is in sub-menu. If the command is rejected, the MMI sends the TERMINAL RESPONSE message to the SIM (UE currently unable to process command - screen busy).
- High priority text shall be displayed on the screen immediately, except if a priority conflict of the alerting events occurs, e.g. incoming call or a URC if the battery needs to be charged, see 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].

8.17 AT^SSTGI SAT Get Information - Get Inkey (34)

This command shall be used after receiving the URC ^SSTN: 34.
The TE is asked to prompt the user for an input, which is a single character. Help can be requested by the user, if available.

Syntax

```
Write Command
AT^SSTGI=34

Response(s)
^SSTGI: <cmdType>, <commandDetails>, <text>, <iconQualifier>, <iconId>
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<code><cmdType></code> ^(num)	
34	Proactive command ID, see Remote-SAT Command Types
<code><commandDetails></code> ^(num)	
0...255	Used as bit field
bit 1	0: Digits only (0 9, *, # and +) 1: Alphabet set
bit 2	0: SMS default alphabet (GSM character set) 1: UCS2 alphabet
bit 3	0: Character sets defined by bit 1 and bit 2 are enabled 1: Character sets defined by bit 1 and bit 2 are disabled and the "Yes/No" response is requested
bit 4-7	RFU
bit 8	0: No help information available 1: Help information available
<code><text></code> ^(str)	
	String as prompt for text.
<code><iconQualifier></code> ^(num)	
0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU

<iconId>^(num)

0...255

0

No Icon

8.18 AT^SSTGI SAT Get Information - Get Input (35)

This command shall be used after receiving the URC ^SSTN: 35.
The TE is asked to prompt the user for an input, of a specified length and type, e.g. digits only. Help can be requested by the user, if available.

Syntax

```
Write Command
AT^SSTGI=35
Response(s)
^SSTGI: <cmdType>, <commandDetails>, <text>, <responseMin>, <responseMax>[,
<defaultText>], <iconQualifier>, <iconId>
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cmdType>^(num)
35 Proactive command ID, see [Remote-SAT Command Types](#)

<commandDetails>^(num)

0...255	Used as bit field
bit 1	0: Digits only (0 9, *, # and +) 1: Alphabet set
bit 2	0: SMS default alphabet (GSM character set) 1: UCS2 alphabet
bit 3	0: UE may echo user input on the display 1: User input shall not be revealed in any way (see note)
bit 4	0: User input to be in unpacked format 1: User input to be in SMS packed format
bit 5-7	RFU
bit 8	0: No help information available 1: Help information available

<text>^(str)
String as prompt for text

<responseMin>^(num)
0...255 Minimum length of user input.

<responseMax>^(num)
0...255 Maximum length of user input.

<defaultText>^(str)

String supplied as default response text

<iconQualifier>^(num)

0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU

<iconId>^(num)

0...255	
0	No Icon

Note

- Hidden entry mode (see 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23]) is only available when using digit input. In hidden entry mode only characters ('0', '9', '*' and '#') are allowed.


8.19 AT^SSTGI SAT Get Information - Select Item (36)

This command shall be used after receiving the URC ^SSTN: 36.

The TE is supplied with a list of items allowing the user to select one. Help can be requested by the user, if available and the presentation style is specified. In addition to text strings and icon identifiers, a next action indicator informs the user of the likely result of selecting a chosen item.

Syntax

```
Write Command
AT^SSTGI=36
Response(s)
The first line of output from the ME is:
^SSTGI: <cmdType>, <commandDetails>, <numOfItems>, <titleText>, <defaultItemId>,
<itemIconsPresent>, <itemIconsQualifier>, <titleIconQualifier>, <titleIconId>
One line follows for every item, repeated for <numOfItems>:
^SSTGI: <cmdType>, <itemId>, <itemText>, <nextActionId>, <iconId>
OK
ERROR
+CME ERROR: <err>
```



Parameter Description

<cmdType>^(num)	
36	Proactive command ID, see Remote-SAT Command Types
<commandDetails>^(num)	
0...255	Used as bit field
bit 1	0: Presentation type is not specified 1: Presentation type is specified in bit 2
bit 2	0: Presentation as a choice of data values, if bit 1 = '1' 1: Presentation as a choice of navigation options if bit 1 is '1'
bit 3	0: No selection preference 1: Selection using soft key preferred
bit 4-7	RFU
bit 8	0: No help information available 1: Help information available
<numOfItems>^(num)	
Number of items in the list	
<titleText>^(str)	
String giving menu title	

<defaultItemId>^(num)

ID of default item

The SIM may supply with the list an indication of the default item, e.g. the previously selected item

0	No default item issued by the SIM application
1...255	Id of the default Item

<itemIconsPresent>^(num)

0	No icons
1	Icons present

<itemIconsQualifier>^(num)

0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU

<titleIconQualifier>^(num)

0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU

<titleIconId>^(num)

0...255	
0	No Icon

<itemId>^(num)

Item identifier (1 - [<numOfItems>](#))

<itemText>^(str)

String giving menu title

<nextActionId>^(num)

The next proactive command type to be issued upon execution of the menu item. See [Remote-SAT Command Types](#)

0	Next Action information available
---	-----------------------------------

<iconId>^(num)

0...255	
0	No Icon

8.20 AT^SSTGI SAT Get Information - Set up Menu (37)

This command shall be used after receiving the URC ^SSTN: 37. The response provides the main menu of the SIM Application to the TE. It needs to be stored by the TE so that it can be displayed without invoking a proactive session.


As with every proactive command the TE is expected to acknowledge the ^SSTGI response with AT^SSTR to confirm that the proactive command has been executed.

Terminal Response via AT^SSTR will not provide any user information in case of this proactive command. Refer to [AT^SSTR](#).

AT^SSTGI can be issued during states IDLE, PAC and WAIT for this proactive command without previously receiving a URC ^SSTN:<cmdType>, see [AT^SSTGI](#).

Syntax

```
Write Command
AT^SSTGI=37
Response(s)
The first line of output from the ME is:
^SSTGI: <cmdType>, <commandDetails>, <numOfItems>, <titleText>,
<menuItemIconsPresent>, <menuItemIconsQualifier>, <titleIconQualifier>,
<titleIconId>
One line follows for every item, repeated for <numOfItems>:
^SSTGI: <cmdType>, <itemId>, <itemText>, <nextActionId>, <iconId>
OK
ERROR
+CME ERROR: <err>
```



Parameter Description

<cmdType>^(num)	
37	Proactive command ID, see Remote-SAT Command Types
<commandDetails>^(num)	
0...255	Used as bit field
bit 1	0: No selection preference 1: Selection using soft key preferred
bit 2-7	RFU
bit 8	0: No help information available 1: Help information available
<numOfItems>^(num)	
Number of menu items in the list	
<titleText>^(str)	
String displaying menu title	

<menuItemIconsPresent>^(num)

0	No icons
1	Icons present

<menuItemIconsQualifier>^(num)

0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU

<titleIconQualifier>^(num)

0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU

<titleIconId>^(num)

0...255	
0	No Icon

<itemId>^(num)

Menu item identifier (1 - [<numOfItems>](#))

<itemText>^(str)

Title of menu item

<nextActionId>^(num)

The next proactive command type to be issued upon execution of the menu item. See [Remote-SAT Command Types](#)

0	No next Action information available
---	--------------------------------------

<iconId>^(num)


0...255	
0	No Icon

8.21 AT^SSTGI SAT Get Information - Set up Idle Mode Text (40)

This command shall be used after receiving the URC ^SSTN: 40.
It provides text and optionally an icon to be displayed by the TE when the display is Idle.

Syntax

```
Write Command
AT^SSTGI=40
Response(s)
^SSTGI: <cmdType>, <commandDetails>, <text>, <iconQualifier>, <iconId>
OK
ERROR
+CME ERROR: <err>
```



Parameter Description

<cmdType>^(num)	
40	Proactive command ID, see Remote-SAT Command Types
<commandDetails>^(num)	
This byte is RFU.	
<text>^(str)	
Text to be displayed when TE in IDLE mode	
<iconQualifier>^(num)	
0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU
<iconId>^(num)	
0...255	
0	No Icon

Note

- AT^SSTGI can be issued during states IDLE, PAC and WAIT for this proactive command without previously receiving a URC ^SSTN:<cmdType>, see AT^SSTGI.

8.22 AT^SSTGI SAT Get Information - Language Notification (53)

This command shall be used after receiving the URC ^SSTN: 53.

It provides text to inform the TE about the language currently used for any text string within proactive commands or envelope command responses.

The notified language remains valid until the end of the card session or upon executing another LANGUAGE NOTIFICATION command.

If the Toolkit application is not aware of the currently selected language, no specific language or several languages will be used. The SIM may notify non-specific language. All LANGUAGE NOTIFICATION previously made will be cancelled.

Two types of language notification are defined:

- specific, where a two-character language notification is issued in `<langText>`,
- non-specific, where no language notification is issued, i.e. `<langText>` is an empty string.

The TE may use the language included in LANGUAGE NOTIFICATION as appropriate. For instance, this could be done to avoid a mix of languages in screen displays combining UE MMI and SIM Toolkit originating text strings.

Syntax

```
Write Command
AT^SSTGI=53
Response(s)
^SSTGI: <cmdType>, <commandDetails>, <langText>
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<code><cmdType></code> ^(num)	
53	Proactive command ID, see Remote-SAT Command Types
<code><commandDetails></code> ^(num)	
0...255	Used as bit field
bit 1	0: non-specific language notification 1: specific language notification
bit 2-8	RFU
<code><langText></code> ^(str)	
Language code string provided as a pair of alpha-numeric characters, defined in ISO 639. Each alphanumeric character is coded on one byte using the SMS default 7-bit coded alphabet as defined in 3GPP TS 23.038[36].	

Note

- AT^SSTGI can be issued during states IDLE, PAC and WAIT for this proactive command without previously receiving a URC ^SSTN:<cmdType>, see AT^SSTGI.

8.23 AT^SSTGI SAT Get Information - Open Channel (64)

The SIM Application is opening a data session for the Bearer Independent Protocol, and can provide the TE with some information about this.

Text and an icon identifier can be passed to the TE for display to the user.

Syntax

```
Write Command
AT^SSTGI=64
Response(s)
^SSTGI: <cmdType>, <commandDetails>, <text>, <iconQualifier>, <iconId>
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cmdType>^(num)
64 Proactive command ID, see Table 8.6, [Command Type Table](#).

<commandDetails>^(num)
This byte is RFU.

<text>^(str)
String to provide the user with information.
If the string is provided by the SIM, the TE shall use it to inform the user. This is also an indication that the TE should not give any other information to the user on the fact that the UE is performing an Open Channel command.
If the alpha identifier is not provided by the SIM, the UE may give information to the user concerning what is happening.

<iconQualifier>^(num)

0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU

<iconId>^(num)

0...255	
0	No Icon

8.24 AT^SSTGI SAT Get Information - Close Channel (65)

The SIM Application is closing a data session for the Bearer Independent Protocol, and can provide the TE with some information about this.

Text and an icon identifier can be passed to the TE for display to the user.

Syntax

```
Write Command
AT^SSTGI=65
Response(s)
^SSTGI: <cmdType>, <commandDetails>, <text>, <iconQualifier>, <iconId>
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cmdType>^(num)
 65 Proactive command ID, see Table 8.6, [Command Type Table](#).

<commandDetails>^(num)
 This byte is RFU.

<text>^(str)
 String to provide the user with information.
 If the string is provided by the SIM, the TE shall use it to inform the user. This is also an indication that the TE should not give any other information to the user on the fact that the UE is performing a Close Channel command.
 If the alpha identifier is not provided by the SIM, the UE may give information to the user concerning what is happening.

<iconQualifier>^(num)

0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU

<iconId>^(num)

0...255	
0	No Icon

8.25 AT^SSTGI SAT Get Information - Receive Data (66)

The SIM Application receives data in an open session for the Bearer Independent Protocol, and can provide the TE with some information about this. Text and an icon identifier can be passed to the TE for display to the user.

Syntax

```
Write Command
AT^SSTGI=66
Response(s)
^SSTGI: <cmdType>, <commandDetails>, <text>, <iconQualifier>, <iconId>
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cmdType>^(num)	
66	Proactive command ID, see Table 8.6, Command Type Table .
<commandDetails>^(num)	
This byte is RFU.	
<text>^(str)	
String to provide the user with information. If the string is provided by the SIM, the TE shall use it to inform the user. This is also an indication that the TE should not give any other information to the user on the fact that the UE is performing an Open Channel command. If the alpha identifier is not provided by the SIM, the UE may give information to the user concerning what is happening.	
<iconQualifier>^(num)	
0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU
<iconId>^(num)	
0...255	
0	No Icon

8.26 AT^SSTGI SAT Get Information - Send Data (67)

The SIM Application sends data in an open session for the Bearer Independent Protocol, and can provide the TE with some information about this. Text and an icon identifier can be passed to the TE for display to the user.

Syntax

```

Write Command
AT^SSTGI=67
Response(s)
^SSTGI: <cmdType>, <commandDetails>, <text>, <iconQualifier>, <iconId>
OK
ERROR
+CME ERROR: <err>
    
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cmdType>^(num)
 67 Proactive command ID, see Table 8.6, [Command Type Table](#).

<commandDetails>^(num)
 This byte is RFU.

<text>^(str)
 String to provide the user with information. If the string is provided by the SIM, the TE shall use it to inform the user. This is also an indication that the TE should not give any other information to the user on the fact that the UE is performing an Open Channel command. If the alpha identifier is not provided by the SIM, the UE may give information to the user concerning what is happening.

<iconQualifier>^(num)

0...255	Used as bit field
bit 1	0: Icon is self explanatory and replaces text 1: Icon is not self-explanatory and shall be displayed with the text Determined value only if associated icon ID is not 0 (an icon exists).
bit 2-8	RFU

<iconId>^(num)

0...255	
0	No Icon

8.27 AT^SSTR SAT Response

The TE is expected to acknowledge the `AT^SSTGI` response with `AT^SSTR` to confirm that the Proactive Command has been executed. `AT^SSTR` will also provide any user information, e.g. a selected menu item.

Syntax

```

Test Command
AT^SSTR=?
Response(s)
^SSTR: (list of supported <state>s), (list of supported <cmdType>s)
OK

Read Command
AT^SSTR?
Response(s)
^SSTR: <state>, <cmdType>
OK

Write Command
AT^SSTR=<cmdType>, <status>[, <inputNumber>][, <inputString>][, <statAddInfo>]
Response(s)
^SSTR: <cmdType>[, <TerminationQualifier>, <TerminationCauseText>]
OK
    
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

`<state>`^(num)

PLS8-X Remote-SAT interface states

0	RESET
1	OFF
2	IDLE
3	PAC
4	WAIT

`<cmdType>`^(num)

Number related to Proactive Command or event type according to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].

`<TerminationQualifier>`^(num)

0	The proactive command has been successfully finished.
1...255	The proactive command did not perform successfully.

`<TerminationCauseText>`^(str)

This text has to be shown to the user for an appropriate time, e.g. 2 seconds. The text contains information regarding the termination cause, e.g. in case of a failed dialing process call barring through Call Control by SIM mechanism may be indicated.

If `<TerminationCauseText>` is an empty string and `<TerminationQualifier>` is not equal to 0, the TE may give an own indication to the user.

`<status>`^(num)

Command status return regarding the type of action that has taken place, e.g. action performed by the user. Values are in accordance with 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].

`<inputNumber>`^(num)

Response number entered by user

`<inputString>`^(str)

Response string entered by user

`<statAddInfo>`^(num)

Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].

8.28 AT^SSTR SAT Response - Refresh (1)

The TE is expected to acknowledge the `AT^SSTGI` response with `AT^SSTR` to confirm that the Proactive Command has been executed.

Syntax

Write Command

```
AT^SSTR=1, <status>, [, <statAddInfo>]
```

Response(s)

```
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

`<status>`^(num)

0...255

0 Command performed successfully

`<statAddInfo>`^(num)

Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].

0...255

Note

- The refresh action (SIM data cache update) will be performed in any case, i.e. `<status>` values other than 0 will be ignored.

8.29 AT^SSTR SAT Response - Set Up Event List (5)

The TE is expected to acknowledge the `AT^SSTGI` response with `AT^SSTR` to confirm that the Proactive Command has been executed. The TE acknowledges that the event list has been set up correctly.

Syntax

Write Command

```
AT^SSTR=5, <status>, [, <statAddInfo>]
```

Response(s)

```
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

`<status>`^(num)

0...255

0	Command performed successfully
32	UE currently unable to process command
48	Command beyond UE's capabilities
132	UE currently unable to process command because screen is busy

`<statAddInfo>`^(num)

Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].


0...255

8.30 AT^SSTR SAT Response - Set Up Call (16)

The TE is expected to acknowledge the AT^SSTGI response with AT^SSTR to confirm that the Proactive Command has been executed.

Syntax

```
Write Command
AT^SSTR=16, <status>, [, <statAddInfo>]
Response(s)
^SSTR: 16, <TerminationQualifier>, <TerminationCauseText>
OK
```



Parameter Description

<status> ^(num)	
0...255	
0	Command performed successfully. Indicate that the user has accepted the call request.
4	Command performed successfully, but requested icon could not be displayed.
16	Proactive SIM session terminated by user
20	USSD/SS Transact terminated by user
32	UE currently unable to process command
34	User did not accept the proactive command. Indicate that the user has denied the call request
35	User cleared down call before connection or network release
48	Command beyond UE's capabilities
132	UE currently unable to process command because screen is busy

<statAddInfo> ^(num)	
Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].	
0...255	

Note

- After confirmation phase the TE may show a dialling animation on the screen until a mandatory response parameter is issued.
 ^SSTR: <cmdType>, <TerminationQualifier>, <TerminationCauseText>

8.31 AT^SSTR SAT Response - Send SS (17)

The TE is expected to acknowledge the AT^SSTGI response with AT^SSTR to confirm that the Proactive Command has been executed.

Syntax

Write Command

```
AT^SSTR=17, <status>
```

Response(s)

```
^SSTR: 17, <TerminationQualifier>, <TerminationCauseText>
```

```
OK
```

PIN MDM APP → Last

- + + + -

Parameter Description

<status>^(num)

0...4

0 Command performed successfully. Indicate that the user has accepted the SS request.

4 Command performed successfully, but requested icon could not be displayed.

8.32 AT^SSTR SAT Response - Send USSD (18)

The TE is expected to acknowledge the AT^SSTGI response with AT^SSTR to confirm that the Proactive Command has been executed.

Syntax

Write Command

```
AT^SSTR=18, <status>
```

Response(s)

```
^SSTR: 18, <TerminationQualifier>, <TerminationCauseText>
```

```
OK
```

PIN MDM APP → Last

- + + + -

Parameter Description

<status>^(num)

0...4

0

Command performed successfully. Indicate that the user has accepted the USSD request.

4

Command performed successfully, but requested icon could not be displayed.

8.33 AT^SSTR SAT Response - Send Short Message (19)

The TE is expected to acknowledge the AT^SSTGI response with AT^SSTR to confirm that the Proactive Command has been executed.

Syntax

Write Command

```
AT^SSTR=19, <status>
```

Response(s)

```
^SSTR: 19, <TerminationQualifier>, <TerminationCauseText>
```

```
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<status>^(num)

0...4

0

Command performed successfully. Indicate that the user has accepted the SMS request.

4

Command performed successfully, but requested icon could not be displayed.

8.34 AT^SSTR SAT Response - Send DTMF (20)

The TE is expected to acknowledge the `AT^SSTGI` response with `AT^SSTR` to confirm that the Proactive Command has been executed.

Syntax

```
Write Command
AT^SSTR=20, <status>, [, <statAddInfo>]
Response(s)
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<code><status></code> ^(num)	
0...255	
0	Command performed successfully. Indicate that the user has accepted the Send DTMF request.
4	Command performed successfully, but requested icon could not be displayed.
16	Proactive SIM session terminated by user
32	UE currently unable to process command
48	Command beyond UE's capabilities
132	UE currently unable to process command because screen is busy

<code><statAddInfo></code> ^(num)	
Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].	
0...255	

8.35 AT^SSTR SAT Response - Launch Browser (21)

The TE is expected to acknowledge the AT^SSTGI response with AT^SSTR to confirm that the Proactive Command has been executed.

Syntax

```
Write Command
AT^SSTR=21, <status>, [, <statAddInfo>]
Response(s)
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<status> ^(num)	
0...255	
0	Command performed successfully. Indicates that the user has accepted the Launch Browser request.
4	Command performed successfully, but requested icon could not be displayed.
32	UE currently unable to process command
34	User did not accept the proactive command. Indicates that the user has denied the Launch Browser request
38	Launch Browser generic error with additional information "No specific cause can be given".
48	Command beyond UE's capabilities
132	UE currently unable to process command because screen is busy
138	Launch Browser generic error with additional information "Bearer unavailable".
238	Launch Browser generic error with additional information "Browser unavailable".
239	Launch Browser generic error with additional information "UE unable to read the provisioning data".

<statAddInfo> ^(num)	
For the general result "Launch Browser generic error code", it is mandatory for the UE to provide additional information.	
0...255	
0	"No specific cause can be given"
1	"Bearer unavailable"
2	"Browser unavailable"
3	"UE unable to read the provisioning data"

8.36 AT^SSTR SAT Response - Play Tone (32)

The TE is expected to acknowledge the `AT^SSTGI` response with `AT^SSTR` to confirm that the Proactive Command has been executed.

Syntax

```
Write Command
AT^SSTR=32, <status>, [, <statAddInfo>]
Response(s)
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<code><status></code> ^(num)	
0...255	
0	Command performed successfully. Indicates that the user has accepted the Play Tone request.
4	Command performed successfully, but requested icon could not be displayed.
16	Proactive SIM session was terminated by user.
32	UE or TE currently unable to process command.
48	Command beyond UE's (respectively TE's) capabilities.
132	TE currently unable to process command because screen is busy.

<code><statAddInfo></code> ^(num)	
Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].	
0...255	

Note

- This command starts playing the tone by the UE. It is possible for the TE to stop playing the tone via user break, i.e. issue any character whilst the command is running.

8.37 AT^SSTR SAT Response - Display Text (33)

The TE is expected to acknowledge the `AT^SSTGI` response with `AT^SSTR` to confirm that the Proactive Command has been executed.

Syntax

```
Write Command
AT^SSTR=33, <status>, [, <statAddInfo>]
Response(s)
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<code><status></code> ^(num)	
0...255	
0	Command performed successfully. Indicates that the user has accepted the Display Text request.
4	Command performed successfully, but requested icon could not be displayed.
16	Proactive SIM session terminated by user
17	Backward move in the proactive SIM session requested by the user
18	No response from user
32	UE currently unable to process command
48	Command beyond UE's capabilities
132	UE currently unable to process command because screen is busy

<code><statAddInfo></code> ^(num)	
Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].	
0...255	

8.38 AT^SSTR SAT Response - Get Inkey (34)

The TE is expected to acknowledge the [AT^SSTGI](#) response with [AT^SSTR](#) to confirm that the Proactive Command has been executed.

Syntax

```
Write Command
AT^SSTR=34, <status>, , <inputString>[, <statAddInfo>]
Response(s)
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<code><status></code> ^(num)	
0...255	
0	Command performed successfully. Indicates that the user has accepted the Get Inkey request.
4	Command performed successfully, but requested icon could not be displayed.
16	Proactive SIM session terminated by user
17	Backward move in the proactive SIM session requested by the user
18	No response from user
19	Help information required by the user
32	UE currently unable to process command
48	Command beyond UE's capabilities
132	UE currently unable to process command because screen is busy

`<inputString>`^(str)
User response entered as a string parameter

`<statAddInfo>`^(num)
Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].
0...255

Notes

- Coding of any input character is related to the selected alphabet:
 - Input of a character in case of GSM character set requests one byte, e.g. "Y".
 - Input of any characters in UCS2 alphabet requests a 4 byte set, e.g. "0059" is coding the same character "Y".
 - If, as a user response, a binary choice (Yes/No) is requested by the SIM application using bit 3 of the `<commandDetails>` parameter the valid content of the `<inputString>` is:
 - GSM alphabet: "Y" or "y" (positive answer) and "N" or "n" (negative answer).
 - UCS2 alphabet "0079" or "0059" (positive answer) and "006E" or "004E" (negative answer). For more detailed information refer to [AT^SSTGI](#).
 - Coding of an empty string is done as a "\1b" string with every alphabet.


-
- The `<Alphabet>` parameter of `AT^SSTA` determines the alphabet used on the AT command interface, while the value reported by the `<commandDetails>` bit 2 of the `AT^SSTGI=34` command determines the set of characters allowed. If these alphabet settings are different, the following applies:
Example: If UCS2 alphabet is selected with `AT^SSTA` and the `<commandDetails>` bit 2 of the `AT^SSTGI=34` command is reported as "SMS default alphabet (GSM character set)" any input has to be done in UCS2 alphabet. However, take care to enter only UCS2 characters for which equivalent characters are defined in the SMS (GSM) default alphabet. In this case, the ME will correctly translate the given UCS2 data into a TERMINAL RESPONSE coded in SMS (GSM) default alphabet. See also Section 1.7.2, [UCS2 and GSM character coding and conversion](#).

8.39 AT^SSTR SAT Response - Get Input (35)

The TE is expected to acknowledge the `AT^SSTGI` response with `AT^SSTR` to confirm that the Proactive Command has been executed.

Syntax

```
Write Command
AT^SSTR=35, <status>, , <inputString>[, <statAddInfo>]
Response(s)
OK
```



Parameter Description

<code><status></code> ^(num)	
0...255	
0	Command performed successfully. Indicates that the user has accepted the Get Input request.
4	Command performed successfully, but requested icon could not be displayed.
16	Proactive SIM session terminated by user
17	Backward move in the proactive SIM session requested by the user
18	No response from user
19	Help information required by the user
32	UE currently unable to process command
48	Command beyond UE's capabilities
132	UE currently unable to process command because screen is busy

`<inputString>`^(str)
User response entered as a string, length depends on the `<responseMin>` and `<responseMax>` values returned by the related `AT^SSTGI=35` command.

`<statAddInfo>`^(num)
Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].
0...255

Notes

- Coding of any input character is related to the selected alphabet:
 - Input of a character in case of GSM character set requests one byte, e.g. "Y".
 - Input of any characters in UCS2 alphabet requests a 4 byte set, e.g. "0059" is coding the same character "Y".
 - Coding of an empty string is done as a "\1b" string with every alphabet.

-
- The `<Alphabet>` parameter of `AT^SSTA` determines the alphabet used on the AT command interface, while the value reported by the `<commandDetails>` bit 2 of the `AT^SSTGI=35` command determines the set of characters allowed. If these alphabet settings are different, the following applies:
Example: If UCS2 alphabet is selected with `AT^SSTA` and the `<commandDetails>` bit 2 of the `AT^SSTGI=35` command is reported as "SMS default alphabet (GSM character set)" any input has to be done in UCS2 alphabet. However, take care to enter only UCS2 characters for which equivalent characters are defined in the SMS (GSM) default alphabet. In this case, the UE will correctly translate the given UCS2 data into a TERMINAL RESPONSE coded in SMS (GSM) default alphabet. See also Section 1.7.2, [UCS2 and GSM character coding and conversion](#).

8.40 AT^SSTR SAT Response - Select Item (36)

The TE is expected to acknowledge the AT^SSTGI response with AT^SSTR to confirm that the Proactive Command has been executed. The TE sends a response that can indicate the user's intentions, e.g. when the user is requesting help or selecting a menu item.

For compatibility reasons <itemId> is optional in case of <status>=19 ("Help information required by the user"). In this case <itemId>=0 is sent to the USIM.

Syntax

```
Write Command
AT^SSTR=36, <status>, <itemId>[, <statAddInfo>]
Response(s)
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<status> ^(num)	
0...255	
0	Command performed successfully. Indicates that the user has accepted the Select Item request.
4	Command performed successfully, but requested icon could not be displayed.
16	Proactive SIM session terminated by user
17	Backward move in the proactive SIM session requested by the user
18	No response from user
19	Help information required by the user
32	UE currently unable to process command
48	Command beyond UE's capabilities
132	UE currently unable to process command because screen is busy

<itemId> ^(num)	
Item IDs are supplied by the SIM Application	
1...255	ID of selected item can be issued if a <status> value of 0 is returned

<statAddInfo> ^(num)	
Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].	
0...255	

8.41 AT^SSTR SAT Response - Set Up Menu (37)

The TE is expected to acknowledge the `AT^SSTGI` response with `AT^SSTR` to confirm that the Proactive Command has been executed.

Syntax

```
Write Command
AT^SSTR=37, <status>, [, <statAddInfo>]
Response(s)
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<code><status></code> ^(num)	
0...255	
0	Command performed successfully. Indicates that the user has accepted the Set Up Menu request.
4	Command performed successfully, but requested icon could not be displayed.
32	UE currently unable to process command
48	Command beyond UE's capabilities
132	UE currently unable to process command because screen is busy

<code><statAddInfo></code> ^(num)	
Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].	
0...255	

Note

- The response simply conveys, to the SAT, the information that the main menu was received and set up on the user interface. It does not transmit any information about a selected item, like in the case of `AT^SSTR`.

Once this command was executed the user can proceed as described in the `AT^SSTR` SAT Response - Setup Menu (37).

8.42 AT^SSTR SAT Response - Set Up Idle Mode Text (40)

The TE is expected to acknowledge the `AT^SSTGI` response with `AT^SSTR` to confirm that the Proactive Command has been executed.

Syntax

```
Write Command
AT^SSTR=40, <status>, [, <statAddInfo>]
Response(s)
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<code><status></code> ^(num)	
0...255	
0	Command performed successfully. Indicates that the user has accepted the Set Up Idle Mode Text request.
4	Command performed successfully, but requested icon could not be displayed.
32	UE currently unable to process command
48	Command beyond UE's capabilities
132	UE currently unable to process command because screen is busy

<code><statAddInfo></code> ^(num)	
Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].	
0...255	

8.43 AT^SSTR SAT Response - Language Notification (53)

The TE is expected to acknowledge the `AT^SSTGI` response with `AT^SSTR` to confirm that the Proactive Command has been executed. The TE indicates whether the Language Notification command was correctly executed.

Syntax

Write Command

```
AT^SSTR=53, <status>, [, <statAddInfo>]
```

Response(s)

```
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

`<status>`^(num)

0...255

0

Command performed successfully. Indicates that the user has accepted the Language Notification request.

`<statAddInfo>`^(num)

Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].


0...255

8.44 AT^SSTR SAT Response - Open Channel (64)

The TE is expected to acknowledge the `AT^SSTGI` response with `AT^SSTR` to confirm that the Proactive Command has been executed.

Syntax

```
Write Command
AT^SSTR=64, <status>, [, <statAddInfo>]
Response(s)
OK
```



Parameter Description

<code><status></code> ^(num)	
0...255	
0	Command performed successfully. Indicates that the user has accepted the Open Channel request.
4	Command performed successfully, but requested icon could not be displayed.
16	Proactive SIM session terminated by user
32	UE currently unable to process command
48	Command beyond UE's capabilities
132	UE currently unable to process command because screen is busy

<code><statAddInfo></code> ^(num)	
Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].	
0...255	

8.45 AT^SSTR SAT Response - Close Channel (65)

The TE is expected to acknowledge the `AT^SSTGI` response with `AT^SSTR` to confirm that the Proactive Command has been executed.

Syntax

Write Command

```
AT^SSTR=65, <status>, [, <statAddInfo>]
```

Response(s)

```
OK
```

PIN MDM APP → Last

- + + + -

Parameter Description

`<status>`^(num)

0...255

0	Command performed successfully. Indicates that the user has accepted the Close Channel request.
4	Command performed successfully, but requested icon could not be displayed.
16	Proactive SIM session terminated by user
32	UE currently unable to process command
48	Command beyond UE's capabilities
132	UE currently unable to process command because screen is busy

`<statAddInfo>`^(num)

Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].

0...255

8.46 AT^SSTR SAT Response - Receive Data (66)

The TE is expected to acknowledge the AT^SSTGI response with AT^SSTR to confirm that the Proactive Command has been executed.

Syntax

```
Write Command
AT^SSTR=66, <status>, [, <statAddInfo>]
Response(s)
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<status> ^(num)	
0...255	
0	Command performed successfully. Indicates that the user has accepted the Receive Data request.
4	Command performed successfully, but requested icon could not be displayed.
16	Proactive SIM session terminated by user
32	UE currently unable to process command
48	Command beyond UE's capabilities
132	UE currently unable to process command because screen is busy

<statAddInfo> ^(num)	
Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].	
0...255	

8.47 AT^SSTR SAT Response - Send Data (67)

The TE is expected to acknowledge the `AT^SSTGI` response with `AT^SSTR` to confirm that the Proactive Command has been executed.

Syntax

```
Write Command
AT^SSTR=67, <status>, [, <statAddInfo>]
Response(s)
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<code><status></code> ^(num)	
0...255	
0	Command performed successfully. Indicates that the user has accepted the Send Data request.
4	Command performed successfully, but requested icon could not be displayed.
16	Proactive SIM session terminated by user
32	UE currently unable to process command
48	Command beyond UE's capabilities
132	UE currently unable to process command because screen is busy

<code><statAddInfo></code> ^(num)	
Optional additional command status; for possible values refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].	
0...255	

8.48 AT^SSTR SAT Event - Menu Selection (211)

The TE specifies the user's selection of an item from the main menu, which was set up using SETUP MENU command. Alternatively help can be requested.

Syntax

Write Command

```
AT^SSTR=211, <status>, <itemId>
```

Response(s)

```
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<status>^(num)

0...255

0 Command performed successfully.

19 Help information required by the user, no other value can be returned.

<itemId>^(num)

ID of selected item

0...255

8.49 AT^SSTR SAT Event - User Activity (232)

Sent by the customer application to indicate that a key has been pressed.

Syntax

Write Command

```
AT^SSTR=232
```

Response(s)

```
OK
```

PIN	MDM	APP	→	Last
-----	-----	-----	---	------

-	+	+	+	-
---	---	---	---	---

8.50 AT^SSTR SAT Event - Idle Screen Available (233)

Sent by the customer application to indicate that the screen has become idle.

Syntax

Write Command

```
AT^SSTR=233
```

Response(s)

```
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

8.51 AT^SSTR SAT Event - Language Selection (235)

Sent by the customer application to indicate that the customer application has changed the language. The last value given via this command is also provided to the SIM as response to the proactive command "Provide Local Information (Language Setting)".

Syntax

Write Command

```
AT^SSTR=235,,,<inputString>
```

Response(s)

```
OK
```

PIN	MDM	APP	→	Last
-----	-----	-----	---	------

-	+	+	+	-
---	---	---	---	---

Parameter Description

<inputString>^(str)

Two character language tag, e.g. "en" for English or "de" for German. Default value is "en".

8.52 AT^SSTR SAT Event - Browser Termination (236)

Sent by the customer application to indicate that the internet browser application has been terminated.

Syntax

```
Write Command
AT^SSTR=236, , , <TermCause>
Response(s)
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<TermCause> ^(num)	
Browser Termination Cause	
0...255	
0	User termination
1	Error termination

8.53 AT^SSTR SAT Event - Terminate Command (254)

This command allows the TE to finish an ongoing proactive command session. As a result, the UE will attempt to return to IDLE mode. This is done by sending repeatedly a Terminal Response ("ME currently unable to process command") to the SIM (see 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23]), if issued in states PAC or WAIT. No action is performed if the interface is already in IDLE state, however, the command returns "OK".

The reaction to the Terminal Response depends on the SIM application: The UE may either be kept in IDLE state or requested to perform another action.

Syntax

Write Command					
AT^SSTR=254					
Response(s)					
OK					
PIN	MDM	APP	→	Last	
-	+	+	+	-	

8.54 Examples for Using Remote-SAT

To give you an idea of how to start and use Remote-SAT, you may follow the steps described below:

```
// Start after switch on the module
at
OK

// Switch on verbose error messages
at+cmee=2
OK

// Enter the PIN code (if necessary due to SIM configuration)
at+cpin=1234
OK

// Query the Remote-SAT activation status
at^ssta?
^SSTA: 1,0,1,"FFFFFFFF7F1F00DFFF00001FE20000000360",300,1 for USIM (3G)
or
^SSTA: 1,0,1,"7FFFFFFFF7F0F00DFFF00001FE200000003",300,1 for SIM (2G).
OK
// First '1' indicates that the interface is in OFF state, i.e. the Automatic Response (AR) mode is enabled. During
this mode all SAT Proactive Commands are handled internally by the UE.

// Tell the module that the TE is interested in handling SAT, i.e. switch to Explicit Response (ER) mode.
at^ssta=1,0
OK

// This setting takes effect after next start of the UE only, so switch off first
AT^SMSO
OK

// Switch on UE again

// Switch on verbose error messages
at+cmee=2
OK

// Enter the PIN code (if necessary due to SIM configuration)
at+cpin=1234
OK

// Receiving the first proactive command (if the mounted SIM carries a SIM Application)
^SSTN:37

// Requesting parameter details
at^sstgi=37

// These are the details:
^SSTGI: 37,0,3,"SAT Special Menu",0,1,1,0
^SSTGI: 37,1,"News",0,0
^SSTGI: 37,2,"EMail",0,0
^SSTGI: 37,3,"Banking",0,0

OK

// To query the status of the proactive command
at^sstr=37,0

OK
```

```
// SAT indicates that the proactive session has ended and enters its main menu (which should then be opened
on the screen by an MMI): ^SSTN:254
```

```
// Selecting item number 1 of the menu sent before:
at^sstr=211,0,1
```

OK

```
// Receiving the next proactive command:
^SSTN:36
```

```
// Requesting more information...
at^sstgi=36
```

```
// ... and get it:
^SSTGI: 36,0,12,"Rubriken >",0,0,1,1,0
^SSTGI: 36,1,"News >",0,0
^SSTGI: 36,2,"Stock Infos>",0,0
^SSTGI: 36,3,"Aktien D >",0,0
^SSTGI: 36,4,"Aktien INT >",0,0
^SSTGI: 36,5,"Sports >",0,0
^SSTGI: 36,6,"1.BL-Clubs >",0,0
^SSTGI: 36,7,"Unterhaltung>",0,0
^SSTGI: 36,8,"Horoskop >",0,0
^SSTGI: 36,9,"Wetter D >",0,0
^SSTGI: 36,10,"Wetter INT >",0,0
^SSTGI: 36,11,"Wetter spez>",0,0
^SSTGI: 36,63,"Extras >",0,0
```

OK

```
// Remember to acknowledge:
at^sstr=36,0,63
```

OK

```
// And again: Receiving the next proactive command:
^SSTN:36
// ...
```

Examples

EXAMPLE 1

```
// Switch on verbose error messages
at+cmee=2
OK
```

EXAMPLE 2

```
// Enter the PIN code
at+cpin=1234
OK
```

EXAMPLE 3

```
// Start Remote-SAT
at^ssta=1,0
OK
```

EXAMPLE 4

```
// Proactive command "GET INKEY" is issued by the SIM
^SSTN: 34
```

EXAMPLE 5

```
// Get complete data
at^sstgi=34
^SSTGI: 34,0,"<COLOUR-ICON>",1,2
OK
```

EXAMPLE 6

```
// Use GET RESPONSE command (192) to analyze SIM file EF-IMG (hex. 4F20)
at+crsm=192,20256,0,0,15
+CRSM: 144,0,000000644F20040014F04401020114
OK
```

EXAMPLE 7

```
// Use READ RECORD command (178) to get its content
at+crsm=178,20256,2,4,20
+CRSM: 144,0,010808214F0200000016FFFFFFFFFFFFFFFFFFFFFFF
OK
```

EXAMPLE 8

```
// Use READ BINARY command (176) to get content of image instance data file (e.g. hex 4F02)
at+crsm=176,20226,0,0,22
+CRSM: 144,0,080802030016AAAA800285428142814281528002AAAA
OK
```

```
at+crsm=176,20226,0,22,9
+CRSM: 144,0,FF000000FF000000FF
OK
```

EXAMPLE 9

```
// Finalize Proactive Command session
at^sstr=34,0,,"+"
OK
```

EXAMPLE 10

```
// Session end indication, i.e. display SAT main menu
^SSTN: 254
```

9. Short Message Service (SMS) Commands

The AT Commands described in this chapter allow an external application to use the Short Message Service with the PLS8-X.

9.1 SMS parameters

This section provides an overview of parameters included in SMS related AT commands and lists references to 3GPP TS specifications.

Parameter Description

`<ackpdu>(num)`

Format is same for `<pdu>` in case of SMS, but without 3GPP TS 24.011 [40] SC address field and parameter shall be bounded by double quote characters like a normal string type parameter.

`<ct>(num)`

Command Type

3GPP TS 23.040 [37] TP-Command-Type in integer format

[0]...255

`<da>(str)(+CSCS)`

Destination Address

3GPP TS 23.040 [37] TP-Destination-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by `<toda>`

`<data>(num)(+CSCS)`

User Data (in text mode)

In case of SMS: 3GPP TS 23.040 [37] TP-User-Data in text mode responses; format:

- If `<dcs>` indicates that 3GPP TS 23.038 [36] default alphabet is used and `<fo>` indicates that 3GPP TS 23.040 [37] TP-User-Data-Header-Indication is not set: UE converts GSM alphabet into current TE character set according to rules covered in Annex A.
- If `<dcs>` indicates that 8-bit or UCS2 data coding scheme is used, or `<fo>` indicates that 3GPP TS 23.040 [37] TP-User-Data-Header-Indication is set: UE converts each 8-bit octet into hexadecimal numbers containing two IRA characters (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).

In case of CBS: 3GPP TS 23.041 [38] CBM Content of Message in text mode responses; format:

- If `<dcs>` indicates that 3GPP TS 23.038 [36] default alphabet is used: UE converts GSM alphabet into current TE character set according to rules covered in Annex A.
- If `<dcs>` indicates that 8-bit or UCS2 data coding scheme is used: UE converts each 8-bit octet into hexadecimal numbers containing two IRA characters.

`<dt>(num)`

Discharge Time

Parameter for Status Reports: 3GPP TS 23.040 [37] TP-Discharge-Time in time-string format: "yy/MM/dd,hh:mm:ss+zz", where characters indicate year (two last digits), month, day, hour, minutes, seconds and time zone. For example, 6th of May 1994, 22:10:00 GMT+2 hours equals "94/05/06,22:10:00+08"

9.1 SMS parameters

<index>^(num)

Integer type; value in the range of location numbers supported by the associated memory.

<length>^(num)

Message Length

Integer type value indicating in PDU mode (**AT+CMGF=0**), the length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length).**<mem1>**^(str)

Memory to be used when listing, reading and deleting messages:

"SM"	SIM message storage
"ME"	GSM/UMTS/LTE Mobile Engine message storage
"MT"	Same as "ME" storage
"SR"	Status report storage Received status reports are not stored by the module. Therefore, AT+CMGR , AT+CMGL , AT^SMGR , AT^SMGL commands will show only status reports previously stored to the "SR" memory.

<mem2>^(str)

Memory to be used when writing and sending messages:

"SM"	SIM message storage
"ME"	GSM/UMTS/LTE Mobile Engine message storage
"MT"	Same as "ME" storage
"SR"	Status report storage

<mem3>^(str)Received messages will be placed in this memory storage if routing to TE is not set. See command **AT+CNMI** with parameter **<mt>=2**.

"SM"	SIM message storage
"ME"	GSM/UMTS/LTE Mobile Engine message storage
"MT"	Same as "ME" storage
"SR"	Status report storage

<mid>^(num)

Message Identifier

3GPP TS 23.041 [38] CBM Message Identifier in integer format

<mn>^(num)

Message Number

3GPP TS 23.040 [37] TP-Message-Number in integer format

<mr>^(num)

Message Reference

3GPP TS 23.040 [37] TP-Message-Reference in integer format

9.1 SMS parameters

<oa>^{(str)(+CSCS)}

Originating Address

3GPP TS 23.040 [37] TP-Originating-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by <toa>

<page>^(num)

Page Parameter

3GPP TS 23.041 [38] CBM Page Parameter bits 4-7 in integer format

<pages>^(num)

Page Parameter

3GPP TS 23.041 [38] CBM Page Parameter bits 0-3 in integer format

<pdu>^(num)

In the case of SMS: 3GPP TS 24.011 [40] SC address followed by 3GPP TS 23.040 [37] TPDU in hexadecimal format: UE converts each octet of TP data unit into hexadecimal numbers containing two IRA characters (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)). In the case of CBS: <ra> 3GPP TS 23.040 [37] TP-Recipient-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted into characters; type of address given by <tora>

<ra>^{(str)(+CSCS)}

Recipient Address

3GPP TS 23.040 [37] TP-Recipient-Address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (refer to command AT+CSCS.); type of address given by <tora>

<sca>^{(str)(+CSCS)}

Service Center Address

3GPP TS 24.011 [40] RP SC address Address-Value field in string format; BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (refer to command AT+CSCS); type of address given by <tosca>

<scts>^(num)

Service Centre Time Stamp

3GPP TS 23.040 [37] TP-Service-Centre-Time-Stamp in time-string format (refer <dt>)

<sn>^(num)

Serial Number

3GPP TS 23.041 [38] CBM Serial Number in integer format

<st>^(num)

Status

3GPP TS 23.040 [37] TP-Status in integer format for Status Report

0...255

9.1 SMS parameters

`<stat>`^(str)

Message status

3GPP 27.005 Interface of SMS and CB. Indicates the status of message in memory.

Description	text mode (<mode>=1)	PDU mode (<mode>=0)	Default
Received unread messages	"REC UNREAD"	0	for SMS reading commands
Received read messages	"REC READ"	1	
Stored unsent messages	"STO UNSENT"	2	for SMS writing commands
Stored sent messages	"STO SENT"	3	
All messages	"ALL"	4	

`<toda>`^(num)

Type of Destination Address

3GPP TS 24.011 [40] TP-Destination-Address Type-of-Address octet in integer format (when first character of <da> is + (IRA 43) default is 145, otherwise default is 129)

0...255

`<toa>`^(num)

Type of Originating Address

3GPP TS 24.011 [40] TP-Originating-Address Type-of-Address octet in integer format (default refer <toda>)

`<tora>`^(num)

Type of Recipient Address

3GPP TS 24.011 [40] TP-Recipient-Address Type-of-Address octet in integer format (default refer <toda>)

`<tosca>`^(num)

Type of Service Center Address

3GPP TS 24.011 [40] RP SC address Type-of-Address octet in integer format (default refer <toda>)

9.2 AT+CMGC Send an SMS command

Syntax

Test Command

AT+CMGC=?

Response(s)

OK

Write Command

If text mode (see [AT+CMGF=1](#))

AT+CMGC=<fo>, <ct>[, <pid>[, <mn>[, <da>[, <toda>]]]]<CR> Text can be entered <CTRL-Z>/<ESC>

Response(s)

+CMGC: <mr>[, <scts>]

If sending fails

ERROR

+CMS ERROR: <err>

Write Command

If PDU mode (see [AT+CMGF=0](#))

AT+CMGC=<length><CR> PDU can be entered <CTRL-Z>/<ESC>

Response(s)

+CMGC: <mr>[, <ackpdu>]

OK

ERROR

+CMS ERROR: <err>

PIN	MDM	APP	→	Last
+	+	+	-	-

Reference(s)

3GPP TS 27.005 [\[47\]](#)

Note

- After invoking the commands [AT+CMGW](#), [AT+CMGS](#) or [AT+CMGC](#) it is necessary to wait for the prompt ">" before entering text or PDU.

9.3 AT+CMGD Delete short message

The write command deletes a short message from the preferred message storage `<mem1>` location `<index>`.

Syntax

Test Command	
AT+CMGD=?	
Response(s)	
+CMGD: (list of used <code><index></code> s)	
OK	
Write Command	
AT+CMGD= <code><index></code>	
Response(s)	
OK	
ERROR	
+CMS ERROR: <code><err></code>	
PIN MDM APP ↗ Last	Reference(s)
+ + + + -	3GPP TS 27.005 [47]

Notes

- Use delete SMS operation only at valid index positions!
- Users should be aware that error will occur when using this AT command quickly after SIM PIN authentication due to the fact the SIM data may not yet be accessible.

9.4 AT+CMGF Select SMS message format

The [AT+CMGF](#) command specifies the input and output format of the short messages.

Syntax

Test Command AT+CMGF=? Response(s) +CMGF: (list of supported <mode>s) OK	
Read Command AT+CMGF? Response(s) +CMGF: <mode> OK	
Write Command AT+CMGF=<mode> Response(s) OK	
PIN MDM APP → Last + + + + -	Reference(s) 3GPP TS 27.005 [47]

Parameter Description

<mode> ^{(num)(&V)(&W)}	
[0] ^(&F)	PDU mode
1	Text mode

9.5 AT+CMGL List SMS messages from preferred store

The write command returns messages with status value `<stat>` from message storage `<mem1>` to the TE. If the status of the message is 'received unread', the status in the storage changes to 'received read'. The execute command is the same as the write command with the given default for `<stat>`.

Syntax

Test Command

AT+CMGL=?

Response(s)

+CMGL: (list of supported `<stat>`s)

OK

Exec Command

AT+CMGL

Response(s)

+CMGL: (see write command for default of `<stat>`)

OK

Write Command

AT+CMGL=`<stat>`

Response(s)

Output if text mode (`AT+CMGF=1`) and command successful:

For SMS- SUBMITs and/or SMS-DELIVERs

+CMGL: `<index>`, `<stat>`, `<oa>/<da>`, , [`<scts>`][, `<toa>/<tda>`, `<length>`]

`<data>`

[...]

OK

For SMS-Commands

+CMGL: `<index>`, `<stat>`, `<fo>`, `<ct>`

[...]

OK

Output if PDU mode `AT+CMGF=0` and command successful:

For SMS-SUBMITs and/or SMS-DELIVERs

+CMGL: `<index>`, `<stat>`, , `<length>`

`<pdu>`

[...]

OK

If error is related to ME functionality

ERROR

+CMS ERROR: `<err>`

PIN MDM APP → Last

+ + + + -

Reference(s)

3GPP TS 27.005 [47]

Notes

- The selected `<mem1>` can contain different types of SMS (e.g. SMS-DELIVERs, SMS-SUBMITs and SMS-COMMANDs), the response may be a mix of the responses of different SM types. TE application can recognize the response format by examining the third response parameter.
- Users should be aware that error will occur when using this AT command quickly after SIM PIN authentication due to the fact the SIM data may not yet be accessible.
- Status reports are not stored by the module and therefore are not displayed by `AT+CMGR` and `AT+CMGL` commands.

9.6 AT+CMGR Read SMS messages

The write command returns SMS message with location value `<index>` from message storage `<mem1>` to the TE. If status of the message is 'received unread', status in the storage changes to 'received read'.

Syntax

Test Command

```
AT+CMGR=?
```

Response(s)

```
OK
```

Write Command

```
AT+CMGR=<index>
```

Response(s)

Output if text mode (`AT+CMGF=1`) and command successful:

For SMS-DELIVER

(in 3GPP SMS format mode only, see `AT^SCFG"SMS/Format"`, `<SmsFormat>`)

```
+CMGR: <stat>, <oa>, , <scts>[, <toa>, <fo>, <pid>, <dc>, <sca>, <tosca>, <length>]  
<data>
```

```
[... ]
```

```
OK
```

For SMS-DELIVER

(in 3GPP2 SMS format mode only, see `AT^SCFG"SMS/Format"`, `<SmsFormat3gpp2>`)

```
+CMGR: <stat>, <oa>, , <scts>[, <toa>, <length>]
```

```
<data>
```

```
[... ]
```

```
OK
```

For SMS-SUBMIT

(in 3GPP SMS format mode only, see `AT^SCFG"SMS/Format"`, `<SmsFormat>`)

```
+CMGR: <stat>, <da>, [, <toda>, <fo>, <pid>, <dc>, [<vp>], <sca>, <tosca>, <length>]
```

```
<data>
```

```
[... ]
```

```
OK
```

For SMS-SUBMIT

(in 3GPP2 SMS format mode only, see `AT^SCFG"SMS/Format"`, `<SmsFormat3gpp2>`)

```
+CMGR: <stat>, <da>, , <scts>[, <toda>, <length>]
```

```
<data>
```

```
[... ]
```

```
OK
```

For SMS-Commands

```
+CMGR: <stat>, <fo>, <ct>[, <pid>[<mn>], [<da>], [<toda>], <length>]
```

```
<data>
```

```
[... ]
```

```
OK
```

Output if PDU mode (`AT+CMGF=0`) and command successful:

For SMS-SUBMITs and/or SMS-DELIVERs

```
+CMGR: <stat>, , <length>
```

```
<pdu>
```

```
[... ]
```

```
OK
```

Write Command					(Continued)
AT+CMGR=<index>					
Response(s)					
ERROR					
+CMS ERROR: <err>					
PIN	MDM	APP	→	Last	Reference(s)
+	+	+	+	-	3GPP TS 27.005 [47]

Notes

- If [AT+CMGR](#) is used to read an empty record the response is: OK.
- If [AT+CMGR](#) is used to read a non-existent record index the response is: "+CMS ERROR: 321" (invalid memory index).
- Users should be aware that error will occur when using this AT command quickly after SIM PIN authentication due to the fact the SIM data may not yet be accessible.
- Status reports are not stored by the module and therefore are not displayed by [AT+CMGR](#) and [AT+CMGL](#) commands.

9.7 AT+CMGS Send Short Message

The write command transmits a short message from TE to network (SMS-SUBMIT).

After invoking the write command wait for the prompt ">" and then start to write the message. To send the message simply enter <CTRL-Z>.

To abort sending use <ESC>. Abortion is acknowledged with "OK", though the message will not be sent.

The message reference <mr> is returned to the TE on successful message delivery. The value can be used to identify the message in a delivery status report provided as an unsolicited result code.

Syntax

Test Command	
AT+CMGS=?	
Response(s)	
OK	
Write Command	
If text mode (see AT+CMGF=1)	
AT+CMGS=<da>[, <toda>]<CR> Text can be entered. <CTRL-Z>/<ESC>	
Response(s)	
+CMGS: <mr>[, <scts>]	
OK	
ERROR	
+CMS ERROR: <err>	
Write Command	
If PDU mode (see AT+CMGF=0)	
AT+CMGS=<length><CR> PDU can be entered. <CTRL-Z>/<ESC>	
Response(s)	
+CMGS: <mr>[, <ackpdu>]	
OK	
ERROR	
+CMS ERROR: <err>	
PIN MDM APP → Last	Reference(s)
+ + + - -	3GPP TS 27.005 [47]

Notes

- Note that some providers do not recognize an @ symbol used in a short message. A widely used alternative is typing "*" as defined in 3GPP TS 23.040 [\[37\]](#).
- Message Length in Text Mode:
The maximum length of a short message depends on the used coding scheme: It is 160 characters if the 7 bit GSM coding scheme is used, and 140 characters according to the 8 bit GSM coding scheme.

9.8 AT+CMGW Write Short Messages to Memory

The execute and write commands transmit a short message (either SMS-DELIVER or SMS-SUBMIT) from TE to memory storage `<mem2>`. Memory location `<index>` of the stored message is returned. Message status will be set to 'stored unsent' unless otherwise given in parameter `<stat>`.

After invoking the execute or write command wait for the prompt ">" and then start to write the message. To save the message simply enter `<CTRL-Z>`.

To abort writing use `<ESC>`. Abortion is acknowledged with "OK", though the message will not be saved.

Syntax

<p>Test Command</p> <p>AT+CMGW=?</p> <p>Response(s)</p> <p>OK</p>											
<p>Exec Command</p> <p>If text mode (see AT+CMGF=1):</p> <p>AT+CMGW</p> <p>Response(s)</p> <p><CR> Text can be entered. <CTRL-Z>/<ESC></p> <p>+CMGW: <code><index></code></p> <p>OK</p> <p>ERROR</p> <p>+CMS ERROR: <code><err></code></p>											
<p>Write Command</p> <p>If text mode (see AT+CMGF=1):</p> <p>AT+CMGW=<code><oa>/<da></code>[, [<code><toa>/<tda></code>]], [<code><stat></code>]]<CR> Text can be entered. <CTRL-Z>/<ESC></p> <p>Response(s)</p> <p>+CMGW: <code><index></code></p> <p>OK</p> <p>ERROR</p> <p>+CMS ERROR: <code><err></code></p>											
<p>Write Command</p> <p>If PDU mode (see AT+CMGF=0):</p> <p>AT+CMGW=<code><length></code>[, [<code><stat></code>]]<CR> PDU can be entered. <CTRL-Z>/<ESC></p> <p>Response(s)</p> <p>+CMGW: <code><index></code></p> <p>OK</p> <p>If writing fails see notes below.</p>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	+	-	<p>Reference(s)</p> <p>3GPP TS 27.005 [47]</p>
PIN	MDM	APP	→	Last							
+	+	+	+	-							

Notes

- Note that some providers do not recognize an @ symbol used in a short message. A widely used alternative is typing "*" as defined in 3GPP TS 23.040 [\[37\]](#).
- Message Length in Text Mode:
The maximum length of a short message depends on the used coding scheme: It is 160 characters if the 7 bit GSM coding scheme is used, and 140 characters according to the 8 bit GSM coding scheme.

9.9 AT+CMSS Send short messages from storage

The write command sends message with location value `<index>` from message storage `<mem2>` to the network (SMS-SUBMIT or SMS-COMMAND).

If new recipient address `<da>` is given for SMS-SUBMIT, it shall be used instead of the one stored with the message. Reference value `<mr>` is returned to the TE on successful message delivery. Value can be used to identify message upon unsolicited delivery status report result code.

If the optional parameter `<da>` is given, the old status of the short message at `<index>` remains unchanged (see `<stat>`).

Syntax

Test Command

```
AT+CMSS=?
```

Response(s)

```
OK
```

Write Command

If text mode (`AT+CMGF=1`):

```
AT+CMSS=<index>[, <da>[, <toda>]]
```

Response(s)

```
+CMSS: <mr>[, <scts>]
```

```
OK
```

If sending fails

```
ERROR
```

```
+CMS ERROR: <err>
```

Write Command

If PDU mode (`AT+CMGF=0`):

```
AT+CMSS=<index>[, <da>[, <toda>]]
```

Response(s)

```
+CMSS: <mr>[, <ackpdu>]
```

```
OK
```

```
ERROR
```

```
+CMS ERROR: <err>
```

PIN	MDM	APP	→	Last
+	+	+	-	-

Reference(s)

3GPP TS 27.005 [47]

9.10 AT+CNMA New Message Acknowledgement to UE/TE

The [AT+CNMA](#) write and execute commands confirm successful receipt of a new message (SMS-DELIVER or SMS-STATUS-REPORT) routed directly to the TE. If the PLS8-X does not receive acknowledgement within required time (network timeout), it sends an "RP-ERROR" message to the network. The UE will automatically disable routing to the TE by setting both `<mt>` and `<ds>` values of [AT+CNMI](#) to zero.

Please see [AT^SCFG](#) subcommand "Sms/AutoAck", parameter `<SmsAcknl>`, for options of automatically acknowledging incoming short messages rather than using [AT+CNMA](#).

Acknowledging short messages with [AT+CNMA](#) or [AT^SCFG](#) subcommand "Sms/AutoAck" is supported only if [AT^SCFG](#) "SMS/Format" is configured for 3GPP SMS format (see parameters `<SmsFormat>` and `<SmsFormat3gpp2>`).

Syntax

<p>Test Command</p> <pre>AT+CNMA=?</pre> <p>Response(s)</p> <pre>+CNMA: (list of supported <n>s) OK</pre>											
<p>Exec Command</p> <pre>AT+CNMA</pre> <p>Response(s)</p> <pre>OK ERROR +CMS ERROR: <err></pre>											
<p>Write Command</p> <pre>AT+CNMA=<n></pre> <p>Response(s)</p> <pre>OK ERROR +CMS ERROR: <err></pre>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>-</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	-	-	<p>Reference(s)</p> <p>3GPP TS 27.005 [47]</p>
PIN	MDM	APP	→	Last							
+	+	+	-	-							

Parameter Description

<code><n></code> ^(num)	Description
0	Command operates similarly as in text mode.
1	Send positive (RP-ACK) acknowledgement to the network. Accepted only in PDU mode.
2	Send negative (RP-ERROR) acknowledgement to the network. Accepted only in PDU mode.

Note

- Execute and write command shall only be used when `AT+CSMS` parameter `<service>` equals 1 (= phase 2+) and an appropriate URC has been issued by the module, i.e.:
 - `<+CMT>` for `<mt>=2` incoming message classes 0,1,3 and none;
 - `<+CMT>` for `<mt>=3` incoming message classes 0 and 3;
 - `<+CDS>` for `<ds>=1`.

9.11 AT+CNMI SMS Event Reporting Configuration

AT+CNMI controls details of the SMS related URC presentation. It selects the procedure how the receipt of a new SMS from the network is indicated to the TE when TE is active.

Please note that some of the settings of **AT+CNMI** are dependent on the SMS format selected with **AT^SCFG** "SMS/Format" parameters **<SmsFormat>** and **<SmsFormat3gpp2>**:

For 3GPP SMS format only:

The rules **<mt>=2** and **<mt>=3** for storing received messages are possible only if phase 2+ compatibility is activated with **AT+CSMS=1**. The parameter **<ds>=1** is also only available in phase 2+.

For 3GPP2 SMS format only:

<mt>=2 and **<mt>=3** are not available because phase 2+ compatibility (**AT+CSMS=1**) is not supported.

<bm> 2 is not available because Cell Broadcast (**AT+CSCB**) is not supported for 3GPP2.

Manual acknowledgement with **AT+CNMA** is not supported.

SMS Status Report may not be supported in some 3GPP2 networks. If originating address is not available, **<oa>** will be displayed as empty quotation marks.

Syntax

<p>Test Command</p> <p>AT+CNMI=?</p> <p>Response(s)</p> <p>+CNMI: (list of supported<mode>s), (list of supported <mt>s), (list of supported <bm>s), (list of supported <ds>s), (list of supported <bfr>s)</p> <p>OK</p>											
<p>Read Command</p> <p>AT+CNMI?</p> <p>Response(s)</p> <p>+CNMI: <mode>, <mt>, <bm>, <ds>, <bfr></p> <p>OK</p>											
<p>Write Command</p> <p>AT+CNMI=[[<mode>][[,<mt>][[,<bm>][[,<ds>][[,<bfr>]]]]]]</p> <p>Response(s)</p> <p>OK</p> <p>ERROR</p> <p>+CMS ERROR: <err></p>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	+	-	<p>Reference(s)</p> <p>3GPP TS 27.005 [47]</p>
PIN	MDM	APP	→	Last							
+	+	+	+	-							

Unsolicited Result Codes

URC 1

<mt>=1,2 or 3 in case of 3GPP SMS format - indication only (text and PDU mode):

<mt>=1 in case of 3GPP2 SMS format - indication only (text and PDU mode):

+CMTI: <mem3>, <index>

Indicates that new message has been received

URC 2

For 3GPP SMS format only:

<mt>=1,2 or 3 - directly routed message (PDU mode enabled):

+CMT: <length><CR><LF><pdu>

Indicates that new message has been received

URC 3

For 3GPP SMS format only:

<mt>=1,2 or 3 - directly routed message (text mode enabled):

+CMT: <oa>, , <scts>[, <toa>, <fo>, <pid>, <dcs>, <sca>, <tosca>, <length>] <CR><LF><data>

Indicates that new message has been received

URC 4

For 3GPP SMS format only:

<bm>=2 (PDU mode enabled):

+CBM: <length><CR><LF><pdu>

Indicates that new cell broadcast message has been received

URC 5

For 3GPP SMS format only:

<bm>=2 (text mode enabled):

+CBM: <sn>, <mid>, <dcs>, <page>, <pages><CR><LF><data>

Indicates that new cell broadcast message has been received

URC 6

For 3GPP SMS format and 3GPP2 SMS format:

<ds>=1 (PDU mode enabled):

+CDS: <length><CR><LF><pdu>

Indicates that new SMS status report has been received

URC 7

For 3GPP SMS format only:

<ds>=1 (text mode enabled):

+CDS: <fo>, <mr>[, <ra>][, <tora>], <scts>, <dt>, <st>

Indicates that new SMS status report has been received

URC 8

For 3GPP2 SMS format only:

<ds>=1 (text mode enabled):

+CDS: <fo>, <mr>, <ra>, <tora>, <scts>, , <st>, <length><CR><LF><data>

Indicates that new SMS status report has been received

URC 9

For 3GPP2 SMS format only:

<mode>=2

<mt>=1 - directly routed message (PDU mode enabled):

+CMT: <length><CR><LF><pdu>

Indicates that new MMS message indication has been received

URC 10

For 3GPP2 SMS format only:

<mode>=0

<mt>=1 - directly routed message (text mode enabled):

+CMT: <stat>, <oa>, <scts>, <length>

Indicates that new MMS message indication has been received

Parameter Description

<mode> ^{(num)&(V)&(W)}	
0(&F)(D)	SMS related URCs are always buffered in the UE. If the buffer is full, the oldest indications are discarded and replaced with newly received indications.
1	SMS related URCs are forwarded directly to the TE. However, if this is not possible because UE-TE link is reserved, e.g. during a data call, these URCs are discarded.
2	SMS related URCs are forwarded directly to the TE. However, if this is not possible because UE-TE link is reserved these URCs are buffered and flushed to the TE afterwards. Additionally, while UE-TE link is reserved, buffered URCs are signaled to the TE via sending a BREAK or activating the RING line, according to AT^SCFG parameters <urcRinglineCfg>, <udri> and <urcRinglineDuration>.

<mt> ^{(num)&(V)&(W)}	
For 3GPP SMS format only: Rules for storing received short messages depend on the relevant data coding method (refer to 3GPP TS 23.038 [36]), preferred memory storage setting (AT+CPMS) and this value. For 3GPP2 SMS format only: In 3GPP2 networks <mt>=2 and <mt>=3 are not supported.	
0(&F)(D)	No SMS-DELIVER indications are routed to the TE.
1	Class 0 SMS-DELIVERs are routed directly to the TE via URC. For all other messages the following applies: If SMS-DELIVER is stored in UE, indication of the memory location is routed to the TE via URC.
2	For 3GPP SMS format only: SMS-DELIVERs, except class 2 messages and messages in the message waiting indication group (store message) are routed directly to the TE via URC. Class 2 messages and messages in the message waiting indication group (store message) result in indication as defined for <mt>=1
3	For 3GPP SMS format only: Class 0 and 3 SMS-DELIVERs are routed directly to the TE via URCs defined in <mt>=2. Messages of other data coding schemes result in indication as defined in <mt>=1.

<bm> ^{(num)&(V)&(W)}	
Rules for storing received CBMs depend on the relevant data coding method (refer to 3GPP TS 23.038 [36]), the setting of Select CBM Types (AT+CSCB) and this value:	
0(&F)(D)	No CBM indications are routed to the TE.
2	For 3GPP SMS format only: New CBMs are routed directly to the TE via URC.

<ds> ^{(num)&(V)&(W)}	
0(&F)(D)	No SMS-STATUS-REPORTs are routed to the TE. Also see notes.
1	SMS-STATUS-REPORTs are routed to the TE via URC.

`<bfr>`^{(num)(&V)(&W)}

1(&F)(D)

UE's buffer of SMS related URCs is cleared when `<mode>` changes from 0 to 1, 2 or 3.

`<index>`^(num)

Integer type; value in the range of location numbers supported by the associated memory

`<fo>`^(num)

For 3GPP2 SMS format only:

First octet displayed in decimal form, message types defined in C.S0015-A (Table 4.5.1-1). For 3GPP SMS format see [AT+CSMP](#), parameter `<fo>`.

`<st>`^(num)

For 3GPP2 SMS format only:

Message status code in decimal form, message status defined in C.S0015-A (Table 4.5.21-1). For 3GPP SMS format see description of the parameter: `<st>` in chapter "SMS parameters".

Notes

- Note for 3GPP SMS format mode:
With `<mt>=2,3` and `<ds>=1` messages routed directly to the TE (either short messages or status reports) have to be acknowledged with [AT+CNMA](#). To do this, GSM Phase 2+ has to be enabled (see [AT+CSMS](#)).
- Note for for 3GPP SMS format mode:
If Phase 2+ is enabled and either a short message or a status report is not acknowledged within the required time, then `<mt>` and `<ds>` will be set to zero. See [AT+CNMA](#) for further detail.
- Received status reports are not stored by the module. Therefore, [AT+CMGR](#), [AT+CMGL](#), [AT^SMGR](#), [AT^SMGL](#) commands will show only status reports previously stored to the "SR" memory.

9.12 AT+CPMS Preferred SMS message storage

The [AT+CPMS](#) write command selects memory storages [<mem1>](#), [<mem2>](#), [<mem3>](#) to be used for reading, writing, etc.

The [AT+CPMS](#) test command lists the supported memory storages.

The [AT+CPMS](#) read command indicates the currently selected memory storages incl. the numbers of used and total entries.

The supported memory storage types are dependent on the SMS format selected with [AT^SCFG](#) "SMS/Format" parameters [<SmsFormat>](#) and [<SmsFormat3gpp2>](#).

3GPP SMS format: "ME", "MT", "SM", "SR" are available. [<mem1>](#), [<mem2>](#) and [<mem3>](#) settings are persistent. 3GPP2 SMS format: "ME" and "MT" are available. [<mem1>](#), [<mem2>](#) and [<mem3>](#) settings are volatile. Default "ME" will be set for all parameters after changing to 3GPP2 SMS format, and after powerup in 3GPP2 SMS format mode.

Syntax

<p>Test Command</p> <pre>AT+CPMS=?</pre> <p>Response(s)</p> <pre>+CPMS: (list of supported <mem1>s), (list of supported <mem2>s), (list of supported <mem3>s) OK</pre>											
<p>Read Command</p> <pre>AT+CPMS?</pre> <p>Response(s)</p> <pre>+CPMS: <mem1>, <used1>, <total1>, <mem2>, <used2>, <total2>, <mem3>, <used3>, <total3> OK ERROR +CMS ERROR: <err></pre>											
<p>Write Command</p> <pre>AT+CPMS=<mem1>[, <mem2>[, <mem3>]]</pre> <p>Response(s)</p> <pre>+CPMS: <used1>, <total1>, <used2>, <total2>, <used3>, <total3> OK ERROR +CMS ERROR: <err></pre>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	+	-	<p>Reference(s)</p> <p>3GPP TS 27.005 [47]</p>
PIN	MDM	APP	→	Last							
+	+	+	+	-							

Parameter Description

- [<used1>](#)^(num)
Number of messages currently in [<mem1>](#)
- [<used2>](#)^(num)
Number of messages currently in [<mem2>](#)
- [<used3>](#)^(num)
Number of messages currently in [<mem3>](#)

<total1>^(num)

Number of messages storable in <mem1>

<total2>^(num)

Number of messages storable in <mem2>

<total3>^(num)

Number of messages storable in <mem3>

Notes

- The Mobile Equipment storage "ME" offers space for 255 short messages in 3GPP SMS format mode and 99 short messages in 3GPP2 SMS format mode. See <mem1>.
- Incoming Class 1 short messages (ME specific) will be preferably stored to "ME" and may be transferred to the "SM" storage if "ME" is used up.
Incoming Class 2 messages (SIM specific) will be stored to the SIM card only, no matter whether or not there is free "ME" space. For more information regarding SIM and ME specific message classes refer to parameter <dc> and the following specification: 3GPP TS 23.038 [36].
- While <mem3> equals "SM" and <mem1> equals "ME" it is possible that, after deleting short messages from "ME", the freed space on "ME" is reclaimed for new incoming short messages, when there is no space left on the "SM" storage. As it is often the clients concern to have received short messages stored only to the SIM card, inconsistent settings should be generally avoided. This can be achieved simply by using the same memory for all parameters.
- Users should be aware that error will occur when using this AT command quickly after SIM PIN authentication due to the fact the SIM data may not yet be accessible.

9.13 AT+CSCA SMS Service Center Address

Write command updates the SMSC address, through which mobile originated SMs are transmitted. In text mode, setting is used by send and write commands. In PDU mode, setting is used by the same commands, but only when the length of the SMSC address coded into the `<pdu>` parameter equals zero.

Syntax

Test Command	
AT+CSCA=?	
Response(s)	
OK	
Read Command	
AT+CSCA?	
Response(s)	
+CSCA: <code><sca></code> , <code><tosca></code>	
OK	
Write Command	
AT+CSCA= <code><sca></code> [, <code><tosca></code>]	
Response(s)	
OK	
PIN MDM APP → Last	Reference(s)
+ + + + -	3GPP TS 27.005 [47]

Notes

- The SMS service center address should be entered as specified by the service provider.
- An empty string ("") for `<sca>` is not accepted and denied with error.

9.14 AT+CSCB Select Cell Broadcast Message Indication

Cell Broadcast is supported only if `AT^SCFG "SMS/Format"` is configured for 3GPP SMS format (see parameters `<SmsFormat>` and `<SmsFormat3gpp2>`).

The test command returns the supported `<operation>`s as a compound value.

The read command displays the accepted message types.

Depending on the `<operation>` parameter, the write command adds or deletes the message types accepted by the ME.

Syntax

<p>Test Command</p> <pre>AT+CSCB=?</pre> <p>Response(s)</p> <pre>+CSCB: (list of supported <operation>s) OK ERROR +CMS ERROR: <err></pre>											
<p>Read Command</p> <pre>AT+CSCB?</pre> <p>Response(s)</p> <pre>+CSCB: <operation>, <mids>, <dcss> OK ERROR +CMS ERROR: <err></pre>											
<p>Write Command</p> <pre>AT+CSCB=[<operation>[, <mids>[, <dcss>]]]</pre> <p>Response(s)</p> <pre>OK ERROR +CMS ERROR: <err></pre>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	+	-	<p>Reference(s)</p> <p>3GPP TS 27.005 [47]</p>
PIN	MDM	APP	→	Last							
+	+	+	+	-							

Parameter Description

<code><operation></code> ^(num)	Add/delete operation	Description
0(&F)(P)		Add new message types defined in <code><mids></code> to the list of accepted message types by ME and replace types defined in <code><dcss></code> . In case of using this operation code without parameters default (0-65535) range will be added to the list of <code><mids></code> .
1		Delete message types defined in <code><mids></code> from the list of accepted message types by ME and replace types defined in <code><dcss></code> . In case of using this operation code without parameters all <code><mids></code> s will be deleted. (for more see notes)

`<mid_s>`^{(str)(NV)}

Cell Broadcast Message ID specification

All different possible combinations of CBM message identifiers; e.g. "0,1,5,320-478,922". Maximum length of the string is 50 characters (including ',' as separator and '-' in ranges).

""(D)

`<dcss>`^(str)

CBM data coding scheme specification

All different possible combinations of CBM data coding schemes (e.g. "0-3,5"). Maximum length of the string is 50 characters (including ',' as separator and '-' in ranges). A given `<dcss>` replaces any former value and is used for consecutive requests.

""(&F)(P)

Default is empty string and if it is used all CBMs are received independent of their dcss.

Note

- The `<operation>` parameter shown in the `AT+CSCB` read command response retains the value last used in the write command. This way, the read command response always reflects the last action done: 0 means that the last action was adding new channel(s), 1 means that the last action was deleting channel(s).

9.15 AT+CSDH Show SMS text mode parameters

The write command sets whether or not detailed header information is shown in text mode result codes.

Syntax

Test Command AT+CSDH=? Response(s) +CSDH: (list of supported <show>s) OK	
Read Command AT+CSDH? Response(s) +CSDH: <show> OK	
Write Command AT+CSDH=<show> Response(s) OK	
PIN MDM APP → Last + + + + -	Reference(s) 3GPP TS 27.005 [47]

Parameter Description

<show> ^{(num)(&W)}	
0 ^{(&F)(D)}	Do not show header values defined in commands AT+CSCA and AT+CSMP (<sca>, <tosca>, <fo>, <vp>, <pid> and <dcs>) nor <length>, <toda> or <tooa> in "+CMT", AT+CMGL , AT+CMGR result codes for SMS-DELIVERs and SMS-SUBMITs in text mode; for SMS-COMMANDs in +CMGR result code, do not show <pid>, <mn>, <da>, <toda>, <length>
1	Show the values in result codes

9.16 AT+CSMP Set SMS Text Mode Parameters

AT+CSMP controls additional parameters needed when an SMS is sent to the network or placed in a storage if text format message mode is selected.

It is possible to set the validity period starting from the time when the short message is received by the SMSC (**<vp>** is in the range 0... 255) or define an absolute time for validity period termination (**<vp>** is a string). The format of **<vp>** is given by **<fo>**. The enhanced validity period format is given as hexadecimal coded string (e.g. **< pdu>**) with quotes.

Syntax

<p>Test Command</p> <p>AT+CSMP=?</p> <p>Response(s)</p> <p>OK</p>											
<p>Read Command</p> <p>AT+CSMP?</p> <p>Response(s)</p> <p>+CSMP: <fo>, <vp>/ <scts>, <pid>, <dcs></p> <p>OK</p>											
<p>Write Command</p> <p>AT+CSMP=<fo>[, [<vp>/<scts>][, [<pid>][, [<dcs>]]]]</p> <p>Response(s)</p> <p>OK</p> <p>ERROR</p> <p>+CMS ERROR: <err></p>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	+	-	<p>Reference(s)</p> <p>3GPP TS 27.005 [47]</p>
PIN	MDM	APP	→	Last							
+	+	+	+	-							

Parameter Description

<p><fo>^(num)</p> <p>First Octet</p> <p>In 3GPP mode:</p> <p>Depending on the command or result code: First octet of 3GPP TS 23.040 [37] SMS-DELIVER, SMS-SUBMIT, SMS-STATUS-REPORT, or SMS-COMMAND in integer format. If a valid value has been entered once, parameter can be omitted.</p> <p>0...255</p> <p>In 3GPP2 mode:</p> <p>Parameter can be used to set the Delivery Acknowledgement Request</p> <table border="0"> <tr> <td>0^(P)</td> <td>No Delivery Acknowledgement Request</td> </tr> <tr> <td>1</td> <td>Delivery Acknowledgement Request</td> </tr> </table>	0 ^(P)	No Delivery Acknowledgement Request	1	Delivery Acknowledgement Request
0 ^(P)	No Delivery Acknowledgement Request			
1	Delivery Acknowledgement Request			
<p><vp>^(num)</p> <p>Validity Period</p> <p>Depending on SMS-SUBMIT <fo> setting: 3GPP TS 23.040 [37] TP-Validity-Period either in integer format or in time-string format (refer <dt>).</p> <p>0...255</p>				

<pid>^(num)

Protocol Identifier

3GPP TS 23.040 [37] TP-Protocol-Identifier in integer format.

0^(&F)...255

<dcS>^(num)

Data Coding Scheme

In 3GPP mode:

3GPP TS 23.038 [36] SMS Data Coding Scheme, or Cell Broadcast Data Coding Scheme in integer format.

0^(&F)...247

In 3GPP2 mode:

SMS Data Coding Scheme, possible values:

0 ^(P)	Octet (8 bits)
2	Ascii (7 bits)
3	IA5 (7 bits)
4	UCS2 (16 bits)
7	Latin-Hebrew (8 bits)
8	Latin (8 bits)
9	GSM encoding scheme (7 bits)

Notes

- When storing a SMS DELIVER from the TE to the preferred memory storage in text mode (using the [AT+CMGW](#) write command), <vp> field can be used for <scts>.
- In 3GPP mode [AT+CSMP](#) stores parameters <dcS> and <pid> in UE's non-volatile memory. In 3GPP2 mode [AT+CSMP](#) settings are volatile.

9.17 AT+CSMS Select Message Service

Syntax

<p>Test Command</p> <p>AT+CSMS=?</p> <p>Response(s)</p> <p>+CSMS: (list of supported<service>s)</p> <p>OK</p>											
<p>Read Command</p> <p>AT+CSMS?</p> <p>Response(s)</p> <p>+CSMS: <service>, <mt>, <mo>, <bm></p> <p>OK</p>											
<p>Write Command</p> <p>AT+CSMS=<service></p> <p>Response(s)</p> <p>+CSMS: <mt>, <mo>, <bm></p> <p>OK</p> <p>ERROR</p> <p>+CMS ERROR: <err></p>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	+	-	<p>Reference(s)</p> <p>3GPP TS 27.005 [47]</p>
PIN	MDM	APP	→	Last							
+	+	+	+	-							

Parameter Description

<service> ^{(num)(&V)(&W)}	
0(&F)	3GPP TS 23.040 [37] and 3GPP TS 23.041 [38] (the syntax of SMS AT commands is compatible with 3GPP TS 27.005 [47] Phase 2 version 4.7.0; Phase 2+ features which do not require new command syntax may be supported, e.g. correct routing of messages with new Phase 2+ data coding schemes)
1	For 3GPP SMS format only (see AT^SCFG "SMS/Format" parameters <SmsFormat> and <SmsFormat3gpp2>): 3GPP TS 23.040 [37] and 3GPP TS 23.041 [38] (the syntax of SMS AT commands is compatible with 3GPP TS 27.005 [47] Phase 2+ version; the requirement of <service> setting 1 is mentioned under corresponding command descriptions).
<mt> ^{(num)(&V)}	
Mobile Terminated Messages:	
0	Type not supported
1	Type supported
<mo> ^{(num)(&V)}	
Mobile Originated Messages:	
0	Type not supported
1	Type supported

<bm>^{(num)(&V)}

Broadcast Type Messages:

0	Type not supported
1	Type supported

Note

- Phase 2+ (<service>=1) must be set before acknowledging incoming short messages with [AT+CNMA](#) is possible. Acknowledgements are required for directly routed messages delivered using "+CMT" and "+CDS" URCS. Direct routing is used for certain message classes when <mt>=2, <mt>=3 or <ds>=1.

9.18 AT^SMGL List Short Messages from preferred store without setting status to REC READ

The write command allows to select a status type and lists, from the message storage `<mem1>`, all messages that currently have the specified `<stat>`. The major difference over the standard command `AT+CMGL` is that the status of the listed messages remains `unread` (unread remains unread).

The execute command is the same as the write command, but uses the given default of `<stat>`.

Syntax

Test Command

AT^SMGL=?

Response(s)

same as [AT+CMGL](#)

Exec Command

AT^SMGL

Response(s)

^SMGL: (For default values of `<stat>`, see "Section 9.1, SMS parameters.")

OK

Write Command

AT^SMGL=`<stat>`

Response(s)

same as [AT+CMGL](#)

PIN	MDM	APP	→	Last
+	+	+	+	-

Notes

- The selected `<mem1>` can contain different types of SMS (e.g. SMS-DELIVERs, SMS-SUBMITs and SMS-COMMANDs), the response may be a mix of the responses of different SM types. TE application can recognize the response format by examining the third response parameter.
- Users should be aware that when using this AT command quickly after SIM PIN authentication the SIM data may not yet be accessible, resulting in an error or a short delay before the requested AT command response is returned.

9.19 AT^SMGR Read short message without setting status to REC READ

The [AT^SMGR](#) command is a proprietary command which has the same syntax as [AT+CMGR](#). The only functional difference is that the status "REC UNREAD" of a short message is not overwritten to "REC READ".

Syntax

Test Command				
AT^SMGR=?				
Response(s)				
OK				
Write Command				
AT^SMGR=<index>				
Response(s)				
see AT+CMGR				
PIN	MDM	APP	→	Last
+	+	+	+	-

Note

- Users should be aware that when using this AT command quickly after SIM PIN authentication the SIM data may not yet be accessible, resulting in a short delay before the requested AT command response is returned.

9.20 AT^SSDA Set SMS Display Availability

AT^SSDA determines whether to display an incoming Class 0 short message directly to the user or to store it automatically in the SMS memory. This means, for Class 0 short messages, **AT^SSDA** overrides the **AT+CNMI** **<mt>** settings.

For all other short message classes **AT^SSDA** is not effective, i.e. they will be indicated as specified with **AT+CNMI**.

In case of Class 0 SMS, the **<da>** setting modifies the **AT+CNMI** functionality for **<mt>** as follows:

- If **AT^SSDA=0**:
The UE handles Class 0 short messages as though there was no message class: SMS-DELIVER is stored in the UE and indication of the memory location is routed to the TE via URC. This approach is compliant with 3GPP TS 23.038 [36].
- If **AT^SSDA=1**:
Class 0 SMS-DELIVERs are routed directly to the TE via URC.

Syntax

```
Test Command
AT^SSDA=?
Response(s)
^SSDA: (list of supported <da>s)
OK

Read Command
AT^SSDA?
Response(s)
^SSDA: <da>
OK

Write Command
AT^SSDA=<da>
Response(s)
OK
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<da> ^{(num)(NV)}	
Display Availability	
0	Application is not able to display incoming short message
1(&F)(D)	Application is able to display incoming short message

10. Internet Service Commands

PLS8-X has an embedded TCP/IP stack that is driven by AT commands and enables the host application to easily access the Internet. The advantage of this solution is that it eliminates the need for the application manufacturer to implement own TCP/IP and PPP stacks, thus minimizing cost and time to integrate Internet connectivity into a new or existing host application. This chapter is a reference guide to all the AT commands and responses defined for use with the TCP/IP stack.

The embedded TCP/IP stack provides the following services:

1. Socket Services:
 - TCP Client in Non-Transparent or Transparent Mode
 - UDP Client in Non-Transparent or Transparent Mode
 - Transparent TCP Listener
 - Standard TCP Listener in Non-Transparent or Transparent Mode
 - Non-Transparent UDP Endpoint
2. FTP Client
3. HTTP Client
4. SMTP Client

Step-by-step overview of how to configure and use TCP/IP communications with PLS8-X:

- Use `AT+CGDCONT` to create an Internet connection profile (= bearer). The PDP context IDs set with `<cid>` will later be used as "conId" parameter when creating a service profile with `AT^SISS`. Optionally, you can specify DNS preferences using `AT^SICS`. To activate or deactivate the bearer use the `AT^SICA` command.
- Use `AT^SISS` to create service profile(s), each identified by the `<srvProfileId>`. The service profile specifies the type of Internet service to use, e.g., Socket, FTP, HTTP, SMTP.
- Once the bearer has been established with `AT^SICA`, and the service profile is created with `AT^SISS`, an Internet session can be opened by entering the `AT^SISO` write command and the desired `<srvProfileId>`. A URC indicates how to proceed. The "`^SIS`" URC with `<urcCause>` "5" shows that an opened listener or endpoint is ready. The "`^SISW`" URC means that data can be sent. The "`^SISR`" URC means that received data are available for reading. Error or event information is reported by the "`^SIS`" URC with `<urcCause>` "0".
- The next steps differ depending on the service type and the transfer mode (Non-Transparent or Transparent).
- Once a service is opened, the `AT^SISI` command shall be used to monitor the progress of the session. The command reports the service state of the used service profile and indicates the number of bytes sent and received, and, in the case of sending, the number of bytes acknowledged or unacknowledged at TCP layer.
- If an error occurs during a session you can enter the `AT^SISE` command and the `<srvProfileId>` to identify the reason. This is especially important in polling mode.
- Finally, to close an opened service, enter the `AT^SISC` write command and the `<srvProfileId>`. Then you can deactivate the bearer using `AT^SICA`.
`AT^SISH` disconnects a remote client from a Transparent TCP Listener without closing the listener (see also below).

Transparent Mode or Non-Transparent Mode:

- *Transparent Mode* is stream-oriented, i.e. a single data stream can be sent, and another single data stream can be received. Packetizing of data is done automatically by the embedded TCP/IP stack. Transparent Mode is activated with `AT^SIST` and then indicated by the "CONNECT" result code. The mode eliminates the need for `AT^SISW` and `AT^SISR` read and write sequences. Transparent Mode may be used either on the Modem interface or on the dedicated Mux Channels 5 and 6. This solution requires that Multiplex Mode is enabled.
- *Non-Transparent Mode* is packet oriented, i.e. data is transferred in separate packets. Maximum packet size is 1500 bytes for TCP, 1460 bytes for UDP. To read and write data `AT^SISW` and `AT^SISR` sequences shall be used. FTP, HTTP, SMTP employ Non-Transparent Mode, for Socket services it is optional. To send or receive more than 1500 bytes, the read or write action shall be repeated until the data transfer has

completed. Each read or write action requires that the command response (of [AT^SISR](#) or [AT^SISW](#)) confirms that the service is ready to send or receive data. The read/write cycles can be controlled by URCs or polling. For details see below, section "URC mode and polling mode".

To end an upload data stream set the [<eodFlag>](#) in the last [AT^SISW](#) command.

Non-Transparent Mode may be used on the Modem instance or on the Application instance.

Listener services:

A listener is waiting for incoming remote client requests. PLS8-X supports two listener types: Transparent TCP Listener and Standard TCP Listener.

After opening a listener with [AT^SISO](#) no "[^SISW](#)" URC appears. Instead, the "[^SIS](#)" URC with [<urcCause>](#) "5" shows that the opened listener is ready and starts listening. Additionally, the states can be verified with [AT^SISI](#) which shows state "4" (Up - listening).

An incoming remote client request is indicated by the "[^SIS](#)" URC. For details please refer to Section 10.14, [Internet Service URC](#), especially parameters [<urcCause>](#) and [<urcInfoId>](#).

• *Transparent TCP Listener:*

- The Transparent TCP Listener can accept 1 remote client. The connection to the remote client does not need an additional service profile, as it uses the Transparent TCP Listener instance.
- To define a listener service profile as Transparent TCP Listener the "etx" parameter is mandatory in the address. See [AT^SISS](#).
- [AT^SISS](#) allows some specific options for the Transparent TCP Listener service, such as "autoconnect", "connecttimeout", "addrfilter";
- If autoconnect is enabled an incoming remote client is indicated by the "[^SIS](#)" URC with [<urcCause>](#) "3" (Transparent) and [<urcInfoId>](#) "1" (= autoconnect enabled). The request is automatically accepted. The Listener profile instantly changes to Server mode ([AT^SISO <socketState>](#) to 4 = SERVER) and opens transparent data mode (indicated by "CONNECT" result code).
- If autoconnect is disabled, the remote client connection request is indicated by the "[^SIS](#)" URC with [<urcCause>](#) "3" (Transparent) and [<urcInfoId>](#) "0" (= autoconnect disabled). The request can be accepted with [AT^SISO](#) or rejected with [AT^SISH](#). In all cases the same [<srvProfileId>](#) shall be used. After accepting the client the Listener profile instantly changes to Server mode ([AT^SISO <socketState>](#) to 4 = SERVER).
If a remote client connection request is not accepted within the configured 'connecttimeout', it will be rejected automatically, and the URC "[^SIS](#)" is sent with [<urcCause>](#) set to '4'.
- As long as one remote client is connected all other remote client requests are rejected automatically without displaying the "[^SIS](#)" URC. The [<rejCounter>](#) in the response of the [AT^SISO](#) read command indicates such hidden rejects.
- [AT^SISH](#) disconnects a remote client, without closing the service, allowing the Transparent TCP Listener to wait for the next remote client.
[AT^SISC](#) both disconnects the remote client and shuts down the Transparent TCP Listener.
- An example can be found in Section 10.14, [Internet Service URC](#) and Section 10.15.5, [Transparent TCP Listener: Accepting / Rejecting Incoming Remote Client](#)

• *Standard TCP Listener:*

- The Standard Listener can accept several remote clients. Each incoming remote client connection request is dynamically assigned to the next free service profile indicated as [<srvProfileId>](#) within the "[^SIS](#)" URC. [<urcCause>](#) in the "[^SIS](#)" URC equals "1" (Non-Transparent). The dynamically assigned profile acts as Server ([AT^SISO <socketState>](#) equals 4 = SERVER). Its [<srvProfileId>](#) shall be used to accept the remote client with [AT^SISO](#), or to reject it with [AT^SISC](#). The number of acceptable remote clients depends on the number of free service profiles.
- To transfer data it is possible to proceed with Transparent Mode using [AT^SIST](#), or Non-Transparent Mode using [AT^SISR](#) and [AT^SISW](#) read / write sequences.
- An example can be found in Section 10.14, [Internet Service URC](#) and Section 10.15.3, [Configuring Non-Transparent Listener](#)

Socket service used with UDP protocol

The significant differences between the TCP and UDP protocols imply that UDP sometimes requires particular procedures or even specific parameters. Details on how to handle UDP services can be found in extra notes or are included in the general parameter descriptions.

The PLS8-X offers two kinds of Socket service with UDP protocol.

- *UDP Client:* Intended for connections to a given remote host. In this case the IP address and the UDP port of the remote host are set as a fixed parameter in the service profile. The UDP Client can use Transparent Mode and Non-Transparent Mode.
- *Non-Transparent UDP Endpoint:* IP address and UDP port of the remote hosts are handled in each read (`AT^SISR`) and write (`AT^SISW`) request. This enables the host application to communicate with different remote hosts.
See example in Section 10.15.9, [UDP Scenario](#).

Secure connection (TLS)

All services except Listener services support server and client authentication for Transport Layer Security (TLS).

- To set TLS add "s" to the address type, such as socktcps, sockudps, ftps, https, smtps. For details see `AT^SISS <srvParmTag>` parameter "address".
- To create, load, delete and read customized TLS certificates use the commands `AT^SBNW` and `AT^SBNR`.
- The `AT^SISS` session profile parameter "secopt" specifies whether or not to check certificates received from the server against the local certificate store (if at least one local certificate is set).
- The `AT^SCFG` subcommand "Tcp/TLS/Version" specifies the security level.
- The used certificates can be shown in text format (issuer, serial, subject, signatureAlg, thumbprint). For this purpose it is recommended to enable the "+CIEV: "is_cert" URC, see `AT^SIND`.

Destination Interface for URCs

Particularly when using Non-Transparent Mode bear in mind that all URCs are, by default, generated on the Application instance (depending on `AT^SSRVSET` settings and Multiplex Mode). To handle AT commands and URCs on the same interface, you have two options:

- Use the Application instance.
- When working on the Modem instance you may use the `AT^SCFG` subcommand "URC/DstIfc" and select the Modem instance for URC output. See parameter `<urcDestIfc>`.

URC mode or polling mode (for non-Transparent Mode only)

The PLS8-X offers two modes of controlling a Non-Transparent Mode session opened with `AT^SISO`. To select the mode use the `AT^SCFG` command, parameter "Tcp/WithURCs" (refer to `<tcpWithUrc>`).

- **URC mode (delivery default):**
The progress of a Non-Transparent Mode session is URC driven. The URCs notify the host whether data can be sent or received, whether data transfer has completed, whether the service can be closed or whether an error has occurred. This mechanism eliminates the need to poll the service until the necessary progress information is received.
To enable the URC mode select: `AT^SCFG="Tcp/WithURCs",on`.
- **Polling mode:**
In polling mode, the presentation of URCs related to the Internet Services is disabled. The host is responsible to retrieve all the status information needed for controlling the Internet session. This is done by polling, where the host application keeps sending the commands `AT^SISR`, `AT^SISW`, `AT^SISI`.
To enable the polling mode select: `AT^SCFG="Tcp/WithURCs",off`.
The disabled URCs are the following: `^SISR` URC, `^SISW` URC and `^SIS` URC for parameter `<urcCause>=0` (Internet service events), but not for all other `<urcCause>s` (needed for listener or endpoint and therefore always enabled).

Address notation

Server addresses shall be provided as IPv4 addresses in standard dot format, e.g. "192.168.1.2", or as IPv6 addresses in standard colon format enclosed in square brackets, e.g. "[FE80::2]", or as server address names

resolvable by a DNS server.

Timeouts

Timeouts are not part of the Internet AT command functionality implemented in PLS8-X and, if desired, are the responsibility of the host application. It is recommended that the host application validates URCs and AT command responses and reacts adequately, for example by sending a close message or starting a timer.

Using the DCD line to detect the connection status of Internet services

With **AT&C** you can configure the DCD line of the used serial interface to indicate whether an Internet service is active. For Socket, HTTP the states "Up" or "Connecting" are indicated, for FTP and transparent TCP only the state "Up", for the Transparent TCP Listener service the states "Up", "Alerting", "Connected" and "Released".

10.1 AT^SICA Internet Connection Activate or Deactivate

The `AT^SICA` write command can be used to activate or deactivate an Internet service connection using a PDP context defined with `AT+CGDCONT`. To track activation errors the `AT^SIND` indicator "ceer" should be used.

The `AT^SICA` read command shows whether a connection for Internet services is active and which PDP context is used for it. If no connection is active, then the read command just returns OK.

Syntax

Test Command

`AT^SICA=?`

Response(s)

`^SICA: (list of supported <state>s), (list of supported <cid>s)`

OK

ERROR

+CME ERROR: <err>

Read Command

`AT^SICA?`

Response(s)

`[^SICA: <cid>, <state>]`

`[^SICA: ...]`

OK

ERROR

+CME ERROR: <err>

Write Command

`AT^SICA=<state>, <cid>`

Response(s)

OK

ERROR

+CME ERROR: <err>

PIN MDM APP  Last

+ + + - -

Parameter Description

`<state>`^(num)

0	Deactivate(d)
1	Activate(d)

`<cid>`^(num)

Parameter specifies a particular PDP context definition (see `AT+CGDCONT` parameter `<cid>`).

10.2 AT^SICS Internet Connection Settings

AT^SICS serves to specify additional settings for Internet connection specified with the AT+CGDCONT command. Currently only setup and query of DNS server addresses is supported.

Table 10.1: Applicability of AT^SICS <conParmTag> values

<conParmTag>	Mandatory or optional
"dns1"	optional
"dns2"	optional
"ipv6dns1"	optional
"ipv6dns2"	optional

Syntax

```

Test Command
AT^SICS=?
Response(s)
OK

Read Command
AT^SICS?
Response(s)
^SICS: <conProfileId>, <conParmTag>, <conParmValue>
[^SICS: ...]
OK

Write Command
AT^SICS=<conProfileId>[, <conParmTag>, <conParmValue>]
Response(s)
OK
ERROR
+CME ERROR: <err>

```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<conProfileId>^{(num)(NV)}
Internet connection profile as specified with AT+CGDCONT parameter <cid>. Invoking command only with this parameter will delete related DNS server address.

<conParmTag>^{(str)(NV)}
Internet connection parameter.
"dns1"
Primary DNS server address (IP address in dotted-four-byte format). This value determines whether to use the DNS server addresses dynamically assigned by the network or a specific DNS server address given by the user. "dns1" = "0.0.0.0" (default) means that the connection profile uses dynamic DNS assignment. Any other address means that the Primary DNS is manually set. The default value applies automatically if no other address is set. Note that the

AT^SICS read command only returns a manually configured IP address, while the value "0.0.0.0" is not indicated at all, no matter whether assumed by default or explicitly specified.
See also note below.

"dns2"
Secondary DNS server address (IP address in dotted-four-byte format).
If "dns1" = "0.0.0.0" this setting will be ignored. Otherwise this value can be used to manually configure an alternate server for the DNS1.
If "dns1" is not equal "0.0.0.0" and no "dns2" address is given, then "dns2"="0.0.0.0" will be assumed automatically. The **AT^SICS** read command only returns a manually configured IP address, while the value "0.0.0.0" is not indicated at all, no matter whether assumed by default or explicitly specified.

"ipv6dns1"
Primary IPV6 DNS server address (IP address Each group is written as 4 hexadecimal digits and the groups are separated by colons (:). The whole address is encapsulated by brackets ([]).
This value determines whether to use the DNS server addresses dynamically assigned by the network or a specific DNS server address given by the user.
"ipv6dns1" = "" (default) means that the connection profile uses dynamic DNS assignment. Any other address means that the Primary DNS is manually set. The default value applies automatically if no other address is set. Note that the **AT^SICS** read command only returns a manually configured IP v6 address, while the value "" is not indicated at all, no matter whether assumed by default or explicitly specified.
See also note below.

"ipv6dns2"
Secondary IPV6 DNS server address (IP address Each group is written as 4 hexadecimal digits and the groups are separated by colons (:). The whole address is encapsulated by brackets ([]).
"ipv6dns2" = "" (default) means that the connection profile uses dynamic DNS assignment. Any other address means that the secondary DNS is manually set.
The default value applies automatically if no other address is set. Note that the **AT^SICS** read command only returns a manually configured IP v6 address, while the value "" is not indicated at all, no matter whether assumed by default or explicitly specified.

<conParmValue>^{(str)(NV)}

Parameter value; type and supported content depend on related <conParmTag>.

Note

- If a network does not support or is not correctly configured for automatic DNS address assignment the TCP/IP stack cannot resolve fully qualified domain names. In this case, a warning message will be returned when trying to open an Internet service configured for automatic DNS address assignment.

10.3 AT^SIPS Internet Profile Storage

AT^SIPS saves and loads the settings of the Internet connection and service profiles in the non-volatile memory. AT^SIPS can also be used to reset the settings to their default values without saving.

Syntax

```

Test Command
AT^SIPS=?
Response(s)
^SIPS:(list of supported <type>s), (list of supported <action>s), (list of supported <ProfileId>s)
OK

Write Command
AT^SIPS=<type>, <action>[, <ProfileId>]
Response(s)
OK
ERROR
+CME ERROR: <err>
  
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<type>^(str)

Internet profile storage type parameter.

- “service” Handle AT^SISS parameter set.
- “all” Handle AT^SICS parameters AT^SISS parameters listed above.

<action>^(str)

Internet profile storage action parameter

- “reset” Reset current profile(s) for given <type> to default settings without saving. If <ProfileId> is given only specific profile will be reset. Only the connections which are in "Down" status and the services which are in "Allocated" status could be affected.
- “save” Stores current profile(s) for given <type>. If <ProfileId> is given only specific profile will be stored.
- “load” Loads current profile(s) for given <type>. If <ProfileId> is given only specific profile will be loaded.

<ProfileId>^(num)

Internet connection or service profile storage identifier

- 0...9 In case of connection profile, max = 5, please see <conProfileId>. In case of a service profile, max = 9, please see <srvProfileId>.
- If parameter is omitted, AT^SIPS applies to all possible profile identifiers of used <type>.

10.4 AT^SISS Internet Service Setup Profile

AT^SISS specifies the Internet service profiles needed to control data connections by using AT^SICA, AT^SISO, AT^SISC, AT^SISR, AT^SISW, AT^SIST and AT^SISE.

The AT^SISS read command requests the current settings of all Internet service profiles. One line is issued for every possible parameter of a given <srvParmTag> "srvType" value.

The AT^SISS write command specifies the parameters for a service profile identified by <srvProfileId>. At first the type of Internet service needs to be selected via <srvParmTag> value "srvType". This determines the applicability of all other <srvParmTag> values related to this "srvType" and, partially, sets their defaults. Changing the <srvParmTag> "srvType" of an existing service profile will reset all <srvParmTag> values.

To change the settings the write command needs to be executed for each single <srvParmTag>. All profile parameters set with AT^SISS are volatile. mandatory (= m) or optional (= o).

Table 10.2: Applicability of AT^SISS <srvParmTag> values

<srvParmTag>	Socket	FTP	HTTP	SMTP
SrvType	m	m	m	m
conId	m	m	m	m
address	m	m	m	m
tcpMR	o	o	o	o
tcpOT	o	o	o	o
cmd		m	m	o
files		o	o	o
ftpath		o		
smFrom				m
smRcpt				m
smCC				o
smSubj				m
smMsg				o
smAuth				m
hcContent			o	
hcContLen			m	
hcUserAgent			o	
hcProp			o	
user		o	o	o
passwd		o	o	o
alphabet	o	o	o	o
ipVer	o	o	o	o
secopt	o	o	o	o

Syntax

<p>Test Command</p> <pre>AT^SISS=?</pre> <p>Response(s)</p> <pre>OK</pre>										
<p>Read Command</p> <pre>AT^SISS?</pre> <p>Response(s)</p> <pre>^SISS: <srvProfileId>, <srvParmTag>, <srvParmValue> [^SISS: ...] OK ERROR +CME ERROR: <err></pre>										
<p>Write Command</p> <pre>AT^SISS=<srvProfileId>, <srvParmTag>, <srvParmValue></pre> <p>Response(s)</p> <pre>OK ERROR +CME ERROR: <err></pre>										
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>-</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	-	+	+	+	-
PIN	MDM	APP	→	Last						
-	+	+	+	-						

Parameter Description

<srvProfileId>^(num)	
Internet service profile identifier. The <srvProfileId> is used to reference all parameters related to the same service profile. Furthermore, when using the AT commands AT^SISO , AT^SISR , AT^SISW , AT^SIST , AT^SISH and AT^SISC the <srvProfileId> is needed to select a specific service profile.	
0...9	
<srvParmTag>^(u)	
Internet service profile parameter.	
srvType	Type of Internet service to be configured with consecutive usage of AT^SISS . For supported values of <srvParmValue> refer to <srvParmValue-srv-Type> .
alphabet	Selects the character set for input and output of string parameters within a profile. The selected value is bound to the specific profile. This means that different profiles may use different alphabets. Unlike other parameters the alphabet can be changed no matter whether the <srvParmTag> value "srvType" has been set. For supported values of <srvParmValue> refer to <srvParmValue-alphabet> .
user	User name string for FTP, HTTP, SMTP authentication. Parameter is optional: The user name can be set by <srvParmTag> parameter "user" or as part of "address" parameter. For HTTP only simple authentication is supported. Length: 32 octects

passwd	<p>Password string for FTP, HTTP, SMTP authentication. Parameter is optional: The password can be set by <code><srvParmTag></code> parameter "password" or as part of "address" parameter. Length: 32 octets</p>
conld	<p>Internet connection profile as defined with <code>AT+CGDCONT</code>. The value is one of the PDP context IDs set with parameter <code><cid></code>. If the UE is configured for Verizon Wireless Network the "conld" value set by default shall be changed to value 3 (= APN 3).</p>
address	<p>String value containing the URL for the specific service:</p> <ol style="list-style-type: none"> 1. Non-transparent Socket <ul style="list-style-type: none"> - TCP client URL "socktcp[s]://<host>:<remotePort>[;keepidle=<value>][;keepcnt=<value>][;keepintvl=<value>]" - TCP server URL "socktcp://listener:<localPort>[;keepidle=<value>][;keepcnt=<value>][;keepintvl=<value>]" - UDP endpoint URL "sockudp://:<localPort>" - UDP client URL "sockudp[s]://<host>:<remotePort>[;port=<localPort>]" 2. Transparent Socket <ul style="list-style-type: none"> - Transparent TCP client "socktcp[s]://<host>:<remotePort>;etx[=<etx-Char>][;timer=<value>][;bufsize=<value>][;keepidle=<value>][;keepcnt=<value>][;keepintvl=<value>]" - Transparent UDP client "sockudp[s]://<host>:<remotePort>;etx[=<etx-Char>][;timer=<value>][;bufsize=<value>]" - Transparent TCP Listener "socktcp://listener:<localPort>;etx[=<etxChar>][;timer=<value>][;autoconnect='0 1']";connecttimeout=<value>][;keepidle=<value>][;keepcnt=<value>][;keepintvl=<value>][;addrfilter=<filter>]" <p>Supported parameters for Socket services:</p> <ul style="list-style-type: none"> - <host>: IPv4 address in standard dot format, e.g. "192.168.1.2", or IPv6 address in standard colon format enclosed in square brackets, e.g. "[FE80::2]". - <remotePort>: 1 ... 2¹⁶-1 for the remote port number. - <localPort>: 1 ... 2¹⁶-1 for the local port number. - "etx": Parameter is mandatory for Transparent Socket. Otherwise Socket service is non-transparent. - "<etxChar>": Specifies the character used to change from transparent access mode to AT command mode. range: 1...15,17...255 (16 is not allowed because it is used as DLE (0x10)) If parameter is not set no escaping is configured, thus requiring either +++ or DTR ON-OFF transition for changing to AT command mode. If value is set, the transmitted bytes are parsed for the DLE (0x10) character followed by the specified <etxChar> value. If both characters are found the service returns to AT command mode without transmitting these two bytes. This behavior differs from +++ handling, where +++ is transmitted over the air. If you wish to send DLE characters as normal text string within your payload data the characters shall be doubled (DLE DLE). - "bufsize": maximum packet size, to setup the maximum send packet

- size.
range: 1..1460
- "timer": The parameter configures the Nagle algorithm, which is used in transparent access mode.
range: 0, 20...[100]...500 milliseconds in steps of 20
Value 0 disables the Nagle algorithm.
 - "keepidle": specifies the TCP parameter TCP_KEEPIDLE (see RFC1122; not for Transparent UDP client)
range: 1...65535 seconds, 0 disabled (default)
 - "keepcnt": specifies the TCP parameter TCP_KEEPCNT (see RFC1122; not for Transparent UDP client); ignored if option "keepidle" is not set
range: 1...[9]...127
 - "keepintvl": specifies the TCP parameter TCP_KEEPIIDVL (see RFC1122; not for Transparent UDP client); ignored if option "keepidle" is not set
range: 1...[75]...255 seconds
 - "autoconnect" (for Transparent TCP Listener service only):
0 ... disabled (default) 1 ... automatically accept incoming client connects
 - "connecttimeout": specifies the time after which incoming client connects are rejected automatically (for Transparent TCP Listener service only)
range: 1...[30]...180 seconds
 - "addrfilter": This option allows to filter incoming client connects based on the IP address of the client (for Transparent TCP Listener service only). It is possible to specify a maximum of 3 filters separated by commas. If the IP address of any incoming client connect does not match any of the specified filters, then the connect is rejected automatically. If the option is not specified, then all client connects are allowed.
In IPv4: Each filter is specified as 4 numbers separated by dots ("In IPv6: Each filter is specified by up to 8 bytes separated by colons ("Examples: *:5678:9abc:def0:1234:5678:9ABC:D*F0
1234::
::1**4
1*34:*::3456

3. FTP

"ftp[s]://[<user>:<passwd>@]<host>[:<port>][/<path>]"
"ftp://": The default TCP port 21 for ftp server is used.
"ftps://": The default SSL port 990 for secure ftp server is used.
<host>: element can be an IPv4 address, or an IPv6 address enclosed in square brackets, or a DNS FQDN string.
<port>: element can be set optionally to replace the default port.
<user>: username for authentication, 32 octets. Can be set as part of "address" or separately by <srvParmTag> parameter "user".
<passwd>: password for authentication, 32 octets. Can be set as part of "address" or separately by <srvParmTag> parameter "passwd".
<path>: path of file or directory. To read a root directory or subdirectory path shall be terminated with slash: <path>/.

4. HTTP

HTTP client URL
Length: 6...255
"http[s]://[<user>:<passwd>@]<server>[:<port>]/<path>]"

<server>: element can be an FQDN, or an IPv4 address, or an IPv6 address enclosed in square brackets.
<path>: path of file or directory.
<port>: If parameter is omitted the service connects to HTTP default port 80.
<user>: username for authentication, 32 octets.
<passwd>: password for authentication, 32 octets.
"https://": Used for SSL connection.
Refer to "IETF-RFC 2616".

5. SMTP

"smtp[s]://[<user>:<passwd>@]<host>[:<Port>]"
"smtp://": The default TCP port 25 for smtp server is used.
"smtps://": The default SSL port 465 for secure smtp server is used.
<host>: element can be an IPv4 address, or an IPv6 address enclosed in square brackets, or a DNS FQDN string.
<port>: element can be set optional and replace the default port.
<user>: username for authentication, 32 octets. Can be set as part of "address" or separately by <srvParmTag> parameter "user".
<passwd> is for authentication, 32 octets. Can be set as part of "address" or separately by <srvParmTag> parameter "passwd".

cmd

1. HTTP service

- "0" or "get": Send HTTP GET request to server
- "1" or "post": Send HTTP POST request to server
- "2" or "head": Send HTTP HEAD request to server

2. FTP service

- get [<OffsetString>]: get a single file from FTP server.
- put [<OffsetString>]: create and write a single file to FTP server using AT^SISS.
- dir: List the directory on the FTP server and show file size.
- list: List the directory on the FTP server without showing file size.
- size: Request the size of the file element on the FTP server. The size result is output as "^SIS" URC.
- del: Delete a file specified with <srvParmTag> parameter "files" on FTP server.
- append: Append data to existing file on FTP server
- unique: Selects the FTP Store Unique command to create a file name unique to the current directory. If the file name is assigned by the server then the "^SIS" URC will appear, indicating <urcInfoId> 2100 and the file name.

<OffsetString> is an optional parameter for "get" and "put". It allows resuming a broken uplink or downlink transfer to resend data. The <OffsetString> value specifies the offset in number of octets to start the transfer from. Maximum length is 16 digits. For "get" the <OffsetString> value must be calculated from the <urcInfoId> 2100 of the "^SIS" URC requested before by using "size".

3. SMTP service

- at: send a single attachment to the server (default). The content of the attachment should be provided using AT^SISS after the service was opened with AT^SISO.
- files: send file(s) specified via <srvParmTag> parameter "files". Max. 5 files allowed. The content of the file(s) should be provided using AT^SISS after the service was opened with AT^SISO.

ftpath

Specifies the path of the remote FTP server after login. If no path is set the default path will be used.

files	Name of a single file for upload from the AT command interface to a server, or download from a server to the AT command interface if the "cmd" parameter is given with "get" or "post" in case of HTTP, with "get", "put" or "del" in case of FTP, or with "at" in case of SMTP.
hcContent	<p>HTTP "POST": Variable mode. Optional parameter if HTTP "post" is set with <srvParmTag> parameter "cmd". Length: 1...255 bytes Can be used to transfer a small amount of data. The content of this string will only be sent if "hcContLen" = 0. To transmit a larger amount of data "hcContLen" must be set to a non-zero value. In this case the "hcContent" string will be ignored, and data transmission from the client to the server is done with AT^SISW. Usage example: AT^SISS=x,cmd,"POST"</p> <p>AT^SISS=x,hcContent,"This text will be sent to the server now response OK" OK</p> <p>AT^SISS=x,hcContLen,0</p> <p>AT^SISO=x OK</p> <p>^SIS: x,0,2200,"Http connect 10.42.228.61:80" ^SISW: x,2</p> <p>Please take care not to exceed the maximum "hcContent" length 255 bytes. Otherwise data is truncated.</p>
hcContLen	<p>HTTP "POST": Fixed mode. Mandatory parameter if HTTP "post" is set with <srvParmTag> parameter "cmd". Length: 0...2³¹-1 The value of this parameter indicates the amount of bytes of data to be transmitted with Http POST. If "hcContLen" = 0 then the data given in the "hcContent" string will be posted without AT^SISW required. If "hcContLen" > 0 then AT^SISW command and "^SISW: x, 1" sequences will be used to send data from the client to the server. In this case "hcContent" parameter will be ignored. Usage example, send 200 bytes: AT^SISS=x,cmd,"POST"</p> <p>AT^SISS=x,hcContLen,200</p> <p>AT^SISO=x OK</p> <p>^SIS: x,0,2200,"Http connect 10.42.228.61:80" ^SIS: x,0,2200,"POST Bytes: 200" ^SISW: x,1</p> <p>AT^SISW=x,200 ### 200 bytes of data ###</p>
hcUserAgent	The user agent string must be set by the application to identify the mobile. Usually operation system and software version info is set with this browser identifier. Length: 0...63

hcProp	Parameter for several HTTP settings. Length: 0...127 The general format is 'key': <space> 'value' Multiple settings can be given separated by "\0d\0a" sequences within the string, do not put them at the end. Possible 'key' values are defined at HTTP/1.1 Standard RFC 2616.
smFrom	Email sender address, i.e. "MAIL FROM" address (string). Length: 6...254 A valid address parameter consists of local part and domain name delimited by a '@' character, e.g. "john.smith@somedomain.de".
smRcpt	Recipient address of the email, i.e. "RCPT TO" address (string). Length: 6...254 If multiple recipient addresses are to be supplied the comma character is used as delimiter to separate individual address values, e.g. "john.smith@somedomain.de,tom.meier@somedomain.de". Some mail servers do not accept recipient addresses without brackets <>. It is recommended to use the "RCPT TO" variable with brackets.
smCC	CC recipient address of the email (string). Length: 6...254 If multiple CC recipient addresses are to be supplied the comma character is used as delimiter to separate individual address values, e.g. "john.smith@somedomain.de,tom.meier@somedomain.de".
smSubj	Subject content of the email (string). Length: 0...254 If no subject is supplied the email will be sent with an empty subject.
smAuth	SMTP authentication control flag (string). If "smAuth" = "0" or "none": No authentication (for test environment only, not applicable to real network) If "smAuth" = "1" or "plain" (default): Authentication with PLAIN authentication If "smAuth" = "2" or "login": Authentication with LOGIN authentication If "smAuth" = "3" or "cram": Authentication with CRAM authentication
smMsg	SMTP message body. If no attachment is defined this is only the content of the email. Length: 0...254
tcpMR	Parameter can be used to overwrite the global AT^SCFG parameter "Tcp/MaxRetransmissions" <tcpMr> for a specific Internet Service connection profile. If the parameter is not specified the value specified with AT^SCFG will be used. Supported values <srvParmValue> for this parameter are the same as described for <tcpMr>. Setting is not relevant for Internet Service "Socket" with type "UDP".
tcpOT	Parameter can be used to overwrite the global AT^SCFG parameter "Tcp/OverallTimeout" <tcpOt> for a specific Internet Service connection profile. If the parameter is not specified the value specified with AT^SCFG will be used. Supported values <srvParmValue> for this parameter are the same as described for <tcpOt>. Setting is not relevant for Internet Service "Socket" with type "UDP".
ipVer	Used version of IP service <ul style="list-style-type: none">• 4 IPv4 (default)• 6 IPv6 This parameter will be used for the following situations only: <ul style="list-style-type: none">• An IPV4V6 context is used, and this context provides both IPV4 and IPV6 interfaces AND• the service acts as a listener OR the client address is a hostname, and the DNS server provides IPV4 and IPV6 addresses
secopt	Security Option of IP service. Values:

- 1 (default): Check received certificates from server against local store, if local store has at least one certificate.
- 0: Do not check received certificates from server against the local store.

NOTE: Local store is created with [AT^SBNW,is_cert](#).

`<srvParmValue>(str)(+CSCS)`

Parameter value; type and supported content depend on related [<srvParmTag>](#).

`<srvParmValue-srvType>(str)`

Supported Internet service type values in [<srvParmValue>](#) for [<srvParmTag>](#) value "srvType". Before changing the "srvType" of an existing service profile be sure that the profile is closed. To verify the connection state of the service profile enter the read command [AT^SISI](#). Only when [<srvState>](#)=2 is returned for this specific service profile you can change its service type.

"Socket"	PLS8-X acting as client or server (listener) for TCP or UDP. "etx" subparameter in URL configures Transparent mode for Socket service.
"Ftp"	PLS8-X acting as FTP client.
"Http"	PLS8-X acting as HTTP client.
"Sntp"	PLS8-X acting as SMTP client.
"none"	Reset Internet service profile settings. Operation is not allowed if profile is in use, i.e. it was activated via AT^SISO .

`<srvParmValue-alphabet>(str)`

Supported string parameter character set selections in [<srvParmValue>](#) for [<srvParmTag>](#) value "alphabet".

["0"]	Applicable character set is determined by current setting of AT+CSCS .
"1"	International Reference Alphabet (IRA, seven bit ASCII).

Notes

- String parameters are truncated if greater than the maximum length specified above.
- For correct input of the @ character in address parameters please refer to Section 1.7, [Supported character sets](#).

10.5 AT^SISI Internet Service Information

AT^SISI serves to monitor the status of Internet service profiles defined with AT^SISS.

The AT^SISI read command requests the current status of all defined Internet service profiles.

The AT^SISI write command requests the status of the specified Internet service profile. If the specified service profile is not defined yet, "+CME ERROR" is returned.

Syntax

Test Command

```
AT^SISI=?
```

Response(s)

```
[^SISI: (list of defined <srvProfileId>s)]  
OK
```

Read Command

```
AT^SISI?
```

Response(s)

If response is related to service profile(s) created / opened on this interface:

```
[^SISI: <srvProfileId>, <srvState>, <rxCount>, <txCount>, <ackData>, <unackData>]  
[^SISI: ...]
```

If response is related to service profile(s) created / opened on other interface(s):

```
[^SISI: <srvProfileId>, <srvParmTag>value "srvType"]  
[^SISI: ...]
```

OK

ERROR

Write Command

```
AT^SISI=<srvProfileId>
```

Response(s)

```
^SISI: <srvProfileId>, <srvState>, <rxCount>, <txCount>, <ackData>, <unackData>  
OK  
ERROR  
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

`<srvProfileId>`^(num)

Internet service profile identifier as defined by `AT^SISS (<srvProfileId>)`.

0...9

`<srvState>`^(num)

Internet service state (for details see `AT^SISO` parameter `<srvState>`).

2	Allocated
3	Connecting
4	Up
5	Closing
6	Down
7	Alerting
8	Connected

`<rxCount>`^(num)

Number of bytes received via `AT^SISR` or `AT^SIST` since last successful `AT^SISO` write command. This is the same value as displayed by the `AT^SISO` read command with the parameter `<rxCount>`.

`<txCount>`^(num)

Number of bytes sent via `AT^SISW` or `AT^SIST` since last successful `AT^SISO` write command. This is the same value as displayed by the `AT^SISO` read command with the parameter `<txCount>`.

`<ackData>`^(num)

Number of data bytes already sent and acknowledged at TCP layer. Value 0 indicates that no sent data is acknowledged yet.

Parameter is not applicable to HTTP, SMTP, Socket with UDP. For these services the counter is always set to 0.

`<unackData>`^(num)

Number of data bytes already sent but not yet acknowledged at TCP layer. A value 0 indicates that all sent data is already acknowledged.

This is the same value as displayed in the response of the `AT^SISW` write command with the parameter `<unackData>`.

Parameter is not applicable to HTTP, SMTP, Socket with UDP. For these services the counter is always set to 0.

Note

- If a service is in state "Down" the responses for `<rxCount>`, `<txCount>`, `<ackData>` and `<unackData>` are the last known values for the service in the states "Connecting", "Up/Listening", "Connected" and "Closing".

10.6 AT^SISO Internet Service Open

The `AT^SISO` write command starts an Internet service configured with `AT^SIS`. Before you can start a service it is necessary to activate the bearer with `AT^SICA`. The command may be aborted by any character sent from the TE to the UE during execution.

Syntax

<p>Test Command</p> <pre>AT^SISO=?</pre> <p>Response(s)</p> <pre>OK</pre>
<p>Read Command</p> <pre>AT^SISO?</pre> <p>Response(s)</p> <pre>^SISO: <srvProfileId>, <srvType>[, <srvState>, <socketState>, <rxCount>, <txCount>, <locAddr>, <remAddr>, <rejCounter>] [^SISO: ...] OK</pre>
<p>Write Command</p> <pre>AT^SISO=<srvProfileId>[, <optParam>]</pre> <p>Response(s)</p> <pre>OK ERROR +CME ERROR: <err></pre>
<p>PIN MDM APP → Last</p> <pre>- + + - -</pre>

Parameter Description

`<srvProfileId>`^(num)

`<srvProfileId>` 0 ... 9 specified with `AT^SIS`.

`<srvType>`^(str)

The type of the internet service as specified by the `AT^SIS` parameter `<srvParmValue-srvType>`.

`<srvState>`^(num)

Internet service state.

Please note, that the state of an Internet service may influence the state of the serial DCD line. For details see description of value 2 for parameter `<value>` of command `AT&C`.

2	<p>Allocated</p> <p>Service profile resources are allocated, i.e. at least the service type has been set (parameter <code><srvParmTag></code>, value "srvType" of <code>AT^SIS</code>). The service is not opened, but ready for configuration.</p>
3	<p>Connecting</p> <p>State after opening a service with <code>AT^SISO</code> where the connection is being established.</p> <p>If connection setup is successful the service proceeds to the state "4" (Up) and one of the URCs "<code>^SISW</code>" and "<code>^SISR</code>" may follow. If connection setup is not successful, the "<code>^SIS</code>" URC may appear and the service enters <code><srvState></code> 6 (Down).</p>

	In the case of FTP, <code><srvState>=3</code> means that the command channel is being established. If the service profile is configured as Standard Listener, then the Listener always stays at <code><srvState>=3</code> and <code><socketState>=3</code> (LISTENER), while the <code><srvState></code> and <code><socketState></code> of the dynamically assigned service profile may change. See examples in Section 10.15.5.
4	Up The service performs its purpose. The data transfer process is the major function at this state. FTP: Data channel is up. SMTP: The SMTP service will not enter <code><srvState>=4</code> until the host has written the first data packet with <code>AT^SISW</code> . Transparent TCP Listener service: the service is listening to remote client connection requests. Not applicable to Standard Listener. See examples in Section 10.15.6.
5	Closing Internet Service is closing the network connection. FTP: Command channel is released.
6	Down This state is entered if <ul style="list-style-type: none"> - the service has successfully finished its session (see note on Socket), - the remote peer has reset the connection or - the IP connection has been closed because of an error (see note below on service or network errors). <p>If a service in this state be sure to close it with <code>AT^SISC</code> before reopening it.</p>
7	Alerting A client tries to connect to the Transparent TCP Listener service. Not applicable to Standard Listener.
8	Connected A client is connected with the Transparent TCP Listener service. Not applicable to Standard Listener.

`<socketState>`^(num)

Socket state identifier.

1	Socket not assigned, i.e. no TCP/UDP connection active.
2	Socket assigned as CLIENT.
3	Socket assigned as LISTENER or UDP Endpoint.
4	Socket assigned as SERVER.

`<rxCount>`^(num)

Number of bytes received via `AT^SISR` or `AT^SIST` since last successful `AT^SISO` write command.

`<txCount>`^(num)

Number of bytes sent via `AT^SISW` or `AT^SIST` since last successful `AT^SISO` write command.

`<locAddr>`^(str)

Recently used local IPv4 address in dotted-four-byte format and TCP port separated by colon, e.g. "192.60.10.10:80", or recently used local IPv6 address in colon format enclosed in square brackets, e.g. "[FE80::2]" and TCP port separated by colon, e.g. "[FE80::2]:80".

<remAddr>^(str)

Remote IPv4 address in dotted-four-byte format and TCP port, separated by colon, e.g. "192.60.10.10:80", or remote IPv6 address in colon format enclosed in square brackets, e.g. "[FE80::2]" and TCP port separated by colon, e.g. "[FE80::2]:80".

<rejCounter>^(num)

Number of automatically rejected client connect attempts to a Transparent TCP Listener service because the service is already connected with a client (only relevant for Transparent TCP Listener services with Autoconnect enabled).

<optParam>^(num)

1 Show only parameters of service profile for given <srvProfileId>.

Notes

- If the bearer cannot be established and AT^SISO returns an error there might be a general mobile network problem. To identify the reason you can take advantage of the AT+CEER command. Using AT+CEER is especially recommended when the <infoID> parameter of the AT^SISE command equals 0.
- If a service or network error occurs during an IP session and the "^SIS" URC or the AT^SISE command display an error message, the service enters <srvState>=5 and then 6, i.e. the IP connection is closed. In this case, the service still allows reading the data stored in the buffer, but writing data is denied. After reading, close the service and open it again.
- If an FTP connection is no longer available after network loss or server shutdown a 3-minute closing timeout for each of the two used sockets takes effect, adding up to 6 minutes. The timeout is effective if the AT^SISC is not sent. Please keep in mind that this time may vary depending on the settings of <tcpMr> and <tcpOt>.
- As in polling mode no error URCs are available you are advised to integrate the commands AT^SISI and AT^SISE into the command sequences for upload and download jobs. So, the AT^SISO command may be followed by AT^SISI to check that the service has entered the <srvState>=4 before sending AT^SISR, AT^SISW or AT^SIST. This helps you to detect errors even though the "^SIS" URCs are disabled. A typical example is that the service fails to be opened because the service profile contains a wrong destination address. In such a case, after opening with AT^SISO and OK response, the service quickly enters the states <srvState>=2, 4 and 6, with an error being returned no earlier than after sending the first AT^SISR or AT^SISW command. In URC mode, an error URC, such as "Host not found" would be received in this situation, but in polling mode the only way to detect the state is using AT^SISI or, alternatively, AT^SISO.

10.7 AT^SISC Internet Service Close

The `AT^SISC` write command closes the TCP/IP connection to the remote peer which was opened with `AT^SISO`. All resources are released, all status information parameters, e.g. `<srvState>`, `<rxCount>` and `<txCount>` counters are reset. Only the initial configuration settings are preserved. The service can be restarted any time, using the same configuration or a new one.

Syntax

```
Test Command
AT^SISC=?
Response(s)
OK

Write Command
AT^SISC=<srvProfileId>
Response(s)
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
±	+	+	-	-

Parameter Description

<code><srvProfileId></code> ^(num)	
0...9	<code><srvProfileId></code> specified with <code>AT^SISC</code> .

10.8 AT^SISR Internet Service Read Data

The `AT^SISR` write command can be used to read data for the specified service. It may return the following errors: The `AT^SISR` command either triggers a read operation (download) or queries the number of bytes in the internal buffer.

The "`^SISR: x, 1`" URC is also used to report status changes of the transparent TCP service while the client is in AT command mode.

The `AT^SISR` write command may return the following errors:

- "+CME ERROR: operation failed" if there is a problem on application, socket, PPP or network level. The `AT^SISE` command and the "`^SIS`" URC offer additional error information.
- "+CME ERROR: operation temporary not allowed" e.g. if the service has not network resources allocated.
- "+CME ERROR: operation not allowed" e.g. if the service is not configured.

Syntax

Test Command
<code>AT^SISR=?</code>
Response(s)
OK
Write Command
<code>AT^SISR=<srvProfileId>, <reqReadLength></code>
Response(s)
<code>^SISR: <srvProfileId>, <cnfReadLength>[, <remainUdpPacketLength>[, <Udp_RemClient>]]</code>
Number of data bytes are sent as specified by <code><cnfReadLength></code> . If peek operator was used no data bytes are sent.
OK
ERROR
+CME ERROR: <code><err></code>
PIN MDM APP → Last
- + + - +

Unsolicited Result Code

`^SISR: <srvProfileId>, <urcCauseId>`

Data availability status of the Internet service configured with `AT^SISR` has changed. The URC is issued when:

- data is available after opening an Internet service or
- less data was confirmed (in `<cnfReadLength>`) than requested (with `<reqReadLength>`) during the last "Read Data" operation and new data is available.

The URC is disabled in polling mode. See `AT^SCFG`, parameter "Tcp/WithURCs", `<tcpWithUrc>`.

Parameter Description

`<srvProfileId>`^(num)

`<srvProfileId>` 0 ... 9 specified with `AT^SISR`. Transparent TCP Listener services are not supported.

<reqReadLength>^(num)

- 0 Peek Operator: Query number of received bytes within internal buffers. The behaviour of the peek operator depends on the selected Internet service, i.e. it may not be supported by all IP Services. For "Socket" service configured for UDP the size of the next available UDP packet is returned.
- 1...1500 Requested number of data bytes to be read via the Internet service specified in <srvProfileId>.

<cnfReadLength>^(num)

- 2 Indicates end of data. Data transfer has been finished (all data have been read) and the service can be closed with AT^SISC.
- 1 Applies only to HTTP: Querying number of available bytes is not supported by the HTTP service.
- 0 Indicates that no further data is available at the moment.
- >0 Number of available data bytes. The range is determined by <reqReadLength>:
If <reqReadLength> was greater than 0, then <cnfReadLength> may be less or equal to the value requested with <reqReadLength>.
If <reqReadLength> equals 0 (peek operator) the value indicated by <cnfReadLength> may be greater than 1500.

<urcCauseId>^(num)

Indicates whether or not data is available for reading with AT^SISR and AT^SIST.

- 1 *Meaning of value "1" for all services except Transparent TCP service:*
Data is available and can be read by sending the AT^SISR command. The URC appears when less data was confirmed (in <cnfReadLength>) than requested (with <reqReadLength>) during the last "Read Data" operation and new data is available.

Meaning of value "1" for Transparent TCP service:
If the Transparent TCP service is in AT command mode the "^SISR: x, 1" URC notifies the client that the server has sent new data. In this case the client shall enter the AT^SIST command to go to transparent access mode and read the data.
- 2 End of data. Data transfer has completed (all data read). The service can be closed with AT^SISC.

<remainUdpPacketLength>^(num)

Optional third parameter of the AT^SISR write command response displayed only if the Socket service uses the UDP protocol.

The reception of each datagram must be completed before the next datagram can be received. This may be a problem if the buffer of the host application is limited and not designed to handle the maximum packet size of 1500 bytes. To compensate this, the host is advised to request, via <reqReadLength>, an amount less or equal its maximum buffer capacity and wait for the resulting AT^SISR write command response with parameter <remainUdpPacketLength>. The benefit of this approach is that the host may properly receive all parts of a UDP datagram, as after each received data part the number of remaining bytes is synchronized, until reading the datagram is finished.

If the currently read datagram is smaller than the number of bytes requested by the host the `<remainUdpPacketLength>` parameter is omitted.

Further write attempts with `AT^SISR` are denied as long as the `<remainUdpPacketLength>` is unequal 0 or is not omitted. In this case the service returns `" +CME ERROR: operation of service temporary not allowed"`.

- 0 Indicates that all bytes of the current UDP datagram are read.
- (max. data size)-1...1 Indicates that the currently read UDP datagram is not yet complete. The displayed value is the remaining number of bytes. `<remainUdpPacketLength>` is unequal 0 until reading all parts of the current datagram is finished.

`<Udp_RemClient>`^(str)

Service specific parameter of the `AT^SISR` write command response. If the Socket service is configured as UDP endpoint this parameter shows the IP address and the UDP port of the remote host that has sent the current UDP data. See example in Section 10.15.9, [UDP Scenario](#).

10.8.1 Example: Socket Host Reads Small Amounts of UDP Data Packets (URC Mode)

This section applies only to the Socket service using the UDP protocol. The example shows how to read UDP packets if the buffer of the host application can handle only a few bytes. There are two datagrams available for reading.

Buffer size: 6 bytes

Datagram A = 18 bytes (content "THIS_IS_DATAGRAM_A")

Datagram B = 3 bytes (content "NEW")

```

^SISR: 0,1
Service profile 0 is configured for Socket service and UDP. The URC
at^sizr=0,6
notifies host that data is available for reading.
^SISR: 0,6,12
The host requests to read 6 bytes.
THIS_I
The first 6 bytes of datagram A are confirmed and transmitted. Another
OK
12 bytes are still available.
at^sizr=0,6
The host requests to read the next part of 6 bytes.
^SISR: 0,6,6
The next 6 bytes of datagram A are confirmed and transmitted. Another
S_DATA
6 bytes are still available.
OK
at^sizr=0,6
The host requests to read the next part of 6 bytes.
^SISR: 0,6,0
Last part of datagram A was received, no remainder is left.
GRAM_A
OK
at^sizr=0,6
Again, the host requests to read 6 bytes. This time, the request refers to
datagram B which has only 3 bytes. As the read datagram is smaller
than the size requested by the host, the response does not include the
<remainUdpPacketLength>.
^SISR: 0,3
3 bytes are confirmed and transmitted. Datagram B was properly
NEW
received.
OK
  
```

10.9 AT^SISW Internet Service Write Data

`AT^SISW` triggers a write operation (upload) and queries the amount of data already sent, but not acknowledged at the TCP layer. The URC "`^SISW: <srvProfileId>, <urcCauseId>`" will be issued if the PLS8-X is ready to accept user data.

The `AT^SISW` write command may return the following errors:

- "+CME ERROR: operation failed" if there is a problem on application, socket, PPP or network level. The `AT^SISE` command and the "`^SIS`" URC offer additional error information.
- "+CME ERROR: operation temporary not allowed" e.g. if the service has not network resources allocated.
- "+CME ERROR: operation not allowed" e.g. if the service is not configured.

Syntax

```
Test Command
AT^SISW=?
Response(s)
OK

Write Command
AT^SISW=<srvProfileId>, <reqWriteLength>[, <eodFlag>[, <Udp_RemClient>]]
Response(s)
^SISW: <srvProfileId>, <cnfWriteLength>, <unackData>
Number of data bytes as specified by <cnfWriteLength>.
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
±	+	+	-	+

Unsolicited Result Code

`^SISW: <srvProfileId>, <urcCauseId>`

Data availability status of the Internet service configured with `AT^SISW` has changed. The URC is issued when the service is ready to accept new user data. In this context the URC is also issued for the Transparent TCP or Transparent UDP client that supports data transfer via `AT^SISW` only.

The URC is disabled in polling mode. See `AT^SCFG`, parameter "Tcp/WithURCs", `<tcpWithUrc>`.

Parameter Description

`<srvProfileId>`^(num)
`<srvProfileId>` 0 ... 9 specified with `AT^SISW`. Transparent TCP Listener services are not supported.

`<reqWriteLength>`^(num)
0...1500

Specifies the number of bytes to be sent with `AT^SISW` or, if set to 0, requests the amount of data already sent with `AT^SISW` but not yet acknowledged:

- Parameter `<reqWriteLength>` may be 1...1500 bytes to specify the amount of data to be sent with `AT^SISW`.
- If parameter `<reqWriteLength>` equals 0, `AT^SISW` does not expect any data, but a normal query is performed. This allows the application to explicitly request, in particular at the end of an upload job, the amount of unacknowledged data at the TCP layer indicated by `<unackData>`.
- If Socket service is selected with UDP protocol

- `<reqWriteLength>=0` can be used to send an empty UDP packet;
- it is recommended that the size of each data packet be limited to 1460 bytes. Otherwise, it is possible that the following URC occurs: "`^SIS: <id>, 0, 9, The supplied buffer was too small / large`".

`<eodFlag>`^(num)

End of data indication flag. See also Section 10.9.1.

- | | |
|-----|---|
| [0] | No end of data. Other data may follow to be transmitted via the Internet service. Note for UDP Endpoint service: Value 0 must be set before <code><Udp_RemClient></code> parameter although <code><eodFlag></code> is not effective for UDP Endpoint. |
| 1 | End of data is signalled to the Internet Service. Further <code>AT^SISW</code> write commands return an error response. However, reading data may be possible. The <code><eodFlag></code> is effective only if the <code><reqWriteLength></code> equals <code><cnfWriteLength></code> , in particular if the <code><reqWriteLength></code> equals 0.
End-of-data flag must be enabled for following actions: <ul style="list-style-type: none"> - FTP "cmd", "put" (sending single file to FTP server) - SMTP "cmd", "at" (sending attachment from AT command interface) |

`<Udp_RemClient>`^(str)

Service specific parameter of the `AT^SISW` write command. If the Socket service is configured as UDP endpoint this parameter is mandatory and specifies the IP address (in dotted format) and the UDP port of the remote host. For each write request another IP address and UDP port may be given. See example in Section 10.15.9, [UDP Scenario](#).

`<cnfWriteLength>`^(num)

0...1500
 Confirmed number of data bytes which can be transmitted via the Internet service configured in `<srvProfileId>`. This number may be less or equal to the value requested with `<reqWriteLength>`. The application has to deliver exactly the number of bytes indicated by `<cnfWriteLength>`. A 0 value means that no data can be written at this time, i.e. it serves as a flow control mechanism.

`<unackData>`^(num)

Number of data bytes already sent but not yet acknowledged at the TCP layer. The value is constantly changing until the entire upload job has completed. If the value equals 0 all data sent so far is acknowledged.
`<unackData>` includes the `<cnfWriteLength>` value of the pending write operation. Therefore, the very first write operation of an upload job returns identical values for `<cnfWriteLength>` and `<unackData>`. This mechanism allows the host application to easily verify whether or not the remote host has successfully received the data.
 Parameter is not applicable to HTTP, SMTP, Socket with UDP protocol. For these services the counter is always set to 0.

`<urcCauseId>`^(num)

- | | |
|---|---|
| 1 | The service is ready to accept new user data. |
| 2 | Data transfer has been finished successfully and Internet service may be closed without loss of data. |

Note

- Do not send any characters after `AT^SISW` command line termination until "`^SISW`" URC is received. This is necessary to avoid that any characters related to the AT command can be interpreted as being part of the data stream to be transferred. Also refer to Section 1.5, [AT Command Syntax](#).

10.9.1 Usage of parameter <eodFlag>

Service type	
Socket	<p>Parameter is optional for Socket services. Not applicable to Socket with UDP protocol, i.e. value is ignored.</p> <p>After the service accepts the end-of-data flag the service state changes to "Closing". No further user data is accepted. After releasing the TCP link the service remains in state "Down".</p>
FTP	<p>Parameter is mandatory for FTP "put" (sending single file to FTP server).</p> <p>After accepting the end-of-data flag the service state changes to "Closing" and starts to end the running FTP session. No further user data is accepted. After the FTP session is completed on FTP protocol level the service state switches to "Down". In case of successful completion the URC "^SISW: x,2" is generated.</p>
SMTP	<p>Parameter is mandatory for SMTP "cmd","at" (sending attachment from AT command interface).</p> <p>SMTP service sends some "closing" commands to the SMTP server which are necessary to mark the email as successfully sent on the server. The service enters "Closing" state and remains in it until the final protocol exchange with the SMTP server has been completed. The "OK" response following AT^SISW indicates that the SMTP service has accepted the last data - IT DOES NOT indicate the successful completion of the SMTP service. Successful completion will be indicated either by the appropriate URC "^SISW:x,2" or due to the fact that the SMTP service state changes to "Down" state without any error.</p>
HTTP	<p>Parameter is optional.</p>

10.10 AT^SIST Transparent Mode

[AT^SIST](#) activates / deactivates Transparent Mode. Transparent Mode enables the UE to transparently send or receive payload data stream either over dedicated multiplex channels or over the Modem instance.

Transparent TCP Client or Transparent UDP Client:

[AT^SIST](#) can be used after the transparent client has been opened with [AT^SISO](#) and is in "Up" state ([<srvState>](#)=4). If the service is not "Up" trying to open it will be denied with "+CME ERROR: operation temporary not allowed".

There are two ways to verify that the service is "Up": Each time after opening the service with [AT^SISO](#) wait for the "[^SISW](#): x, 1" URC. In addition, you can request the [<srvState>](#) with [AT^SISO](#) or [AT^SISI](#).

Transparent TCP Listener service:

[AT^SIST](#) can be used after the Transparent TCP Listener service has accepted an incoming client with [AT^SISO](#). Alternatively, if the Transparent TCP Listener operates in Autoconnect mode Transparent Mode starts instantly after the Listener has automatically accepted an incoming connection request..

The handling of Transparent Mode largely depends on whether you are using [AT^SIST](#) on the dedicated multiplex channels or on the Modem interface. The major difference is that the second method blocks the AT command interface used for transparent access, and the first method does not.

1. Using Transparent Mode on dedicated multiplex channels 5 and 6:

In this case, enter the [AT^SIST](#) write command either on the Application instance or the Modem instance along with the parameters [<muxChannelId>](#) and [<muxChannelState>](#) "1". The advantage is that the Application or Modem instance remains accessible for AT commands and URCs, while Transparent Mode is assigned to a dedicated multiplex channel. The multiplex channel is only used for transferring payload data. Therefore, result codes such as "CONNECT" or "NO CARRIER" will not appear. The DCD line goes active when Transparent Mode starts, and inactive when it stops. If a transparent socket is closed (remotely by the server or locally by the client) the Transparent Mode closes automatically.

2. Using Transparent Mode without dedicated multiplex channels:

In this case, enter the [AT^SIST](#) write command on the Modem interface with [<srvProfileId>](#) only. Please note that this method is not supported on the Application interface (trying to do so will be denied with "+CME ERROR: operation not allowed").

After entering [AT^SIST](#) the CONNECT response notifies that the UE has entered Transparent Mode and is ready to transfer payload data over the Modem interface.

There are several ways to quit Transparent Mode and revert to AT command mode on the used interface:

- `+++` escape sequence (also transmitted over the air)
- DTR ON-OFF transition (see [AT&D](#) for configuring DTR handling)
- "etx" parameter set within the server address for Transparent Mode (see [AT^SISS](#), [<srvParmTag>](#) "address").

Switching back and forth between both modes does not affect the underlying socket and has no influence on the service [<srvState>](#).

If the service is released, for example with [AT^SISC](#) or by the remote server, and the service is in Transparent Mode (CONNECT mode) the following applies: The UE returns to AT command mode, issues the 2 bytes 0x10 (DLE) and 0x04 (EOT) before the final result code "NO CARRIER", and goes to [<srvState>](#) 6 ("Down") for transparent client services and to 4 ("Up/Listening") for Transparent TCP Listener services.

The result codes "CONNECT" and "NO CARRIER" are not influenced by [ATV](#).

In AT command mode or after releasing the service, you can use [AT^SISO](#) to check the [<srvState>](#).

Syntax

Test Command

```
AT^SIST=?
```

Response(s)

```
OK
```

```

Read Command
AT^SIST?
Response(s)
[^SIST: <srvProfileId>, <ChannelId>]
OK

Write Command
AT^SIST=<srvProfileId>[, <muxChannelId>, <muxChannelState>]
Response(s)
CONNECT
(indicates that the Modem interface has entered Transparent Mode. Not issued on multiplex channels 5 or 6.)
OK
ERROR
+CME ERROR: <err>

PIN  MDM  APP  →  Last
-    +    +    -    +
    
```

Parameter Description

<srvProfileId>^(num)

<srvProfileId> 0 ... 9 specified with AT^SISS.

<muxChannelId>^(num)

5...6

Identifier of the dedicated multiplex channel to be used for data exchange. If the parameter is not specified, then the Modem interface instead of a dedicated multiplex channel is used to exchange the data. In this case AT^SIST is allowed to be executed on the Modem interface only.

<ChannelId>^(num)

0	Transparent Mode is activated on the Modem interface.
5...6	Transparent mode is activated on a multiplex channel. The value refers to <muxChannelId>.

<muxChannelState>^(num)

Control the Transparent Mode on a dedicated multiplex channel.

[0]	Stop Transparent Mode
1	Start Transparent Mode

Note

- If AT^SIST is running for a certain <srvProfileId>, then the commands AT^SISR and AT^SISW are not usable for the same <srvProfileId>.

10.11 AT^SISH Disconnect Remote Client

[AT^SISH](#) is intended only for a Transparent TCP Listener service. It allows to reject an incoming remote client connection request or to disconnect an established client connection from server side.

Syntax

```
Test Command
AT^SISH=?
Response(s)
OK

Write Command
AT^SISH=<srvProfileId>[, <mode>]
Response(s)
OK
ERROR
+CME ERROR: <err>

PIN  MDM  APP  →  Last
-    +    +    -    -
```

Parameter Description

<code><srvProfileId></code> ^(num)	
0..9	A Transparent TCP Listener service <code><srvProfileId></code> defined with AT^SISS .

<code><mode></code> ^(num)	
Specifies disconnect mode.	
[0]	Socket is closed with graceful option
1	Socket is closed without graceful option

10.12 AT^SISX Internet Service Execution

The `AT^SISX` command can be used to send ICMP (Internet Control Message Protocol) Echo Requests to a target IP address or DNS host name (also referred to as Ping command). This command can also be used to resolve DNS host names to IP addresses (HostByName) or resolve the network time, NTP protocol, in UTC.

The `AT^SISX` command can be used any time while a connection profile (bearer) is active. If issued although no connection is active, then `AT^SISX` returns ERROR.

If the `AT^SISX` write command is executed for Ping, then the command returns one row for every ICMP Echo Request. The last Ping response line is followed by an empty line, then another two lines appear to report a statistic calculated from the Echo Request responses. After starting the ping command the AT channel is blocked until all ICMP requests are executed. To stop the periodic ping early, send any character (user break).

It is also possible to cancel the HostByName or NTP service by user break. But this may temporarily block further `AT^SISX` write commands which is indicated by the error response "+CME ERROR: operation temporary not allowed". As soon as the background activity for the last started HostByName service is finished the `AT^SISX` write command can be used again.

Syntax

Test Command

```
AT^SISX=?
```

Response(s)

```
^SISX: "Ping", (list of supported <conProfileId>s), , (range of supported <request>s), (range of supported <timelimit>s)
```

```
^SISX: "HostByName", (list of supported <conProfileId>s)
```

```
^SISX: "NsLookup", (list of supported <conProfileId>s)
```

```
^SISX: "Ntp", (list of supported <conProfileId>s)
```

```
OK
```

Write Command

```
AT^SISX=<service>, <conProfileId>, <address>[, <request>[, <timelimit>]]
```

Response(s)

In case of <pingInfoType>= 1: ICMP Echo Requests (1 - 30 rows)

```
^SISX: "Ping", <pingInfoType>, <conProfileId>, <ip-address>, <roundTripTime>
```

```
[...]
```

In case of <pingInfoType>= 2: Packet statistic (1 row)

```
^SISX: "Ping", <pingInfoType>, <conProfileId>, <sent>, <received>, <lost>, <lostPercent>
```

In case of <pingInfoType>= 3: Time statistic (1 row)

```
^SISX: "Ping", <pingInfoType>, <conProfileId>, <minRTT>, <maxRTT>, <meanRTT>
```

In case of <service>= "HostByName"

```
^SISX: "HostByName", <ip-address>
```

```
[...]
```

In case of <service>= "NsLookup"

```
^SISX: "NsLookup", <ip-address>, <tTL>
```

```
[...]
```


In case of <service>= "Ntp"

```
^SISX: "Ntp", <ntp>
```

```
OK
```

```
ERROR
```

```
+CME ERROR: <err>
```



Parameter Description

`<service>`^(str)

"Ping"	Ping host.
"HostByName"	Get first address from a host.
"Nslookup"	Get all addresses including TTL from a host.
"Ntp"	Network time protocol.

`<conProfileId>`^(num)

Internet connection profile to be used as specified with [AT+CGDCONT](#) parameter `<cid>`.

`<address>`^{(str)(+CSCS)}

In case of "Ping" this is the target host as FQDN or IP address (i.e. "192.168.1.3"), in case of "HostByName" this is the FQDN to be resolved into the IP address.

`<ip-address>`^(str)

The IP address of the host (i.e. "192.168.1.3").

`<request>`^(num)

[1]...30	Number of "Ping" ICMP Echo Requests to be sent. Not supported for "HostByName".
4	IPV4 only in case of "HostByName" or "NsLookUp"
6	IPV6 only in case of "HostByName" or "NsLookUp"

`<timelimit>`^(num)

200...[5000]...10000 Amount of time, in milliseconds, to wait for an ICMP Echo Response message related to a previously sent Echo Request message.
Parameter is not supported for "HostByName".

`<pingInfoType>`^(num)

Indicate the type and format of the information given in the command responses (see syntax of the [AT^SISX](#) write command above).

1	Ping status received for the ICMP Echo Request(s). Depending on parameter <code><request></code> 1 - 30 rows. Address and Round Trip Time are returned for each request.
2	one row packet statistic calculated from the ping response(s) received for <code><pingInfoType>=1</code> .
3	one row time statistics calculated from the ping response(s) received for <code><pingInfoType>=1</code> (displayed only if at least one Echo response message was received).

`<roundTripTime>`^(num)

Round Trip Time in milliseconds. If the Echo Response message is not received within the time specified by `<timelimit>` the value -1 is returned (e.g. when the bearer shuts down during command execution).

<sent>^(num)

Number of sent packets.

<received>^(num)

Number of received packets.

<lost>^(num)

Number of lost packets.

<lostPercent>^(num)

Lost packets in percent.

<minRTT>^(num)

Minimum Round Trip Time in milliseconds.

<maxRTT>^(num)

Maximum Round Trip Time in milliseconds.

<meanRTT>^(num)

Average Round Trip Time in milliseconds.

<ntp>^(num)

time in extended format UTC

<tTl>^(num)

The TTL value for this address in seconds.

10.13 AT^SISE Internet Service Error Report

The `AT^SISE` write command returns the current error status of the specified Internet service profile. If the service profile is not defined or the value is invalid "+CME ERROR" response is returned. The error status is identical to the content of the "`^SIS`" URC last issued or if a service fails the commands `AT^SISR`, `AT^SISW` or `AT^SIST` will return an error response. However, if the `AT^SISE` command returns `<infoID>=0` it is recommended to use the `AT+CEER` command because a general network problem might be the reason.

Syntax

```

Test Command
AT^SISE=?
Response(s)
OK

Write Command
AT^SISE=<srvProfileId>
Response(s)
^SISE: <srvProfileId>, <infoID>[, <info>]
OK
ERROR
+CME ERROR: <err>
  
```

PIN	MDM	APP	→	Last
-	+	+	-	-

Parameter Description

`<srvProfileId>`^(num)

Internet service profile identifier as defined by `AT^SISS <srvProfileId>`.
 0...9

`<infoID>`^(num)

Reason for Internet service error. This is a subset of the `<urcInfoID>`s which can be found in Section 10.14, [Internet Service URC](#).
 The value 0 indicates there is no special Internet service error. In this case the application may use `AT+CEER` to check for general GSM/GPRS problems.

`<info>`^(str)

Information text related to `<infoID>`. This is a subset of the `<urcInfoText>`s which can be found in Section 10.14, [Internet Service URC](#).

Note

- In particular cases, the `AT^SISE` command may deliver information and warnings. This applies the following services:
 FTP: Information 2100
 SMTP: Warnings
 If an error occurs the information and warning messages are overwritten by error messages.

10.14 Internet Service URC

This section first describes the syntax and the parameters of the "^SIS" URC. The second part consists of tables listing the information elements delivered within the "^SIS" URC and the command response of AT^SISE.

The presentation of the "^SIS" URC containing the parameter <urcCause>=0 can be disabled or enabled depending on whether polling mode or URC mode is preferred. To do so, use the AT^SCFG command, parameter "Tcp/WithURCs" (refer to <tcpWithUrc>). However, if related to <urcCause>=1, 2, 3 or 4, the "^SIS" URC will always be delivered regardless of the setting made with AT^SCFG.

Unsolicited Result Code

Indicates an event, an error or an information element. The same information can be obtained via AT^SISE.

^SIS: <srvProfileId>, <urcCause>[, [<urcInfoId>][, <urcInfoText>]]

The URC may appear if an event or an error occurs, for example after opening an Internet service with AT^SISO or any time during operation. The URC also indicates a request for a mobile terminated Internet service client connection, or a failure if a mobile terminated request is rejected. Furthermore, the URC may deliver an information element resulting from a specific command given in the service profile.

A list of possible causes can be found in the tables below. The tables contain the <urcInfoId> and, if applicable, a specific <urcInfoText>. If marked with *) the precise text related to a <urcInfoId> varies greatly depending on the scenario and the implementation of the remote server. In these cases, only a brief explanation of the scenario can be found in the table column "Description".

Parameter Description

<urcCause> ^(num)	URC cause identifier.	
0		An event has occurred after opening or while using an Internet service. The event number is presented via <urcInfoId> and may be an error, a warning, an information element or a note. Optionally additional information may be supplied via <urcInfoText>.
1		Indicates that an opened Standard TCP Listener service (in Non-Transparent Mode) is receiving a connection request from a remote client. The incoming socket connection is dynamically assigned to the next free Internet service profile. In this case, the parameter <urcInfoId> inside the "^SIS" URC equals the <srvProfileId> of the dynamically assigned service profile. This ID shall be used to accept the connection request with AT^SISO or to reject it with AT^SISC. The connection status may be requested by using the AT^SISI read or write command or the AT^SISO read command. Among other details, the response indicates the IP address of the remote client (parameter <remAddr>). This may be helpful to decide whether to accept or reject the request.
2		Incoming Socket service client connection has failed. The client request was rejected automatically because no free Internet service profile was available.
3		Indicates that an opened Transparent TCP Listener service is receiving a connection request from a remote client. The parameter <urcInfoId> then indicates whether auto answering is active for the service (<urcInfoId>=1) or not. Parameter <urcInfoText> contains the remote IP address and the port of the connecting client. Example: "^SIS: 5,3,0,\"192.168.105.17:1712\"" means that a client from host 192.168.105.17 tries to connect from port 1712 to our listening Transparent TCP Listener with profile 5. Auto answering is disabled.
4		Indicates for a Transparent TCP Listener service, that a remote client which is allowed due to the used address filter (see option "addrfilter" for AT^SISS), was internally rejected, e.g. because the connect timeout has expired (see option "connecttimeout" for AT^SISS). The URC is not generated if the remote

10.14 Internet Service URC

client is rejected because its IP address is not matching the address filters.
If `<urcCause>` equals "4", then `<urcInfoId>` always equals "0".
This cause is also used if UE is not in Transparent Mode and a connected client has closed the connection remotely.

- 5 Only for TCP Listeners, Non-Transparent UDP Endpoint.
Indicates that the service is ready.

`<urcInfoId>`^(num)

Information identifier related to `<urcCause>`. See tables below for further detail. The `<urcInfoId>` number ranges indicate the type of information element:

0: Service is working properly.

1 - 2000: Error, service is aborted and enters `<srvState>=6` (Down). Value 1000 notifies that service profile contains invalid parameter(s).

2001 - 4000: Information related to progress of service.

4001 - 6000: Warning, but no service abort.

6001 - 8000: Notes

Additional information for Socket service: As stated above, if a Socket connection request from a remote client is received (see `<urcCause>=1`) the `<urcInfoId>` equals the `<srvProfileId>` of the dynamically assigned free service profile.

If `<urcCause>` is 3, `<urcInfoId>` is used as auto answer indicator. If the value is 0, auto answering is disabled, if the value is 1, auto answering is enabled.

`<urcInfoText>`^(str)

Information text related to `<urcCause>`. See tables below for further detail. The maximum length of an information text is 255 bytes. Any longer messages will be truncated.

If `<urcCause>` is 3, `<urcInfoText>` is used to indicate the IP address and port of the connecting client, e.g. "192.168.105.17:1712".

10.14.1 Information Elements Related to the Service Application

The following table lists the information elements which may be returned by all supported services within the "`^SIS`" URC and the command response of `AT^SISE`. It should be noted that TCP/IP socket problems may occur in all Internet service connections (Socket, Transparent TCP or Transparent UDP, FTP, HTTP or SMTP).

<code><urcInfoId></code>	<code><urcInfoText></code>	Description
<i>Information Elements Returned by the TCP/IP socket</i>		
2	Invalid socket descriptor	Socket error
3	Bad address specified	Socket error
4	Invalid operation	Socket error
5	No free socket descriptors	Socket error
6	The operation would block	Socket error
7	A previous attempt at this operation is still ongoing	Socket error
8	Socket is not bound	Socket error
9	The supplied buffer is too small / large	Socket error
10	Flags not supported	Socket error
11	Operation not supported	Socket error
12	The address is already in use	Socket error
13	The network is unavailable	Socket error
14	An established connection was aborted (transmission time-out or protocol error)	Socket error

<urcInfoId>	<urcInfoText>	Description
15	Remote host has reset the connection	Socket error
16	No buffer space available	Socket error
17	The socket is already connected	Socket error
18	For TCP/IP sockets, the socket is not connected	Socket error
19	Socket has been shut down	Socket error
20	Connection timed out	Socket error
21	Remote host has rejected the connection	Socket error
22	Remote host is unreachable	Socket error
23	An unexpected error occurred	Socket error
24	Host not found	DNS error
25	An error occurred that may be transient; a further attempt may succeed.	DNS error
26	An unrecoverable error occurred	DNS error
<i>General Information Elements</i>		
46	Fatal: The service has detected an unknown error	
47	*)	Indicates that the remote service has closed the connection. The host shall close the service.
48	Remote peer has closed the connection	Remote peer has closed the connection unexpectedly, and no data are available. The host shall close the service. Note that the "^SIS" URC only indicates the <urcInfoId>, but the AT^SISE command indicates both the <urcInfoId> and the <urcInfoText>.
49	Fatal: No memory is available for service action	
50	Fatal: Service has detected an internal error	
51	Application Task ID is not registered	
52	Fatal: Entity not supported	
53	No free Entity available	
54	Index not supported	
55	Service is not writeable	
56	Syntax error in URL	
57	Configuration Error	
58	No more data available	
59	Peek operation rejected	
60	Service don't accept further data	
61	Fatal: Service has no socket connection	
62	Unknown internal TLS error	SSL error
63	Wrong format of certificate data	SSL error
64	Certificate validity period is in future	SSL error
65	Certificate validity period expired	SSL error

<urcInfoId>	<urcInfoText>	Description
66	Peer certificate is not confirmed	SSL error
67	Wrong signature key format	SSL error
68	Unsupported signature key type	SSL error
69	Wrong protocol data format	SSL error
70	Wrong protocol data format	SSL error
71	No memory available for TLS	SSL error
72	Buffer error in TLS	SSL error
73	Wrong input data for RSA operation	SSL error
74	TLS/SSL protocol error	SSL error
75	Internal error in TLS	SSL error
76	Certificate format error	SSL error
77	The certificate does not exist	SSL error
78	Unknown TLS error code!	SSL error
80		Connection profile not defined.
84	PPP LCP FAILED	PPP error
85	PAP Authentication failed	PPP error
86	CHAP Authentication failed	PPP error
87	IPCP failed	PPP error
89	PDP: can not obtain controlling task	
90	PDP: internal error 1	
91	PDP: internal error 2	
92	PDP: no authentication req	
93	PDP: internal error 3	
94	PDP: connection failed	
95	PDP: internal error 4	
96	PDP: no IP assigned	
97	PDP: no network	
98	PDP: network is not up	
99	PDP: internal error 5	
119	PDP: no DNS received	
120	DNS: no data	
121	DNS: timeout	
122	DNS: connection refused	
123	DNS: terminated lookup	
124	DNS: domain name is too long	
125	DNS: invalid server	
126	DNS: undefined error	
<i>General Information Elements</i>		

<urcInfoId>	<urcInfoText>	Description
1000	PARA-ERR: <Info>	Notifies that service profile contains a wrong parameter. <Info> text indicates the service profile parameter that contains an error.
6001		General progress information for connection setup.

) Text varies depending on scenario.

10.14.2 Information Elements Related to FTP Service

<urcInfoId>	<urcInfoText>	Description
2100	<info>	<info> text depends on FTP server implementation

10.14.3 Information Elements Related to HTTP Service

<urcInfoId>	<urcInfoText>	Description
<i>Error URCs</i>		
200	HTTP-ERR: Not connected - cannot send request HTTP-ERR: failed on sending request	
201	<HTTP Response Str>	Client error
202	<HTTP Response Str> HTTP-ERR: Service unavailable	Server error
203	HTTP-ERR: Redirect failed - too many redirects HTTP-ERR: Redirect failed - not allowed HTTP-ERR: Redirect failed - location missing	Max. number of allowed redirects: 6
204	HTTP-ERR: auth failed - user name or password missing HTTP-ERR: auth failed - user name or password wrong HTTP-ERR: Authority required for this URL HTTP-ERR: No access to this URL allowed	
<i>Info URCs</i>		
2200	HTTP Redirect to: <Host>:<Port> <Path>	
2201	HTTP Response <Response code> Example: ^SIS: 2,3,2201, "HTTP Response: HTTP/1.1 200 OK"	

10.14.4 Information Elements Related to SMTP Service

<urcInfoId>	<urcInfoText>	Description
<i>Errors</i>		
400	***)	Indicates that the SMTP service could not be executed successfully.

<urcInfoId>	<urcInfoText>	Description
<i>Warnings</i>		
4400	***)	SMTP specific warning

***) Text varies depending on scenario.

10.15 Examples of how to Configure and Use Internet Service Profiles

Below you can find selective examples of how to configure and use Internet service profiles. To visualize the difference between URC mode and polling mode the operation of services (after opening with `AT^SISO`) is explained in separate examples for either mode.

10.15.1 Selecting URC Mode or Polling Mode

To enable or disable the presentation of URCs for the Internet services use the `AT^SCFG` command, type "TcpIp/WithURCs" and select "on" or "off" for parameter `<tcpWithUrc>`.

<code>at^scfg=tcp/withurcs</code>	Query the current setting.
<code>^SCFG: "Tcp/WithURCs", "on"</code>	URC mode is enabled (delivery default).
OK	
<code>at^scfg=tcp/withurcs,off</code>	Select polling mode (by switching off URC mode).
<code>^SCFG: "Tcp/WithURCs", "off"</code>	Polling mode is accepted.
OK	

10.15.2 Configuring an Internet Connection Profile

<code>AT+COPS?</code>	Checking network registration.
<code>+COPS: 0,0,"E-Plus",0</code>	ME is registered to German provider E-Plus.
OK	
<code>AT+CGATT=1</code>	Attaching to GPRS network (optional).
OK	
<code>AT+CGDCONT=1,"IP","internet.eplus.de"</code>	Specifying PDP context 1 with APN for E-Plus.
OK	
<code>AT^SICS=1,"dns1","198.023.097.002"</code>	Specifying primary DNS address (optional).
OK	
<code>AT^SICS=1,"dns2","212.023.097.003"</code>	Specifying secondary DNS address (optional).
OK	
<code>AT^SICA=1,1</code>	Activating PDP context 1.
OK	
<code>AT+CGPADDR=1</code>	Requesting dynamic IP address assigned to local client for context 1.
<code>+CGPADDR: 1,"10.129.137.217"</code>	Response returns currently assigned IP address.
OK	

10.15.3 Configuring Non-Transparent Listener

Keep in mind that if the host is configured as Non-Transparent Listener another service profile must be left free to be dynamically assigned as Server when the Non-Transparent Listener receives a connection request from a remote client.

Configure the service profile 4 for use as Non-Transparent Listener:

<code>AT^SISS=4, srvType, "Socket"</code>	Select service type Socket.
OK	
<code>AT^SISS=4, conId, "1"</code>	Select connection profile.
OK	

10.15 Examples of how to Configure and Use Internet Service Profiles

```
AT^SISS=4,address,"socktcp://lis-
tener:65534"
```

The host specifies its local port 65534 to be used for the Socket listener service. The local IP address will be dynamically assigned when the service is opened with [AT^SISO](#).

```
OK
```

Open the Listener service and query the IP address dynamically assigned to the Listener:

```
AT^SISO=4
```

Open the Listener service.

```
OK
```

```
AT^SISO?
```

Query the current status of services. All service profiles are unused, except for service profile 4 which is running in listener mode, where `<srvState>=3` (listening) and `<socketState>=3` (LISTENER). The response also indicates the IP address dynamically assigned to the listener.

```
^SISO: 0,""
```

```
^SISO: 1,""
```

```
^SISO: 2,""
```

```
^SISO: 3,""
```

```
^SISO: 4,"Socket",3,3,0,0,"10.10.0.187:65534","0.0.0.0"
```

```
^SISO: 6,""
```

```
^SISO: 7,""
```

```
^SISO: 8,""
```

```
^SISO: 9,""
```

```
OK
```

10.15.4 Configuring TCP Client for Calling a TCP Listener

Configure the client's service profile for calling a TCP Listener on another host:

```
AT^SISS=1,svrType,"Socket"
```

Select service type Socket.

```
OK
```

```
AT^SISS=1,conId,"1"
```

Select connection profile.

```
OK
```

```
AT^SISS=1,address,"socktcp://
10.10.0.187:65534"
```

Add the IP address and the TCP port of the remote host (from example in Section [10.15.3, Configuring Non-Transparent Listener](#)).

```
OK
```

10.15.5 Transparent TCP Listener: Accepting / Rejecting Incoming Remote Client

Host 1: Configure Transparent TCP Listener with Autoconnect disabled:

```
AT^SISS=1,"svrType","Socket"
```

Select service type Socket.

```
OK
```

```
AT^SISS=1,conId,"1"
```

Select connection profile.

```
OK
```

```
AT^SISS=1,"address","socktcp://lis-
tener:2000;etx=26;autoconnect=0"
```

"etx" configures Transparent mode. Autoconnect disabled.

```
OK
```

```
AT^SISS=1,"tcpMR","3"
```

```
OK
```

```
AT^SISS=1,"tcpOT","5555"
```

```
OK
```

Host 1: Open Transparent TCP Listener and query IP address dynamically assigned to Listener:

10.15 Examples of how to Configure and Use Internet Service Profiles

```

AT^SISO=1
OK
^SIS: 1,5           Listener ready, listening (value 5).
AT^SISO=1,1       Query status of profile 1.
^SISO:           Profile is running in listener mode, where
1,"Socket",4,3,0,0,"10.10.0.187:65534","0.0
.0.0:0"          <srvState>=4 (listening) and <socketState>=3
                 (LISTENER). Dynamic IP address is shown.

OK

```

Host 2: Configure TCP Client:

```

AT^SISS=0,srvType,"Socket"   Select service type Socket.
OK
AT^SISS=0,conId,"1"         Select connection profile.
OK
AT^SISS=0,"address","socktcp://
10.10.0.187:65534"          Set Listener's IP address.
OK
AT^SISS=0,"tcpMR","3"
OK
AT^SISS=0,"tcpOT","5555"
OK

```

Host 2: Start TCP Client

```

AT^SISO=0
OK
^SISW: 0,1           URC indicates that sending data is possible.

```

Host 1: Listener rejects incoming connection request from host 2:

```

^SIS: 1,3,0,"10.66.90.165:46723" URC indicates incoming connection request.
AT^SISH=1           Listener rejects connection request.
OK
AT^SISO=1,1       Query status of profile 1.
1,"Socket",4,3,0,0,"10.10.0.187:65534","0.0
.0.0:0"          Listener is listening again.
OK

```

Host 1: Listener accepts incoming connection request from host 2:

```

^SIS: 1,3,0,"10.66.90.165:46723" URC indicates incoming connection request.
AT^SISO=1         Listener accepts connection request, profile
                 changes to Server mode.
OK
^SISW: 1,1       URC indicates that data transmission is possible.
AT^SISO=1,1     Query status of profile 1.
1,"Socket",8,4,0,0,"10.10.0.187:65534","10.
66.90.165:46723",0 Service connected (value 8) and in Server mode /
                 value 4).
OK
AT^SIST=0       Change to transparent access mode.
CONNECT        Service enters transparent access mode.
Hello ....     For further handling see examples below, e.g. Sec-
                 tion 10.15.11, Opening and Closing Transparent TCP Service, Section 10.15.12, Transparent TCP Client Receives Data While in AT Command Mode

```

10.15.6 Transparent TCP Listener: Autoanswering Incoming Remote Client

Host 1: Configure Transparent TCP Listener with Autoconnect enabled.

```
AT^SISS=1,"srvType","Socket"           Select service type Socket.
OK
AT^SISS=1,conId,"1"                     Select connection profile.
OK
AT^SISS=1,"address","socktcp://lis-    "etx" configures Transparent mode. Autoconnect
tener:2000;etx=26;autoconnect=1"       enabled.
OK
AT^SISS=1,"tcpMR","3"
OK
AT^SISS=1,"tcpOT","5555"
OK
```

Host 1: Open Transparent TCP Listener and query IP address dynamically assigned to Listener:

```
AT^SISO=1
OK
^SIS: 1,5                               Listener ready, listening (value 5).
AT^SISO=1,1                             Query status of Listener profile.
^SISO:                                   Listener ready, listening (value 4). Dynamic IP
1,"Socket",4,3,0,0,"10.10.0.187:2000", address is shown.
"0.0:0"
OK
^SISW: 1,1
```

Host 2: Configure TCP Client.

```
AT^SISS=0,srvType,"Socket"             Select service type Socket.
OK
AT^SISS=0,conId,"1"                     Select connection profile.
OK
AT^SISS=0,"address","socktcp://        Set Listener's IP address.
10.10.0.187:2000"
OK
AT^SISS=0,"tcpMR","3"
OK
AT^SISS=0,"tcpOT","5555"
OK
```

Host 2: Start TCP Client

```
AT^SISO=0
OK
^SISW: 0,1
```

Host 1: Transparent TCP Listener automatically accepts connection request from host 2:

```
^SIS: 1,3,1,"10.66.90.165:46723"      URC indicates incoming connection request.
CONNECT                                  Service autoconnects to client and enters Transpar-
                                          ent Mode.
Hello ....                               For further handling see examples below, e.g. Sec-
                                          tion 10.15.11, Opening and Closing Transparent TCP Service, Section 10.15.12, Transparent TCP Client Receives Data While in AT Command Mode
                                          Type +++ to return to AT command mode (+++ not
                                          visible in example).
OK
AT^SISO=1,1                             Query status of profile 1.
```

10.15 Examples of how to Configure and Use Internet Service Profiles

```

^SISO: Transparent TCP Listener connected to client (value
1, "Socket", 8, 4, 0, 0, "10.10.0.187:2000", "10.6 8) and in Server mode (value 4).
6.90.165:46723", 0
OK

```

10.15.7 Socket Client Sends Data via TCP Connection (Polling Mode)

The example uses service profile 0 configured for Socket service and TCP.

```

AT^SISO=0 The host opens service profile 0.
OK Note: URC ^SISW:0,1 does not appear! The host
must poll the service state by means of AT^SISI until
the service is in <srvState> "Up".

AT^SISI=0 The service is still in <srvState> "Connecting".
^SISI: 0,3,0,0,0,0
OK
AT^SISI=0 The service is now in <srvState> "Up" and is
^SISI: 0,4,0,0,0,0 ready to accept data.
OK
AT^SISW=0,10 The host requests to write 10 bytes.
^SISW: 0,10,10 Response that 10 bytes can be sent and are unac-
knowledged.

0123456789
OK
AT^SISW=0,10,1 The host requests to write next 10 bytes and enables
^SISW: 0,0,10 the <eodFlag>.
But the service refuses the request, even the end-of-
data flag remains without effect.

OK
AT^SISW=0,10,1 Next try (polling).
^SISW: 0,10,20 Response that the service accepts 10 bytes and this
data and the previously sent data are unacknowl-
edged.

0123456789
OK
AT^SISW=0,0,0 Polling to request unacknowledged data.
^SISW: 0,0,10 There are 10 bytes still unacknowledged.
OK
AT^SISI=0 Polling for <srvState> change ("Closing" ->
^SISI: 0,5,0,20,10,10 "Down").
20 bytes are transfered via serial interface, 10 bytes
are acknowledged by remote peer, 10 bytes are on
the way.

OK
AT^SISI=0 Polling for <srvState> change ("Closing" ->
^SISI: 0,6,0,20,20,0 "Down").
The Service is in state "Down" and all data is con-
firmed by the remote peer.

OK
AT^SISC=0 Closing the Socket service.
OK

```

10.15.8 Socket Client Sends Data via TCP Connection with URCS

The example uses service profile 0 configured for Socket service and TCP.

10.15 Examples of how to Configure and Use Internet Service Profiles

AT^SISO=0	The host opens service profile 0.
OK	
^SISW: 0,1	Socket service is ready for upload.
AT^SISW=0,10	The host requests to write 10 bytes.
^SISW: 0,10,10	Response that 10 bytes can be sent and are unacknowledged.
0123456789	
OK	
^SISW: 0,1	The URC indicates that the Socket service is ready to transfer more data. Data of the last AT^SISW command are transferred to the remote host.
AT^SISW=0,10,1	The host requests to write next 10 bytes and enables the <eodFlag> to notify that these are the last 10 bytes of the session.
^SISW: 0,10,20	Response that the service accepts 10 bytes and this data and the previously sent data are unacknowledged.
0123456789	
OK	
-----	Waiting for URC.
^SISW: 0,2	Data transfer has been finished.
AT^SISC=0	Closing the Socket service.
OK	

10.15.9 UDP Scenario

The following example shows a communication between a UDP endpoint (host 1) and a UDP client (host 2). Part 1 of the example refers to the UDP endpoint and shows the configuration which allows the UDP endpoint to communicate with any UDP client. Part 2 shows the settings of a UDP client. Part 3 and 4 are running in parallel: Part 3 shows the procedures on the UDP endpoint side done when communicating with a UDP client. Part 4 shows the equivalent steps done by the UDP client when communicating with the UDP endpoint.

Part 1 - host 1 is configured for use as UDP endpoint:

AT^SISS=0, srvttype, socket	Select service type Socket.
OK	
AT^SISS=0, conid, 1	Select connection profile 1.
OK	
AT^SISS=0, alphabet, 1	Choose ASCII alphabet.
OK	
AT^SISS=0, address, "sockudp://:6666"	Specify the local UDP port.
OK	

Part 2 - host 2 is configured for use as UDP client:

AT^SISS=1, srvttype, socket	Select service type Socket.
OK	
AT^SISS=1, conid, 1	Select connection profile 1.
OK	
AT^SISS=1, alphabet, 1	Choose ASCII alphabet.
OK	
AT^SISS=1, address, "sockudp://10.10.0.219:6666"	Specify the address of host 1.
OK	

10.15 Examples of how to Configure and Use Internet Service Profiles

Part 3 - host 1 opens the service and communicates with host 2:

AT^SISO=0	Open the service.
OK	
^SIS: 0,5	URC indicates that host 1 is waiting (on UDP port 6666).
AT^SISO=0,1	
^SISO:	Request connection status.
0,"Socket",4,3,0,0,"10.10.0.219:6666","0.0.0.0:0"	
OK	
^SISR: 0,1	URC indicates that host 2 has opened the connection to host 1 and has sent some data.
AT^SISR=0,100	Host 1 requests to read 100 bytes.
OK	
^SISR: 0,22,"10.10.0.222:6561"	Host 1 is reading the text string received from host 2 (see part 4 of the example) and gets information about the remote client, i.e. the address of host 2.
Hello, I'm the client!	
OK	
AT^SISW=0,25,0,"10.10.0.222:6561"	Host 1 starts sending 25 bytes to host 2.
^SISW: 0,25,0	Host 1 is sending the message "Hi, I'm the UDP endpoint!" (25 bytes) to host 2. As a result, host 2 is receiving the URC "^SISR: 1,1" shown below in part 4 of the example.
OK	
^SISW: 0,1	URC confirms that host 1 can send data again.
AT^SISC=0	Close the service.
OK	

Part 4 - host 2 opens the service and communicates with host 1:

AT^SISO=1	Open the service.
OK	
^SISW: 1,1	URC indicates that host 2 can send data.
AT^SISO=1,1	
^SISO:	Request connection status.
1,"Socket",4,2,0,0,"10.10.0.222:6561","10.10.0.219:6666"	
OK	
AT^SISW=1,22	Host 2 starts to write 22 bytes.
^SISW: 1,22,0	Host 2 is writing the message "Hello, I'm the client!" (22 bytes). As a result, host 1 is receiving the URC "^SISR: 0,1" shown above in part 3 of this example.
OK	
^SISW: 1,1	URC confirms that host 2 could send data.
^SISR: 1,1	URC indicates that host 2 has received data from host 1.
AT^SISR=1,100	Host 2 requests to read 100 bytes.
^SISR: 1,25	Response indicates that host 2 has received 25 characters from host 1.
Hi, I'm the UDP endpoint!	
OK	
AT^SISC=1	Close the service.
OK	

10.15 Examples of how to Configure and Use Internet Service Profiles

10.15.10 Creating Transparent TCP Socket Client

AT^SISS=1, srvType, "Socket"	Select service type "Socket".
OK	
AT^SISS=1, conId, 1	Select connection profile 1.
OK	
AT^SISS=1, address, "socktcp:// 10.10.0.110:9996;etx;timer=200"	Specify server address. Add "etx" parameter to set Transparent mode.
OK	

10.15.11 Opening and Closing Transparent TCP Service

AT^SISO=1	Open Transparent TCP service.
OK	
^SISW: 1,1	URC indicates that Transparent TCP service is ready.
at^sist=1	Open transparent access mode.
CONNECT	Service is ready to send or receive data. Client is sending data, e.g Good Morning (not visible in example).
	Client types +++ to return to AT command mode (+++ not visible in example).
OK	
at^sisi=1	Check the service state of service profile 1.
^SISI: 1,4,0,16,16,0	Service is in state "Up" (4). 0 bytes received, 16 bytes sent and acknowledged.
OK	
AT^SISO?	Check the service state of service profile 1.
^SISO: 0, ""	
^SISO:	Service is in state "Up" (4). Socket is assigned. 0 bytes received, 16 bytes sent. Local and remote IP address are assigned.
1, "Socket", 4, 2, 0, 16, "10.10.0.200:1024", "10. 10.0.108:65532"	
^SISO: 2, ""	
^SISO: 3, ""	
^SISO: 4, ""	
^SISO: 5, ""	
^SISO: 6, ""	
^SISO: 7, ""	
^SISO: 8, ""	
^SISO: 9, ""	
OK	
AT^SISC=1	Close the service.
OK	
at^sisi=1	Check the service state of service profile 1.
^SISI: 1,2,0,0,0,0	Service profile 1 is in state "Allocated" (2).
OK	
AT^SISO?	Check the service state of service profile 1.
^SISO: 0, ""	
^SISO:	Service is in state "Allocated" (2). Socket not assigned.
1, "Socket", 2, 1, 0, 0, "0.0.0.0:0", "0.0.0.0:0"	
^SISO: 2, ""	
^SISO: 3, ""	
^SISO: 4, ""	
^SISO: 5, ""	
^SISO: 6, ""	

10.15 Examples of how to Configure and Use Internet Service Profiles

```

^SISO: 7, ""
^SISO: 8, ""
^SISO: 9, ""
OK

```

10.15.12 Transparent TCP Client Receives Data While in AT Command Mode

AT^SISO=1	Open Transparent TCP service.
OK	
^SISW: 1,1	URC indicates that Transparent TCP service is ready.
at^sist=1	Open transparent access mode.
CONNECT	Service is ready to send or receive data.
Hello	Client is reading received data.
	Client types +++ to return to AT command mode (+++ not visible in example).
OK	
^SISR: 1,1	URC indicates that new data is available for the client.
at^sist=1	Return to transparent access mode.
CONNECT	Service is ready to send or receive data.
Goodbye	Client is reading received data.
	Client types +++ to return to AT command mode (not visible in example).
OK	
at^sisi=1	Check the service state of service profile 1.
^SISI: 1,4,12,6,6,0	Service is in state "Up" (4). 12 bytes received, 6 bytes sent and acknowledged.
OK	
AT^SISO?	Check the service state of service profile 1.
^SISO: 0, ""	
^SISO:	Service is in state "Up" (4). Socket is assigned. 12 bytes received, 6 bytes sent. Local and remote IP address are assigned.
1, "Socket", 4, 2, 12, 6, "10.10.0.200:1025", "10.10.0.108:65532"	
^SISO: 2, ""	
^SISO: 3, ""	
^SISO: 4, ""	
^SISO: 5, ""	
^SISO: 6, ""	
^SISO: 7, ""	
^SISO: 8, ""	
^SISO: 9, ""	
OK	
AT^SISC=1	Close the service.
OK	
at^sisi=1	Check the service state of service profile 1.
^SISI: 1,2,0,0,0,0	Service profile 1 is in state "Allocated" (2).
OK	
AT^SISO?	Check the service state of service profile 1.
^SISO: 0, ""	
^SISO:	Service is in state "Allocated" (2). Socket not assigned.
1, "Socket", 2, 1, 0, 0, "0.0.0.0:0", "0.0.0.0:0"	
^SISO: 2, ""	
^SISO: 3, ""	

10.15 Examples of how to Configure and Use Internet Service Profiles

```

^SISO: 4, ""
^SISO: 5, ""
^SISO: 6, ""
^SISO: 7, ""
^SISO: 8, ""
^SISO: 9, ""
OK

```

10.15.13 Remote Server Disconnects While Transparent TCP Service is in Transparent Access Mode

AT^SISO=1	Open Transparent TCP service.
OK	
^SISW: 1,1	URC indicates that Transparent TCP service is ready.
at^sist=1	Open transparent access mode.
CONNECT	Service is ready to send or receive data.
Good Morning	Remote server has sent data and disconnected. Client reads data. Then client gets NO CARRIER in AT command mode.
NO CARRIER	
at^sisi=1	Check the service state of service profile 1.
^SISI: 1,6,12,0,0,0	Service is in state "Down" (6). 12 bytes received.
OK	
AT^SISO?	Check the service state of service profile 1.
^SISO: 0, ""	
^SISO:	Service is in state "Down" (6). Socket is assigned. 6 bytes received. 12 bytes sent. Local and remote IP address are assigned.
1, "Socket", 6, 2, 12, 0, "10.10.0.200:1026", "10.10.0.108:65532"	
^SISO: 2, ""	
^SISO: 3, ""	
^SISO: 4, ""	
^SISO: 5, ""	
^SISO: 6, ""	
^SISO: 7, ""	
^SISO: 8, ""	
^SISO: 9, ""	
OK	
AT^SISC=1	Close the service.
OK	
at^sisi=1	Check the service state of service profile 1.
^SISI: 1,2,0,0,0,0	Service profile 1 is in state "Allocated" (2).
OK	

10.15.14 Server Disconnects While Transparent TCP Service is in AT Command Mode and Data is Pending

AT^SISO=1	Open Transparent TCP service.
OK	
^SISW: 1,1	URC indicates that Transparent TCP service is ready.
at^sist=1	Open transparent access mode.
CONNECT	Service is ready to send or receive data.
Good Morning	Client is reading data.

10.15 Examples of how to Configure and Use Internet Service Profiles

OK	Client types +++ to return to AT command mode (not visible in example).
^SISR: 1,1	Remote server has sent data and closed the connection (not visualized in this example). URC indicates that remaining data is available for reading.
at^sisi=1	Check service state of service profile 1.
OK	
^SISI: 1,4,12,3,3,0	Service profile 1 is in state "Up" (4). 12 bytes received. 3 bytes sent and acknowledged.
OK	
AT^SISO?	Check the service state of service profile 1.
^SISO: 0,""	
^SISO:	Service is in state "Up" (4). Socket is assigned. 12 bytes received. 3 bytes sent. Local and remote IP address are assigned.
1,"Socket",4,2,12,3,"10.10.0.200:1027","10.10.0.108:65532"	
^SISO: 2,""	
^SISO: 3,""	
^SISO: 4,""	
^SISO: 5,""	
^SISO: 6,""	
^SISO: 7,""	
^SISO: 8,""	
^SISO: 9,""	
OK	
at^sist=1	Return to transparent access mode.
CONNECT	Service is ready to send or receive data.
Good bye	Client reads remaining data. Then client gets NO CARRIER in AT command mode.
NO CARRIER	
at^sisi?	Check service state of service profile 1.
^SISI: 1,6,20,3,3,0	Service is in service "Down" state (6). 20 bytes received. 3 bytes sent and acknowledged.
OK	
AT^SISO?	Check the service state of service profile 1.
^SISO: 0,""	
^SISO:	Service is in state "Down" (6). Socket is assigned. 20 bytes received. 3 bytes sent. Local and remote IP address are assigned.
1,"Socket",20,3,"10.10.0.200:1027","10.10.0.108:65532"	
^SISO: 2,""	
^SISO: 3,""	
^SISO: 4,""	
^SISO: 5,""	
^SISO: 6,""	
^SISO: 7,""	
^SISO: 8,""	
^SISO: 9,""	
OK	
AT^SISC=1	Close the service.
OK	
at^sisi=1	Check service state of service profile 1.
^SISI: 1,2,0,0,0,0	Service profile 1 is in state "Allocated" (2).
OK	
AT^SISO?	Check the service state of service profile 1.
^SISO: 0,""	
^SISO:	Service is in state "Allocated" (2). Socket is not assigned. Local and remote IP address not assigned.
1,"Socket",2,1,0,0,"0.0.0.0:0","0.0.0.0:0"	
^SISO: 2,""	

10.15 Examples of how to Configure and Use Internet Service Profiles

```

^SISO: 3, ""
^SISO: 4, ""
^SISO: 5, ""
^SISO: 6, ""
^SISO: 7, ""
^SISO: 8, ""
^SISO: 9, ""
OK

```

10.15.15 FTP Upload Single File (URC Mode)

Configure the service profile 2 for FTP:

AT^SISS=2, "srvType", "Ftp"	Select service type FTP.
OK	
AT^SISS=2, conId, "1"	Select connection profile 1.
OK	
AT^SISS=2, "address", "ftp:// myname:mypasswd@testnetwork/upload"	Specify FTP address with individual user name and password.
OK	
AT^SISS=2, "cmd", "put"	Select command type upload for single file.
OK	
AT^SISS=2, "files", "newdata.txt"	File "newdata.txt" shall be put on FFTP server.
OK	

Make an FTP connection:

AT^SISO=2	Open the service.
OK	Bearer is established, service is getting started.
^SIS: 2,0,2100, "Ftp open(testnetwork:21)"	"^SIS" URC with <urcInfoId> 2100 (FTP) status information from FTP server.
^SIS: 2,0,2100, "220 FTP server (Version 6.4/OpenBSD/Linux-ftpd-0.17) ready."	
^SIS: 2,0,2100, "FTP Login OK"	
^SIS: 2,0,2100, "put newdata.txt"	
^SISW: 2,1	URC indicates that FTP service is ready for upload.
AT^SISW=2,40	Client requests to send 40 bytes.
^SISW: 2,40,0	The write command response confirms that 40 bytes must be transferred now.
01234567890123456789012345678901234567890	User data is transferred.
OK	
^SISW: 2,1	URC indicates that the FTP service is ready to transfer more data.
AT^SISW=2,40	Client requests to send 40 bytes.
^SISW: 2,40,0	The write command response confirms that 40 bytes must be transferred now.
01234567890123456789012345678901234567890	User data is transferred.
OK	
^SISW: 2,1	URC indicates that the FTP service is ready to transfer more data.
AT^SISW=2,0,1	No more data available. <eodFlag> set. File "newdata.txt" shall be closed on FTP server.
^SISW: 2,0,0	
OK	
^SIS: 2,0,2100, "226 Transfer complete."	
^SISW: 2,2	URC indicates that data transfer finished successfully. Connection to the FTP server closes.

10.15 Examples of how to Configure and Use Internet Service Profiles

AT^SISC=2	Close the FTP service.
OK	

10.15.16 HTTP Download Using TLS

Configure the service profile 4 for HTTPS:

AT^SISS=4, srvType, "Http"	Select service type HTTP.
OK	
AT^SISS=4, conId, "1"	Select connection profile 1.
OK	
AT^SISS=4, address, "https://www.facebook.com"	Specify access to Facebook website (always secured).
OK	
AT^SISS=4, cmd, "get"	Select command type download.
OK	

Opening connection:

AT^SISO=4	Open the service.
OK	
^SISS: 4,0,2200,"Http www.facebook.com:443"	
^SISR: 4,1	
	URC indicates that the HTTP service is ready to read data.
AT^SISR=4,1000	Read 1000 bytes.
^SISR: 4,1000	
<?xml version="1.0" encoding="utf-8"?> <!DOCTYPE html PUBLIC "-//WAPFORUM//DTD XHTML Mobile 1.0//EN" "http://www.wapforum.org	
OK	
AT^SISR=4,1000	Repeat reading data n times.
^SISR: 4,1000	
....	
^SISR: 4,2	
	URC indicates that data transfer finished successfully. Connection to the HTTP server closes.
AT^SISC=4	Close the HTTP service.
OK	

10.15.17 HTTP Post

Configure the service profile 6 for HTTP:

AT^SISS=6, srvType, "Http"	Select service type HTTP.
OK	
AT^SISS=6, conId, "1"	Select connection profile 1.
OK	
AT^SISS=6, "address", "http://testnetwork/cgi/first.pl"	Specify URL.
OK	
AT^SISS=6, "user", "myuser"	Specify user name.
OK	
AT^SISS=6, "passwd", "mypasswd"	Specify password.
OK	
AT^SISS=6, cmd, "post"	Select command type download.

10.15 Examples of how to Configure and Use Internet Service Profiles

```

OK
AT^SISS=6,"hcContent"," "      Parameter is ignored.
OK
AT^SISS=6,"hcContLen","2"     "hcContlen" greater than "0". Data wil be sent from
                                AT command interface.
OK

```

Opening connection:

```

AT^SISO=6                      Open the service.
OK
^SISS: 6,0,2200,"Http pegasus.testnetz.sw5:80"

^SISW: 6,1                    URC indicates that the HTTP service is ready to
                                send data.
AT^SISW=6,30                  Send 30 bytes.
^SISW: 6,30,0

OK
^SISW: 6,1                    URC indicates that the HTTP service is ready to
                                send data.
AT^SISW=6,30                  Send 30 bytes.
^SISW: 6,30,0

OK
^SISW: 6,1                    URC indicates that the HTTP service is ready to
                                send data.
AT^SISW=6,0,1                Finish input by setting <eodFlag> and start HTTP
                                POST request.
^SISW: 6,0,0

OK
^SISW: 6,2                    URC confirms: all data sent to server.
OK
^SIS: 6,0,2200,"HTTP POST: http://testnetwork/cgi/first.pl"

6,0,2200,"HTTP POST Response: 200"
^SISR: 6,1                    Read response from server.
^SISR: 6,500                  Read 500 bytes.
^SISR: 6,197                  Reading 197 bytes.
Hello ..... Goodbye
OK
^SISR: 6,1                    All data read.
AT^SISC=6                     Close the HTTP service.
OK

```

10.15.18 Ping

This example shows a Ping output. The example uses the Internet connection profile shown in Section [10.15.2](#).

```

AT^SISX=Ping,1,"74.125.39.99",5,5000
^SISX: "Ping",1,1,"74.125.39.99",1696
^SISX: "Ping",1,1,"74.125.39.99",175
^SISX: "Ping",1,1,"74.125.39.99",174
^SISX: "Ping",1,1,"74.125.39.99",174
^SISX: "Ping",1,1,"74.125.39.99",2111
^SISX: "Ping",2,1,5,5,0,0
^SISX: "Ping",3,1,174,2111,865
OK

```

10.15.19 Resolving DNS Host Name to IP Address

This example uses the Internet connection profile shown in Section [10.15.2](#).

```
AT^SISX=HostByName,1,"www.google.de"  
^SISX: "HostByName", "74.125.39.99"  
OK
```

11. Supplementary Service Commands

The AT commands described in this chapter are related to Supplementary Services.

11.1 ATD Dialing Supplementary Service Number

[ATD](#) can be used to send *# codes for Supplementary Services. The termination character ";" is mandatory.

Syntax

Exec Command

```
ATD<n>;
```

Response(s)

When sending *# sequences response is specific to *# sequence. For details see [Section 20.1, Star-Hash \(*#\) Network Commands](#)

OK

NO CARRIER

ERROR

PIN	MDM	APP	→	Last
±	+	±	-	-

Reference(s)

[ITU-T V.250 \[16\]](#)

Parameter Description

<n>^(text)

String of dialing digits and optional V.250 modifiers: 0-9, *, #, +, A, B, C, D

11.2 AT+CCFC Call forwarding number and conditions control

AT+CCFC controls the call forwarding supplementary service. Registration, erasure, activation, deactivation and status query are supported.

Syntax

<p>Test Command</p> <pre>AT+CCFC=?</pre> <p>Response(s)</p> <pre>+CCFC: (list/range of supported <reason>s) OK</pre>	<p>Write Command</p> <pre>AT+CCFC=<reason>, <mode>[, <number>, <type>][, <class>][, <sub-number>, <sub-type>][, <time>]</pre> <p>Response(s)</p> <pre>If <mode> is not equal 2 and command successful: OK If <mode>= 2, <reason> is not equal 2 and command successful: +CCFC: <status>, <class>[, <number>, <type>, <sub-number>, <sub-type>] OK If <mode>= 2, <reason>= 2 and command successful: +CCFC: <status>, <class>[, <number>, <type>, <sub-number>, <sub-type>, <time>] OK If error is related to UE functionality ERROR +CME ERROR: <err></pre>	<p>Reference(s)</p> <p>3GPP TS 27.007 [48], 3GPP TS 22.004 [26], 3GPP TS 22.082 [31], 3GPP TS 24.082</p>
--	---	--

Parameter Description

<reason> ^(num)	
Reason for call forwarding	
0	Unconditional
1	Mobile busy
2	No reply
3	Not reachable
4	All call forwarding (includes reasons 0, 1, 2 and 3)
5	All conditional call forwarding (includes reasons 1, 2 and 3)
<mode> ^(num)	
Network operation to be performed for Supplementary service "call forwarding"	
0	Disable call forwarding (disable service)
1	Enable call forwarding (enable service)
2	Query status of call forwarding (query service status)

- 3 Register <number> and activate call forwarding (register service)
- 4 Erase <number> and deactivate call forwarding (erase service)

<number>^(str)

String type phone number of forwarding address in format specified by <type>. If you select <mode>= 3, the phone <number> will be registered in the network. This allows you to disable / enable CF to the same destination without the need to enter the phone number once again. Depending on the services offered by the provider the registration may be mandatory before CF can be used. The number remains registered in the network until you register another number or erase it using <mode> = 4.

<type>^(num)

Type of address octet

- 145 Dialing string <number> includes international access code character '+'
- 129 Otherwise

<class>^(num)

Integer or sum of integers each representing a class of information, i.e. a bearer service, telecommunication service or bearer service group as defined in 3GPP TS 22.004 [26].

- 1 Voice
- 2 Data
 <class> 2 (data) comprises all those <class> values between 16 and 128, that are supported both by the network and the MS. This means, a setting made for <class> 2 applies to all remaining data classes (if supported). In addition, you can assign a different setting to a specific class. For example, you can activate call forwarding for all data classes, but deactivate it for a specific data class.
- 4 Fax (only for compatibility reasons, not supported by PLS8-X)
- 8 SMS
- 16 Data circuit sync
- 32 Data circuit async
- 64 Dedicated packet access
- 128 Dedicated PAD access
- 1...[7]...255 Combination of some of the above classes. For example, the default setting 7 represents the sum of the integers 1, 2 and 4 for voice, data and fax (fax only for compatibility reasons). If the <class> parameter is omitted, the default value 7 is used.

<sub-number>^(str)

String type phone number of sub address in format specified by <type>.

<sub-type>^(num)

Type of sub-address octet

- 145 International access code character '+'
- 129 Otherwise

<time>^(num)

- 5...[20]...30 Time to wait before call is forwarded, rounded to a multiple of 5 sec. (only for <reason>=no reply)

<status>^(num)

0	Call forwarding not active
1	Call forwarding active

Notes

- For some networks, the interrogation command will return the same result for each requested class.
- You can register, disable, enable and erase <reason> 4 and 5 as described above. However, querying the status of <reason> 4 and 5 with AT+CCFC will result in an error.
- Most networks will not permit registration of new parameters for conditional call forwarding (reasons 1,2,3,5) while unconditional call forwarding is enabled.
- The AT+CCFC command offers a broad range of call forwarding options according to the 3GPP Technical Specifications. However, when you attempt to set a call forwarding option which is not provisioned or not yet subscribed to, the setting will not take effect regardless of the response returned. The responses in these cases vary with the network (for example "OK", "Operation not allowed", "Operation not supported" etc.). To make sure check the call forwarding status with <mode>=2.
- Some networks may choose to have certain call forwarding conditions permanently enabled (e.g. forwarding to a mailbox if the mobile is not reachable). In this case, erasure or deactivation of call forwarding for these conditions will not be successful, even if the CCFC request is answered with response "OK".
- The command has been implemented with the full set of <class> parameters according to 3GPP TS 27.007 [48]. For actual applicability of SS "call forwarding" to a specific service or service group (a specific <class> value) please consult table A.1 of 3GPP TS 22.004 [26].
- There is currently no release of 3GPP TS 22.004 [26], in which the call forwarding supplementary service is defined as applicable to SMS services.
- As stated above <class> 2 is intended only to send the data classes 16/32/64/128 to the network. However, the responses returned when the subscriber sets or queries call forwarding refer only to the status of the data classes received from the network. This means that the responses will display only those data classes between 16 and 128 which are supported by the network and currently activated. There will be no output for class 2, nor for classes which are not supported or not set.
- The parameter <class> will not be sent to the network if <mode>=2. Therefore it may happen that the response of the query command contains information about classes which were not requested, or it shows only the inactive status of the class 1 or 255, This means that the status is valid for all classes. The response shows the status in the order of the network response.

Example

Please note that when you configure or query call forwarding without specifying any classes, the settings will refer to classes 1, 2 and 4 only (= default).

- To register the destination number for unconditional call forwarding (CFU):

```
at+ccfc=0,3,"+493012345678",145
OK
```

The destination number will be registered for above default classes.

In most networks, the registration will also cause call forwarding to be activated for these <class> values.

- To query the status of CFU without specifying <class>:

```
at+ccfc=0,2
+CCFC: 1,1,"+493012345678",145
+CCFC: 1,4,"+493012345678",145
OK
```

- To erase the registered CFU destination number:

```
at+ccfc=0,4
OK
```

Now, when you check the status, no destination number will be indicated:

```
at+ccfc=0,2
+CCFC: 0,1
+CCFC: 0,4
OK
```

- To query the status of CFU for all classes:

```
at+ccfc=0,2,,255
+CCFC: 0,255
OK
```

- **<reason>** 4 or 5 cannot be used to query the status of all call forwarding reasons (see also notes above):

```
at+ccfc=4,2
error
at+ccfc=5,2
error
```

11.3 AT+CUSD Unstructured Supplementary Service Data

AT+CUSD allows to control the handling of Unstructured Supplementary Service Data (USSD) according to 3GPP TS 22.090 [35]. Both network and mobile initiated operations are supported. The interaction of this command with other AT commands based on other supplementary services is described in the related technical specifications.

Parameter `<ussdMode>` is used to control the presentation of "+CUSD" URCs to the TE, which will be caused by a USSD response from the network or by different network or **USAT** initiated operations. Therefore, it is recommended to always have "+CUSD" URCs enabled.

If parameter `<ussdReq>` is given, a mobile initiated USSD send request or a USSD response to a network or **USAT** initiated operation is sent to the network. A possible response USSD of the network is again presented by a subsequent "+CUSD" URC.

Syntax

<p>Test Command</p> <p>AT+CUSD=?</p> <p>Response(s)</p> <p>+CUSD: (list of supported<ussdMode>s)</p> <p>OK</p>											
<p>Read Command</p> <p>AT+CUSD?</p> <p>Response(s)</p> <p>+CUSD: <ussdMode></p> <p>OK</p>											
<p>Write Command</p> <p>AT+CUSD=<ussdMode>[, <ussdReq>[, <ussdDCS>]]</p> <p>Response(s)</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>-</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	-	-	<p>Reference(s)</p> <p>3GPP TS 27.007 [48], 3GPP TS 22.090 [35], 3GPP TS 24.090</p>
PIN	MDM	APP	→	Last							
+	+	+	-	-							

Unsolicited Result Code

+CUSD: <ussdStatus> [, <ussdRsp> [, <ussdDCS>]]

"+CUSD" URC indicates a USSD response from the network, respectively caused by a network or **USAT** initiated operation.

Parameter Description

<code><ussdMode></code> ^(num)	
0(&F)	Disable "+CUSD" URC presentation.
1	Enable "+CUSD" URC presentation.
2	Cancel session (not applicable to read command response).

<ussdReq>^{(str)(+CSCS)}

Unstructured Supplementary Service Data (USSD) to be sent to the network.

If <ussdReq> parameter is not given, network is not interrogated. [AT+CUSD](#) write command only supports setting <ussdDCS>=15.

<ussdRsp>^{(str)(+CSCS)}

Unstructured Supplementary Service Data (USSD) received from the network.

If <ussdDCS> indicates that 3GPP TS 23.038 [36] GSM 7 bit default alphabet is used, the UE converts GSM alphabet into current TE character set according to rules of 3GPP TS 27.005 [47], Annex A. See also Section 1.7, [Supported character sets](#). However, in case of invalid or omitted <ussdDCS>, conversion of <ussdRsp> is not possible.

<ussdDCS>^(num)

3GPP TS 23.038 [36] Cell Broadcast Data Coding Scheme (default 15).

In case of an incoming USSD with invalid or omitted data coding scheme information <ussdDCS> will not be presented.

<ussdStatus>^(num)

0	No further user action required (network initiated USSD notification, or no further information needed after mobile initiated operation).
1	Further user action is required (network initiated USSD request, or further information is needed after mobile initiated operation). If <ussdStatus>=1 the user input needs to be sent via an additional AT+CUSD action <ESC>.
2	USSD exchange is terminated by network.
3	A (UE local) client has responded, i.e. the interface was not idle and a busy indication was sent to the network.
4	Operation not supported (e.g. wrong input value given).
5	Network timeout.

Note

- It is recommended to finalize or escape a pending USSD user interaction before further actions are done to prevent blocking situations.

12. Packet Domain Related Commands

12. Packet Domain Related Commands

The AT commands described in this chapter allow the Customer Application to control packet switched services in GSM/UMTS/LTE networks.

12.1 AT+CGDCONT Define PDP Context

AT+CGDCONT specifies the parameters for a PDP context identified by the context identifier `<cid>`. The number of contexts that may be in a defined state at the same time is given by the range returned by the **AT+CGDCONT** test command. A special form of the write command (**AT+CGDCONT=<cid>**) causes the values for context `<cid>` to become undefined. If context 1 is undefined on startup, it will be recreated automatically with `<PDP_type>` "IPV4V6" and all other parameters set to their defaults.

It is not allowed to undefine an already activated context.

The **AT+CGDCONT** read command returns the current settings for each defined PDP context.

PDP contexts can be associated with APN Classes configurable with **AT^SGAPN**. Please note that changing the PDP context definitions with **AT^SGAPN** will also affect the settings of **AT+CGDCONT**.

In Verizon Wireless networks PDP contexts with APN class 1, 2 and 4 are dedicated to specific profile settings for LTE (see **AT^SGAPN**), meaning that `<cid>` 1, 2 and 4 are not allowed to be used for DUN, WWAN (RmNet) or IP service connections. `<cid>` 3 is by default associated to APN class 3 and the "vzwinternet" APN. This APN is available for Internet connections set up either over Dial-up network (see **AT+CGACT**, **ATD*99#**), or WWAN (RmNet) adapter (see **AT^SWWAN**), or AT commands over IP (see **AT^SICA**). It is also used as default bearer for LTE. As long as the UE is attached and registered to LTE any attempt to deactivate the third PDP context (via **AT+CGACT=0,3**) will be denied with "+CME ERROR: operation not allowed". The detach command **AT+CGATT=0** is accepted but will cause the UE to deregister from LTE.

Syntax

Test Command

```
AT+CGDCONT=?
```

Response(s)

```
+CGDCONT: (range of supported <cid>s), "IP", , , (list of supported <d_comp>s), (list of supported
<h_comp>s)
+CGDCONT: (range of supported <cid>s), "PPP", , , (list of supported <d_comp>s), (list of supported
<h_comp>s)
+CGDCONT: (range of supported <cid>s), "IPV6", , , (list of supported <d_comp>s), (list of supported
<h_comp>s)
+CGDCONT: (range of supported <cid>s), "IPV4V6", , , (list of supported <d_comp>s), (list of supported
<h_comp>s)
OK
ERROR
+CME ERROR: <err>
```

Read Command

```
AT+CGDCONT?
```

Response(s)

```
+CGDCONT: [<cid>, <PDP_type>, <APN>, <PDP_addr>, <d_comp>, <h_comp>]
[+CGDCONT: <cid>, <PDP_type>, <APN>, <PDP_addr>, <d_comp>, <h_comp>]
[+CGDCONT: ...]
OK
ERROR
+CME ERROR: <err>
```

Write Command

AT+CGDCONT=<cid>[, <PDP_type>[, <APN>[, <PDP_addr>[, <d_comp>[, <h_comp>]]]]

Response(s)

OK
ERROR
+CME ERROR: <err>

PIN	MDM	APP	→	Last
-	+	+	+	-

Reference(s)

3GPP TS 27.007,
3GPP TS 23.003,
3GPP TS 24.301,
3GPP TS 25.323,
3GPP TS 44.065

Parameter Description

<cid>^{(num)(NV)}

PDP Context Identifier

Parameter specifies a particular PDP context definition. This parameter is used in other PDP context-related commands.

1...16

<PDP_type>^{(str)(NV)}

Packet Data Protocol type

Specifies the type of the packet data protocol.

Changing the PDP type with [AT+CGDCONT](#) will also change the [AT^SGAPN](#) value.

- “IP“ Internet Protocol (IETF STD 5)
Applicable to dialup connections, WWAN interface, embedded TCP/IP stack
- “PPP“ Point to Point Protocol (IETF STD 51)
Intended only for dialup connections (e.g. [ATD*99#](#))
- “IPV6“ Internet Protocol, version 6 (see RFC 2460)
- “IPV4V6“ Virtual <PDP_type> introduced to handle dual IP stack UE capability. (See 3GPP TS 24.301).
Not applicable to PPP (dialup) connections).

<APN>^{(str)(NV)}

Access Point Name

Logical name used to select the GGSN or the external packet data network. Maximum length: 100 characters. An Access Point Name has to follow the syntax rules specified in 3GPP TS 23.003 in section 9.1.

If the value is null or omitted, then the subscription value will be requested.

Changing the APN with [AT+CGDCONT](#) will also change the [AT^SGAPN](#) value.

<PDP_addr>^{(str)(NV)}

Packet Data Protocol address

Identifies the MT in the address space applicable to PDP (e.g. IPv4 address for PDP type IP). If the value is null or omitted, then a value may be provided by the TE during the PDP startup procedure or, failing that, a dynamic address will be requested. The read command will continue to return the null string even if an address has been allocated during the PDP startup procedure. A string consisting of the values 0.0.0.0 has the same meaning as a null string. The allocated address may be read using [AT+CGPADDR](#).

<d_comp>^{(num)(NV)}

Data Compression

Controls the PDP data compression (applicable for Subnetwork Dependent Convergence Protocol (SNDCP) only); see 3GPP TS 44.065 and GPP TS 23.003 for details.

[0]	off
1	on
2	V.42bis

<h_comp>^{(num)(NV)}

Header Compression

Controls the PDP header compression; see 3GPP TS 44.065 and 3GPP TS 25.323 for details.

[0]	off
1	on
2	RFC1144
3	RFC2507
4	RFC3095

12.1.1 Attaching to LTE Networks

The following considerations are only valid if the UE is not configured for Verizon Wireless Network (see [AT^SCFG](#) subcommand "MEopMode/Prov/Cfg parameter <provCfg>):

To allow access to the PS domain, the UE has to perform the attach and context activation procedure. For context activation, the access point name (APN) specifies the packet data network to which the context will be established.

In contrast to 2G (GSM) and 3G (UMTS) where attach and context activation are performed separately, the LTE attach procedure always includes the automatic activation of one context (either using the default bearer or the APN specified for <cid> 1). This means, you have two methods to trigger an LTE attach:

- auto attach procedure if [AT^SCFG](#) subcommand "GPRS/AutoAttach" is set to "enabled"
- manual attach procedure by using [AT+CGATT](#).

Please consider that one of the two methods shall be employed, otherwise the UE never attaches to LTE. A successful LTE attach is prerequisite for activating a WWAN connection in an LTE network (see with [AT^SWWAN](#) command).

As long as the UE is attached and registered to LTE any attempt to deactivate the first PDP context (via [AT+CGACT=0,1](#)) will be denied with "+CME ERROR: operation not allowed". The detach command [AT+CGATT=0](#) is accepted but will cause the UE to deregister from LTE.

When PS Domain auto attach is enabled and the UE automatically tries to attach to LTE after the SIM PIN1 is unlocked, the application shall ensure that the correct APN is specified *before* the UE attaches to LTE.

LTE attach with no APN

If no APN is specified for <cid> 1 when the UE attaches to LTE, the network will automatically select the so called default APN, specified in the HSS, to establish the initial context (PDN connection/default bearer). Although the LTE attach procedure will be successful in that case, the context for the default APN might be configured with restrictions concerning the transmission of data, depending on the operator settings.

LTE attach with wrong APN

If a wrong APN is configured for <cid> 1 during the LTE attach procedure, e.g. if an application allows the user to change SIM cards and the APN was not set correctly after the SIM change, the LTE attach will be rejected by the network. As result, the RAT type LTE will be disabled by the UE for a limited amount of time and the UE will only use 2G and 3G RAT types for PS access. The duration while RAT type LTE is disabled depends on network

configuration (timer T3402, default 12 minutes).

Recommendations for LTE attach

When using LTE auto attach, the application shall ensure that the correct APN is specified for <cid> 1 before the UE attaches to LTE. To do so, use the command `AT+CGDCONT=1,<PDP_type>,<APN>`.

If the application cannot ensure that the correct APN is configured for <cid> 1 before the UE attempts to attach to LTE, the application shall set the correct APN with `AT+CGDCONT`, and then employ one of the following command sequences:

- `AT+COPS=2` and `AT+COPS=0` to deregister from the network and force a new network registration, thus enabling a new LTE auto attach attempt. If running, the T3402 timer will be stopped by `AT+COPS=0`.
- `AT+CGATT=0` and `AT+CGATT=1` to manually trigger a detach and re-attach attempt. If running, the T3402 timer will be stopped by `AT+CGATT=0`.
- `AT+CFUN=1,1` to restart the UE (since the `AT+CGDCONT` setting is non-volatile).

12.2 AT+CGATT PS Attach or Detach

The [AT+CGATT](#) write command is used to attach the MT to, or detach the MT from, the Packet Domain service. After the command has completed, the MT remains in V.25ter command state. If the MT is already in the requested state, the command is ignored and the OK response is returned. If the requested state cannot be achieved, an ERROR or +CME ERROR response is returned.

Any active PDP contexts will be automatically deactivated when the attachment state changes to detached.

The [AT+CGATT](#) read command returns the current Packet Domain service state.

The [AT+CGATT](#) test command is used for requesting information on the supported Packet Domain service states.

Syntax

Test Command AT+CGATT=? Response(s) +CGATT: (list of supported <state>s) OK											
Read Command AT+CGATT? Response(s) +CGATT: <state> OK											
Write Command AT+CGATT=[<state>] Response(s) OK ERROR +CME ERROR: <err>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>-</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	-	-	Reference(s) 3GPP TS 27.007 [48]
PIN	MDM	APP	→	Last							
+	+	+	-	-							

Parameter Description

<state> ^(num)	
Indicates the state of PS attachment.	
0 ^(P)	Detached
[1]	Attached

12.3 AT+CGACT PDP Context Activate or Deactivate

AT+CGACT write command is used to activate or deactivate the specified PDP context(s). After command has completed, the MT remains in V.250 command state. If any PDP context is already in the requested state, the state for that context remains unchanged. If MT is not PS attached when the activation form of the command is executed, MT firstly performs a PS attach and then attempts to activate the specified contexts. If no **<cid>**s are specified the activation/deactivation form of the command activates/deactivates all defined contexts.

AT+CGACT read command returns the current activation states for all defined PDP contexts.

AT+CGACT test command is used for requesting information on supported PDP context activation states.

Syntax

<p>Test Command</p> <pre>AT+CGACT=?</pre> <p>Response(s)</p> <pre>+CGACT: (list of supported <state>s) OK ERROR +CME ERROR: <err></pre>											
<p>Read Command</p> <pre>AT+CGACT?</pre> <p>Response(s)</p> <pre>+CGACT: [<cid>, <state>] [+CGACT: <cid>, <state>] ... OK ERROR +CME ERROR: <err></pre>											
<p>Write Command</p> <pre>AT+CGACT=<state>[, <cid>[, <cid>]]</pre> <p>Response(s)</p> <pre>OK ERROR +CME ERROR: <err></pre>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>-</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	-	-	<p>Reference(s)</p> <p>3GPP TS 27.007 [48]</p>
PIN	MDM	APP	→	Last							
+	+	+	-	-							

Parameter Description

<p><state>^(num)</p> <p>Indicates the state of PDP context activation.</p> <table border="1"> <tr> <td>0</td> <td>Deactivated</td> </tr> <tr> <td>1</td> <td>Activated</td> </tr> </table>	0	Deactivated	1	Activated
0	Deactivated			
1	Activated			
<p><cid>^(num)</p> <p>Parameter specifies a particular PDP context definition (see AT+CGDCONT parameter <cid>).</p>				

Notes

- A maximum of 3 contexts can be activated at the same time, no matter on which interface (for interface restrictions see Section 1.4, [AT Command Interpreter](#)). Note that, depending on the provider, the number of activated contexts may be further restricted.
Remember that contexts may be activated implicitly by using other commands, e.g. [AT+CGDATA](#) or [ATD*99#](#).
- Contexts activated by , e.g. [AT+CGDATA](#) or [ATD*99#](#) can not be handled by the [AT+CGACT](#) write command but their activation state is still visible via [AT+CGACT](#) read command. A write command without specifying any `<cid>` will always fail as long as some contexts are still in use by [AT+CGDATA](#) or [ATD*99#](#).
- If activation or deactivation of a context fails, then [AT+CEER](#) may provide further informations about the reason.

12.4 AT+CGDATA Enter Data State

[AT+CGDATA](#) write command causes the MT to perform all actions which are necessary to establish communication between the TE and the network using one or more Packet Domain PDP types. This may include performing a PS attach and one or more PDP context activations. Commands following the [AT+CGDATA](#) command in the AT command line will not be processed by the MT.

If the write command is successful, the MT issues the intermediate result code CONNECT and enters V.250 online data state.

The application that initiates the PPP mode must be designed to start all LCP configure requests in accordance with TS 27.060 par 9.1. Otherwise the MT remains, after the CONNECT, infinitely in a waiting state.


After data transfer is complete, and layer 2 protocol termination procedure has completed successfully, command state is reentered and MT returns the final result code OK.

If [<L2P>](#) parameter value is unacceptable to the MT it returns ERROR or +CME ERROR.

In the event of erroneous termination or a failure to start up, command state is reentered and MT returns NO CARRIER, or if enabled +CME ERROR.

[AT+CGDATA](#) test command is used for requesting information on the supported layer 2 protocols to be used between TE and MT.

Syntax

Test Command AT+CGDATA=? Response(s) +CGDATA: (list of supported <L2P>s) OK	
Write Command AT+CGDATA=[<L2P> [, <cid>]] Response(s) CONNECT NO CARRIER ERROR +CME ERROR: <err>	
PIN MDM APP  Last + + - - +	Reference(s) 3GPP 27.007

Parameter Description

<p><L2P>^(str)</p> <p>Layer 2 protocol to be used between TE and MT.</p> <p>["PPP"] Layer 2 protocol PPP</p>
<p><cid>^(num)</p> <p>Parameter specifies a particular PDP context definition (see AT+CGDCONT parameter <cid>).</p> <p>If parameter is not specified, then the first defined primary context is used.</p>

12.4.1 Automatic deactivation of PDP context during dial-up PPP

From using [AT+CGDATA](#) write command or [ATD*99#](#) follows that MT issues intermediate result code CONNECT and enters V.250ter online data state. In V.250 online data state, first some LCP protocol exchange between MT and TE is performed to set up the PPP link. After successfully establishing the PPP link, the MT performs PDP context activation procedure if the context is not already activated. As a result, MT is in a "PDP context activated" state within the PLMN, the PPP link is established on the mobile side and the mobile is ready for IP data transfer. If the TE wants to close the LCP link the MT may perform an LCP termination request procedure on PPP level. After this LCP termination procedure the MT deactivates the PDP context automatically and the MT returns to V.250 command mode and issues the final result code NO CARRIER.

If DTR is configured to disconnect data connections ([AT&D2](#)), the application should not toggle DTR during implicit PDP context deactivation and before "NO CARRIER" is received.

12.5 AT+CGPADDR Show PDP Address

The [AT+CGPADDR](#) exec command returns a list of PDP addresses for all defined contexts.

The [AT+CGPADDR](#) write command returns a list of PDP addresses for the specified context identifiers. If a context is not defined, then no output line is generated for it. If no `<cid>` is specified, the addresses for all defined contexts are returned.

The [AT+CGPADDR](#) test command returns a list of defined `<cid>`s.

Syntax

<p>Test Command</p> <pre>AT+CGPADDR=?</pre> <p>Response(s)</p> <pre>[+CGPADDR: (list of defined <cid>s)] OK</pre>											
<p>Exec Command</p> <pre>AT+CGPADDR</pre> <p>Response(s)</p> <pre>[+CGPADDR: <cid>[, <PDP_address_1>[, <PDP_address_2>]]] [+CGPADDR: ...] OK ERROR +CME ERROR: <err></pre>											
<p>Write Command</p> <pre>AT+CGPADDR=[<cid>[,<cid>[, ...]]]</pre> <p>Response(s)</p> <pre>[+CGPADDR: <cid>[, <PDP_address_1>[, <PDP_address_2>]]] [+CGPADDR: ...] OK ERROR +CME ERROR: <err></pre>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	+	-	<p>Reference(s)</p> <p>3GPP 27.007</p>
PIN	MDM	APP	→	Last							
+	+	+	+	-							

Parameter Description

`<cid>`^(num)

Parameter specifies a particular PDP context definition (see [AT+CGDCONT](#) parameter `<cid>`).

`<PDP_address_1>`^(str)

A string that identifies the MT in the address space applicable to the PDP. The address may be static or dynamic. If address is not available parameter is omitted.

Parameter specifies the assigned address as a dot-separated numeric (0-255) parameter of the form "a1.a2.a3.a4" for IPv4 and "a1.a2.a3.a4.a5.a6.a7.a8.a9.a10.a11.a12.a13.a14.a15.a16" for IPv6.

The settings of [AT+CGPIAF](#) can influence the format of the IPv6 address.

<PDP_address_2>^(str)

A string that identifies the MT in the address space applicable to the PDP. The address may be static or dynamic. Parameter is displayed only when both IPv4 and IPv6 addresses are assigned, with <PDP_address_1> containing the IPv4 address and this parameter the IPv6 address.

Parameter specifies the assigned IPv6 address as a dot-separated numeric (0-255) parameter of the form "a1.a2.a3.a4.a5.a6.a7.a8.a9.a10.a11.a12.a13.a14.a15.a16".

The settings of [AT+CGPIAF](#) can influence the format of this parameter.

12.6 AT+CGPIAF Select Printing IP address format

AT+CGPIAF specifies the format to print IPV6 address parameters of other AT commands. See RFC 4291 for details of the IPv6 address format. The +CGPIAF parameters `<format>`, `<subnet>`, `<lzeros>` and `<czeros>` affect the following commands and parameters:

- in **AT+CGDCONT**, the `<PDP_addr>`;
- in **AT+CGPADDR**, the `<PDP_address_1>` and `<PDP_address_2>`;
- in **AT+CGCONTRDP**, the `<LocalAddr and SubNetMask>`, `<DNS_prim_addr>` and `<DNS_sec_addr>`.

The read command returns the current command parameter settings.
The test command returns supported parameter values.

Syntax

<p>Test Command</p> <pre>AT+CGPIAF=?</pre> <p>Response(s)</p> <pre>+CGPIAF: (list of supported <format>s), (list of supported <subnet>s), (list of supported <lzeros>s), (list of supported <czeros>s) OK</pre>											
<p>Read Command</p> <pre>AT+CGPIAF?</pre> <p>Response(s)</p> <pre>+CGPIAF: <format>, <subnet>, <lzeros>, <czeros> OK</pre>											
<p>Write Command</p> <pre>AT+CGPIAF=[<format>[, <subnet>[, <lzeros>[, <czeros>]]]]</pre> <p>Response(s)</p> <pre>OK ERROR +CME ERROR: <err></pre>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	+	-	<p>Reference(s)</p> <p>3GPP 27.007</p>
PIN	MDM	APP	→	Last							
+	+	+	+	-							

Parameter Description

<code><format></code> ^(num)	
A numeric parameter which decides the IPv6 address format. Relevant for all AT command parameters that can hold an IPv6 address.	
0(&F)(P)	Use IPv4-like dot-notation. IP address, and subnetwork mask if applicable, are dot-separated, e.g. "32.1.13.184.0.0.205.48.0.0.0.0.0.0.0.0.0.255.255.255.255.255.255.240.0.0.0.0.0.0" for parameters holding address and subnet mask and "32.1.13.184.0.0.205.48.0.0.0.0.0.0.0" for other IP address parameters.

1 Use IPv6-like colon-notation. IP address, and subnetwork mask if applicable and when given explicitly, are separated by a space, e.g.
"2001:0DB8:0000:CD30:0000:0000:0000:0000
FFFF:FFFF:FFFF:FFF0:0000:0000:0000:0000"
for parameters holding address and subnet mask and
"2001:0DB8:0000:CD30:0000:0000:0000:0000"
for other IP address parameters.

<subnet>^(num)

A numeric parameter which decides the subnet-notation for parameters that hold remote address and subnet mask Setting does not apply if <format>= 0.

0(&F)(P) Both IP Address and subnet mask are stated explicitly, separated by a space, e.g.
"2001:0DB8:0000:CD30:0000:0000:0000:0000
FFFF:FFFF:FFFF:FFF0:0000:0000:0000:0000".
1 The printout format is applying / (forward slash) subnet-prefix Classless Inter-Domain Routing (CIDR) notation, e.g.
":0DB8:0000:CD30:0000:0000:0000:0000/60"

<lzeros>^(num)

A numeric parameter which decides whether leading zeros are omitted or not. Setting does not apply if <format>= 0.

0(&F)(P) Leading zeros are omitted, e.g. "2001:DB8:0:CD30:0:0:0:0".
1 Leading zeros are included, e.g.
"2001:0DB8:0000:CD30:0000:0000:0000:0000".

<czeros>^(num)

A numeric parameter which decides whether 1-n instances of 16-bit zero-values are replaced by only '::'. This applies only once. Setting does not apply if <format>= 0.

0(&F)(P) No zero compression, e.g. "2001:DB8:0:CD30:0:0:0:0".
1 Use zero compression, e.g. "2001:DB8:0:CD30::".

12.7 AT+CGEREP Packet Domain Event Reporting

The **AT+CGEREP** write command enables or disables sending of unsolicited result codes, +CGEV URCs from MT to TE in the case of certain events occurring in the Packet Domain MT or the network.

Parameter **<mode>** controls the processing of unsolicited result codes specified within this command. **<bfr>** controls the effect on buffered codes when **<mode>** 1 or 2 is entered. If a setting is not supported by the MT, ERROR or +CME ERROR: is returned.

The **AT+CGEREP** read command returns the current **<mode>** and buffer settings.

The **AT+CGEREP** test command returns the modes and buffer settings supported by the MT as compound values.

Syntax

<p>Test Command</p> <pre>AT+CGEREP=?</pre> <p>Response(s)</p> <pre>+CGEREP: (list of supported <mode>s), (list of supported <bfr>s) OK</pre>											
<p>Read Command</p> <pre>AT+CGEREP?</pre> <p>Response(s)</p> <pre>+CGEREP: <mode>, <bfr> OK</pre>											
<p>Write Command</p> <pre>AT+CGEREP=[<mode>[, <bfr>]]</pre> <p>Response(s)</p> <pre>OK ERROR +CME ERROR: <err></pre>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	+	-	<p>Reference(s)</p> <p>3GPP TS 27.007 [48]</p>
PIN	MDM	APP	→	Last							
+	+	+	+	-							

Unsolicited Result Codes

URC 1

```
+CGEV: REJECT <PDP_type>, <PDP_addr>
```

A network request for PDP context activation occurred when the MT was unable to report it to the TE with a +CRING unsolicited result code and was automatically rejected.

URC 2

```
+CGEV: NW REACT <PDP_type>, <PDP_addr>[, <cid>]
```

The network has requested a context reactivation. The **<cid>** that was used to reactivate the context is provided if known to the MT.

URC 3

```
+CGEV: NW DEACT <PDP_type>, <PDP_addr>[, <cid>]
```

The network has forced a context deactivation. The **<cid>** that was used to activate the context is provided if known to the MT.

URC 4

+CGEV: ME DEACT <PDP_type>, <PDP_addr>[, <cid>]

The UE has forced a context deactivation. The <cid> that was used to activate the context is provided if known to the MT.

URC 5

+CGEV: NW DETACH

The network has forced a PS detach.

URC 6

+CGEV: ME DETACH

The mobile equipment has forced a PS detach.

URC 7

+CGEV: NW CLASS <class>

The network has forced a change of MS class. The highest available class is reported.

URC 8

+CGEV: ME CLASS <class>

The UE has forced a change of MS class. The highest available class is reported.

URC 9

+CGEV: PDN ACT <cid>

A context activation has been forced. The <cid> that was used to activate the context is provided if known to the MT. The context represents a PDN connection in LTE or a Primary PDP context in GSM/UMTS.

URC 10

+CGEV: PDN DEACT <cid>

A context deactivation has been forced. The <cid> that was used to activate the context is provided if known to the MT. The context represents a PDN connection in LTE or a Primary PDP context in GSM/UMTS.

URC 11

+CGEV: NW MODIFY <cid>, <change-reason>, <event-type>

The network has modified a context. The associated <cid> is provided to the TE in addition to the <change-reason> and <event-type>. The format of the parameter <cid> is found in command AT+CGDCONT.

URC 12

+CGEV: ME MODIFY <cid>, <change-reason>, <event-type>

The mobile termination has modified a context. The associated <cid> is provided to the TE in addition to the <change-reason> and <event-type>.

URC 13

+CGEV: ME PDN ACT <cid>[, <reason>]

The UE has activated a context. The context represents a Primary PDP context in GSM/UMTS/LTE. The <cid> for this context is provided to the TE. This event is sent either in result of explicit context activation request (AT+CGACT), or in result of implicit context activation request associated to attach request (AT+CGATT=1).

Parameter Description

<mode>^(num)

0^(P)

Buffer unsolicited result codes in the MT. Currently 3 +CGEV URCs can be buffered. If MT result code buffer is full, the oldest ones will be discarded. No codes are forwarded to the TE.

- | | |
|---|---|
| 1 | Discard unsolicited result codes when MT TE link is reserved (e.g. in on line data mode); otherwise forward them directly to the TE. |
| 2 | Buffer unsolicited result codes in the MT when MT TE link is reserved (e.g. in on line data mode) and flush them to the TE when MT TE link becomes available; otherwise forward them directly to the TE. Currently 3 +CGEV URCs can be buffered. If MT result code buffer is full, the oldest URCs will be discarded. |

<bfr>^(num)

- | | |
|---|---|
| 0 | MT buffer of unsolicited result codes defined within this command is cleared when <mode> 1 or 2 is entered |
| 1 | MT buffer of unsolicited result codes defined within this command is flushed to the TE when <mode> 1 or 2 is entered (OK response will be given before flushing the codes). Buffer is empty afterwards. |

<class>^(str)

Parameter indicates the GPRS mobile class.

- | | |
|------|----------------------------------|
| “A“ | Class A (highest) |
| “B“ | Class B |
| “CG“ | Class C in GPRS mode |
| “CC“ | Class C in circuit switched mode |

<reason>^(num)

Indicates the reason why the context activation request for PDP type IPv4v6 was not granted. This parameter is only included if the requested PDP type associated with <cid> is IPv4v6, and the PDP type assigned by the network for <cid> is either IPv4 or IPv6.

- | | |
|---|--|
| 0 | IPV4 only allowed |
| 1 | IPV6 only allowed |
| 2 | Single address bearers only allowed |
| 3 | Single address bearers only allowed and MT initiated context activation for a second address type bearer was not successful. |

<change-reason>^(num)

Integer type parameter indicates what kind of change occurred.

- | | |
|---|--------------------------|
| 0 | Not available |
| 1 | TFT only changed |
| 2 | Qos only changed |
| 3 | Both TFT and QoS changed |

<event-type>^(num)

Integer type parameter indicates whether this is an informational event or whether the TE has to acknowledge it.

- | | |
|---|---------------------|
| 0 | Informational event |
|---|---------------------|

12.8 AT+CGREG Packet Domain Network Registration Status

The **AT+CGREG** write command enables the presentation of the URC "+CGREG: <stat>" when <n>=1 and ME's Packet Domain network registration status in GSM or UMTS changes, or URC "+CGREG: <stat>[, <lac>][, <ci>][, <AcT>]" when <n>=2 and the current network cell in GSM or UMTS changes.

AT+CGREG read command queries the current URC presentation status <n> and an integer <stat> which shows whether the network has currently indicated the registration of the ME.

Location information elements <lac>, <ci> and <AcT> are sent only if available, if <n>=2 and if ME is registered to the network.

Syntax

Test Command					
AT+CGREG=?					
Response(s)					
+CGREG: (list of supported <n>s)					
OK					
Read Command					
AT+CGREG?					
Response(s)					
+CGREG: <n>, <stat>[, <lac>][, <ci>][, <AcT>]					
OK					
Write Command					
AT+CGREG=<n>					
Response(s)					
OK					
ERROR					
+CME ERROR: <err>					
PIN	MDM	APP	→	Last	Reference(s)
+	+	+	+	-	3GPP 27.007

Unsolicited Result Codes

URC 1

+CGREG: <stat>

Indicates a change in the ME's Packet Domain network registration status.

URC 2

+CGREG: <stat>[, <lac>][, <ci>][, <AcT>]

Indicates a change in the ME's Packet Domain network registration status or a change of the network cell including location information.

Parameter Description

<n> ^(num)	
0(&F)(P)	Disable Packet Domain network registration URC
1	Enable Packet Domain network registration URC "+CGREG: <stat>"
2	Enable Packet Domain network registration URC "+CGREG: <stat>[, <lac>][, <ci>][, <AcT>]"

<stat>^(num)

0	Not registered, ME is not currently searching an operator to register to.
1	Registered, home network.
2	Not registered, but ME is currently trying to attach or searching an operator to register to.
3	Registration denied.
4	Unknown
5	Registered, roaming.

<lac>^(str)

Two byte location area code in hexadecimal format.

<ci>^(str)

Cell ID in hexadecimal format:

- 16 bit for 2G
- 28 bit for 3G

<AcT>^(num)

Radio access technology

0	GSM
2	UTRAN
3	GSM w/EGPRS
4	UTRAN w/HSDPA
5	UTRAN w/HSUPA
6	UTRAN w/HSDPA and w/HSUPA
7	E-UTRAN (not applicable)

12.9 AT+CEREG EPS Network Registration Status

AT+CEREG write command enables presentation of URC "+CEREG: <stat>" when <n>=1 and UE's EPS network registration status in LTE changes, or URC "+CEREG: <stat>[, <tac>][, <ci>][, <AcT>]" when <n>=2 and the current network cell in LTE changes.

AT+CEREG execute command restores default value "0" for parameter <n>.

AT+CEREG read command queries the current URC presentation status and <stat> which shows whether the network has currently indicated the registration of the ME. Location information elements <tac> and <ci> are returned only if <n>=2 and ME is registered to the network.

Syntax

<p>Test Command</p> <p>AT+CEREG=?</p> <p>Response(s)</p> <p>+CEREG: (list of supported <n>s)</p> <p>OK</p>											
<p>Read Command</p> <p>AT+CEREG?</p> <p>Response(s)</p> <p>+CEREG: <n>, <stat>[, <tac>][, <ci>][, <AcT>]</p> <p>OK</p>											
<p>Exec Command</p> <p>AT+CEREG</p> <p>Response(s)</p> <p>OK</p>											
<p>Write Command</p> <p>AT+CEREG=<n></p> <p>Response(s)</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	+	-	<p>Reference(s)</p> <p>3GPP TS 27.007 [48]</p>
PIN	MDM	APP	→	Last							
+	+	+	+	-							

Unsolicited Result Codes

URC 1

+CEREG: <stat>

Indicates a change in the UE's EPS network registration status.

URC 2

+CEREG: <stat>[, <tac>][, <ci>][, <AcT>]

Indicates a change in the UE's EPS network registration status or a change of the network cell including location information.

Parameter Description

<n> ^(num)	
0(&F)(P)	Disable network registration unsolicited result code

- 1 Enable network registration URC "+CEREG: <stat>"
- 2 Enable network registration URC "+CEREG: <stat>[, <tac>][, <ci>][, <AcT>]"

<stat>^(num)

- 0 Not registered, ME is not currently searching an operator to register to.
- 1 Registered, home network.
- 2 Not registered, but ME is currently trying to attach or searching an operator to register to.
- 3 Registration denied.
- 4 Unknown, e.g. out of LTE coverage
- 5 Registered, roaming.

<tac>^(str)

Two byte tracking area code in hexadecimal format (e.g. "00C3" equals 195 in decimal)

<ci>^(str)

Four byte LTE cell ID in hexadecimal format.

<AcT>^(num)

Radio access technology

- 0 GSM (not applicable)
- 2 UTRAN (not applicable)
- 3 GSM w/EGPRS (not applicable)
- 4 UTRAN w/HSDPA (not applicable)
- 5 UTRAN w/HSUPA (not applicable)
- 6 UTRAN w/HSDPA and w/HSUPA (not applicable)
- 7 E-UTRAN

12.10 AT+CGCONTRDP PDP context read dynamic parameters

The `AT+CGCONTRDP` write command returns dynamic parameters for the active non-secondary PDP context specified with `<cid>`.

The `AT+CGCONTRDP` execute command returns dynamic parameters for all active non-secondary PDP contexts. For contexts of `<PDP_type>` "IPV4V6" the response of exec and write command will have two lines per `<cid>`. First line describes the IPV4 dynamic parameters followed by another line with the IPV6 dynamic parameters.

Syntax

<p>Test Command</p> <pre>AT+CGCONTRDP=?</pre> <p>Response(s)</p> <pre>+CGCONTRDP: (list of supported <cid>s) associated with active contexts OK</pre>											
<p>Exec Command</p> <pre>AT+CGCONTRDP</pre> <p>Response(s)</p> <pre>+CGCONTRDP: <cid>, <Bearer_ID>, <APN>[, <LocalAddr and SubNetMask>[, <GwAddr>[, <DNS_prim_addr>[, <DNS_sec_addr>]]]] +CGCONTRDP: <cid>, <Bearer_ID>, <APN>[, <LocalAddr and SubNetMask>[, <GwAddr>[, <DNS_prim_addr>[, <DNS_sec_addr>]]]] [+CGCONTRDP: ...] OK ERROR +CME ERROR: <err></pre>											
<p>Write Command</p> <pre>AT+CGCONTRDP=<cid></pre> <p>Response(s)</p> <pre>+CGCONTRDP: <cid>, <Bearer_ID>, <APN>[, <LocalAddr and SubNetMask>[, <GwAddr>[, <DNS_prim_addr>[, <DNS_sec_addr>]]]] OK ERROR +CME ERROR: <err></pre>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>-</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	-	-	<p>Reference(s)</p> <p>3GPP TS 27.007 [48]</p>
PIN	MDM	APP	→	Last							
+	+	+	-	-							

Parameter Description

`<cid>`^(num)

Specifies a particular non-secondary PDP context definition. The parameter is local to the TE-MT interface and is used in other PDP context-related commands. See `AT+CGDCONT`.

`<Bearer_ID>`^(num)

Identifies the bearer, EPS Bearer in EPS and NSAPI in UMTS/GPRS.

`<APN>`^(str)

Access Point Name

Logical name used to select the GGSN or the external packet data network.

<LocalAddr and SubNetMask>^(str)

Shows the IP address and subnet mask of the UE in the format specified by [AT+CGPIAF](#).

<GwAddr>^(str)

Shows the Gateway Address of the UE in the format specified by [AT+CGPIAF](#).

<DNS_prim_addr>^(str)

Shows the IP address of the primary DNS server.
The settings of [AT+CGPIAF](#) influences the format of this parameter.

<DNS_sec_addr>^(str)

Shows the IP address of the secondary DNS server.
The settings of [AT+CGPIAF](#) influences the format of this parameter.

12.11 AT+CGEQOS Define EPS Quality of Service

The write command allows the UE to specify the EPS Quality of Service parameters for a PDP context or Traffic Flows. When in UMTS/GPRS the MT applies a mapping function to UMTS/GPRS Quality of Service. A special form of the write command, `AT+CGEQOS=<cid>`, causes the values for context number `<cid>` to become undefined.

Syntax

<p>Test Command</p> <pre>AT+CGEQOS=?</pre> <p>Response(s)</p> <pre>+CGEQOS: (range of supported <cid>s), (list of supported <QCI>s), (list of supported <DL_GBR>s), (list of supported <UL_GBR>s), (list of supported <DL_MBR>s), (list of supported <UL_MBR>s) OK</pre>	
<p>Read Command</p> <pre>AT+CGEQOS?</pre> <p>Response(s)</p> <pre>[+CGEQOS: <cid>, <QCI>, [<DL_GBR>, <UL_GBR>], [<DL_MBR>, <UL_MBR>]] [+CGEQOS: ...] OK</pre>	
<p>Write Command</p> <pre>AT+CGEQOS=<cid>[, <QCI>[, <DL_GBR>, <UL_GBR>[, <DL_MBR>, <UL_MBR>]]]</pre> <p>Response(s)</p> <pre>OK ERROR +CME ERROR: <err></pre>	
<p>PIN MDM APP → Last</p> <p>- + + + -</p>	<p>Reference(s)</p> <p>3GPP TS 27.007 [48]</p>

Parameter Description

<code><cid></code> ^(num)	Specifies a particular EPS Traffic Flows definition in EPS and a PDP Context definition in UMTS/GPRS (see AT+CGDCONT).
[1]	subscribed value
<code><QCI></code> ^(num)	Specifies a class of EPS QoS.
0	QCI is selected by network
1...4	Value range for guaranteed bit rate Traffic Flows
5...9	Value range for non-guaranteed bit rate Traffic Flows
<code><DL_GBR></code> ^(num)	Indicates DL GBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301 [43]).
[0]	subscribed value

<UL_GBR>^(num)

Indicates UL GBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301 [43]).

[0] subscribed value

<DL_MBR>^(num)

Indicates DL MBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301 [43]).

[0] subscribed value

<UL_MBR>^(num)

Indicates UL MBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI (see 3GPP TS 24.301 [43]).

[0] subscribed value

12.12 AT+CGEQOSRDP EPS Quality of Service Read Dynamic Parameters

The write command returns Quality of Service parameters of the active PDP context associated to the provided context identifier `<cid>`.

If the parameter `<cid>` is omitted, the Quality of Service parameters for all non-secondary active PDP contexts are returned.

The test command returns a list of `<cid>`s associated with active PDP contexts. Parameters of both network and MT/TA initiated PDP contexts will be returned.

Syntax

Test Command AT+CGEQOSRDP=? Response(s) +CGEQOSRDP: (list of <code><cid></code> s associated with active contexts) OK	
Write Command AT+CGEQOSRDP=[<code><cid></code>] Response(s) [+CGEQOSRDP: <code><cid></code> , <code><QCI></code> , [<code><DL_GBR></code> , <code><UL_GBR></code>], [<code><DL_MBR></code> , <code><UL_MBR></code>][, <code><DL_AMBR></code> , <code><UL_AMBR></code>]] [+CGEQOSRDP: ...] OK ERROR +CME ERROR: <code><err></code>	
PIN MDM APP → Last + + + - -	Reference(s) 3GPP TS 27.007 [48]

Parameter Description

`<cid>`^(str)
 Specifies a particular EPS Traffic Flows definition in EPS and a PDP Context definition in UMTS/GPRS (see [AT+CGDCONT](#) and).

`<QCI>`^(num)
 Specifies a class of EPS QoS.

0	QCI is selected by network
1...4	Value range for guaranteed bit rate Traffic Flows
5...9	Value range for non-guaranteed bit rate Traffic Flows
128...254	Value range for for Operator-specific QCIs

`<DL_GBR>`^(num)
 Indicates DL GBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI.

`<UL_GBR>`^(num)
 Indicates UL GBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI.

<DL_MBR>^(num)

Indicates DL MBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI.

<UL_MBR>^(num)

Indicates UL MBR in case of GBR QCI. The value is in kbit/s. This parameter is omitted for a non-GBR QCI.

<DL_AMBR>^(num)

Indicates DL APN aggregate MBR. The value is in kbit/s.

<UL_AMBR>^(num)

Indicates UL APN aggregate MBR. The value is in kbit/s.

Note

- If multiple lines in a response belong to the same PDN connection they contain the same <DL_AMBR> <UL_AMBR> values.

12.13 AT+CGSMS Select Service for MO Short Messages

AT+CGSMS specifies the service or service preference that the MT will use to send MO (mobile originated) short messages.

Syntax

Test Command AT+CGSMS=? Response(s) +CGSMS: (list of supported <service>s) OK	
Read Command AT+CGSMS? Response(s) +CGSMS: <service> OK	
Write Command AT+CGSMS=<service> Response(s) OK ERROR +CME ERROR: <err>	
PIN MDM APP → Last + + + + -	Reference(s) 3GPP 27.007

Parameter Description

<service> ^{(num)(NV)}	
A numeric parameter which indicates the service or service preference to be used.	
0	Packet Domain
1 ^(D)	Circuit switched
2	Packet Domain preferred (use circuit switched SMS transfer if mobile is not PS attached)
3	Circuit switched preferred (use Packet Domain if circuit switched is not available)

12.14 AT+CNMPD No more PS data

The [AT+CNMPD](#) command indicates that no application on the MT is expected to exchange data. Upon receiving this command, the final result code OK is returned. When in UTRAN, if further conditions defined in 3GPP TS 25.331 [46] are met, this can cause transmission of a SIGNALLING CONNECTION RELEASE INDICATION message with the cause "UE Requested PS Data session end".

Syntax

Test Command				
AT+CNMPD=?				
Response(s)				
OK				
Exec Command				
AT+CNMPD				
Response(s)				
OK				
PIN	MDM	APP	→	Last
+	+	+	-	+
				Reference(s)
				3GPP 27.007

12.15 ATD*99# Request Packet Domain service

This command causes the MT to perform whatever actions are necessary to establish a communication between the TE and the external PDN.

The V.250 'D' (Dial) command causes the MT to enter the V.250 online data state and, with the TE, to start the specified layer 2 protocol. No further commands may follow on the AT command line. PS attachment and PDP context activation procedures may take place prior to or during the PDP startup if they have not already been performed using the [AT+CGATT](#) and [AT+CGACT](#) commands.

To confirm acceptance of the command before entering the V.250 online data state command will respond with CONNECT.

The application that initiates the PPP mode must be designed to start all LCP configure requests in accordance with TS 27.060 par 9.1. Otherwise the MT remains, after the CONNECT, infinitely in a waiting state.

When the layer 2 protocol has terminated, either as a result of an orderly shut down of the PDP or an error, the MT enters V.250 command state and returns NO CARRIER (for details refer to Section [12.4.1, Automatic deactivation of PDP context during dial-up PPP](#)).

[ATD*99#](#) is blocked when the Fixed Dialing lock is enabled and the number "*99#" is not present in the "FD" phonebook (see [AT+CLCK](#) SIM Fixed Dialing lock). In this case "+CME ERROR: call barred" is returned.

Syntax

Exec Command					
ATD*99[* [<called_address>][* [<L2P>][* [<cid>]]]]#					
Response(s)					
CONNECT					
NO CARRIER					
ERROR					
+CME ERROR: <err>					
PIN	MDM	APP	→	Last	Reference(s)
+	+	-	-	+	3GPP TS 27.007

Parameter Description

<called_address>^(str)

IP V4 address in the form w.x.y.z, which identifies the called party; if it is provided, the MT will automatically set up a virtual call to the specified address after the context has been activated.

<L2P>^(num)

Layer 2 protocol to be used between the TE and MT.

[1] layer 2 protocol PPP

<cid>^(num)

Parameter specifies a particular PDP context definition (see [AT+CGDCONT](#) parameter <cid>). If parameter is not specified, then the first defined primary context is used.

12.16 AT^SGAPN Configure APN class settings

Command allows to query or set APN class parameters for PDP contexts.

The `AT^SGAPN` test command returns the supported ranges of the APN class parameters.

The read command returns the current values for the APN class parameters for all defined PDP contexts.

The write command can be used to set the APN class parameters for a PDP context already defined by `AT+CGDCONT` and identified by the context identifier `<cid>`. If a context is newly defined by using `AT+CGDCONT`, then its APN class is 0, the APN bearer is "ANY", it is enabled and its inactivity timer is disabled.

When parameter settings are changed for an active context, it is necessary to close and reestablish the connection to make the changes take effect.

In Verizon Wireless networks PDP context with APN class 1 - 4 are dedicated to specific profile settings for LTE bearer and IPV4 / IPV6:

- Profile 1 is for the "vzwims" APN dedicated for IMS (IP Multimedia Subsystem). The UE registers to IMS only if registered to LTE, configured for IPV4 / IPV6 and if registered to the VzW IMS server via the dedicated APN "vzwims".
- Profile 2 is for the "vzwadmin" APN dedicated for OMA-DM.
- Profile 3 is for the "vzwinternet" APN available for Internet connections set up either over Dial-up network (see `AT+CGACT`, `ATD*99#`), or WWAN (RmNet) adapter (see `AT^SWWAN` command), or AT commands over IP (see `AT^SICA`). This APN is used as default bearer for LTE.
- Profile 4 is for the "vzwapp" APN intended only for Verizon specific applications.

Modules manufactured / configured for Verizon Wireless are delivered with following context definitions:

- Context 1: `<apnType>="IPV4V6"`, `<APN>="VZWIMS"`, `<bearer>="LTE"`, `<enabledFlag>="Enabled"` and `<inactivityTimeout>=0`;
- Context 2: `<apnType>="IPV4V6"`, `<APN>="VZWADMIN"`, `<bearer>="LTE"`, `<enabledFlag>="Enabled"` and `<inactivityTimeout>=0`;
- Context 3: `<apnType>="IPV4V6"`, `<APN>="VZWINTERNET"`, `<bearer>="LTE"`, `<enabledFlag>="Enabled"` and `<inactivityTimeout>=0`;
- Context 4: `<apnType>="IPV4V6"`, `<APN>="VZWAPP"`, `<bearer>="LTE"`, `<enabledFlag>="Enabled"` and `<inactivityTimeout>=0`;
- All other contexts are undefined.

Modules manufactured / configured for other operators are delivered with all contexts undefined. See also `AT^SCFG` "MEopMode/Prov/Cfg" parameter `<provCfg>`.

Syntax

Test Command

`AT^SGAPN=?`

Response(s)

```
^SGAPN: (list of supported <cid>s), (list of supported <apnClass>s), (list of supported <apnType>s), ,
(list of supported <bearer>s), (list of supported <enabledFlag>s), (range of supported
<inactivityTimeout>s)
OK
ERROR
+CME ERROR: <err>
```

Read Command

`AT^SGAPN?`

Response(s)

```
[^SGAPN: <cid>, <apnClass>, <apnType>, <APN>, <bearer>, <enabledFlag>,
<inactivityTimeout>]
[^SGAPN: ...]
OK
ERROR
+CME ERROR: <err>
```

Write Command

```
AT^SGAPN=<cid>, <apnClass>[, <apnType>[, <APN>[, <bearer>[, <enabledFlag>[,  
<inactivityTimeout>]]]]]]
```

Response(s)

```
OK  
ERROR  
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cid>^{(num)(NV)}

Parameter specifies a particular PDP context definition (see [AT+CGDCONT](#) parameter <cid>).

1...16

<apnClass>^{(num)(NV)}

Parameter specifies an APN class. If not provided in the write command, the current setting is unchanged.

0...16

<APN>^{(str)(NV)}

Access Point Name

Parameter specifies the logical name used to select the GGSN or the external packet data network. It is the same parameter as the [AT+CGDCONT](#) parameter <APN>.

Changing this parameter using [AT^SGAPN](#) will also change the [AT+CGDCONT](#) value.

If parameter is not provided in write command, then the current setting is unchanged.

<apnType>^{(str)(NV)}

Parameter specifies the type of the APN. It is the same parameter as the [AT+CGDCONT](#) parameter <PDP_type>.

Changing this parameter using [AT^SGAPN](#) will also change the [AT+CGDCONT](#) value.

If parameter is not provided in write command, then the current setting is unchanged.

“IP“

“PPP“

“IPV6“

“IPV4V6“

<bearer>^{(str)(NV)}

Parameter specifies the APN bearer. If parameter is not provided in write command, then the current setting is unchanged.

“GSM“

“WCDMA“

“LTE“

“ANY“

12.17 AT^SGAUTH Set Type of Authentication for PDP-IP Connections

[AT^SGAUTH](#) specifies the authentication protocol, password and user name to be given if a Packet Domain network requires authentication and the subscriber uses [AT+CGACT](#) for PDP context activation.

See also parameter [<gauth>](#) provided by the configuration command [AT^SCFG](#). This parameter specifies the authentication protocol applied by [AT+CGDATA](#) or [ATD*99#](#) during the PPP startup phase if no PDP context is activated yet.

Syntax

```

Test Command
AT^SGAUTH=?
Response(s)
^SGAUTH: (range of supported<cid>s), (list of supported <auth_type>s), ,
OK
ERROR
+CME ERROR: <err>

Read Command
AT^SGAUTH?
Response(s)
^SGAUTH:<cid>, <auth_type>[, <user>]
^SGAUTH:<cid>, <auth_type>[, <user>]
...
OK
ERROR
+CME ERROR: <err>

Write Command
AT^SGAUTH=<cid>[, <auth_type>[, <passwd>, <user>]]
Response(s)
OK
ERROR
+CME ERROR: <err>
    
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

[<cid>](#)^{(num)(NV)}

Parameter specifies a particular PDP context definition (see [AT+CGDCONT](#) parameter [<cid>](#)).

[<auth_type>](#)^{(num)(NV)}

Indicates the types of authentication to be used for the specified context. If CHAP or PAP is selected two additional parameters [<passwd>](#) and [<user>](#) need to be specified.

[0]	none
1	PAP
2	CHAP

`<passwd>`^{(str)(NV)}

Parameter specifies the password used for authentication. It is required for the authentication types PAP and CHAP.

Maximum length: 127 characters.

`<user>`^{(str)(NV)}

Parameter specifies the user name used for authentication. It is required for the authentication types PAP and CHAP.

Maximum length: 127 characters.

12.18 AT^SWWAN PDP Context Activate or Deactivate

AT^SWWAN write command can be used to activate or deactivate a WWAN connection for a PDP context defined with AT+CGDCONT.

UE supports two WWAN adapters (also referred to as Wireless Adapters or RmNet interfaces). The benefit is that different APNs can be assigned to each WWAN adapter. Both WWAN adapters can be activated at the same time.

AT^SWWAN read command shows whether a WWAN connection is active and which PDP context is used for it. If no WWAN connection is active, then read command just returns OK. To track activation errors AT^SIND indicator "ceer" can be used.

Syntax

```

Test Command
AT^SWWAN=?
Response(s)
^SWWAN: (list of supported <state>s), (list of supported <cid>s), (list of supported <WWAN adapter>s)
OK
ERROR
+CME ERROR: <err>

Read Command
AT^SWWAN?
Response(s)
[^SWWAN: <cid>, <state>[, <WWAN adapter>]]
[^SWWAN: ...]
OK
ERROR
+CME ERROR: <err>

Write Command
Activate/Deactivate WWAN connection
AT^SWWAN=<action>, <cid>[, <WWAN adapter>]
Response(s)
OK
ERROR
+CME ERROR: <err>
    
```

PIN	MDM	APP	→	Last
+	+	+	-	-

Parameter Description

<action> ^(num)	
0	Deactivate
1	Activate

<state> ^(num)	
0 ^(P)	Deactivated
1	Activated

<cid>^(num)

Parameter specifies a particular PDP context definition (see [AT+CGDCONT](#) parameter <cid>).

<WWAN adapter>^(num)

- | | |
|---|--|
| 1 | First WWAN adapter
If parameter <WWAN adapter> is omitted in the AT^SWWAN write command, the first WWAN adapter will be used. |
| 2 | Second WWAN adapter |

Notes

- Contexts already activated by other commands as for example [AT+CGACT](#) cannot be reused for WWAN, except in LTE mode where the PDP context activated for LTE attach can also be used to start a WWAN connection. For more information please refer to Section [12.1.1, Attaching to LTE Networks](#).
- If activation or deactivation of a WWAN connection fails, then [AT+CEER](#) may provide further informations about the reason.

13. USIM related Commands

13. USIM related Commands

AT commands described in this chapter are related to the Universal Subscriber Identity Module (USIM) connected to the PLS8-X.

Note:

If using data from the USIM please bear in mind that the content of all Elementary Files is *subject to change* at any moment!

This is because the network can change the USIM's data in the background via [USIM Application Toolkit \(USAT\)](#) procedure "Data download to USIM". For a detailed description please refer to 3GPP TS 11.14 [21], 3GPP TS 31.111 [22], ETSI TS 102 223 [23].

To get informed that changing Elementary Files has taken place the Customer Application (TE) needs to hook up [USAT](#) Proactive Command "REFRESH". For more information please refer to Chapter 8., [USIM Application Toolkit \(USAT\) Commands](#) and Section 8.7, [SAT Get Information - Refresh \(1\)](#) in particular.

13.1 AT+CRSM Restricted USIM Access

[AT+CRSM](#) offers easy access of the Elementary Files on the USIM. Access to the USIM database is restricted to the commands listed with parameter `<command>`.

All parameters of [AT+CRSM](#) are used as defined by the specifications listed below. PLS8-X handles internally all required USIM interface locking and file selection routines.

As response to the command, the PLS8-X sends the actual USIM information parameters and response data. "+CME ERROR" may be returned if the command cannot be passed to the USIM, e.g. if the USIM is not inserted. Failures to execute the command on the USIM will be reported by the `<sw1>` and `<sw2>` parameters.

Please beware of *possible changes to Elementary Files* by the network at any time, refer Chapter 13., [USIM related Commands](#).

Syntax

Test Command AT+CRSM=? Response(s) OK	
Write Command AT+CRSM=<command>[, <fileID>[, <P1>, <P2>, <P3>[, <data>]]] Response(s) +CRSM: <sw1>,<sw2>[,<response>] OK ERROR +CME ERROR: <err>	
PIN MDM APP → Last - + + + -	Reference(s) 3GPP TS 27.007 [48], 3GPP TS 11.11 [17], 3GPP TS 31.101 [18], 3GPP TS 31.102 [19] ETSI TS 102 221 [20]

Parameter Description

`<command>`^(num)

USIM command number.

176	READ BINARY
178	READ RECORD
192	GET RESPONSE
214	UPDATE BINARY
220	UPDATE RECORD
242	STATUS

`<fileID>`^(num)

Identifier for an elementary data file on USIM, if used by `<command>`.

`<P1>`^(num)

Parameter to be passed on by the PLS8-X to the USIM.

0...255

`<P2>`^(num)

Parameter to be passed on by the PLS8-X to the USIM.

0...255

`<P3>`^(num)

Parameter to be passed on by the PLS8-X to the USIM.

0...255

`<data>`^(str)

Information which shall be written to the USIM (hexadecimal character format).

`<sw1>`^(num)

Status information from the USIM about the execution of the actual command. It is returned in both cases, on successful or failed execution of the command.

0...255

`<sw2>`^(num)

Status information from the USIM about the execution of the actual command. It is returned in both cases, on successful or failed execution of the command.

0...255

`<response>`^(str)

Response data in case of a successful completion of the previously issued command. "STATUS" and "GET RESPONSE" commands return data, which gives information about the currently selected elementary data field. This information includes the type of file and its size. After "READ BINARY" or "READ RECORD" commands the requested data will be returned. `<response>` is empty after "UPDATE BINARY" or "UPDATE RECORD" commands.

13.2 AT+CSIM Generic USIM Access

AT+CSIM allows direct control of the USIM.

Compared to the restricted USIM access command **AT+CRSM**, the definition of **AT+CSIM** allows to take more control over the USIM interface.

However, the **USIM Application Toolkit** functionality is not supported by **AT+CSIM**. Therefore the following USIM commands cannot be used: TERMINAL PROFILE, ENVELOPE, FETCH and TEMINAL RESPONSE.

Syntax

Test Command	
AT+CSIM=?	
Response(s)	
OK	
Write Command	
AT+CSIM=<length>, <command>	
Response(s)	
+CSIM: <length>,<response>	
OK	
ERROR	
+CME ERROR: <err>	
PIN MDM APP → Last	Reference(s)
- + + + -	3GPP TS 27.007 [48], 3GPP TS 11.11 [17], 3GPP TS 31.101 [18], 3GPP TS 31.102 [19] ETSI TS 102 221 [20]

Parameter Description

<length> ^(num)
Number of characters in <command> or <response> string.
<command> ^(str)
Command passed on by the PLS8-X to the USIM. Parameter length: maximum 260 Bytes.
<response> ^(str)
Response data of the command returned by the USIM. Parameter length: maximum 258 Bytes.

Note

- Access to datafields via SELECT is only allowed to files according to 3GPP TS 11.11 [17], 3GPP TS 31.101 [18], 3GPP TS 31.102 [19].

Examples

EXAMPLE 1

The following examples show SELECT and GET RESPONSE commands for a 2G SIM card.

AT+CSIM=14, "A0A40000027F10" +CSIM: 4, "9F19"	SELECT DF-Telecom. Command successful. Indicates that x19 bytes response data are available and can be requested by using GET RESPONSE.
OK AT+CSIM=14, "A0A40000026F3A" +CSIM: 4, "9F0F"	SELECT EF-ADN (Abbreviated dialing numbers). Command successful. Indicates that x0F bytes response data are available and can be requested by using GET RESPONSE.
OK AT+CSIM=10, "A0C000000F" +CSIM: 34, "000002306F3A040011F0220102011C9000" OK	GET RESPONSE command requests x0F bytes EF-ADN data.

EXAMPLE 2

The following examples show SELECT and GET RESPONSE commands for a 3G USIM card.

AT+CSIM=14, "00A40004023F00" +CSIM: 4, "6138"	SELECT Master File (MF). Command successful. Indicates that x38 bytes response data are available and can be requested by using GET RESPONSE.
OK AT+CSIM=10, "00C00000038" +CSIM: 116, "6236.....A9000" OK	GET RESPONSE command requests x38 bytes MF data. (Response truncated here.)

13.3 AT^SATR Query SIM's Answer to Reset Data

AT^SATR performs multiple USIM related commands. It serves to trigger a USIM restart and query of Answer to Reset (ATR) data. The ATR data string of up to 33 bytes sent from the USIM to the UE, contains information about the USIM and the supported data transfer protocols. For ATR coding refer to 3GPP TS 11.11 [17], 3GPP TS 31.101 [18], 3GPP TS 31.102 [19].

Syntax

Test Command AT^SATR=? Response(s) OK
Write Command AT^SATR=<command> Response(s) In case of <command>="GetAtr" ^SATR: <response> OK ERROR +CME ERROR: <err> For all other Commands OK ERROR +CME ERROR: <err>
PIN MDM APP → Last - + + + -

Parameter Description

<command> ^(str)	
List of possible subcommands provided by AT^SATR .	
“RestartSim“	Restart the currently inserted USIM.
“GetAtr“	Retrieve the Answer to Reset (ATR) data of the currently inserted USIM.
<response> ^(str)	
GetAtr Response	
Answer to Reset (ATR) data of currently inserted USIM.	

13.4 AT^SCKS Query USIM and Chip Card Holder Status

AT^SCKS write command enables or disables the presentation of URCs to report the connection status of the USIM.

AT^SCKS read command returns the URC presentation mode and the status of the USIM connection. Also refer to **AT^SIND**, which supplies indicator "simstatus" to monitor the USIM status.

Syntax

<p>Test Command</p> <p>AT^SCKS=?</p> <p>Response(s)</p> <p>^SCKS: (list of supported <mode>s)</p> <p>OK</p>
<p>Read Command</p> <p>AT^SCKS?</p> <p>Response(s)</p> <p>^SCKS: <mode>, <SimStatus></p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>
<p>Write Command</p> <p>AT^SCKS=<mode></p> <p>Response(s)</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>
<p>PIN MDM APP → Last</p> <p>- + + + -</p>

Unsolicited Result Code

^SCKS: <SimStatus>

If the USIM connection status has changed an unsolicited result code (URC) is issued.

Parameter Description

<mode> ^{(num)(&V)(&W)}	
0(&F)	Disable URC " ^SCKS ".
1	Enable URC " ^SCKS ".
<SimStatus> ^{(num)(&V)}	
0	USIM is not inserted.
1	USIM inserted.
2	Possible reasons: <ul style="list-style-type: none"> The USIM interface hardware has been deactivated to prevent possible damage (e.g. if a USIM with invalid or unsupported electrical specifications has been detected). The USIM interface can be reactivated only by restarting the UE, e.g. with "AT+CFUN= n,1".

- In case a 5V USIM is inserted it might be possible that the USIM is not functional at all. As a result, URC "[^SCKS: 0](#)" occurs.

3

If during power up the USIM returns status words 6F00h (Technical problem, no precise diagnosis) to three consecutive APDUs sent by PLS8-X, the USIM interface hardware has been deactivated.

The USIM interface can be reactivated only by restarting the UE, e.g. via "[AT+CFUN= n,1](#)".

Note

- If `<mode>=1` ("[^SCKS](#)" URC enabled) is stored to the user profile with [AT&W](#) it may happen that the "[^SCKS](#)" URC shows up after the "[^SYSSTART](#)" URC although the (U)SIM connection status has not changed.

13.5 AT^SSET USIM Data Ready Indication

After power-up and personalization (PIN entry if required) PLS8-X starts reading data from the USIM. AT^SSET controls the presentation of "[^SSIM READY](#)" URC which indicates that the UE has finished this initial reading. Afterwards all AT commands that depend on USIM data can be used, e.g. phonebook and SMS related AT commands.

Syntax

<p>Test Command</p> <p>AT^SSET=?</p> <p>Response(s)</p> <p>^SSET: (list of supported <n>s)</p> <p>OK</p>										
<p>Read Command</p> <p>AT^SSET?</p> <p>Response(s)</p> <p>^SSET: <n></p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>										
<p>Write Command</p> <p>AT^SSET=[<n>]</p> <p>Response(s)</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>										
<table border="1"> <tr> <td>PIN</td> <td>MDM</td> <td>APP</td> <td>→</td> <td>Last</td> </tr> <tr> <td>-</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </table>	PIN	MDM	APP	→	Last	-	+	+	+	-
PIN	MDM	APP	→	Last						
-	+	+	+	-						

Unsolicited Result Code

[^SSIM READY](#)

This URC indicates that the UE has finished its initial USIM access.

Any attempt to access phonebook, SMS or other USIM data before having received the "[^SSIM READY](#)" URC, may either result in a "+CME: SIM busy" message or, in some cases, a couple of seconds delay before the command is executed.

Parameter Description

<n> ^{(num)(&V)(&W)}	
URC presentation mode	
0 ^(&F)	Disable " ^SSIM READY " URC.
1	Enable " ^SSIM READY " URC.

13.6 AT^SCID USIM Identification Number

AT^SCID serves to query the USIM identification number. This information is retrieved from USIM elementary file EF_{ICCID}; for details refer to 3GPP TS 11.11 [17], 3GPP TS 31.101 [18], 3GPP TS 31.102 [19].

Syntax

Test Command

```
AT^SCID=?
```

Response(s)

```
OK
```

Exec Command

```
AT^SCID
```

Response(s)

```
^SCID: <cid>
```

```
OK
```

```
ERROR
```

```
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cid>^(text)

USIM identification number.

14. Phonebook Commands

The AT commands described in this chapter allow the external application to access the phonebooks located in the PLS8-X's memory or on the attached Subscriber Identity Module (SIM).

14.1 AT+CPBS Select phonebook memory storage

AT+CPBS selects the active phonebook storage, i.e. the phonebook storage that all subsequent phonebook commands will be operating on.

The read command returns the currently selected **<storage>**, the number of **<used>** entries and the **<total>** number of entries available for this storage.

The test command returns all supported **<storage>**s as compound value.

As PLS8-X does not support voice calls no entries will be stored in "MC", "RC", "LD" phonebooks. Also no numbers will be stored to the "DC" phonebook.

Syntax

Test Command

AT+CPBS=?

Response(s)

+CPBS: (list of supported **<storage>**s)

OK

ERROR

+CME ERROR: **<err>**

Read Command

AT+CPBS?

Response(s)

+CPBS: **<storage>**, **<used>**, **<total>**

OK

ERROR

+CME ERROR: **<err>**

Exec Command

All records of the "MC", "RC", "DC" and "LD" phonebooks will be deleted.

AT+CPBS

Response(s)

OK

ERROR

+CME ERROR: **<err>**

Write Command

AT+CPBS=**<storage>**

Response(s)

OK

ERROR

+CME ERROR: **<err>**

Write Command

For write access to FD phonebook

AT+CPBS=<storage>, <pin>

Response(s)

OK
ERROR
+CME ERROR: <err>

PIN MDM APP → Last
+ + + + -

Reference(s)
3GPP TS 27.007 [48]

Parameter Description

<storage> ^(str)	
"SM" ^{(&F)(P)}	USIM phonebook Capacity: depending on USIM Location: USIM
"DC"	Dialed calls list Capacity: max. 100 entries Location: ME AT+CPBW command is not applicable to this storage.
"FD"	Fixed dialing phonebook Capacity: depending on USIM Location: USIM
"LD"	Last number dialed phonebook.
"MC"	Missed (unanswered received) voice calls list
"ME"	Mobile equipment phonebook Capacity: max. 500 entries Location: ME
"RC"	Received voice calls list
"EN"	Emergency number Capacity: depending on USIM or ME Location: USIM or ME Can be accessed without entering PIN. AT+CPBW command is not applicable to this storage.
"ON"	MSISDN list Availability and capacity: depending on USIM Location: USIM
"VM"	CPHS voice mailbox phonebook Capacity: depending on USIM Location: USIM
"SD"	Service dialing number phonebook. Read only. Capacity: depending on USIM Location: USIM
<used> ^(num)	
Value indicating the number of used locations in selected memory storage.	
<total> ^(num)	
Value indicating the maximum number of locations allowed in the selected memory storage.	

Notes

- Users should be aware that when using this AT command quickly after USIM PIN authentication the USIM data may not yet be accessible, resulting in a short delay before the requested AT command response is returned.
- To get write access to the "FD" phonebook the following input is required: `AT+CPBS="FD", "PIN2"`
- When using "EN" phonebook the numbers 911 and 112 must always be output by using `AT+CPBR` write command.
- Emergency number ("EN") phonebook can be accessed (using `AT+CPBS="EN"`) without entering PIN usually used by `AT+CPIN="PIN1"`. Then `AT+CPBS` read command and `AT+CPBR` write command are also possible without entering PIN.
- "LD" phonebook is only supported when corresponding Elementary File is available on USIM. Elementary Files belonging to "LD" phonebook are optional on USIM.

14.2 AT+CPBR Read from phonebook

AT+CPBR serves to read one or more entries from the phonebook selected with AT command AT+CPBS.

The AT+CPBR test command returns the location range supported by the current phonebook storage, the maximum length of <number> field and the maximum length of <text> field.

Note: Length information may not be available while SIM storage is selected. If storage does not offer format information, the format list contains empty parentheses.

The AT+CPBR write command determines the phonebook entry to be displayed with <location1> or a location range from <location1> to <location2>. Hence, if no <location2> is given only the entry at <location1> will be displayed.

If no entries are found at the selected location "+CME ERROR: not found" will be returned.

Syntax

<p>Test Command</p> <pre>AT+CPBR=?</pre> <p>Response(s)</p> <pre>+CPBR: (1-<maxloc>), <nlength>, <tlength> OK ERROR +CME ERROR: <err></pre>	<p>Write Command</p> <pre>AT+CPBR=<location1>[, <location2>]</pre> <p>Response(s)</p> <pre>[+CPBR: <location1>, <number>, <type>, <text>] [+CPBR: <location2>, <number>, <type>, <text>] OK ERROR +CME ERROR: <err></pre>										
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	+	-	<p>Reference(s)</p> <p>3GPP TS 27.007 [48], 3GPP TS 24.008 [41], 3GPP TS 11.11 [17], 3GPP TS 31.101 [18], 3GPP TS 31.102 [19]</p>
PIN	MDM	APP	→	Last							
+	+	+	+	-							

Parameter Description

<location1>^(num)

The first (lowest) location number within phonebook memory where to start reading. The maximum range supported by the current phonebook is given in the test command response.

If <location1> exceeds the upper bound <maxloc> (as indicated by the test command), command will respond with "+CME ERROR: invalid index".

<location2>^(num)

The last (highest) location number within phonebook memory where to stop reading. The maximum range supported by the current phonebook is given in the test command response.

If both <location1> and <location2> are in the range indicated by the test command parameter <max-loc>, the list of entries will be output and terminated with "OK". If <location2> exceeds the range indicated by the test command parameter <maxloc>, the command returns only "+CME ERROR: invalid index".

`<number>`^(str)

Phone number in format specified by `<type>`, it may be an empty string.

`<type>`^(num)

Type of address octet, which defines the used type of number (ton) and the numbering plan identification (npi). Possible values are:

128	Restricted <code><number></code> includes unknown type and format.
145	Dialing string <code><number></code> includes international access code character '+'. National number <code><number></code> . Network support of this type is optional.
161	Dialing string <code><number></code> has been saved as ASCII string and includes non-digit characters other than "*", "#", "+" or "P". Note that phonebook entries saved with this type cannot be dialed.
209	Dialing string <code><number></code> contains "*", "#" characters for Supplementary Service codes. Network support of this type is optional.
255	Otherwise.
129	

`<text>`^{(str)(+CSCS)}

Text assigned to a phone number. The maximum length for this parameter is given with test command response parameter `<tlength>`.

If using an ASCII terminal characters which are coded differently in ASCII and GSM have to be entered via escape sequences as described in Section 1.7, [Supported character sets](#).

`<maxloc>`^(num)

Maximum location number for the currently selected storage. For phonebooks located on SIM, this value varies depending on the SIM card. See [AT+CPBS](#) for typical values.

`<nlength>`^(num)

Maximum length of phone number for "normal" locations. Depending on the storage a limited number of locations with extended memory is available per phonebook. These locations allow storing numbers with twice the standard length, which is $2 \times \text{<nlength>}$ digits for normal numbers, but only `<nlength>` digits for numbers saved with `<type>=209`.

`<tlength>`^(num)

Maximum length of `<text>` assigned to the telephone number. The value indicated by the test command is given in octets. If the `<text>` string is given in GSM characters, each character corresponds to one octet. If the `<text>` string is given in UCS2, the maximum number of characters depends on the coding scheme used for the alpha field of the SIM. In the worst case the number of UCS2 characters is at least one less than half the number of GSM characters. If the `<text>` string is given in IRA characters, each character corresponds to one octet. In some cases, e.g. escape sequence, it is not possible to store the full `<tlength>` on SIM.

For a detailed description please refer to 3GPP TS 11.11 [17], 3GPP TS 31.101 [18], 3GPP TS 31.102 [19], Annex B.

Notes

- Users should be aware that when using this AT command quickly after SIM PIN authentication the SIM data may not yet be accessible, resulting in a short delay before the requested AT command response is returned.
- When a supplementary service command was stored to the phonebook along with a "+" within the phone number please note that the UE will not display the "+" after restart, but correctly handles the phone number as international type.
- When emergency number ("EN") phonebook is selected by [AT+CPBS](#) write command the numbers 911 and 112 must always be output by using [AT+CPBR](#) write command.

- Emergency number ("EN") phonebook can be accessed (using `AT+CPBS="EN"`) without entering PIN usually used by `AT+CPIN="PIN1"`. Then `AT+CPBS` read command and `AT+CPBR` write command are also possible without entering PIN.
- There is no restriction reading unsupported values for `<type>`.

Example

```
AT+CPBR=?
```

```
+CPBR: (1-100),20,17
```

```
AT+CPBR=1,3
```

```
+CPBR: 1,"+999999",145,"Charlie"
```

```
+CPBR: 2,"+777777",145,"Bill"
```

```
+CPBR: 3,"+888888",145,"Arthur"
```

First run the `AT+CPBR` test command to find out the maximum range of entries stored in the active phonebook.

PLS8-X returns the supported values, where 100 is the supported range of location numbers, 20 is the length of the phone number and 17 is the maximum length of the associated text.

Then use the `AT+CPBR` write command to display the phonebook entries sorted by location numbers.

14.3 AT+CPBW Write into phonebook

The [AT+CPBW](#) write command can be used to create, edit and delete a phonebook entry at a [<location>](#) of the active storage selected with [AT+CPBS](#).

If [<storage>](#)="FD" (SIM fixed dialing numbers) is selected, PIN2 authentication has to be performed prior to any write access.

The [AT+CPBW](#) test command returns the location range supported by the current storage, the maximum length of the [<number>](#) field, the range of supported [<type>](#) values and the maximum length of the [<text>](#) field. Note: The length may not be available while SIM storage is selected. If storage does not offer format information, the format list contains empty parentheses.

Syntax

Test Command AT+CPBW=? Response(s) +CPBW: (1- <maxloc>), <nlength> , (list of supported <type> s), <tlength> OK ERROR +CME ERROR: <err>											
Write Command AT+CPBW=[<location>][, <number>][, <type>][, <text>]] Response(s) OK ERROR +CME ERROR: <err>											
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>+</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	+	+	+	+	-	Reference(s) 3GPP TS 27.007 [48] , 3GPP TS 24.008 [41] , 3GPP TS 11.11 [17] , 3GPP TS 31.101 [18] , 3GPP TS 31.102 [19]
PIN	MDM	APP	→	Last							
+	+	+	+	-							

Parameter Description

[<location>](#)^(num)
 Location number within phonebook memory. The maximum range supported by each storage type is indicated in the test command response. If [<location>](#) is not given, the first free entry will be used. If [<location>](#) is given as the only parameter, the phonebook entry specified by [<location>](#) is deleted.

[<number>](#)^(str)
 Phone number in format specified by [<type>](#). Parameter must be present, although it may be an empty string. Alphabetic characters are not permitted. The [<number>](#) may contain dialstring modifiers "*", "#", "+" or "P". If other printable non-alphabetic characters are used the entry needs to be saved with [<type>](#)=209. Otherwise, if [<type>](#)=209 is not used any non-digit characters other than "*", "#", "+" or "P" will be removed from the string and only accepted modifiers from the GSM alphabet will be saved. A [<number>](#) saved with [<type>](#)=209 requires double memory. In order to fit into a standard location, the number needs to be reduced to a maximum length of [<nlength>](#)/2, including all digits and dial string modifiers. Extended locations may be used as stated below for [<nlength>](#).

14.3 AT+CPBW

<type>^(num)

Type of address octet, which defines the used type of number (ton) and the numbering plan identification (npi). Please consider that for types other than 129 or 145 dialing from phonebook with `ATD<mem><n>` is, depending on the network, not always possible (refer 3GPP TS 24.008 [41], subclause 10.5.4.7 for details).

If **<type>** is not specified the unknown **<type>**=129 is used. If **<number>** contains a leading "+" **<type>**=145 (international) is used.

Supported values are:

128	Restricted <number> includes unknown type and format.
145	Dialing string <number> includes international access code character "+".
161	National number <number> . The network support for this type is optional.
209	Dialing string <number> will be saved as ASCII string. This is the default value, if <type> is not specified explicitly and characters other than "*", "#", "+" or "P" are included in <number> . Note that phonebook entries saved with this type cannot be dialed.
255	Dialing string <number> contains "*", "#" characters for Supplementary Service codes. Network support of this type is optional.
129	Unknown number. If <type> is unknown and the <number> contains a leading "+", then this sign is removed.

<text>^{(str)(+CSCS)}

Text assigned to the phone number. The maximum length of this parameter is given in the test command response **<tlength>**. When using an ASCII terminal, characters which are coded differently in ASCII and GSM have to be entered via escape sequences as described in Section 1.7, [Supported character sets](#).

<maxloc>^(num)

Maximum number of locations supported by the currently selected storage. For phonebooks located on SIM, this value varies depending on the SIM card. See [AT+CPBS](#) for typical values.

<nlength>^(num)

Maximum length of phone number for "normal" locations. Depending on the storage, a limited number of locations with extended memory is available per phonebook. These locations allow storing numbers with twice the standard length, which is 2***<nlength>** digits for normal numbers, but only **<nlength>** digits for numbers saved with parameter **<type>**= 209. If all extended locations of the selected phonebook are used up, then any attempt to write a number which requires extended memory will be denied with "+CME ERROR: memory full".

<tlength>^(num)

Maximum length of **<text>** assigned to the telephone number. The value indicated by the test command is given in octets. If the **<text>** string is given in GSM characters, each character corresponds to one octet. If the **<text>** string is given in UCS2, the maximum number of characters depends on the coding scheme used for the alpha field of the SIM. In the worst case the number of UCS2 characters is at least one less than half the number of GSM characters. If the **<text>** string is given in IRA characters, each character corresponds to one octet. In some cases, e.g. escape sequence, it is not possible to store the full **<tlength>** on SIM.

For a detailed description please refer to 3GPP TS 11.11 [17], 3GPP TS 31.101 [18], 3GPP TS 31.102 [19], Annex B.

Notes

- Users should be aware that when using this AT command quickly after SIM PIN authentication the SIM data may not yet be accessible, resulting in a short delay before the requested AT command response is returned.
- See for more details [AT+CPBS](#) select command which phonebook <storage> is possible to write by the user.
- DTMF transmission:
If a dial string contains the call modifier "P" the digits after this call modifier will be saved as DTMF tones. The DTMF tones 'A','B','C' and 'D' can not be saved due to BCD limitations.

Examples

EXAMPLE 1

Make a new phonebook entry at the first free location

```
AT+CPBW=,"+431234567",145,"international"
```

EXAMPLE 2

Delete entry at location 1

```
AT+CPBW=1
```

EXAMPLE 3

The following examples are provided to illustrate the effect of writing phonebook entries with different types of dial string modifiers in <number>

```
AT+CPBW=5,"12345678",,"Arthur"  
AT+CPBW=6,"432!P-765()&54*654#",,"John"  
AT+CPBW=7,"432!P-765()&54*654#",129,"Eve"  
AT+CPBW=8,"432!P-765()&54*654#",145,"Tom"  
AT+CPBW=9,"432!P-765()&54*654#",209,"Richard"
```

EXAMPLE 4

Read phonebook entries from locations 5 - 9 via [AT+CPBR](#)

```
+CPBR:5,"12345678",129,"Arthur"  
+CPBR:6,"432!P-765()&54*654#",209,"John"  
+CPBR:7,"432P76554*654#",129,"Eve"  
+CPBR:8,"+432P76554*654#",145,"Tom"  
+CPBR:9,"432!P-765()&54*654#",209,"Richard"
```

14.4 AT+CNUM Read own numbers

[AT+CNUM](#) returns the subscribers own number(s) from the SIM.

Syntax

Test Command	
AT+CNUM=?	
Response(s)	
OK	
Exec Command	
AT+CNUM	
Response(s)	
[+CNUM: [<alpha>], <number> , <type>]	
[+CNUM: ...]	
OK	
ERROR	
+CME ERROR: <err>	
PIN MDM APP ↗ Last	Reference(s)
+ + + + -	3GPP TS 27.007 [48]

Parameter Description

[<alpha>](#)^(str)

Optional alphanumeric string associated with [<number>](#).

[<number>](#)^(str)

Phone number in format specified by [<type>](#).

[<type>](#)^(str)

Type of address octet, see also: [AT+CPBR <type>](#).

Notes

- Users should be aware that when using this AT command quickly after SIM PIN authentication the SIM data may not yet be accessible, resulting in a short delay before the requested AT command response is returned.
- The subscribers own number(s) are stored in the "ON" phonebook and can be set using the [AT+CPBW](#) command.
- For alphanumeric representation the number stored in the phonebook must be identical to the number transported over the network - then the associated name will be recognized.

15. GNSS Commands

PLS8-X integrates a GNSS engine (Global Navigation Satellite System) which supports GPS (Global Positioning System) and GLONASS (Globalnaja Nawigazionnaja Sputnikowaja Sistema) based on the NMEA 0183 V2.3 protocol.

To configure, activate or deactivate the GNSS engine, to choose Standalone GNSS or A-GNSS operation, to start and stop NMEA output, to select the NMEA output frequency, please use the `AT^SGPSC` command.

A-GNSS (Assisted GNSS) will improve the startup performance, i.e. the Time to First Fix (TTFF), if the GNSS engine has not yet precise location and time information. For A-GNSS, valid GpsOneXTRA assistance data shall be stored to the UE's FFS and injected into the GNSS receiver by using the `AT^SBNW` command. The assistance data files provided on the GpsOneXTRA server are named xtra.bin for GPS only and xtra2.bin for GPS + GLONASS. The XTRA data is valid up to 7 days, although after 3 days the accuracy would start to degrade faster. We recommend to update XTRA data every 2 days. To check the validity of the injected XTRA data you can use the `AT^SGPSC` parameter `<InfoXtraDurationMinutes>`. In most cases, however, it will be sufficient to activate the GNSS driver since the GNSS engine dynamically determines the best startup scenario depending on the available position, time, Almanac and/or Ephemeris data.

If Multiplex mode is started NMEA data will be output on the third Multiplex channel. Otherwise NMEA data will be printed to the dedicated NMEA interface (depending on the settings made with `AT^SSRVSET`). The dedicated NMEA interfaces and the third Multiplex channel do not accept any AT commands. If the serial port ASC0 is selected for NMEA output please consider that NMEA data is transmitted at a fixed bit rate of 115200 bps regardless of the `AT+IPR` value set on ASC0.

In addition, the commands `AT^SGPSC="Nmea/Output/,"last"` and `AT^SGPSC="NMEA/URC","on"` can be used to get all GNSS information on the AT command instances(s), eliminating the need to poll the dedicated NMEA instance.

The UE may connect to an active or passive GNSS antenna. Active GNSS antennas need an extra power supply which can be switched on or off with `AT^SGPSC`. Take care that the antenna is capable of GPS and GLONASS as well (if required). Details on how to connect and handle active or passive antennas can be found in [2].

15.1 GNSS Sentences

All of the standard NMEA sentences have a two letter prefix defining the device. One NMEA sentence set consists of the sentences listed below. Each sentence starts with a two letter prefix followed by a three letter sequence which indicates the sentence contents. The data is provided in ASCII format.

For GPS the prefix is GP. PLS8-X supports the following GPS related NMEA sequences:

- GPGGA - Global Positioning System Fix Data, Time, Position and fix related data for a GNSS receiver
- GPRMC - Recommended minimum data for GPS
- GPGSV - Detailed satellite data
- GPGSA - Overall satellite data
- GPVTG - Vector track and speed over the ground

The device prefix "GL" is for GLONASS related data. "GN" refers to GPS and GLONASS together. PLS8-X supports the following GLONASS related NMEA sentences:

- GLGSV - Detailed satellite data
- GNGSA - Overall satellite data
- GNGNS - Positioning System

The following NMEA sentences are switchable via `<DeadReckoningVal>` of the `AT^SGPSC` command.

The device prefix "PC" is for Gemalto related data.

- PCWMV - a proprietary Gemalto NMEA sentence
- GPZDA - consists of NMEA 0183 standard Time and Date
- GPGRS - consists of the GPS Range Residuals

The PCWMV sentence will be decoded in the following way:

PCWMV,<1>,<2>,<3>,<4>,<5>,<6>,<7>,<8>*CS

Meaning of PCWMV fields:

- <1> East velocity (m/s)
- <2> North velocity (m/s)
- <3> Up velocity (m/s)
- <4> Position standard deviation estimate (m)
- <5> Latitude uncertainty (m)
- <6> Longitude uncertainty (m)
- <7> Vertical uncertainty (m)
- <8> Velocity uncertainty (m/s)
- CS) Checksum.

15.2 GNSS Power Saving Considerations

If GNSS is switched on (see [AT^SGPSC](#) parameters [<EngineVal>](#) and [<OutVal>](#)), both GPS and GLONASS may be employed for position calculation. The GNSS engine will automatically reduce power consumption when signal quality is good. Usage of GLONASS is added only if needed to get position fix. If the GPS signal is sufficient to get a fix, the GNSS engine automatically deactivates usage and output of GLONASS. See also [AT^SGPSC](#) parameter [<GlonassVal>](#).

15.3 ^SGPSE GNSS Event Notification

The following URCs provide GNSS related status information. The URCs show up on the instance specified for URC output, by default the "APP" instance (see [AT^SCFG](#), parameter `<urcDestIfc>`).

Unsolicited Result Codes

URC 1

NMEA buffer notification.

^SGPSE: `<UrcType>`, `<BufferStatus>`, `<BufferCount>`

URC 2

Position fix notification.

^SGPSE: `<UrcType>`, `<PositionStatus>`

URC 3

GPS XTRA file invalidity notification

^SGPSE: `<UrcType>`, `<InfoUrcMinutes>`

Parameter Description

<code><UrcType></code> ^(num)	
0	<p>URC type "NMEA buffer notification". This URC type is enabled by setting the AT^SGPSC "Nmea/Output" subcommand with parameter <code><OutVal>= "buffered"</code>. The buffer mechanism and the URC are disabled if <code><OutVal>= "on"</code> or "off". If the NMEA buffering mechanism is active (see <code><OutVal></code>), two URCs will be generated: The first URC will show up when approximately 80% of the buffer is filled. This way, the application has enough time to wake up and select <code><OutVal>= "on"</code> in order to read and empty the buffer and get new NMEA sentences. The second URC will show up when the buffer is full.</p>
1	<p>URC type "Position fix notification". This URC type is enabled by setting the AT^SGPSC "Nmea/Urc" subcommand with parameter <code><FixUrcVal>= "on"</code>. <code><FixUrcVal>= "off"</code> disables the URC. The URC is emitted each time when the state of the positioning fix changes, i.e. when the fix becomes valid or invalid.</p>
2	<p>URC type "XTRA file invalidity notification". This URC type is enabled by setting the AT^SGPSC subcommand "Info" with <code><InfoType>= "Urc"</code> and <code><InfoUrcVal>= "on"</code>. Parameter <code><InfoUrcMinutes></code> specifies the number of minutes the URC shall show up before the injected XTRA file validity expires. <code><InfoUrcVal>= "Off"</code> disables the URC.</p>

<code><BufferStatus></code> ^(num)	
Status of NMEA buffer	
0	Buffer fill status is 80%.
1	<p>Buffer is full. If the buffer is not emptied buffering stops to retain the data buffered data. This allows the TE to store the buffered data, e.g. for position tracking.</p>

<code><BufferCount></code> ^(num)	
GNSS NMEA buffer count	
Number of bytes located in NMEA buffer	

<PositionStatus>^(num)

0	Engine has no position fix.
1	Engine gets a fix position.

<InfoUrcMinutes>^(num)

0	Injected XTRA file is invalid.
1...10080	Injected XTRA file will be invalid in <InfoUrcMinutes> minutes.

15.4 AT^SGPSC GNSS Configuration

AT^SGPSC is a configuration command that can be used to set GNSS parameters and to switch the GNSS engine on and off.

Syntax

Test Command

AT^SGPSC=?

Response(s)

```
^SGPSC: "Engine", (list of supported <EngineVal>s)
^SGPSC: "Info", (list of supported <InfoType>s), (list of supported <InfoUrcVal>s), (list of supported <InfoUrcMinutes>s)
^SGPSC: "Nmea/Freq", (list of supported <FreqVal>s)
^SGPSC: "Nmea/Glonass", (list of supported <GlonassVal>s)
^SGPSC: "Nmea/DeadReckoning", (list of supported <DeadReckoningVal>s)
^SGPSC: "Nmea/DRSync", (list of supported <DRSyncVal>s)
^SGPSC: "Nmea/Output", (list of supported <OutVal>s)
^SGPSC: "Nmea/Urc", (list of supported <FixUrcVal>s)
^SGPSC: "Power/Antenna", (list of supported <AntVal>s)
OK
ERROR
+CME ERROR: <err>
```

Read Command

AT^SGPSC?

Response(s)

```
^SGPSC: "Engine", <EngineState>
^SGPSC: "Info", "Urc", [<InfoUrcVal>][, <InfoUrcMinutes>]
^SGPSC: "Nmea/Freq", <FreqVal>
^SGPSC: "Nmea/Glonass", <GlonassVal>
^SGPSC: "Nmea/DeadReckoning", <DeadReckoningVal>
^SGPSC: "Nmea/DRSync", <DRSyncVal>
^SGPSC: "Nmea/Output", <OutVal>
^SGPSC: "Nmea/Urc", <FixUrcVal>
^SGPSC: "Power/Antenna", <AntVal>
OK
ERROR
+CME ERROR: <err>
```

Write Command

Activating or deactivating GNSS engine.

AT^SGPSC="Engine", <EngineVal>

Response(s)

```
^SGPSC: "Engine", <EngineState>[, <AssistDataError>]
OK
ERROR
+CME ERROR: <err>
```

Write Command

If <InfoType>= "Xtra": Requesting validity of XTRA file.

AT^SGPSC="Info", "Xtra"

Response(s)

```
^SGPSC: "Info", "Xtra", <InfoXtraWeek>, <InfoXtraMinute>, <InfoXtraDurationMinutes>
OK
```

Write Command (Continued)

If **<InfoType>**= "Xtra": Requesting validity of XTRA file.

AT^SGPSC="Info", "Xtra"

Response(s)

ERROR

+CME ERROR: **<err>**

Write Command

If **<InfoType>**= "Urc": Configuring "**^SGPSE**" URC type "XTRA file invalidity notification".

AT^SGPSC="Info", "Urc", [**<InfoUrcVal>**][, [**<InfoUrcMinutes>**]

Response(s)

^SGPSC: "Info", "Urc", **<InfoUrcVal>**[, **<InfoUrcMinutes>**]

OK

ERROR

+CME ERROR: **<err>**

Write Command

Setting frequency of position requests.

AT^SGPSC="Nmea/Freq", [**<FreqVal>**]

Response(s)

^SGPSC: "Nmea/Freq", **<FreqVal>**

OK

ERROR

+CME ERROR: **<err>**

Write Command

Setting GLONASS depending output.

AT^SGPSC="Nmea/Glonass", [**<GlonassVal>**]

Response(s)

^SGPSC: "Nmea/Glonass", **<GlonassVal>**

OK

ERROR

+CME ERROR: **<err>**

Write Command

Setting dead reckoning related NMEA output.

AT^SGPSC="Nmea/DeadReckoning", [**<DeadReckoningVal>**]

Response(s)

^SGPSC: "Nmea/DeadReckoning", **<DeadReckoningVal>**

OK

ERROR

+CME ERROR: **<err>**

Write Command

Configuring DR Sync line.

AT^SGPSC="Nmea/DRSync", [**<DRSyncVal>**]

Response(s)

^SGPSC: "Nmea/DRSync", **<DRSyncVal>**

OK

ERROR

+CME ERROR: **<err>**

Write Command

Configuring output of NMEA sentences.

AT^SGPSC="Nmea/Output", <OutVal>

Response(s)

^SGPSC: "Nmea/Output", <OutVal>

OK

ERROR

+CME ERROR: <err>

If <OutVal> is "last":

[^SGPSC: ...]

[Last NMEA sentence set received on dedicated NMEA instance]

OK

ERROR

+CME ERROR: <err>

Write Command

Configuring "^SGPSE" URC type "Position fix notification".

AT^SGPSC="Nmea/Urc", <FixUrcVal>

Response(s)

^SGPSC: "Nmea/Urc", <FixUrcVal>

OK

ERROR

+CME ERROR: <err>

Write Command

Configuring antenna supply.

AT^SGPSC="Power/Antenna", <AntVal>

Response(s)

^SGPSC: "Power/Antenna", <AntVal>

OK

ERROR

+CME ERROR: <err>

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<EngineVal>^(str)

This parameter switches the GNSS engine on or off.

"0" ^(P)	GNSS engine off.
"1"	Start GNSS engine without employing GpsOneXTRA assistance data. The GNSS engine dynamically determines the best startup scenario depending on the available position, time, Almanac and/or Ephemeris data. However, please consider that if GpsOneXTRA assistance data is still injected (due to previously used mode 2), this data might still be effective. To enable cold start in such case first delete assistance data using <code>AT^SBNW="agps",-1</code> before employing <code>AT^SGPSC="Engine","1"</code> .
"2"	Start GNSS engine in A-GNSS mode by employing the GpsOneXTRA assistance data previously stored to the FFS and injected to the GNSS engine with <code>AT^SBNW</code> . Remember that the RTC is correctly set (<code>AT+CCLK</code>) to Greenwich Mean Time (GMT): 0.

Using mode 2 without GpsOneXTRA assistance data:
If the following conditions are met you can use mode 2 instead of mode 1 even though GpsOneXTRA assistance data were not injected beforehand:
Take care that the RTC is set to Greenwich Mean Time (GMT). If Ephemeris data is still valid, mode 2 enables faster TTFF than mode 1. If Ephemeris data has expired, TTFF is about the same in mode 2 or mode 1.
Yet, when doing so, please ignore the [<AssistDataError>](#) code 3 returned (because no GpsOneXTRA assistance data are found):
Example:
AT^SGPSC="Engine", "2"
^SGPSC: "Engine", "1", "3"
OK

<EngineState>^(str)

This parameter shows the GNSS engine state.

"0"	GNSS engine off.
"1"	GNSS engine on.

<AssistDataError>^(str)

This parameter may appear in the write command response only if an error occurs while GpsOneXTRA assistance data are injected into the GNSS engine.

Possible error codes:

"1"	Bad CRC.
"2"	Validity time is out of range.
"3"	Internal resource error.
"4"	GNSS subsystem currently busy.
"5"	Time info error (AT+CCLK not correctly set to Greenwich Mean Time (GMT): 0).
"6"	GNSS subsystem is locked.
"7"	GNSS state error.
"8"	Other error.

<InfoType>^(str)

This parameter specifies the type of information which will be requested.

"Xtra"	Check the validity of the XTRA file which was successfully injected in the GNSS engine before. The write command AT^SGPSC="Info","Xtra" requests the validity of the injected XTRA.bin file and returns the parameters <InfoXtraWeek> , <InfoXtraMinute> and <InfoXtraDurationMinutes> .
"Urc"	Refers to the " ^SGPSE " URC type "XTRA file invalidity notification". The URC shall be enabled / disabled by setting the <InfoUrcVal> parameter. Depending on the <InfoUrcMinutes> parameter, the URC will be emitted either before or at the moment when the validity of the injected XTRA file expires. XTRA file validity is checked at 1 minute frequency. The calculation uses AT+CCLK time. This must be GMT0.

<InfoXtraWeek>^(str)

This parameter shows the GNSS week (time stamp since 1st epoch January 6th, 1980 Sunday 0:00) inside the injected XTRA.bin file. Together with [<InfoXtraMinute>](#) the value can be used to manually calculate the time difference to GMT0 time.

<InfoXtraMinute>^(str)

This parameter shows the GNSS minutes of the current week inside the injected XTRA.bin file. When manually calculating the time difference to GMT0 time, this value has to be added to the <InfoXtraWeek> value.

0...10080 Time in minutes.

<InfoXtraDurationMinutes>^(str)

This parameter counts down the validity duration of the currently injected XTRA file in minutes. The calculation uses AT+CCLK time. This must be GMT0.

“0“ No saved XTRA file or the saved XTRA file is no longer valid.
1...10080 Validity of injected XTRA file in minutes.

<InfoUrcVal>^(str)

This parameter enables / disables the “^SGPSE” URC type “XTRA file invalidity notification”. Parameter <InfoUrcMinutes> is applicable only if parameter <InfoUrcVal> is set to “on”. By default, the URC is emitted on the “APP” instance (see AT^SCFG, parameter <urcDestIfc>).

“off“(P) Disable the “^SGPSE” URC type “XTRA file invalidity notification”.
“on“ Enable the “^SGPSE” URC type “XTRA file invalidity notification”.

<InfoUrcMinutes>^(num)

This parameter specifies the number of minutes the “^SGPSE” URC type “XTRA file invalidity notification” shall show up before the validity of the injected XTRA file expires.

[0] URC shall show up exactly at the time when the validity of the injected XTRA file has expired.
1...10080 Number of minutes the URC shall show up before the validity of the injected XTRA file expires.

<FreqVal>^(num)

This parameter specifies the frequency of position requests (in seconds).
If a position fix is available the GNSS engine will start to output NMEA messages at the given <FreqVal>. If there is no position fix yet, then NMEA data will be output usually every second, regardless of the specified frequency and until the position fix is found. This applies, for example, after starting the GNSS engine (see <EngineVal>) and the output of data is activated (see <OutVal>), or when a position fix was lost for some reason (due to poor signal quality).

1(P)...65534 NMEA data is output every n seconds.
During the NMEA output intervals, the GNSS engine enters IDLE mode and saves power.
Therefore, setting the GNSS engine into IDLE state is a trade-off between trying to save power and maintaining or getting a position fix. The longer the time set with <FreqVal>, the more time will be required to get a position fix.

<GlonassVal>^(str)

This setting can only be changed when the GNSS engine is off (see parameter <EngineVal>).

“off“ Disables output of GLONASS sentences on the dedicated NMEA instance. Nevertheless, GLONASS data is still received by the UE as long as required for positional calculations. Only if the GPS signal is sufficient, GLONASS is automatically deactivated to reduce power consumption.
“on“(P) Enables output of GLONASS sentences, but only as long as used for position fix.

<DeadReckoningVal>^{(str)(NV)}

This parameter configures additional NMEA output of Dead Reckoning related information (see Section 15.1, GNSS Sentences).

Parameter is global for all interfaces, non-volatile and will not be reset by AT&F.

The setting can only be changed when the GNSS engine is off (see parameter <EngineVal>).

“off”^(D) No output of Dead Reckoning related data.
 “on” The additional NMEA sentences for Dead Reckoning will be output.

<DRSyncVal>^{(str)(NV)}

This parameter enables or disables a 1PPS (pulse per second) signal which can be used as an accurate clock signal.

When enabled 1 pulse per second coming from the GNSS receiver's own signal clock is generated on the DR_SYNC line which is available as an alternative function of GPIO1. The accuracy is +/-5 ms, pulse length is 1 ms. The 1PPS signal is provided as long as synchronized with the satellite clock, and continues for approximately 6 minutes after GNSS signal loss.

The 1PPS signal will be accurate only if the GNSS engine is active. Therefore, when using the 1PPS signal, the <FreqVal> interval should not exceed 5 sec to avoid that the GNSS engine enters IDLE state. Also, S <OutVal> shall be set to "on" or "buffered".

This parameter can only be changed when the GNSS engine is off (see parameter <EngineVal>). Changed settings take effect only after next UE restart. Parameter is global for all interfaces, non-volatile and will not be reset by AT&F.

When the DR_SYNC line is enabled, GPIO1 is not usable by GPIO related commands (see AT^SCPIN). Both functions are mutually exclusive.

“off”^(D) 1PPS signal on DR_SYNC line is disabled.
 “on” 1PPS signal on DR_SYNC line is enabled.

<OutVal>^(str)

This parameter configures the output of NMEA sentences (see Section 15.1, GNSS Sentences).

“off”^(P) No output, no buffering of NMEA sentences. Previously buffered NMEA sentences will be discarded. The “^SGPSE” URC for buffer notification is deactivated.
 “on” NMEA sentences will be output on the dedicated NMEA port at the frequency set with <FreqVal>. (For NMEA port settings see AT^SSRVSET). Buffering is deactivated. Previously buffered NMEA sentences will be output (thereby freeing the buffer) before printing new NMEA sentences. If there is no previously buffered data, printing new NMEA sentences starts instantly. The “^SGPSE” URC for buffer notification is deactivated.
 “buffered” No NMEA output on dedicated NMEA port. NMEA sentences will be buffered. The “^SGPSE” URC for buffer notification is activated to notify the TE when the buffer becomes full. If buffering is activated then the TE has to enable NMEA output again in order to get the buffered data and to empty the buffer. This shall be done by selecting <OutVal>= "on". The “^SGPSE” URC for buffer notification may be used to trigger the TE to start reading the buffer. The first URC “^SGPSE: 0,0, x” will be generated when the buffer reaches 80% capacity. When full, the second URC “^SGPSE: 0,1, x” will be generated.

Buffer size: The buffer will hold NMEA data for at least one minute (assuming a max. NMEA sentence length of 640 byte, max. 8 sentences per update and an update interval of one second). The TE may extend the buffering time by increasing the frequency with <FreqVal>. When the buffer is full and not emptied the most recent NMEA sentences will be discarded.

Benefit of buffering: The mechanism of switching back and forth between NMEA output and NMEA buffering can be used, for example, to save power for NMEA output or to store the buffered NMEA data to a log file for position tracking.

“last” This option can be used to query any time the NMEA sentence set most recently received by the GNSS engine and stored in an internal buffer. The benefit is that the NMEA data is instantly returned on the AT command instance, eliminating the need to poll the dedicated NMEA instance. The response comes as one NMEA sentence set containing the sentences defined in Section 15.1, [GNSS Sentences](#). It is provided in ASCII format (incl. "\$" character).

<FixUrcVal>^(str)

This parameter enables / disables the "^SGPSE" URC type "Position fix notification" that reports changes of the positioning fix state. For details see "^SGPSE" parameter <PositionStatus>. The advantage is that the information on the positioning state is displayed on an AT command instance (not on the NMEA instance). By default, the URC is emitted on the "APP" instance (see AT^SCFG, parameter <urcDestIfc>).

“off”^(D) Disable URC.
“on” Enable URC.

<AntVal>^(str)

This parameter configures the GNSS antenna power supply.

“off” Antenna power off.
“on” Antenna power on.
“auto”^(P) Antenna power will be automatically switched on or off depending on GNSS engine activity. This mechanism takes effect either if the GNSS engine is activated with <EngineVal> or if an E-911 emergency call is established by Control Plane.

15.5 Examples of How to Configure and Use GNSS

Below you can find selective examples of how to configure and use the PLS8-X's integrated GNSS engine.

15.5.1 Loading Xtra.Bin File and Activating A-GNSS Start Mode

To take advantage of A-GNSS ensure that valid GpsOneXTRA assistance data (in short XTRA file) is available. To do so, first download a new GpsOneXTRA binary file via HTTP from one of the gpsOneXtra assistance web-servers. The files are named xtra.bin for GPS only and xtra2.bin for GPS + GLONASS. Save the received xtra.bin or xtra2.bin file to your local memory and check the exact file size (approximately 40kB).

- <http://xtra1.gpsonextra.net/xtra.bin>
- <http://xtra2.gpsonextra.net/xtra.bin>
- <http://xtra3.gpsonextra.net/xtra.bin>
- <http://xtra1.gpsonextra.net/xtra2.bin>
- <http://xtra2.gpsonextra.net/xtra2.bin>
- <http://xtra3.gpsonextra.net/xtra2.bin>

Next, use [AT+CCLK](#) to set the RTC. Then, use [AT^SBNW](#) to store the GpsOneXTRA assistance data on the FFS. If [AT^SBNW](#) returns the responses "AGPS END OK" and "OK" the XTRA file will be injected to the GNSS engine. Finally, use [AT^SGPSC](#) to switch on the GNSS engine.

AT+CCLK="12/01/20,13:15:57"	Set PLS8-X RTC to Greenwich Mean Time (instead of local time).
OK	
AT^SGPSC="Engine","0"	Deactivate the GNSS engine.
^SGPSC: "Engine","0"	
OK	
AT^SBNW=agps,-1	Optional: Remove existing xtra.bin file from GNSS receiver and FFS.
CONNECT	
AGPS READY: RESET GPS ENGINE AND DELETE XTRA FILE ...	
AGPS: END OK	
OK	
AT^SBNW="agps",38521	Write new XTRA file to FFS. File size is 38521 bytes.
CONNECT	
AGPS READY: SEND FILE ...	New XTRA file is successfully stored to the FFS and injected into the GNSS engine.
AGPS: END OK	
OK	
AT^SGPSC="Power/Antenna","on"	For active antenna only: Switch on antenna power supply.
^SGPSC: "Power/Antenna","on"	
OK	
AT^SGPSC="Engine","2"	Switch on GNSS engine by using the injected XTRA file. The response confirms that the GNSS engine is active.
^SGPSC: "Engine","1"	
OK	
AT^SGPSC="NMEA/Output","on"	Switch on output of NMEA sentences.
^SGPSC: "Nmea/Output","on"	
OK	

NMEA output will instantly start on the dedicated NMEA port. The example shows a position fix.

```
....
$GPGGA,123521.0,5232.017893,N,01316.443884,E,1,05,3.7,198.0,M,43.0,M,,*5C
$GPVTG,,T,0.0,M,0.0,N,0.0,K,A*0D
$GPRMC,123521.0,A,5232.017893,N,01316.443884,E,0.0,,270711,,,A*44
$GPGSA,A,3,09,14,25,27,29,,,,,,,,,6.4,3.7,5.2*36
$GPGSV,3,1,12,01,,,29,02,19,122,19,09,50,142,26,14,38,288,26*46
$GPGSV,3,2,12,25,43,265,38,27,38,140,36,29,09,205,31,04,24,075,*78
$GPGSV,3,3,12,12,82,293,,17,11,043,,32,03,347,,30,,,*4B
$GPGGA,123522.0,5232.017872,N,01316.443885,E,1,06,1.9,198.0,M,43.0,M,,*5E
....
```

15.5.2 Trying to Load Invalid XTRA File

```
AT^SBNW=agps, -1
CONNECT
AGPS READY: RESET GPS ENGINE AND DELETE FILE ...
AGPS END OK
OK
AT^SBNW="agps", 47616
CONNECT
AGPS READY: SEND FILE ...
BAD CRC
ERROR
```

Optional: Remove existing xtra.bin file from FFS.

Write new XTRA file to FFS. Specified number of bytes is greater than actual XTRA file size.

Wrong check sum. File not saved.

15.5.3 Starting GNSS without Aiding

```
AT^SGPSC="Power/Antenna", "on"
^SGPSC: "Power/Antenna", "on"
OK
AT^SGPSC="Engine", "1"
^SGPSC: "Engine", "1"
OK
AT^SGPSC="NMEA/Output", "on"
^SGPSC: "Nmea/Output", "on"
OK
```

For active antenna only: Switch on antenna power supply.

Switch on GNSS engine.

NMEA output is active by power-up default, therefore setting this command is necessary only if NMEA output was deactivated before.

NMEA output will instantly start on the dedicated NMEA port. The example shows a position fix.

```
....
$GPGGA,123521.0,5232.017893,N,01316.443884,E,1,05,3.7,198.0,M,43.0,M,,*5C
$GPVTG,,T,0.0,M,0.0,N,0.0,K,A*0D
$GPRMC,123521.0,A,5232.017893,N,01316.443884,E,0.0,,270711,,A*44
$GPGSA,A,3,09,14,25,27,29,,,,,,,,,6.4,3.7,5.2*36
$GPGSV,3,1,12,01,,,29,02,19,122,19,09,50,142,26,14,38,288,26*46
$GPGSV,3,2,12,25,43,265,38,27,38,140,36,29,09,205,31,04,24,075,*78
$GPGSV,3,3,12,12,82,293,,17,11,043,,32,03,347,,30,,,*4B
$GPGGA,123522.0,5232.017872,N,01316.443885,E,1,06,1.9,198.0,M,43.0,M,,*5E
....
```

15.5.4 Cold Start

To trigger a cold start first clear current GNSS data inside GNSS receiver. Do not shut down or restart the UE afterwards. Simply switch on the GNSS engine.

This example uses `AT^SGPSC` defaults, such as `<OutVal>="on"`, `<FreqVal>=1` (1 second frequency interval), `<AntVal>="auto"` for antenna power.

```
AT^SBNW=agps, -1
CONNECT
AGPS READY: RESET GPS ENGINE AND DELETE FILE ...
AGPS END OK
OK
AT^SGPSC="Engine", "1"
^SGPSC: "Engine", "1"
OK
```

Clear current GNSS data inside GNSS receiver.

Switch on GNSS engine.

NMEA output will instantly start on the dedicated NMEA port. The example shows a position fix.

```

    . . . .
    $GPGGA,,,,,0,,,,,,*66
    $GPRMC,V,,,,,,N*53
    $GPGSV,3,1,11,02,19,045,35,04,45,295,33,05,16,071,40,09,,,33*44
    $GPGSV,3,2,11,12,10,116,25,23,08,317,24,26,30,295,33,29,80,064,36*7C
    $GPGSV,3,3,11,33,,,37,06,01,033,,14,,,*4F
    $GPVTG,,T,M,N,K,N*2C
    $GPGSA,A,1,,,,,,*1E
    $GPGGA,,,,,0,,,,,,*66
    $GPRMC,V,,,,,,N*53
    $GPGSV,3,1,11,02,19,045,36,04,45,295,34,05,16,071,41,09,,,34*46
    $GPGSV,3,2,11,12,10,116,25,23,08,317,27,26,30,295,33,29,80,064,36*7F
    $GPGSV,3,3,11,33,,,37,06,01,033,,14,,,*4F
    $GPGGA,175612.0,5232.068356,N,01316.494305,E,1,03,6.5,43.8,M,43.0,M,,*60
    $GPVTG,,T,0.0,M,0.0,N,0.0,K,A*0D
    $GPRMC,175612.0,A,5232.068356,N,01316.494305,E,0.0,,120416,,,A*44
    $GPGSA,A,3,02,26,29,,,,,,8.9,6.5,6.1*3A
    $GPGSV,3,1,11,02,19,045,36,04,45,295,34,05,16,071,41,09,,,34*46
    $GPGSV,3,2,11,12,10,116,25,23,08,317,26,26,30,295,33,29,80,064,37*7F
    $GPGSV,3,3,11,33,,,37,06,01,033,,14,,,*4F
    $GPGGA,175613.0,5232.067004,N,01316.494489,E,1,03,2.1,41.6,M,43.0,M,,*65
    $GPVTG,,T,0.0,M,0.0,N,0.0,K,A*0D
    $GPRMC,175613.0,A,5232.067004,N,01316.494489,E,0.0,,120416,,,A*4D
    $GPGSA,A,2,02,26,29,,,,,,2.3,2.1,1.0*3D
    $GPGSV,4,1,15,02,19,045,35,04,45,295,34,05,16,071,41,09,,,32*40
    $GPGSV,4,2,15,12,10,116,24,23,08,317,24,26,30,295,33,29,80,064,37*7F
    $GPGSV,4,3,15,33,,,38,06,01,033,,16,10,295,,20,08,122,*45
    $GPGSV,4,4,15,21,16,192,,25,48,120,,31,51,233,*4F
    . . . .
    
```

15.5.5 Using the GNSS Buffering Mechanism

<pre> AT^SGPSC="Power/Antenna","on" ^SGPSC: "Power/Antenna","on" OK AT^SGPSC="Engine","1" ^SGPSC: "Engine","1" OK AT^SGPSC="NMEA/Output","buffered" ^SGPSC: "Nmea/Output","buffered" OK ^SGPSE: 0,0,308736 ^SGPSE: 0,1,523740 AT^SGPSC="NMEA/Output","on" ^SGPSC: "Nmea/Output","on" OK </pre>	<p>For active antenna only: Switch on antenna power supply.</p> <p>Switch on GNSS engine and start buffering.</p> <p>This setting activates NMEA buffering and enables the presentation of the "^SGPSE" URC. NMEA sentences will be buffered without additional power consumption for data output.</p> <p>The first URC shows up indicating that the buffer is filled to 80%.</p> <p>The second URC shows up indicating that the buffer is full.</p> <p>TE disables buffering and activates NMEA output on the dedicated NMEA port.</p>
--	--

Buffered NMEA sentences will be instantly flushed to the dedicated NMEA port, followed by new NMEA sentences:

```
....  
$GPGGA,155041.0,5232.043142,N,01316.468218,E,1,04,3.0,87.6,M,43.0,M,,*63  
$GPVTG,9.6,T,9.6,M,0.0,N,0.0,K,A*23  
$GPRMC,155041.0,A,5232.043142,N,01316.468218,E,0.0,9.6,020312,,A*65  
$GPGSA,A,3,05,08,10,28,,,,,,,,,4.1,3.0,2.8*38  
$GPGSV,4,1,14,03,06,028,18,05,57,239,29,08,79,077,20,10,23,168,31*72  
$GPGSV,4,2,14,26,47,288,22,27,,34,28,32,157,34,06,03,015,*43  
$GPGSV,4,3,14,07,40,061,,13,08,104,,15,07,288,,19,06,060,*79  
$GPGSV,4,4,14,21,07,333,,24,,*4D  
$GPGGA,155042.0,5232.043142,N,01316.468216,E,1,04,3.0,87.6,M,43.0,M,,*6E  
$GPVTG,9.6,T,9.6,M,0.0,N,0.0,K,A*23  
$GPRMC,155042.0,A,5232.043142,N,01316.468216,E,0.0,9.6,020312,,A*68  
$GPGSA,A,3,05,08,10,28,,,,,,,,,4.1,3.0,2.8*38  
$GPGSV,4,1,14,03,06,028,18,05,57,239,29,08,79,077,20,10,23,168,31*72  
$GPGSV,4,2,14,26,47,288,21,27,,35,28,32,157,35,06,03,015,*40  
$GPGSV,4,3,14,07,40,061,,13,08,104,,15,07,288,,19,06,060,*79  
$GPGSV,4,4,14,21,07,333,,24,,*4D  
$GPGGA,155043.0,5232.043141,N,01316.468213,E,1,04,3.0,87.6,M,43.0,M,,*69  
....
```

Now the buffer mechanism can be activated again:

```
AT^SGPSC="NMEA/Output","buffered"  
^SGPSC: "Nmea/Output","buffered"  
OK
```

This setting activates NMEA buffering and enables the presentation of the "[^SGPSE](#)" URC. NMEA sentences will be buffered without additional power consumption for data output.

16. Audio Commands

The AT Commands described in this chapter are related to the PLS8-X's audio interface.

16.1 AT^SAIC Audio Interface Configuration

[AT^SAIC](#) controls the audio interfaces. The settings of [AT^SAIC](#) as well as [AT^SNFI](#) and [AT^SNFO](#) are individual for each audio mode set with [AT^SNFS](#). For details please see [AT^SNFS](#). Further information regarding audio functionality is available in the "PLS8-X Hardware Interface Description" [2].

Syntax

Test Command

```
AT^SAIC=?
```

Response(s)

```
^SAIC: (list of supported <io>s), (list of supported<mic>s), (list of supported<ep>s), (list of
supported<clock>s), (list of supported<mode>s), (list of supported<frame_mode>s), (list of
supported<ext_clk_mode>s), (list of supported<sample_rate>s)
OK
```

Read Command

```
AT^SAIC?
```

Response(s)

```
^SAIC: <io>, <mic>, <ep>, <clock>, <mode>, <frame_mode>, <ext_clk_mode>, <sample_rate>
OK
ERROR
+CME ERROR: <err>
```

Write Command

```
AT^SAIC=<io>, <mic>, <ep>, <clock>, <mode>, <frame_mode>, <ext_clk_mode>[,
<sample_rate>]
```

Response(s)

```
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<io>^(num)

Input and output selection

1 ^(P)	Digital input and output (PCM)
3	Digital input and output (I ² S)

<mic>^(num)

Microphone selection

1 ^(P)	Microphone 1
------------------	--------------

<ep>^(num)

Select differential earpiece amplifier

1^(P) Selects the earpiece amplifier 1

<clock>^(num)

PCM clock. The parameter value is dependent of <sample_rate>.

0	128 kHz clock if <sample_rate>= 0 256 kHz clock if <sample_rate>= 1
1	256 kHz clock if <sample_rate>= 0 512 kHz clock if <sample_rate>= 1
2	512 kHz clock if <sample_rate>= 0 1024 kHz clock if <sample_rate>= 1
3 ^(P)	2048 kHz clock if <sample_rate>= 0 4096 kHz clock if <sample_rate>= 1

<mode>^(num)

PCM Master or Slave mode

0 ^(P)	Master mode
1	Slave mode

<frame_mode>^(num)

PCM frame length

0 ^(P)	Short frame
1	Long frame

<ext_clk_mode>^(num)

If <io>=1 (digital PCM):

0	External clock will be provided permanently when digital audio path is configured. Please note that if the external clock is permanently provided the UE will no longer enter its power save (SLEEP) state.
1 ^(P)	External clock will be provided only during digital audio activity (non permanent).

If <io>=3 (I²S):

0	I ² S master clock is permanently off.
1	I ² S master clock will be automatically provided only during audio activity (non permanent).

<sample_rate>^(num)

If <io>=1 (digital PCM): Sample rate. Parameter is optional.

[0] ^(P)	8 kHz
1	16 kHz

Notes

- The default values of `AT^SAIC` after restart of ME are ^SAIC: 1,1,1,3,0,0,1,0 for every audio mode.
- As can be seen from the `AT^SAIC` write command syntax, only `<sample_rate>` is an optional parameter. All other parameters are mandatory, even though ignored for the specific audio interface. Therefore, when setting `<io>` 3 (digital I²S) all PCM related parameters shall be set as well. If the optional `<sample_rate>` is omitted the default value applies. Example: `AT^SAIC=3,1,1,3,0,0,1,0`.

16.2 AT^SNFG Generate Tone

The `AT^SNFG` write command generates a 'local tone' via the selected audio output device. Beside the duration up to 2 combinations of frequency can be used to compose a local tone.

Syntax

```

Test Command
AT^SNFG=?
Response(s)
^SNFG: (list of supported <duration>s), (list of supported <gain>s), (list of supported <frequency>s),
(list of supported <frequency>s)
OK

Write Command
AT^SNFG=<duration>, <gain>, <frequency>[, <frequency>]
Response(s)
OK
ERROR
+CME ERROR: <err>

```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<duration> ^(num)	
1...65535	Duration in milliseconds.
0	Mutes the currently played tone immediately.
65535	Activates a tone with infinite duration.
<gain> ^(num)	
1...43	Gain of the tone generator belonging to a frequency, ranging from -42 dB to 0 dB. 43 gain levels adjustable in steps of 1dB. (1 = -42 dB, 43 = 0dB)
<frequency> ^(num)	
200...3400	Frequency in 1 Hz steps. Audible bandwidth is limited due to the voice band filters.

Notes

- Response of the command is always "OK" as long as the input parameters are valid.
- Tone priorities
Ring tones (incoming call/short message), Supervisory tones, Call Progress tones, RTC tones and DTMF tones always have higher priority than a local tone. This means a local tone will be played only if no module tone with a higher priority is being played. A local tone will be stopped and ended when a tone or melody from the module starts to play.
- To suspend a local tone from playing use "`AT^SNFG=0`".
- Local tones started by this AT command trigger the audio related indicators provided by AT interface in the way as these indicators are defined by `AT^SIND` commands.
- If there is a voice call active then the local tone is mixed into the voice signal. In case of a multi party call the local tones are not available.

-
- Tones played by AT^SNFG cannot be muted by AT^SCFG="Audio/SvTone".

16.3 AT^SNFI Set microphone path parameters

AT^SNFI controls microphone settings. The AT^SNFI read and write command parameters are related to the active audio mode set with AT^SNFS.

Syntax

<p>Test Command</p> <p>AT^SNFI=?</p> <p>Response(s)</p> <p>^SNFI: (list of supported <micAmp>s), (list of supported <adcVol>s), (list of supported <reserved>s)</p> <p>OK</p>										
<p>Read Command</p> <p>AT^SNFI?</p> <p>Response(s)</p> <p>^SNFI: <micAmp>, <adcVol>, <reserved></p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>										
<p>Write Command</p> <p>AT^SNFI=<micAmp>, <adcVol>, <reserved></p> <p>Response(s)</p> <p>OK</p> <p>ERROR</p> <p>+CME ERROR: <err></p>										
<table border="1"> <thead> <tr> <th>PIN</th> <th>MDM</th> <th>APP</th> <th>→</th> <th>Last</th> </tr> </thead> <tbody> <tr> <td>-</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </tbody> </table>	PIN	MDM	APP	→	Last	-	+	+	+	-
PIN	MDM	APP	→	Last						
-	+	+	+	-						

Parameter Description

<micAmp> ^(num)	
0...56 ^(P) ...63	Analogue amplifier, adjustable in 64 steps of 0.75 dB from -12 dB to +35.25 dB. (0 = -12 dB, 16 = 0 dB, 63 = +35.25 dB) Parameter is mandatory, but ignored for PCM and I2S.
<adcVol> ^(num)	
0...192 ^(P) ...255	ADC volume, adjustable in 256 steps of 0.375 dB from -71.625 dB to +23.625 dB. (0 = mute, 1 = -71.625 dB, 192 = +0 dB, 255 = +23.625 dB) Parameter is mandatory, but ignored for PCM and I2S.
<reserved> ^(num)	
16384 ^(P)	Reserved value

16.4 AT^SNFO Set audio output parameter (loudspeaker path)

AT^SNFO controls the audio output path amplification. The AT^SNFO read and write command parameters are related to the active audio mode set with AT^SNFS.

Syntax

```

Test Command
AT^SNFO=?
Response(s)
^SNFO: (list of supported <cdcRxVol>s) , (list of supported <reserved1>s) , (list of supported
<reserved2>s) , (list of supported <rxVolStep>s) , (list of supported <toneVolStep>s)
OK

Read Command
AT^SNFO?
Response(s)
^SNFO: <cdcRxVol> , <reserved1> , <reserved2> , <rxVolStep> , <toneVolStep>
OK
ERROR
+CME ERROR: <err>

Write Command
AT^SNFO=<cdcRxVol> , <reserved1> , <reserved2>[ , <rxVolStep>][ , <toneVolStep>]
Response(s)
OK
ERROR
+CME ERROR: <err>

```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<cdcRxVol> ^(num)	0...54 ^(P) ...63	Analogue gain of the output signal after summation of sidetone. The analogue gain has a valid range from -57 dB to +6 dB, adjustable in 64 steps of 1 dB. (0 = -57 dB, 57 = 0 dB, 63 = +6 dB) Parameter is mandatory, but ignored for PCM and I ² S.
<reserved1> ^(num)	33 ^(P)	Reserved value
<reserved2> ^(num)	0 ^(P)	Reserved value
<rxVolStep> ^(num)	0 ^(P) ...5	6 volume levels ranging from -15 dB to 0 dB, adjustable in steps of 3 dB. (0 = 0dB, 5 = -15 dB)

`<toneVolStep>(num)`

`<toneVolStep>` configures the tone generator volume step for locally generated supervisory tones and SAT tones.

1...43^(P) 43 volume levels ranging from -42 dB to 0 dB, adjustable in steps of 1 dB.
(1 = -42 dB, 43 = 0 dB)

Note

- Audio parameters configured by `AT^SNFO` have no effect on the local tones generated by means of the `AT^SNFG` write command.

16.5 AT^SNFS Select audio hardware set

AT^SNFS specifies the audio mode required for the connected equipment.
 The **AT^SNFS** write command serves to set the audio mode required for the connected equipment.
 The **AT^SNFS** read command indicates the currently selected audio mode.
 Further information regarding audio functionality is available in the "PLS8-X Hardware Interface Description" [2].

Syntax

<p>Test Command</p> <pre>AT^SNFS=?</pre> <p>Response(s)</p> <pre>^SNFS: (list of supported <audMode>s) OK</pre>										
<p>Read Command</p> <pre>AT^SNFS?</pre> <p>Response(s)</p> <pre>^SNFS: <audMode> OK ERROR +CME ERROR: <err></pre>										
<p>Write Command</p> <pre>AT^SNFS=<audMode></pre> <p>Response(s)</p> <pre>OK ERROR +CME ERROR: <err></pre>										
<table border="1"> <tr> <td>PIN</td> <td>MDM</td> <td>APP</td> <td>→</td> <td>Last</td> </tr> <tr> <td>-</td> <td>+</td> <td>+</td> <td>+</td> <td>-</td> </tr> </table>	PIN	MDM	APP	→	Last	-	+	+	+	-
PIN	MDM	APP	→	Last						
-	+	+	+	-						

Parameter Description

<audMode> ^(num)	
1 ^(P)	Audio mode 1: Standard mode. Optimized for the reference handset, that can be connected to the audio interface (see "PLS8-X Hardware Interface Description" for information on this handset). Note: The powerup default parameters are determined for type approval.
2	Audio mode 2: Echo canceller and noise suppressor are preset for router applications.
3	Audio mode 3: Echo canceller and noise suppressor are preset for user handset usage.
4	Audio mode 4: Echo canceller and noise suppressor are preset for mono-headset usage.
5	Audio mode 5: Echo canceller and noise suppressor are preset for speakerphone usage.
6	Audio mode 6: Echo canceller and noise suppressor are preset for transparent applications.

17. Hardware related Commands

All AT commands described in this chapter are related to the hardware interface of the PLS8-X. Further information regarding this interface is available in the "PLS8-X Hardware Interface Description" [2].

17.1 AT+CALA Alarm Configuration

AT+CALA allows to set an alarm time for the PLS8-X. For further details on the UE's real time clock (RTC) refer to "PLS8-X Hardware Interface Description, Version 03.017". When the alarm time is reached and alarm is executed the UE presents an Unsolicited Result Code (URC), and the alarm time is reset to "00/01/01,00:00:00". The alarm can adopt two functions, depending on whether or not you switch the UE off after setting the alarm:

- **Reminder message:** You can use the alarm function to generate reminder messages. For this purpose, set the alarm as described below and do not switch off or power down the UE. When executed the message comes as "+CALA" URC which optionally may include a user defined `<text>`.
- **Alarm mode:** You can use the alarm function to restart the UE when powered down. For this purpose, set the alarm as described below. Then power down the UE via `AT^SMSO`. When the alarm time is reached the UE will power on. Its functionality level (`AT+CFUN=<fun>`) depends on setting of `AT^SCFG="MEopMode/CFUN", <volaCFUN>`:
 - `<volaCFUN>=0`: Setting of `AT+CFUN` parameter `<fun>` is stored persistently. The UE re-establishes its functionality level formerly used before power down. Wake up is notified by "^SYSSTART" or "^SYSSTART AIRPLANE MODE" URC.
 - `<volaCFUN>=1` (delivery value): Setting of `AT+CFUN` parameter `<fun>` is volatile. The UE always restarts using Normal Functionality level, which is indicated by "^SYSSTART" URC presentation.

An additional "+CALA" URC with user defined `<text>` can be configured.

AT+CALA test command returns the supported array index values `<n>`, the supported alarm types `<type>` and the maximum length of the text `<tlength>`.

AT+CALA read command returns the current alarm settings.

Syntax

Test Command

AT+CALA=?

Response(s)

+CALA: (list of supported `<n>`s), (list of supported `<type>`s), (supported `<tlength>`)

OK

ERROR

+CME ERROR: `<err>`

Read Command

AT+CALA?

Response(s)

+CALA: `<time>`, `<n>`, `<type>`, `<text>`

+CALA: `<time>`, `<n>`, `<type>`, `<text>`

+CALA: ...

OK

ERROR

+CME ERROR: `<err>`

Write Command				
AT+CALA=<time>[, <n>[, <type>[, <text>]]]				
Response(s)				
OK				
ERROR				
+CME ERROR: <err>				
PIN	MDM	APP	→	Last
-	+	+	+	-
Reference(s)				
3GPP TS 27.007				[48]

Unsolicited Result Codes

URC 1

+CALA: [<text>]

Indicates reminder message.

URC 2

^SYSSTART

+CALA: [<text>]

Indicates UE wake-up at functionality level [AT+CFUN=1](#) (Normal mode).

URC 3

^SYSSTART AIRPLANE MODE

+CALA: [<text>]

Indicates UE wake-up at functionality level [AT+CFUN=0](#) or [AT+CFUN=4](#) (Airplane mode).

Parameter Description

<time>^(str)

Format is "yy/MM/dd, hh:mm:ss". For example, 6th of July 2015, 22:10:00 equals to "15/07/06,22:10:00". See also [AT+CCLK](#).

If you attempt to set <time> to a date and time which is older than the UE's current time, one "+CALA" URC will be returned, and no alarm timer will be set.

To clear a given alarm before its scheduled time simply enter an empty string "" for parameter <time>. This will also clear a given <text>.

<n>^(num)

Integer type value indicating the array index of the alarm.

[0]...4

<type>^(num)

Integer type value indicating the type of the alarm.

0 Alarm indication: text message on AT command instance

<text>^(str)

String type value indicating the text to be displayed when alarm time is reached; maximum length is <tlength>. By factory default, <text> is undefined.

Note: <text> will be stored to the non-volatile flash memory when the device enters the Power Down mode via [AT^SMSO](#). Once saved, it will be available upon next power-up, until you overwrite it by typing another text. This eliminates the need to enter the full string when setting a fresh alarm.

<text> should not contain characters which are coded differently in ASCII and GSM (e.g. umlauts), see also "Supported character sets" and "GSM alphabet tables".

```
<tlength>(num)
```

Integer type value indicating the maximum length of `<text>`. The maximum length is 16.

Notes

- After the alarm was executed the parameter `<time>` of `AT+CALA` will be reset to "00/01/01,00:00:00", but `<text>` will be preserved as described above.
- If UE is totally disconnected from power supply the most recently saved configuration of `+CALA: <time> [,<n> [,<type>[,<text>]]]` will be presented when UE is powered up.

Examples

EXAMPLE 1

You may want to configure a reminder message for July 31, 2015, at 9.30h, including the message "Good Morning".

```
AT+CALA="15/07/31,09:30:00",0,0,"Good Morning"  
OK
```

Do not switch off the UE. When the alarm occurs the UE returns the following URC:

```
+CALA: Good Morning
```

EXAMPLE 2

To set a fresh alarm using the same message as in Example 1, simply enter date and time. `<n>`, `<type>` and `<text>` can be omitted:

```
AT+CALA="15/07/31,08:50:00"  
OK
```

When the alarm is executed the URC comes with the same message:

```
+CALA: Good Morning
```

EXAMPLE 3

To enable the UE to wake up into Alarm mode, e.g. on July 20, 2015, at 8.30h, enter

```
AT+CALA="15/07/20,08:30:00"  
OK
```

Next, power down the UE:

```
AT^SMSO  
OK
```

When the alarm is executed the UE wakes up to functionality level (`AT+CFUN`) which was valid before power down and displays a URC. If available, this line is followed by the individual `<text>` most recently saved.

```
^SYSSTART  
+CALA: Good Morning
```


17.2 AT+CCLK Real Time Clock

[AT+CCLK](#) controls the real time clock (RTC) of PLS8-X.

The current setting of the clock is retained if the UE enters Power Down mode via [AT^SMSO](#) or restarts using [AT+CFUN](#). However, it will be reset to its factory default value if the UE is totally disconnected from power.

If a network supports automatic time update the RTC is constantly updated with the network time. Any changes to the RTC using the command [AT+CCLK](#) will be wiped out by the network time. If a network does not support automatic time update the RTC can be set using [AT+CCLK](#).

Each time the UE is restarted it may take up to two seconds to reinitialize the RTC and to update the current time. Therefore, it is recommended to delay the usage of [AT+CCLK](#) and [AT+CALA](#) after restart.

If the clock is set into the past, then it is recommended to reset the UE using [AT+CFUN](#) to avoid blocked calls because of the autocal restriction.

Changing the RTC influences an active automatic shutdown timer (see [AT^SCFG](#) parameter `<shutdownRemainingTime>` for details).

Syntax

Test Command	
AT+CCLK=?	
Response(s)	
OK	
Read Command	
AT+CCLK?	
Response(s)	
+CCLK: <code><time></code>	
OK	
Write Command	
AT+CCLK= <code><time></code>	
Response(s)	
OK	
ERROR	
+CME ERROR: <code><err></code>	
PIN MDM APP → Last	Reference(s)
- + + + -	3GPP TS 27.007 [48]

Parameter Description

`<time>`^{(str)(NV)}

Real time clock setting

Format is "yy/mm/dd, hh:mm:ss", where the characters yy indicate the two last digits of the year, followed by month (mm), day (dd), hour (hh, 24 hour format), minutes (mm) and seconds (ss).

For the write command the base of the year part is 2000. For example the 6th of July 2011 at ten past ten in the evening equates to "11/07/06,22:10:00".

The factory delivery value, which is also used if the UE was totally disconnected from power, is "80/01/06,00:00:00", where "80" here stands for "1980". So `<time>` values as reponse of the read command are ambiguous if the year part is > "79". To be sure that in such cases the correct time is used, it should be set explicitly using the [AT+CCLK](#) write command.

Note

- If automatic time zone update is enabled and a time zone update occurs additional time zone information will be appended to parameter `<time>`. Format is changing to "yy/mm/dd,hh:mm:ss+zz" or "yy/mm/dd,hh:mm:ss-zz" where zz is time zone. Time zone zz is given as a positive (east) or negative (west) offset from UTC in units of 15 minutes. Example for time and time zone UTC+2: "11/07/06,22:10:00+08". Please note that time zone is displayed only when enabled with [AT+CTZU](#) and provided by the network. See [AT+CTZU](#) for more information.

17.3 AT^SAD Antenna Configuration

AT^SAD controls usage of the module's UMTS/LTE (RX) diversity/MIMO antenna.

For RX antenna diversity, the AT^SAD command enables

- verification of receive paths,
- support of CTIA 3.0 diversity tests (relevant for application approval).

RX antenna diversity means usage of two antennas and two receiver paths to provide significant gains in performance. The gains depend on how 'decoupled' the antennas are from each other. Transmitter (TX) signal is always transferred via primary antenna.

Syntax

```

Test Command
AT^SAD=?
Response(s)
^SAD: (list of supported <sadMode>s)
OK

Write Command
AT^SAD=<sadMode>
Response(s)
^SAD: <sadValue>
OK
ERROR
+CME ERROR: <err>

PIN  MDM  APP  →  Last
-    +    +    +    -
    
```

Parameter Description

<sadMode>^(num)

This parameter controls usage of the RX diversity antenna.

<sadMode> RX antenna diversity related settings 10..12 are stored in non-volatile memory and will be processed after next UE power-up. An error is returned if write access to non-volatile storage fails.

10	Disable RX diversity functionality. Activate only the first antenna for RX operation, i.e. use the primary antenna for reception. The secondary (diversity) receiver path is switched off. Configuration is stored in non-volatile memory and becomes effective after next restart of UE.
11 ^(D)	Enable RX diversity functionality by activating both antennas for RX operation. This setting is active as factory delivery configuration. It is stored in non-volatile memory and becomes effective after next restart of the UE.
12	Query RX diversity functionality setting. <sadValue> returns the currently stored configuration.
13	Configure UMTS antenna test mode for production tests. The primary (main) antenna port is used as TX chain. However, the related receiver path is switched off. Only the secondary (diversity) antenna is activated for RX operation. Configuration is stored in non-volatile memory and becomes effective after next restart of the UE.

<sadValue>^(num)

The meaning of this parameter depends on given <sadMode>.

For <sadMode>=[10, 11, 13] <sadValue> returns the currently stored configuration of the RX diversity functionality, which will be used after next restart of the UE.

For <sadMode>=12 <sadValue> returns the current non-volatile memory setting (range 10, 11, 13).

17.4 AT^SBV Battery/Supply Voltage

[AT^SBV](#) allows to monitor the supply (or battery) voltage of the module. The voltage is periodically measured. The displayed value is averaged.

The measurement is related to the reference points of BATT+ and GND. For details on the reference points please refer to the Hardware Interface Description [2]. If the measured average voltage drops below or rises above the given voltage thresholds the UE will report alert messages by sending the "^SBC" URCs listed in Section 1.8.1, [Common URCs](#).

Syntax

Test Command

```
AT^SBV=?
```

Response(s)

```
OK
```

```
ERROR
```

```
+CME ERROR: <err>
```

Exec Command

```
AT^SBV
```

Response(s)

```
^SBV: <Voltage>
```

```
OK
```

```
ERROR
```

```
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<Voltage>^(num)

Supply (or battery) voltage in mV

17.5 AT^SCTM Critical Operating Temperature Monitoring

AT^SCTM allows to monitor the operating temperature range of the PLS8-X device. Refer to "PLS8-X Hardware Interface Description" [2] for specifications on critical temperature ranges.

AT^SCTM write command controls the presentation of URCs to report critical operating temperature limits.

Use parameter <UrcMode> to enable (1) and disable (0) URC presentation.

Important: Even if setting is <UrcMode>= 1 URC presentation is disabled during the two minute of guard period after the module was switched on. After expiry of the two minute guard period, the presentation will be enabled, i.e. URCs with alert levels "1" or "-1" will be generated. During this period PLS8-X will not switch off, even if the critical temperature limit is exceeded. This allows the user to set up emergency calls before PLS8-X switches off. For details refer to Section 17.5.1, [Deferred shutdown](#).

URCs indicating levels "2" or "-2" are always enabled (except during guard period or if an emergency call is active, but when the guard period is expired or emergency call is finished and temperature is still above/below critical limit, then the URC will be issued), i.e. they will be issued even though the factory setting AT^SCTM=0 was never changed. If level "2" or "-2" URCs occur PLS8-X will switch off within 5 seconds, unless the temperature returns to a valid operating level ("1", "0", "-1"), guard period hasn't expired or a new emergency call isn't dialed. URCs indicating alert levels "1" or "-1" are intended to enable the user to take appropriate precautions, such as protect PLS8-X from exposure to extreme conditions, or save or back up data etc. .

AT^SCTM read command returns:

- The URC presentation mode.
- Information about the current temperature range of the PLS8-X device.
- The board temperature (in degree Celsius) if parameter <tempCtrl>=1.

Syntax

Test Command

AT^SCTM=?

Response(s)

^SCTM: (list of supported <UrcMode>s)[, (range of <temp>in Celsius)]

OK

Read Command

AT^SCTM?

Response(s)

^SCTM: <UrcMode>, <UrcCause>[, <temp>]

OK

ERROR

+CME ERROR: <err>

Write Command

AT^SCTM=<UrcMode>[, <tempCtrl>]

Response(s)

OK

ERROR

+CME ERROR: <err>

PIN MDM APP → Last

- + + + -

Unsolicited Result Code

URCs will be automatically sent to the TE when the temperature reaches or exceeds the critical level, or when it is back to normal.

^SCTM_B: <UrcCause>

URC for PLS8-X device temperature warning.

Parameter Description

<UrcMode>^(num)

URC presentation mode. Setting will not be stored during power-down, i.e. after next restart default setting will be restored.

0 ^{(&F)(P)}	Disable URC presentation (except for <UrcCause> equal to -2 or +2).
1	Enable URC presentation.

<UrcCause>^(num)

-2	Below lowest temperature limit (causes switch-off after 5 s time).
-1	Below low temperature alert limit.
0	Normal operating temperature.
1	Above upper temperature alert limit.
2	Above uppermost temperature limit (causes switch-off after 5 s time).

<tempCtrl>^(num)

0 ^(P)	Suppress output of <temp> in read command.
1	Output <temp> in test and read command.

<temp>^(num)

Board temperature in Celsius. Is comprised between the lowest temperature warning level and the uppermost temperature warning level.

Examples

EXAMPLE 1

URCs issued when the operating temperature is out of range:

^SCTM_B: 1	Caution: Module close to overtemperature limit.
^SCTM_B: 2	Alert: Module is above overtemperature limit and switches off.
^SCTM_B: -1	Caution: Module close to undertemperature limit.
^SCTM_B: -2	Alert: Module is below undertemperature limit and switches off.

EXAMPLE 2

URCs issued when the temperature is back to normal (URC is output once):

^SCTM_B: 0	Module back to normal temperature.
------------	------------------------------------

17.5.1 Deferred shutdown

In the following cases, automatic shutdown will be deferred if a critical temperature limit is exceeded:

- While an emergency call is in progress.
- During a two minute guard period after powerup. This guard period has been introduced in order to allow for the user to make an emergency call. The start of any one of these calls extends the guard period until the end of the call. Any other network activity may be terminated by shutdown upon expiry of the guard time.

While in a "deferred shutdown" situation, the engine continues to measure the temperature and to deliver alert messages, but deactivates the shutdown functionality. Once the guard period is expired or the call is terminated, full temperature control will be resumed. If the temperature is still out of range, the UE switches off immediately (without another alert message).

CAUTION! Automatic shutdown is a safety feature intended to prevent damage to the module. Extended usage of the deferred shutdown facilities provided may result in damage to the module, and possibly other severe consequences.

17.6 AT^SLED LED Feature

AT^SLED controls the LED function provided by the PLS8-X's STATUS line, which acts as an output and can be used to control a connected LED. The electrical specifications of the status line and advice on how to connect the LED circuit can be found in [2].

The LED indicates the operating states listed below:

Table 17.1: PLS8-X Status and Mode Indication via LED

PLS8-X Status	<mode>=1	<mode>=2 <flash>= default	<mode>=2 <flash>= user defined	<mode>=3
- GSM PS data transfer - UMTS/LTE data transfer	Permanently on	10 ms on / 1990 ms off	on + off (interval) = 2000 ms (fixed) on = ((<flash> * 2000) / 1000) ms (variable)	
UE registered to a network. No call, no data transfer	Permanently on	10 ms on / 3990 ms off	on + off (interval) = 4000 ms (fixed) on = ((<flash> * 4000) / 1000) ms (variable)	
Limited Network Service (e.g. because no SIM/USIM, no PIN or during network search)	500 ms on / 500 ms off	500 ms on / 500 ms off	on + off (interval) = 1000 ms (fixed) on = 500 ms (fixed)	
- UMTS/LTE operation mode				Permanently on
- GSM operation mode				Permanently off

Syntax

Test Command

AT^SLED=?

Response(s)

^SLED: (list of supported <mode>s), (range of supported <flash>s)

OK

Read Command

AT^SLED?

Response(s)

^SLED: <mode>[, <flash>]

OK

```
Write Command
AT^SLED=<mode>[, <flash>]
Response(s)
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<mode> ^{(num)(&W)}	
LED operating mode	
0 ^{(&F)(D)}	LED feature is disabled.
1	LED lights steadily when the UE is registered to the network and either awake or in power saving state.
2	LED is flashing when the UE is in Limited Service or registered with a network and either awake or in power saving state. The duration of flashing can be configured using the parameter <flash>.
3	LED line will indicate with status HIGH that the UE is switched to 3G/UMTS or 4G/LTE operation mode. LED line will indicate with status HIGH that the UE is switched to 3G/UMTS operation mode. In all other states of the UE the line will be set to LOW. When changing the state of the LED line it will be ensured that the LED line will always be at LOW state before there is any slotted TX output power in 2G/GSM technology.

<flash> ^{(num)(&W)}	
LED flash period	
1...10 ^(D) ...50	LED flash period (in milliseconds) if <mode>=2.

Notes

- When using <mode>=3 configure it before entering the PIN with AT command AT+CPIN to recognise all changes on LED line. Remember that only the status change (LTE->UMTS->GSM or GSM->UMTS->LTE) will trigger the LED line.
- The lowest value for the user defined flash time using AT^SLED=2,<flash> is 1/1000 from interval length. For example, with 4000 ms interval length the lowest adjustable value is 4 ms.

17.7 AT^SRADC Configure and Read A/D Converter

AT^SRADC controls the Analog-to-Digital Converters (ADC) of the UE. These ADCs can be used to measure the voltage of external devices connected to the ADC inputs.

AT^SRADC write command configures the parameters required for ADC measurement and returns the measurement result(s). The value(s) can be delivered once on request by using the single measurement mode, or periodically by specifying a measurement interval.

Note that the UE uses an unbalanced input with three pins. The pin names are denoted as follows:

- First ADC channel: ADC1_IN.
- Second ADC channel: ADC2_IN.
- Third ADC channel: ADC3_IN.

For details refer to "[PLS8-X Hardware Interface Description, Version 03.017](#)".

Syntax

Test Command

AT^SRADC=?

Response(s)

^SRADC: (list of supported <ch>s), (list of supported <op>s), (list of supported <it>s)

OK

Read Command

AT^SRADC?

Response(s)

^SRADC: <ch>, <op>, <it>

[^SRADC: <ch>, <op>, <it>]

[^SRADC: ...]

OK

Write Command

Single measurement (with automatic channel open and close):

AT^SRADC=<ch>

Response(s)

^SRADC: <ch>, <count>, <value>

OK

ERROR

+CME ERROR: <err>

Write Command

Periodic measurement:

AT^SRADC=<ch>, <op>[, <it>]

Response(s)

[^SRADC: <ch>, <count>, <value>]

OK

ERROR

+CME ERROR: <err>

PIN	MDM	APP	→	Last
-	+	+	+	-

-	+	+	+	-
---	---	---	---	---

Unsolicited Result Code

ADC measurement URC (only used in periodic measurement mode).

```
^SRADC: <ch>, <count>, <value>[, <value>[, <value>[, <value>[, <value>[, <value>[, <value>[, <value>[, <value>]]]]]]]]]]
```

Parameter Description

<ch>^(num)	
ADC channel	
0	First ADC channel (ADC1_IN)
1	Second ADC channel (ADC2_IN)
2	Third ADC channel (ADC3_IN)
<op>^(num)	
Operation	
Open or close ADC channel for measurement.	
If parameter is not specified, then single measurement mode is initiated (with open and close of channel). Single measurement is not allowed if the channel is already open.	
[0]	Close ADC channel (value of parameter <it> is ignored).
1	Open ADC channel
<it>^(num)	
Measurement interval	
Parameter is used only if operation <op> is 1 (Open).	
[0]	Single measurement mode (incl. close of channel)
30,000...100	Measurement interval in millisecond (ms) for periodic measurement mode. The URC output interval is minimum 1000 ms. This means if the measurement interval <it> is smaller than 1000 ms, then every second one URC will be output containing several measurement values. If <it> is equal 1000 ms or greater, each URC contains exactly one single measurement value. URC buffer mechanism: If the interface is not free (e.g., during execution of an AT command) measurement values are buffered. Up to 5 URCs can be buffered, each containing up to 11 measurement values. After freeing the interface, all buffered URCs will be printed out. Loss of measured values, if any, is indicated by an additional 6th URC containing the value "32767". See example below.
<value>^(num)	
Measurement value	
Measurement value in mV	
<count>^(num)	
1...11	Number of measured samples In single measurement mode: <count> is always 1. In periodic measurement mode: <count> is the number of <value>s indicated by the URC "^SRADC". The higher the sample rate set with <it>, the more measured values are reported within the URC "^SRADC".

Examples

EXAMPLE 1

Single measurement

AT^SRADC=0	Open the first ADC channel for single measurement.
^SRADC: 0,1,78	
OK	

EXAMPLE 2

Periodic measurement at low sample rate (5s):

AT^SRADC=0,1,5000	Start periodic measurement mode on the first ADC channel. Samples are taken every 5s. Every 5s the URC " ^SRADC " appears to report the measured voltages. The second parameter represents the number of measured samples, in this case only one.
^SRADC: 0,1,76	
^SRADC: 0,1,78	
^SRADC: 0,1,76	
^SRADC: 0,1,76	
AT^SRADC=0,0	Stop the periodic measurement
OK	

EXAMPLE 3

Periodic measurement at high sample rate (250ms):

AT^SRADC=0,1,250	Start periodic measurement on the first ADC channel. Samples are taken every 250ms. Every second a URC " ^SRADC " appears to report the measured voltage. The number of samples is 4 or 5.
^SRADC: 0,4,76,76,77,76	
^SRADC: 0,4,76,76,75,76	
^SRADC: 0,5,77,77,76,76,76	
^SRADC: 0,4,76,76,75,76	
AT^SRADC=0,0	Stop the periodic measurement
OK	

EXAMPLE 4

Handling of "**^SRADC**" URCs and AT command execution on the same interface:

AT^SRADC=0,1,250	Start periodic measurement mode on the first ADC channel. Samples are taken every 250ms.
^SRADC: 0,4,76,76,77,76	
^SRADC: 0,5,77,77,76,76,76	
^SRADC: 0,4,76,76,75,76	
^SRADC: 0,4,76,76,75,76	
AT^SRADC?	Input of AT command and <CR> takes some seconds.
^SRADC: 0,1,250	
^SRADC: 1,0,0	
OK	
^SRADC:	some URCs were buffered during command input and sent after completion.
0,11,75,75,75,75,75,75,75,75,75	
^SRADC: 0,8,75,75,75,75,75,75,77	
^SRADC: 0,1,75	
^SRADC: 0,4,76,76,75,76	More URCs are delivered.
^SRADC: 0,4,76,76,75,76	
^SRADC: 0,5,77,77,76,76,76	
^SRADC: 0,4,76,76,77,76	
^SRADC: 0,4,76,76,75,76	
AT^SRADC?	Input of AT command and <CR> takes 90s.
^SRADC: 0,1,250	
^SRADC: 1,0,0	
OK	
^SRADC:	some URCs were buffered during command input and sent after completion
0,11,75,75,75,75,75,75,75,75,75	
^SRADC:	
0,11,73,74,73,74,73,73,73,74,74,73,73	

^SRADC: 0,11,74,73,74,73,73,73,73,73,73,73,73

^SRADC: 0,11,73,73,74,74,73,73,74,73,73,74,74

^SRADC: 0,11,73,73,73,73,73,73,73,74,74,73,73

^SRADC: 0,8,73,73,74,73,73,73,73,32767

The URC indicates lost measurement results.
More URCs are delivered.

^SRADC: 0,4,74,74,73,73

^SRADC: 0,4,75,75,75,75

.....

18. General Purpose I/O (GPIO) Pin related Commands

This chapter describes the AT commands used to access and configure the GPIO pins of PLS8-X.

Please also refer to [2] for electrical specifications of the GPIO pins.

18.1 AT^SPIO GPIO Driver Open/Close

`AT^SPIO` write command opens and closes the General Purpose I/O (GPIO) driver. The command must be executed before any GPIO related command can be used. The command does not reserve any GPIO lines, only the driver required for their management will be started.

Syntax

Test Command

```
AT^SPIO=?
```

Response(s)

```
^SPIO:(list of supported <mode>s)
```

```
OK
```

Write Command

```
AT^SPIO=<mode>
```

Response(s)

```
OK
```

```
ERROR
```

```
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<mode>^(num)

0	Close General purpose I/O driver
1	Open General purpose I/O driver

18.2 AT^SCPIN Pin Configuration

The `AT^SCPIN` write command serves to configure GPIOs.

Keep in mind that each GPIO can be assigned only one function. This means that if configured for GPIO handling with `AT^SCPIN` this GPIO is locked for any alternative function, and vice versa. Mutually exclusive functions are:

- Configuring a GPIO with `AT^SCPIN`.
 - Using a GPIO configured as input with `AT^SCPIN` to wake up the UE from power saving. Suitable GPIOs (unless otherwise assigned): GPIO1, GPIO3, GPIO4, GPIO5, GPIO9. Reporting of level state changes at the specified GPIO shall be enabled with `AT^SCPOL`.
- Configuring a GPIO as Remote Wakeup line to wake up the TE (see `AT^SCFG`, `<RemWakeLine>`).
- Configuring GPIO1 as DR_SYNC line (see `AT^SGPSC`, `<DRSyncVal>`).
- Configuring GPIO2 as antenna switch for a 700 MHz antenna (see `AT^SCFG` "GPIO/Mode/Antenna", `<ant>`).
- Configuring a GPIO as Low Current Indicator (see `AT^SCFG` "MEopMode/PowerMgmt/LCI", `<lci>` and `<gpio>`).

Syntax

```
Test Command
AT^SCPIN=?
Response(s)
^SCPIN:(list of supported <mode>s), (list of supported <pin_id>s), (list of supported <direction>s), (list of supported <startValue>s)
OK
```

```
Write Command
AT^SCPIN=<mode>, <pin_id>, <direction>[, <startValue>]
Response(s)
OK
ERROR
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<code><mode></code> ^(num)	
0	Close pin
1	Open pin

<code><pin_id></code> ^(num)	
Pin identifier	
0	GPIO1
1	GPIO2
2	GPIO3
3	GPIO4
4	GPIO5
5	GPIO6
6	GPIO7
7	GPIO8

8	GPIO9
9	GPIO10

`<direction>`^(num)

Parameter `<direction>` is mandatory when opening a pin, but can be omitted when closing a pin.

0	Input
1	Output

`<startValue>`^(num)

Can be set only for outputs.

[0]	Low
1	High

Notes

- For closing a pin with the write command (`<mode>=0`), the parameter `<direction>` is not needed.
- Before changing the configuration of a pin be sure to close the pin.

18.3 AT^SCPOL GPIO Level Polling Configuration

[AT^SCPOL](#) serves to control automatic level polling and reporting for PLS8-X's GPIOs. The GPIO shall already be configured with [AT^SCPIN](#). Level polling is only applicable to input pins. After polling has been activated for a specified GPIO, its latest level state transition will be reported via "[^SCPOL](#)" URC.

GPIO monitoring is interrupt handled. If a state transition is detected at a configured GPIO, a debouncing routine will start. The signal state has to stay stable for at least for proper detection of a state change.

If PLS8-X stays in power save (SLEEP) state, a transition at GPIO1, GPIO3, GPIO4, GPIO5 and GPIO9 ([<pin_id>=\[0,2,3,4,8\]](#)) will wake up the UE.

For all other GPIOs the state detection will only be triggered when the UE suspends power saving state for another reason.

Refer to [AT^SCFG](#), "MeOpMode/PwrSave" parameter [<PwrSaveMode>](#) and [<PwrSaveWakeup>](#) which allow to fine-tune power saving behaviour of the UE.

Syntax

```

Test Command
AT^SCPOL=?
Response(s)
^SCPOL:(list of supported <mode>s), (list of supported <ioId>s)
OK

Write Command
AT^SCPOL=<mode>, <ioId>
Response(s)
OK
ERROR
+CME ERROR: <err>
    
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Unsolicited Result Code

[^SCPOL](#): [<ioId>](#), [<value>](#)

Parameter Description

<mode> ^(num)	
0 ^(P)	Disable level polling for a general purpose I/O pin.
1	Enable level polling for a general purpose I/O pin.

<ioId> ^(num)	
This can be either an already configured or an already opened <pin_id> .	

<value> ^(num)	
Level state transition detected on <ioId> .	
0	<pin_id> is in low state.
1	<pin_id> is in high state.

18.4 AT^SGIO Get IO state of a specified pin

Syntax

Test Command

```
AT^SGIO=?
```

Response(s)

```
^SGIO:(list of supported <io_id>s)  
OK
```

Write Command

```
AT^SGIO=<io_id>
```

Response(s)

```
^SGIO: <value>  
OK  
ERROR  
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<io_id>^(num)

This is an already configured <pin_id>.

<value>^(num)

State read on this <io_id>.

0	Low for <pin_id>
1	High for <pin_id>

18.5 AT^SSIO Set IO state of a specified pin

Syntax

Test Command

```
AT^SSIO=?
```

Response(s)

```
^SSIO:(list of supported <io_id>s), (list of supported <value>s)  
OK
```

Write Command

```
AT^SSIO=<io_id>, <value>
```

Response(s)

```
OK  
ERROR  
+CME ERROR: <err>
```

PIN	MDM	APP	→	Last
-	+	+	+	-

Parameter Description

<io_id>^(num)

This is an already configured <pin_id>.

<value>^(num)

State to be set for this <io_id>.

0	Low for <pin_id>
1	High for <pin_id>

19. Miscellaneous Commands

The AT Commands described in this chapter are related to various areas.

19.1 A/ Repeat Previous Command Line

Repeat previous AT command line.

In general, after beginning a command line with character "a" or "A" a second character "t", "T" or "/" has to follow. "/" acts as line terminating character. In case of using a wrong second character, it is necessary to start again with character "a" or "A".

Syntax

Exec Command					
A/					
Response(s)					
PIN	MDM	APP	→	Last	Reference(s)
-	+	+	+	-	V.250

19.2 +++ Escape from Data Mode to AT Command Mode

The +++ character sequence causes the PLS8-X to pause data mode and return to AT command mode. To prevent the +++ character sequence from being misinterpreted as data, it must be preceded and followed by a pause of at least 1000 ms. The +++ characters must be entered in quick succession, all within 1000 ms.

+++ is not supported in Packet Switched and PPP connections.

Syntax

Exec Command					
+++					
Response(s)					
OK					
PIN	MDM	APP	→	Last	Reference(s)
-	+	+	-	-	ITU-T V.250 [16]

19.3 AT^SBNR Binary Read

Syntax

Test Command

```
AT^SBNR=?
```

Response(s)

```
OK
```

Read Command

```
AT^SBNR?
```

Response(s)

```
OK
```

Write Command

If **<type>**= "ciphersuites": Gets the accepted values by default for IPoverAT TLS Cipher suites:

```
AT^SBNR="ciphersuites", "default"
```

Response(s)

```
(default CYASSL ciphers string)
```

```
OK
```

Write Command

If **<type>**= "ciphersuites": Gets the user-accepted values for IPoverAT TLS Cipher suites, or default values if not defined:

```
AT^SBNR="ciphersuites", "current"
```

Response(s)

```
(ciphersuite user file contents)
```

```
OK
```

If no user values defined:

```
No Cipher Suites file found or loaded
```

```
Default Cipher Suites:
```

```
(default CYASSL ciphers string)
```

```
OK
```

Write Command

If **<type>**= "is_cert": Read certificates for secure connection of client IP services

```
AT^SBNR="is_cert"
```

Response(s)

```
^SBNR:<index>, <size>, <issuer>, <serial-number>, <subject>, <signature-algorithm>,  
<thumbprint-algorithm>, <thumbprint>
```

```
[...]
```

```
OK
```

If error is related to ME functionality:

```
ERROR
```

```
+CME ERROR: <err>
```

If certificate file is corrupted:

```
<index>, certificate is corrupted
```

PIN MDM APP → Last

- + + + -

Parameter Description

<type>^(str)

“ciphersuites“ IOverAT TLS Cipher suites
“is_cert“ Read certificate details

<index>^(num)

Certificate index
0...10 Index 0 is handled as client certificate (only 1 allowed). Indexes from 1 to 10 are handled as server certificates.

<size>^(str)

Size of certificate file in bytes

<issuer>^(str)

Certificate issuer

<serial-number>^(str)

Serial number of certificate

<subject>^(str)

Subject of certificate

<signature-algorithm>^(str)

Signature algorithm of certificate

<thumbprint-algorithm>^(str)

Thumbprint algorithm of certificate

<thumbprint>^(str)

Thumbprint of certificate

19.4 AT^SBNW Binary Write

[AT^SBNW](#) allows for writing binary or hexadecimal data to the non-volatile memory or to the Flash File System (FFS). The handling of the [AT^SBNW](#) write command varies depending on the type of data.

Syntax

Test Command

```
AT^SBNW=?
```

Response(s)

```
^SBNW: (list of supported <type>s), (list of supported <subtype>s)
```

```
OK
```

Write Command

Cipher suites user file modification:

```
AT^SBNW="ciphersuites", file size
```

Response(s)

```
CONNECT
```

```
CIPHERSUITES: SEND FILE ...
```

Indicates that UE has entered binary data mode. Data can be transferred.

When Ciphersuites file data are transferred and updated, or error occurs the UE returns one of following answers:

```
CIPHERSUITES: LENGTH ERROR
```

```
CIPHERSUITES: FILE WRITE ERROR
```

```
CIPHERSUITES: SUITE NOT FOUND
```

```
CIPHERSUITES: UNDEFINED ERROR
```

```
CIPHERSUITES: INTERNAL ERROR
```

```
CIPHERSUITES: I/O ERROR
```

```
OK
```

Write Command

Cipher suites user file removal:

```
AT^SBNW="ciphersuites", 0
```

Response(s)

```
CIPHERSUITES: DELETE CIPHERSUITES FILE...
```

```
CIPHERSUITES: DONE
```

```
OK
```

```
+CME ERROR: <err>
```

Write Command

Save the xtra.bin file to local memory (if [<agps_length>](#) is used to specify file size):

```
AT^SBNW="agps", <agps_length>
```

Response(s)

```
CONNECT
```

```
AGPS READY: SEND FILE ...
```

(Indicates that UE has entered binary data mode. Data can be transferred.)

After data transfer the UE returns one of the following result codes:

```
AGPS: END OK
```

```
AGPS: TIME INFO ERROR
```

```
AGPS: BAD CRC
```

```
AGPS: SERVICE TIMEOUT ERROR
```

```
AGPS: I/O ERROR
```

Write Command

(Continued)

Save the xtra.bin file to local memory (if <agps_length> is used to specify file size):

AT^SBNW="agps", <agps_length>

Response(s)

AGPS: FILE WRITE ERROR
AGPS: UNDEFINED ERROR
OK
ERROR

Write Command

Delete existing xtra.bin file (if <agps_length>= -1):

AT^SBNW="agps", <agps_length>

Response(s)

CONNECT

AGPS READY: RESET GPS ENGINE AND DELETE XTRA FILE...

(Indicates that UE tries to reset all current GPS data and to delete a saved xtra.bin file)

After that the UE returns one of the following result codes:

AGPS: END OK
AGPS: TEMPORARY NOT ALLOWED ERROR
AGPS: GENERAL FAILURE
AGPS: UNSUPPORTED
AGPS: INVALID PARAMETER
AGPS: ENGINE BUSY
AGPS: PHONE OFFLINE
AGPS: TIMEOUT
AGPS: CONFIG NOT SUPPORTED
AGPS: INSUFFICIENT MEMORY
OK

Write Command

Command to write and read certificates for OMA DM purpose:

AT^SBNW="omadm", <subtype>

Response(s)

CONNECT

OMADM SECURE CMD READY: SEND COMMAND ...

(Indicates that UE has entered binary data mode. Command can be sent.)

After command sending the UE returns one of the following result codes:

OMADM SECURE CMD SERVICE TIMEOUT ERROR
OMADM SECURE CMD LENGTH ERROR
OMADM SECURE CMD TO MANY DATA ERROR
OMADM SECURE CMD CERTIFIACATE WRITE ERROR
OMADM SECURE CMD CERTIFIACATE NOT FOUND
OMADM SECURE CMD ERROR
OMADM SECURE CMD END OK

Write Command

Certificate management for secure connection of client IP services

AT^SBNW="is_cert", <subtype>

Response(s)

CONNECT

SECURE CMD READY: SEND COMMAND ...

(Indicates that UE has entered binary data mode. Secure command data can be transferred.)

When secure command data is processed the UE will send one of following answers:

Write Command

(Continued)

Certificate management for secure connection of client IP services

AT^SBNW="is_cert", <subtype>

Response(s)

```
SECURE CMD LENGTH ERROR
SECURE CMD PUBLIC CERTIFICATE IS CORRUPTED
SECURE CMD PRIVATE KEY WAS REMOVED
SECURE CMD SERVICE TIMEOUT ERROR
SECURE CMD TO MANY DATA ERROR
SECURE CMD ERROR
SECURE CMD END OK
```

PIN MDM APP → Last

- + + + -

Parameter Description

<type>^(str)

"agps"	Activates A-GPS binary data mode.
"ciphersuites"	Command for IOverAT TLS Cipher Suite file management.
"is_cert"	Secure Command Mode (Manage Certificates).
"omadm"	Command for OMA DM certificate management.

<subtype>^(num)

1	Start Secure Command Block Transfer mode
---	--

<agps_length>^(num)

4097...61440	Size of xtra.bin file (number of bytes).
-1	Delete stored xtra.bin file. Also all currently used GPS data are deleted.

Notes

- The AT^SBNW="AGPS" write command can be used to load binary data for A-GNSS (Assisted GNSS) from a local memory to the PLS8-X Flash File System (FFS). The GNSS receiver integrated in PLS8-X supports gpsOneXTRA™ assistance data.

Before transferring A-GNSS data ensure that the following conditions are met:

- Take care that the RTC of PLS8-X is correctly set to Greenwich Mean Time (GMT):0 with AT+CCLK and is up to date.
- Deactivate the GNSS receiver with AT^SGPSC="<EngineVal>",0.
- Download a new GpsOneXTRA binary file (named xtra.bin for GPS and xtra2.bin for GPS + GLONASS) via HTTP from one of the following gpsOneXtra assistance webservers:
 - <http://xtra1.gpsonextra.net/xtra.bin>
 - <http://xtra2.gpsonextra.net/xtra.bin>
 - <http://xtra3.gpsonextra.net/xtra.bin>
- <http://xtra1.gpsonextra.net/xtra2.bin>
- <http://xtra2.gpsonextra.net/xtra2.bin>
- <http://xtra3.gpsonextra.net/xtra2.bin>
- Save the received XTRA file to your local memory and check the exact file size (approximately 40kB). This is because the precise data length shall be given when storing the XTRA file to the PLS8-X FFS. The data

length shall be the second parameter `<agps_length>`.

The UE verifies the XTRA file. If the validation check is successful the UE will send the responses "AGPS END OK" and "OK" and return to command mode. The file will be saved in the FFS and injected into the GNSS engine. If the validation check is not successful the file will also be saved in the FFS, but not injected. The data can be used to achieve faster TTFF (Time to First Fix). For this purpose, set `AT^SGPSC="<EngineVal>`",2 and activate the GNSS receiver. Assistance data is valid for up to 7 days.

19.5 AT^SFDL Enter Firmware Download Mode

[AT^SFDL](#) allows the application manufacturer to download PLS8-X firmware into the module by starting the download process from the host application or a customer-designed download program.

This manual only describes the handling of the [AT^SFDL](#) command. All technical requirements and steps to prepare the host application for this download solution can be found in the Application Note "Updating Firmware". An example for developing an appropriate download program is included.

The [AT^SFDL](#) execute command causes the module to enter the firmware download mode.

Syntax

Test Command				
AT^SFDL=?				
Response(s)				
OK				
Exec Command				
AT^SFDL				
Response(s)				
OK				
PIN	MDM	APP	→	Last
-	+	-	+	+

20. Appendix

20.1 Star-Hash (*#) Network Commands

The following command strings can be sent to the network via ATD and have to be terminated with a semicolon. The command strings are defined with 3GPP TS 22.030 [27].

Table 20.1: Star-Hash (*#) Command Overview

Star-Hash Code	Functionality	Response, also refer to Table 20.3
Phone Security		
*#06#	Query IMEI	<IMEI> OK
**04[2]*oldPin[2]*newPin[2]*newPin[2]#	Change SIM pwd	+CME ERROR: <err> / OK
**05[2]*unblKey[2]*newPin[2]*newPin[2]#	Change/Unblocking SIM pwd	+CME ERROR: <err> / OK
[]03*[ZZ]*oldPw*newPw*newPw#	Registration of net password	+CME ERROR: <err> / OK
USSD messages		
[C]...[C]#	Send USSD message	+CME ERROR: <err> / OK
C[C] (excluded 1[C])	Send USSD message	+CME ERROR: <err> / OK

Table 20.2: Abbreviations of Codes and Parameters used in Table 20.1

Abbreviation	Meaning	Value
ZZ	Type of supplementary services: Barring services All services	330 Not specified
DN	Dialing number	String of digits 0-9
BS	Basic service equivalent to parameter class: Voice Fax (only for compatibility reasons) SMS SMS+Fax (only for compatibility reasons) Data circuit asynchron Data circuit synchron Dedicated PAD access Dedicated Packet access Data circuit asynchron+PAD Data circuit synchron+Packet Data circuit asynchron+synchron+Packet+PAD All Services	11 13 16 12 25 24 27 26 21 22 20 --
T	Time in seconds	In contrast to AT+CCFC, parameter T has no default value. If T is not specified, an operator defined default or the last known value may be used, depending on the network operator.

20.1 Star-Hash (*#) Network Commands

Abbreviation	Meaning	Value
PW	Password	--
C	Character of TE character set (e.g. asterisk, hash or digit in case of USSD, or digits in case of held calls or multiparty calls)	--

Table 20.3: Star-Hash Command Response Parameters

Parameter	Meaning
<m>	Mode: 0 = not active, 1 = active
<n>	Unsolicited result code: 0 = presentation disabled, 1 = presentation enabled
<status>	Status: 0 = not active, 1 = active
<class>	Represents BS = basic service, refer to AT+CCFC , AT+CLCK
<fac>	Facility lock, refer to AT+CLCK
<reason>	Call forwarding reason

For exact specification of format and parameters for Star-Hash commands refer to Table 3.2 of 3GPP TS 22.004 [26], and Annex C of 3GPP TS 22.030 [27].

Table 20.4: Star-Hash Commands for Supplementary Services

Star-Hash Code	Abbreviations in Table 20.1	Functionality
*	act	Activate (except for CLIR, see list above)
**	reg	Register and activate
*#	int	Check status (interrogate)
#	deact	Deactivate (except for CLIR, see list above)
##	eras	Unregister and deactivate

20.2 Available AT Commands and Dependency on SIM PIN

20.2 Available AT Commands and Dependency on SIM PIN

- ∅ ... Command not available
 - ... Command does not require PIN1
 + ... Command requires PIN1
 ± ... Command sometimes requires PIN1

Table 20.5: Available AT Commands and Dependency on SIM PIN

AT Command	Exec	Test	Read	Write
Configuration Commands				
AT&F	-	∅	∅	∅
AT&V	-	∅	∅	∅
AT&W	-	∅	∅	∅
ATQ	-	∅	∅	∅
ATV	-	∅	∅	∅
ATX	+	∅	∅	∅
ATZ	+	∅	∅	∅
AT+CMEE	-	-	-	-
AT+CSCS	∅	-	-	-
AT+CFUN	∅	-	-	-
AT+GCAP	+	+	∅	∅
AT^SMSO	-	-	∅	∅
AT^SCFG	∅	-	-	-
AT^SSRVSET	∅	-	-	-
Status Control Commands				
AT+CEER	+	+	∅	+
AT^SIND	∅	-	-	-
AT+CPAS	-	-	∅	∅
AT+WS46	∅	-	-	-
Serial Interface Control Commands				
AT\Q	-	∅	∅	∅
AT&C	+	∅	∅	∅
AT&D	+	∅	∅	∅
AT&S	-	∅	∅	∅
ATE	-	∅	∅	∅
AT+IPR	∅	-	-	-
AT+CMUX	∅	-	-	-
AT^SQPORT	-	-	-	∅
Security Commands				
AT+CPIN	∅	-	-	-
AT+CLCK	∅	+	∅	+

20.2 Available AT Commands and Dependency on SIM PIN

AT Command	Exec	Test	Read	Write
AT+CPWD	∅	+	∅	+
AT^SPIC	-	-	-	-
Identification Commands				
ATI	±	∅	∅	∅
AT+CGMI	-	-	∅	∅
AT+GMI	-	-	∅	∅
AT+CGMM	-	-	∅	∅
AT+GMM	-	-	∅	∅
AT+CGMR	-	-	∅	∅
AT+GMR	-	-	∅	∅
AT+CGSN	-	-	∅	∅
AT+GSN	-	-	∅	∅
AT+CIMI	+	+	∅	∅
Network Service Commands				
AT+COPN	+	+	∅	∅
AT+COPS	∅	+	+	+
AT+CPOL	∅	+	+	+
AT+CPLS	∅	+	+	+
AT+CREG	∅	-	-	-
AT+CESQ	+	+	∅	∅
AT+CSQ	+	+	∅	∅
AT+CTZU	∅	-	-	-
AT^SMONI	-	-	∅	-
AT^SMONP	-	-	∅	-
AT^SNMON	∅	-	∅	-
AT^SNCSGLS	+	+	∅	∅
AT^SNCSGSC	∅	-	-	-
AT^SNRSRP	∅	+	+	∅
AT^SNRSRQ	∅	+	+	∅
USIM Application Toolkit (USAT) Commands				
AT^SSTA	∅	-	-	-
AT^SSTGI	∅	-	-	-
AT^SSTGI	∅	∅	∅	-
AT^SSTGI	∅	∅	∅	-
AT^SSTGI	∅	∅	∅	-
AT^SSTGI	∅	∅	∅	-
AT^SSTGI	∅	∅	∅	-
AT^SSTGI	∅	∅	∅	-
AT^SSTGI	∅	∅	∅	-
AT^SSTGI	∅	∅	∅	-

AT Command	Exec	Test	Read	Write
AT+CMGD	∅	+	∅	+
AT+CMGF	∅	+	+	+
AT+CMGL	+	+	∅	+
AT+CMGR	∅	+	∅	+
AT+CMGS	∅	+	∅	+
AT+CMGW	+	+	∅	+
AT+CMSS	∅	+	∅	+
AT+CNMA	+	+	∅	+
AT+CNMI	∅	+	+	+
AT+CPMS	∅	+	+	+
AT+CSCA	∅	+	+	+
AT+CSCB	∅	+	+	+
AT+CSDH	∅	+	+	+
AT+CSMP	∅	+	+	+
AT+CSMS	∅	+	+	+
AT^SMGL	+	+	∅	+
AT^SMGR	∅	+	∅	+
AT^SSDA	∅	-	-	-
Internet Service Commands				
AT^SICA	∅	+	+	+
AT^SICS	∅	-	-	-
AT^SIPS	∅	-	∅	-
AT^SISS	∅	-	-	-
AT^SISI	∅	-	-	-
AT^SISO	∅	-	-	+
AT^SISC	∅	-	∅	+
AT^SISR	∅	-	∅	+
AT^SISW	∅	-	∅	+
AT^SIST	∅	-	-	-
AT^SISH	∅	-	∅	-
AT^SISX	∅	+	∅	+
AT^SISE	∅	-	∅	-
Supplementary Service Commands				
ATD	±	∅	∅	∅
AT+CCFC	∅	+	∅	+
AT+CUSD	∅	+	+	+
Packet Domain Related Commands				
AT+CGDCONT	∅	-	-	-
AT+CGATT	∅	+	+	+
AT+CGACT	∅	+	+	+

20.2 Available AT Commands and Dependency on SIM PIN

AT Command	Exec	Test	Read	Write
AT+CGDATA	∅	+	∅	+
AT+CGPADDR	+	+	∅	+
AT+CGPIAF	∅	+	+	+
AT+CGEREP	∅	+	+	+
AT+CGREG	∅	+	+	+
AT+CEREG	+	+	+	+
AT+CGCONTRDP	+	+	∅	+
AT+CGEQOS	∅	-	-	-
AT+CGEQOSRDP	∅	+	∅	+
AT+CGSMS	∅	+	+	+
AT+CNMPSD	+	+	∅	∅
ATD*99#	+	∅	∅	∅
AT^SGAPN	∅	-	-	-
AT^SGAUTH	∅	-	-	-
AT^SWWAN	∅	+	+	+
USIM related Commands				
AT+CRSM	∅	-	∅	-
AT+CSIM	∅	-	∅	-
AT^SATR	∅	-	∅	-
AT^SCKS	∅	-	-	-
AT^SSET	∅	-	-	-
AT^SCID	-	-	∅	∅
Phonebook Commands				
AT+CPBS	+	+	+	+
AT+CPBR	∅	+	∅	+
AT+CPBW	∅	+	∅	+
AT+CNUM	+	+	∅	∅
GNSS Commands				
AT^SGPSC	∅	-	-	-
Audio Commands				
AT^SAIC	∅	-	-	-
AT^SNFG	∅	-	∅	-
AT^SNFI	∅	-	-	-
AT^SNFO	∅	-	-	-
AT^SNFS	∅	-	-	-
Hardware related Commands				
AT+CALA	∅	-	-	-
AT+CCLK	∅	-	-	-

AT Command	Exec	Test	Read	Write
AT^SAD	∅	-	∅	-
AT^SBV	-	-	∅	∅
AT^SCTM	∅	-	-	-
AT^SLED	∅	-	-	-
AT^SRADC	∅	-	-	-
General Purpose I/O (GPIO) Pin related Commands				
AT^SPIO	∅	-	∅	-
AT^SCPIN	∅	-	∅	-
AT^SCPOL	∅	-	∅	-
AT^SGIO	∅	-	∅	-
AT^SSIO	∅	-	∅	-
Miscellaneous Commands				
A/	-	∅	∅	∅
+++	-	∅	∅	∅
AT^SBNR	∅	-	-	-
AT^SBNW	∅	-	∅	-
AT^SFDL	-	-	∅	∅

20.3 Availability of AT Commands Depending on Operating Mode of ME

20.3 Availability of AT Commands Depending on Operating Mode of ME

- ... AT command not supported
 - + ... AT command supported
 - ± ... AT command partially supported
- See description of AT command for details.

Table 20.6: Availability of AT Commands Depending on Operating Mode of ME

AT Command	Normal Mode	→
Configuration Commands		
AT&F	+	+
AT&V	+	+
AT&W	+	+
ATQ	+	+
ATV	+	+
ATX	+	+
ATZ	+	+
AT+CMEE	+	+
AT+CSCS	+	+
AT+CFUN	+	+
AT+GCAP	+	+
AT^SMSO	+	+
AT^SCFG	+	+
AT^SSRVSET	+	+
Status Control Commands		
AT+CEER	+	+
AT^SIND	+	+
AT+CPAS	+	+
AT+WS46	+	+
Serial Interface Control Commands		
AT\Q	+	+
AT&C	+	+
AT&D	+	+
AT&S	+	+
ATE	+	+
AT+IPR	+	+
AT+CMUX	+	+
AT^SQPORT	+	+
Security Commands		
AT+CPIN	+	+
AT+CLCK	+	±

20.3 Availability of AT Commands Depending on Operating Mode of ME

AT Command	Normal Mode	→
AT+CPWD	+	±
AT^SPIC	+	+
Identification Commands		
ATI	+	+
AT+CGMI	+	+
AT+GMI	+	+
AT+CGMM	+	+
AT+GMM	+	+
AT+CGMR	+	+
AT+GMR	+	+
AT+CGSN	+	+
AT+GSN	+	+
AT+CIMI	+	+
Network Service Commands		
AT+COPN	+	+
AT+COPS	+	-
AT+CPOL	+	+
AT+CPLS	+	-
AT+CREG	+	-
AT+CESQ	+	-
AT+CSQ	+	-
AT+CTZU	+	+
AT^SMONI	+	-
AT^SMONP	+	-
AT^SNMON	+	-
AT^SNCSGLS	+	+
AT^SNCSGSC	+	-
AT^SNRSRP	+	-
AT^SNRSRQ	+	-
USIM Application Toolkit (USAT) Commands		
AT^SSTA	+	+
AT^SSTGI	+	+
AT^SSTGI	+	+
AT^SSTGI	+	+
AT^SSTGI	+	+
AT^SSTGI	+	+
AT^SSTGI	+	+
AT^SSTGI	+	+
AT^SSTGI	+	+

20.3 Availability of AT Commands Depending on Operating Mode of ME

AT Command	Normal Mode	→
Short Message Service (SMS) Commands		
AT+CMGC	+	-
AT+CMGD	+	+
AT+CMGF	+	+
AT+CMGL	+	+
AT+CMGR	+	+
AT+CMGS	+	-
AT+CMGW	+	+
AT+CMSS	+	-
AT+CNMA	+	-
AT+CNMI	+	+
AT+CPMS	+	+
AT+CSCA	+	+
AT+CSCB	+	+
AT+CSDH	+	+
AT+CSMP	+	+
AT+CSMS	+	+
AT^SMGL	+	+
AT^SMGR	+	+
AT^SSDA	+	+
Internet Service Commands		
AT^SICA	+	-
AT^SICS	+	+
AT^SIPS	+	+
AT^SISS	+	+
AT^SISI	+	+
AT^SISO	+	-
AT^SISC	+	-
AT^SISR	+	-
AT^SISW	+	-
AT^SIST	+	-
AT^SISH	+	-
AT^SISX	+	-
AT^SISE	+	-
Supplementary Service Commands		
ATD	+	-
AT+CCFC	+	-
AT+CUUSD	+	-

20.3 Availability of AT Commands Depending on Operating Mode of ME

AT Command	Normal Mode	→
Packet Domain Related Commands		
AT+CGDCONT	+	+
AT+CGATT	+	-
AT+CGACT	+	-
AT+CGDATA	+	-
AT+CGPADDR	+	+
AT+CGPIAF	+	+
AT+CGEREP	+	+
AT+CGREG	+	+
AT+CEREG	+	+
AT+CGCONTRDP	+	-
AT+CGEQOS	+	+
AT+CGEQOSRDP	+	-
AT+CGSMS	+	+
AT+CNMPD	+	-
ATD*99#	+	-
AT^SGAPN	+	+
AT^SGAUTH	+	+
AT^SWWAN	+	-
USIM related Commands		
AT+CRSM	+	+
AT+CSIM	+	+
AT^SATR	+	+
AT^SCKS	+	+
AT^SSET	+	+
AT^SCID	+	+
Phonebook Commands		
AT+CPBS	+	+
AT+CPBR	+	+
AT+CPBW	+	+
AT+CNUM	+	+
GNSS Commands		
AT^SGPSC	+	+
Audio Commands		
AT^SAIC	+	+
AT^SNFG	+	+
AT^SNFI	+	+
AT^SNFO	+	+

20.3 Availability of AT Commands Depending on Operating Mode of ME

AT Command	Normal Mode	→
AT^SNFS	+	+
Hardware related Commands		
AT+CALA	+	+
AT+CCLK	+	+
AT^SAD	+	+
AT^SBV	+	+
AT^SCTM	+	+
AT^SLED	+	+
AT^SRADC	+	+
General Purpose I/O (GPIO) Pin related Commands		
AT^SPIO	+	+
AT^SCPIN	+	+
AT^SCPOL	+	+
AT^SGIO	+	+
AT^SSIO	+	+
Miscellaneous Commands		
A/	+	+
+++	+	-
AT^SBNR	+	+
AT^SBNW	+	+
AT^SFDL	+	+

20.4 AT Command Settings storable with AT&W

Table 20.7: Settings Stored to User Profile

AT Command	Stored Parameters
Configuration Commands	
ATQ	<n>
ATV	<value>
ATX	<value>
AT+CMEE	<errMode>
Serial Interface Control Commands	
AT\Q	<n>
AT&C	<value>
AT&D	<value>
AT&S	<value>
ATE	<value>
Network Service Commands	
AT+COPS	<format>
AT+CREG	<urcMode>
Short Message Service (SMS) Commands	
AT+CMGF	<mode>
AT+CNMI	<mode>, <mt>, <bm>, <ds>, <bfr>
AT+CSDH	<show>
AT+CSMS	<service>
USIM related Commands	
AT^SCKS	<mode>
AT^SSET	<n>
Hardware related Commands	
AT^SLED	<mode>, <flash>

20.5 Factory Default Settings Restorable with AT&F

Table 20.8: Factory Default Settings Restorable with AT&F

AT Command	Factory Defaults
Configuration Commands	
ATQ	<n>=0
ATV	<value>=1
ATX	<value>=0
AT+CMEE	<errMode>=2
AT+CSCS	<charSet>="GSM"
AT^SCFG	<tcpMr>="10", <tcpOt>="6000"
Serial Interface Control Commands	
AT\Q	<n>=3
AT&C	<value>=1
AT&D	<value>=2
AT&S	<value>=0
ATE	<value>=1
Network Service Commands	
AT+CREG	<urcMode>=0
AT+CTZU	<n>=0
Short Message Service (SMS) Commands	
AT+CMGF	<mode>=0
AT+CNMI	<mode>=0, <mt>=0, <bm>=0, <ds>=0, <bfr>=1
AT+CSCB	<operation>=0, <dcss>=" "
AT+CSDH	<show>=0
AT+CSMP	<pid>=0, <dcs>=0
AT+CSMS	<service>=0
AT^SSDA	<da>=1
Supplementary Service Commands	
AT+CUSD	<ussdMode>=0
Packet Domain Related Commands	
AT+CGPIAF	<format>=0, <subnet>=0, <lzeros>=0, <czeros>=0
AT+CGREG	<n>=0
AT+CEREG	<n>=0
USIM related Commands	
AT^SCKS	<mode>=0
AT^SSET	<n>=0

AT Command	Factory Defaults
Phonebook Commands	
AT+CPBS	<storage>="SM"
Hardware related Commands	
AT^SCTM	<UrcMode>=0
AT^SLED	<mode>=0

20.6 Summary of Unsolicited Result Codes (URC)

Table 20.9: Summary of Unsolicited Result Codes (URC)

AT Command	URC
Unsolicited Result Code Presentation	
	^SBC: Undervoltage
	^SBC: Overvoltage Warning
	^SBC: Overvoltage Shutdown
Configuration Commands	
AT+CFUN	^SYSSTART
AT+CFUN	^SYSSTART AIRPLANE MODE
Status Control Commands	
AT^SIND	+CIEV: <indDescr>, <indValue>
AT^SIND	+CIEV: <indDescr>, <cmdType>, <commandDetails>[, <pathLen>, <fileNum>, <fileList>[, <status>, <statAddInfo>]]
AT^SIND	+CIEV: <indDescr>, <indValue>, <eonsOperator>, <servProvider>, <servProviderType>
AT^SIND	+CIEV: <indDescr>, <nitzUT>, <nitzTZ>[, <nitzDST>]
AT^SIND	+CIEV: <indDescr>
AT^SIND	+CIEV: <indDescr>, <indValue>, <lstaEdvs>, <lstaRssi>
AT^SIND	+CIEV: <indDescr>, <indValue>, <lstaNo>, <lstaMin>, <lstaMax>, <lsta-Mean>, <lstaVar>
AT^SIND	+CIEV: <indDescr>, <ceerRelCauseGroup>, <ceerReport>
AT^SIND	+CIEV: <indDescr>, <indValue> _{slot_1} , <indValue> _{slot_2}
AT^SIND	+CIEV: <indDescr>[, <newsmsact>, <newsmsmem>, <newsmsindex>]
AT^SIND	+CIEV: <indDescr>, <srvProfileId>, <issuer>, <serialNumber>, <subject>, <signatureAlgorithm>, <thumbprintAlgorithm>, <thumbprint>
AT^SIND	+CIEV: <indDescr>, <OmaDmAction>[, <OmaDmStatus>]
AT^SIND	+CIEV: <indDescr>, <containerid>, <mccmnc>, <clength>, <container>
AT^SIND	+CIEV: <indDescr>, <simreadEf>
AT^SIND	+CIEV: <indDescr>, <ltebotTimerstat>, <ltebotReason>, <APN>[, <ltebotReasonTxt>]
AT^SIND	+CIEV: <indDescr>, <provMm>, <provCur>
Network Service Commands	
AT+CREG	+CREG: <regStatus>
AT+CREG	+CREG: <regStatus>[, <netLac>, <netCellId>[, <Act>]]
AT+CTZU	+CTZU:<nitzUT>, <nitzTZ>[, <nitzDST>]
USIM Application Toolkit (USAT) Commands	
^SSTN SAT Notif-ication	^SSTN: <cmdType>

AT Command	URC
^SSTN SAT Notification	^SSTN: <cmdTerminateValue>
^SSTN SAT Notification	^SSTN: 254
^SSTN SAT Notification	^SSTN: 255
Short Message Service (SMS) Commands	
AT+CNMI	+CMTI: <mem3>, <index>
AT+CNMI	+CMT: <length><CR><LF><pdu>
AT+CNMI	+CMT: <oa>, , <scts>[, <tooa>, <fo>, <pid>, <dcsc>, <sca>, <tosca>, <length>]<CR><LF><data>
AT+CNMI	+CBM: <length><CR><LF><pdu>
AT+CNMI	+CBM: <sn>, <mid>, <dcsc>, <page>, <pages><CR><LF><data>
AT+CNMI	+CDS: <length><CR><LF><pdu>
AT+CNMI	+CDS: <fo>, <mr>[, <ra>][, <tora>], <scts>, <dt>, <st>
AT+CNMI	+CDS: <fo>, <mr>, <ra>, <tora>, <scts>, , <st>, <length><CR><LF><data>
AT+CNMI	+CMT: <length><CR><LF><pdu>
AT+CNMI	+CMT: <stat>, <oa>, <scts>, <length>
Internet Service Commands	
AT^SISR	^SISR: <srvProfileId>, <urcCauseId>
AT^SISW	^SISW: <srvProfileId>, <urcCauseId>
Internet Service URC	^SIS: <srvProfileId>, <urcCause>[, [<urcInfoId>][, <urcInfoText>]]
Supplementary Service Commands	
AT+CUUSD	+CUUSD: <ussdStatus>[, <ussdRsp>[, <ussdDCS>]]
Packet Domain Related Commands	
AT+CGEREP	+CGEV: REJECT <PDP_type>, <PDP_addr>
AT+CGEREP	+CGEV: NW REACT <PDP_type>, <PDP_addr>[, <cid>]
AT+CGEREP	+CGEV: NW DEACT <PDP_type>, <PDP_addr>[, <cid>]
AT+CGEREP	+CGEV: ME DEACT <PDP_type>, <PDP_addr>[, <cid>]
AT+CGEREP	+CGEV: NW DETACH
AT+CGEREP	+CGEV: ME DETACH
AT+CGEREP	+CGEV: NW CLASS <class>
AT+CGEREP	+CGEV: ME CLASS <class>
AT+CGEREP	+CGEV: PDN ACT <cid>
AT+CGEREP	+CGEV: PDN DEACT <cid>
AT+CGEREP	+CGEV: NW MODIFY <cid>,<change-reason>,<event-type>
AT+CGEREP	+CGEV: ME MODIFY <cid>, <change-reason>, <event-type>
AT+CGEREP	+CGEV: ME PDN ACT <cid>[, <reason>]
AT+CGREG	+CGREG: <stat>

20.7 AT Commands Supported Only on the Modem Interface

Table 20.10: AT Commands Supported Only on the Modem Interface

AT Command
Serial Interface Control Commands
AT&D
AT&S
AT+CMUX
Packet Domain Related Commands
AT+CGDATA
ATD*99#
Miscellaneous Commands
AT^SFDL

20.8 Alphabetical List of AT Commands

Table 20.11: Alphabetical List of AT Commands

AT Command	Description	Section and Page
+++	Escape from Data Mode to AT Command Mode	Section 19.2, page 454
A/	Repeat Previous Command Line	Section 19.1, page 453
AT&C	Set Data Carrier Detect (DCD) line mode	Section 4.2, page 107
AT&D	Set Data Terminal Ready (DTR) line mode	Section 4.3, page 108
AT&F	Reset AT Command Settings to Factory Default Values	Section 2.1, page 30
AT&S	Set Data Set Ready (DSR) line mode	Section 4.4, page 109
AT&V	Display current Configuration	Section 2.2, page 31
AT&W	Store AT Command Settings to User Defined Profile	Section 2.3, page 32
AT+CALA	Alarm Configuration	Section 17.1, page 430
AT+CCFC	Call forwarding number and conditions control	Section 11.2, page 344
AT+CCLK	Real Time Clock	Section 17.2, page 433
AT+CEER	Extended Error Report	Section 3.1, page 79
AT+CEREG	EPS Network Registration Status	Section 12.9, page 368
AT+CESQ	Extended Signal Quality	Section 7.6, page 149
AT+CFUN	PLS8-X Functionality Level	Section 2.10, page 43
AT+CGACT	PDP Context Activate or Deactivate	Section 12.3, page 355
AT+CGATT	PS Attach or Detach	Section 12.2, page 354
AT+CGCONTRDP	PDP context read dynamic parameters	Section 12.10, page 370
AT+CGDATA	Enter Data State	Section 12.4, page 357
AT+CGDCONT	Define PDP Context	Section 12.1, page 350
AT+CGEQOS	Define EPS Quality of Service	Section 12.11, page 372
AT+CGEQOSRDP	EPS Quality of Service Read Dynamic Parameters	Section 12.12, page 374
AT+CGEREP	Packet Domain Event Reporting	Section 12.7, page 363
AT+CGMI	Request manufacturer identification	Section 6.2, page 134
AT+CGMM	Request model identification	Section 6.4, page 135
AT+CGMR	Request revision identification of software status	Section 6.6, page 136
AT+CGPADDR	Show PDP Address	Section 12.5, page 359
AT+CGPIAF	Select Printing IP address format	Section 12.6, page 361
AT+CGREG	Packet Domain Network Registration Status	Section 12.8, page 366
AT+CGSMS	Select Service for MO Short Messages	Section 12.13, page 376
AT+CGSN	Request International Mobile Equipment Identity (IMEI)	Section 6.8, page 137
AT+CIMI	Request International Mobile Subscriber Identity (IMSI)	Section 6.10, page 138
AT+CLCK	Facility Lock	Section 5.2, page 117
AT+CMEE	Error Message Format	Section 2.8, page 37
AT+CMGC	Send an SMS command	Section 9.2, page 258
AT+CMGD	Delete short message	Section 9.3, page 259
AT+CMGF	Select SMS message format	Section 9.4, page 260
AT+CMGL	List SMS messages from preferred store	Section 9.5, page 261
AT+CMGR	Read SMS messages	Section 9.6, page 263

AT Command	Description	Section and Page
AT+CMGS	Send Short Message	Section 9.7, page 265
AT+CMGW	Write Short Messages to Memory	Section 9.8, page 266
AT+CMSS	Send short messages from storage	Section 9.9, page 267
AT+CMUX	Multiplex mode	Section 4.7, page 112
AT+CNMA	New Message Acknowledgement to UE/TE	Section 9.10, page 268
AT+CNMI	SMS Event Reporting Configuration	Section 9.11, page 270
AT+CNMPD	No more PS data	Section 12.14, page 377
AT+CNUM	Read own numbers	Section 14.4, page 404
AT+COPN	Read operator names	Section 7.1, page 139
AT+COPS	Operator Selection	Section 7.2, page 140
AT+CPAS	Activity Status	Section 3.3, page 104
AT+CPBR	Read from phonebook	Section 14.2, page 398
AT+CPBS	Select phonebook memory storage	Section 14.1, page 395
AT+CPBW	Write into phonebook	Section 14.3, page 401
AT+CPIN	PIN Authentication	Section 5.1, page 115
AT+CPLS	Select Preferred Operator List	Section 7.4, page 145
AT+CPMS	Preferred SMS message storage	Section 9.12, page 274
AT+CPOL	Preferred Operator List	Section 7.3, page 143
AT+CPWD	Change Password	Section 5.3, page 124
AT+CREG	Network Registration Status	Section 7.5, page 146
AT+CRSM	Restricted USIM Access	Section 13.1, page 386
AT+CSCA	SMS Service Center Address	Section 9.13, page 276
AT+CSCB	Select Cell Broadcast Message Indication	Section 9.14, page 277
AT+CSCS	Character Set	Section 2.9, page 42
AT+CSDH	Show SMS text mode parameters	Section 9.15, page 279
AT+CSIM	Generic USIM Access	Section 13.2, page 388
AT+CSMP	Set SMS Text Mode Parameters	Section 9.16, page 280
AT+CSMS	Select Message Service	Section 9.17, page 282
AT+CSQ	Signal Quality	Section 7.7, page 151
AT+CTZU	Automatic Time Zone Update	Section 7.8, page 152
AT+CUSD	Unstructured Supplementary Service Data	Section 11.3, page 348
AT+GCAP	Capabilities List	Section 2.11, page 45
AT+GMI	Request manufacturer identification	Section 6.3, page 134
AT+GMM	Request model identification	Section 6.5, page 135
AT+GMR	Request revision identification of software status	Section 6.7, page 136
AT+GSN	Request International Mobile Equipment Identity (IMEI)	Section 6.9, page 137
AT+IPR	Bit Rate	Section 4.6, page 111
AT+WS46	Select wireless network	Section 3.4, page 105
AT\Q	Flow Control	Section 4.1, page 106
AT^SAD	Antenna Configuration	Section 17.3, page 435
AT^SAIC	Audio Interface Configuration	Section 16.1, page 421
AT^SATR	Query SIM's Answer to Reset Data	Section 13.3, page 390

AT Command	Description	Section and Page
AT^SBNR	Binary Read	Section 19.3, page 455
AT^SBNW	Binary Write	Section 19.4, page 457
AT^SBV	Battery/Supply Voltage	Section 17.4, page 437
AT^SCFG	Extended Configuration Settings	Section 2.13, page 47
AT^SCID	USIM Identification Number	Section 13.6, page 394
AT^SCKS	Query USIM and Chip Card Holder Status	Section 13.4, page 391
AT^SCPIN	Pin Configuration	Section 18.2, page 448
AT^SCPOL	GPIO Level Polling Configuration	Section 18.3, page 450
AT^SCTM	Critical Operating Temperature Monitoring	Section 17.5, page 438
AT^SFDL	Enter Firmware Download Mode	Section 19.5, page 461
AT^SGAPN	Configure APN class settings	Section 12.16, page 379
AT^SGAUTH	Set Type of Authentication for PDP-IP Connections	Section 12.17, page 382
AT^SGIO	Get IO state of a specified pin	Section 18.4, page 451
AT^SGPSC	GNSS Configuration	Section 15.4, page 410
AT^SICA	Internet Connection Activate or Deactivate	Section 10.1, page 291
AT^SICS	Internet Connection Settings	Section 10.2, page 292
AT^SIND	Extended Indicator Control	Section 3.2, page 88
AT^SIPS	Internet Profile Storage	Section 10.3, page 294
AT^SISC	Internet Service Close	Section 10.7, page 308
AT^SISE	Internet Service Error Report	Section 10.13, page 321
AT^SISH	Disconnect Remote Client	Section 10.11, page 317
AT^SISI	Internet Service Information	Section 10.5, page 303
AT^SISO	Internet Service Open	Section 10.6, page 305
AT^SISR	Internet Service Read Data	Section 10.8, page 309
AT^SISS	Internet Service Setup Profile	Section 10.4, page 295
AT^SIST	Transparent Mode	Section 10.10, page 315
AT^SISW	Internet Service Write Data	Section 10.9, page 312
AT^SISX	Internet Service Execution	Section 10.12, page 318
AT^SLED	LED Feature	Section 17.6, page 441
AT^SMGL	List Short Messages from preferred store without setting status to REC READ	Section 9.18, page 284
AT^SMGR	Read short message without setting status to REC READ	Section 9.19, page 285
AT^SMONI	Monitoring Serving Cell	Section 7.9, page 154
AT^SMONP	Monitoring Neighbour Cells	Section 7.10, page 163
AT^SMSO	Switch Off PLS8-X	Section 2.12, page 46
AT^SNCSGLS	Operator CSG lists on USIM	Section 7.12, page 172
AT^SNCSGSC	Closed Subscriber Group Network Scan	Section 7.13, page 173
AT^SNFG	Generate Tone	Section 16.2, page 424
AT^SNFI	Set microphone path parameters	Section 16.3, page 426
AT^SNFO	Set audio output parameter (loudspeaker path)	Section 16.4, page 427
AT^SNFS	Select audio hardware set	Section 16.5, page 429
AT^SNMON	Network Monitoring	Section 7.11, page 170

AT Command	Description	Section and Page
AT^SNRSRP	Neighbour Reference Signal Received Power	Section 7.14, page 175
AT^SNRSRQ	Neighbour Reference Signal Received Quality	Section 7.15, page 176
AT^SPIC	Display PIN Counter	Section 5.4, page 127
AT^SPIO	GPIO Driver Open/Close	Section 18.1, page 447
AT^SQPORT	Query Port Type	Section 4.8, page 114
AT^SRADC	Configure and Read A/D Converter	Section 17.7, page 443
AT^SSDA	Set SMS Display Availability	Section 9.20, page 286
AT^SSET	USIM Data Ready Indication	Section 13.5, page 393
AT^SSIO	Set IO state of a specified pin	Section 18.5, page 452
AT^SSRVSET	Service Interface Configuration	Section 2.14, page 73
AT^SSTA	Remote-SAT Interface Activation	Section 8.4, page 187
AT^SSTGI	SAT Get Information	Section 8.6, page 191
AT^SSTGI	SAT Get Information - Refresh (1)	Section 8.7, page 192
AT^SSTGI	SAT Get Information - Set Up Event List (5)	Section 8.8, page 194
AT^SSTGI	SAT Get Information - Set Up Call (16)	Section 8.9, page 195
AT^SSTGI	SAT Get Information - Send SS (17)	Section 8.10, page 197
AT^SSTGI	SAT Get Information - Send USSD (18)	Section 8.11, page 198
AT^SSTGI	SAT Get Information - Send Short Message (19)	Section 8.12, page 199
AT^SSTGI	SAT Get Information - Send DTMF (20)	Section 8.13, page 200
AT^SSTGI	SAT Get Information - Launch Browser (21)	Section 8.14, page 201
AT^SSTGI	SAT Get Information - Play Tone (32)	Section 8.15, page 203
AT^SSTGI	SAT Get Information - Display Text (33)	Section 8.16, page 205
AT^SSTGI	SAT Get Information - Get Inkey (34)	Section 8.17, page 207
AT^SSTGI	SAT Get Information - Get Input (35)	Section 8.18, page 209
AT^SSTGI	SAT Get Information - Select Item (36)	Section 8.19, page 211
AT^SSTGI	SAT Get Information - Set up Menu (37)	Section 8.20, page 213
AT^SSTGI	SAT Get Information - Set up Idle Mode Text (40)	Section 8.21, page 215
AT^SSTGI	SAT Get Information - Language Notification (53)	Section 8.22, page 216
AT^SSTGI	SAT Get Information - Open Channel (64)	Section 8.23, page 217
AT^SSTGI	SAT Get Information - Close Channel (65)	Section 8.24, page 218
AT^SSTGI	SAT Get Information - Receive Data (66)	Section 8.25, page 219
AT^SSTGI	SAT Get Information - Send Data (67)	Section 8.26, page 220
AT^SSTR	SAT Response	Section 8.27, page 221
AT^SSTR	SAT Response - Refresh (1)	Section 8.28, page 223
AT^SSTR	SAT Response - Set Up Event List (5)	Section 8.29, page 224
AT^SSTR	SAT Response - Set Up Call (16)	Section 8.30, page 225
AT^SSTR	SAT Response - Send SS (17)	Section 8.31, page 226
AT^SSTR	SAT Response - Send USSD (18)	Section 8.32, page 227
AT^SSTR	SAT Response - Send Short Message (19)	Section 8.33, page 228
AT^SSTR	SAT Response - Send DTMF (20)	Section 8.34, page 229
AT^SSTR	SAT Response - Launch Browser (21)	Section 8.35, page 230
AT^SSTR	SAT Response - Play Tone (32)	Section 8.36, page 231

AT Command	Description	Section and Page
AT^SSTR	SAT Response - Display Text (33)	Section 8.37 , page 232
AT^SSTR	SAT Response - Get Inkey (34)	Section 8.38 , page 233
AT^SSTR	SAT Response - Get Input (35)	Section 8.39 , page 235
AT^SSTR	SAT Response - Select Item (36)	Section 8.40 , page 237
AT^SSTR	SAT Response - Set Up Menu (37)	Section 8.41 , page 238
AT^SSTR	SAT Response - Set Up Idle Mode Text (40)	Section 8.42 , page 239
AT^SSTR	SAT Response - Language Notification (53)	Section 8.43 , page 240
AT^SSTR	SAT Response - Open Channel (64)	Section 8.44 , page 241
AT^SSTR	SAT Response - Close Channel (65)	Section 8.45 , page 242
AT^SSTR	SAT Response - Receive Data (66)	Section 8.46 , page 243
AT^SSTR	SAT Response - Send Data (67)	Section 8.47 , page 244
AT^SSTR	SAT Event - Menu Selection (211)	Section 8.48 , page 245
AT^SSTR	SAT Event - User Activity (232)	Section 8.49 , page 246
AT^SSTR	SAT Event - Idle Screen Available (233)	Section 8.50 , page 247
AT^SSTR	SAT Event - Language Selection (235)	Section 8.51 , page 248
AT^SSTR	SAT Event - Browser Termination (236)	Section 8.52 , page 249
AT^SSTR	SAT Event - Terminate Command (254)	Section 8.53 , page 250
AT^SWWAN	PDP Context Activate or Deactivate	Section 12.18 , page 384
ATD	Dialing Supplementary Service Number	Section 11.1 , page 343
ATD*99#	Request Packet Domain service	Section 12.15 , page 378
ATE	AT Command Echo	Section 4.5 , page 110
ATI	Display product identification information	Section 6.1 , page 132
ATQ	Result Code Presentation Mode	Section 2.4 , page 33
ATV	Result code format mode	Section 2.5 , page 34
ATX	Result Code Selection	Section 2.6 , page 35
ATZ	Restore AT Command Settings from User Defined Profile	Section 2.7 , page 36

About Gemalto

Gemalto (Euronext NL0000400653 GTO) is the world leader in digital security with 2014 annual revenues of €2.5 billion and blue-chip customers in over 180 countries. Our 14,000 employees operate out of 99 offices, 34 personalization and data centers, and 24 research and software development centers located in 46 countries.

We are at the heart of the rapidly evolving digital society. Billions of people worldwide increasingly want the freedom to communicate, travel, shop, bank, entertain and work - anytime, everywhere - in ways that are enjoyable and safe. Gemalto delivers on their expanding needs for personal mobile services, payment security, authenticated cloud access, identity and privacy protection, eHealthcare and eGovernment efficiency, convenient ticketing and dependable machine-to-machine (M2M) applications.

Gemalto develops secure embedded software and secure products which we design and personalize. Our platforms and services manage these secure products, the confidential data they contain and the trusted end-user services they enable. Our innovations enable our clients to offer trusted and convenient digital services to billions of individuals.

Gemalto thrives with the growing number of people using its solutions to interact with the digital and wireless world.

For more information please visit

m2m.gemalto.com, www.facebook.com/gemalto, or [Follow@gemaltom2m](https://twitter.com/Follow@gemaltom2m) on twitter.

Gemalto M2M GmbH
St.-Martin-Str. 60
81541 Munich
Germany

➔ M2M.GEMALTO.COM

gemalto
security to be free