


Product Configuration System



MHz Range Crystal Units



NOTE:
If you require a load capacitance other than the above listed, please contact your EEA representative for assistance.