

C5 AND C6 ADJUSTABLE STOP

NOTES:

- 1) REMOVE HEX NUT, LOCK WASHER AND FLAT WASHER
- 2) LIFT AND ROTATE ADJUSTABLE STOP TO DESIRED POSITION
- 3) REPLACE FLATWASHER, LOCK WASHER AND HEX NUT

