

## C1 ADJUSTABLE STOP

### NOTES:

- 1) REMOVE HEX NUTS AND LOCKWASHERS
- 2) REMOVE REARPLATE BY SLIDING ALONG SHAFT AND SCREWS
- 3) MOVE STOP PINS TO DESIRED POSITION
- 4) REPLACE REARPLATE LOCKWASHERS AND HEX NUTS
- 5) TIGHTEN HEX NUTS

