



Molex Japan Co., Ltd.

INSTRUCTION MANUAL NO.	
IS-0037E	
ISSUED	1987-07-29
REVISED	2005-01-28
REV.	A

OPERATING MANUAL

EXTRACTION TOOL: 2.0mm Pitch Board-in Crimp Terminal

Tool Number : 57057-6000


1. Introduction

This document is prepared so that the tool is properly used.

Please take the time to read this manual, making sure you understand the operating procedures described herein before attempting to operate the tool.

2. Specifications

Applicable housing number	51015
Applicable terminal number	50034



3. Operation steps

No	Operation steps	Explanation figure
1	Hold an extraction tool, and make up the "Molex" engraving side of it as shown in a right picture.	
2	Hold a housing, and upturn the lance part of it. Next, (1) bend a wire to downward, and (2) insert the tool to the interior of the housing in the lance side in a right picture.	
3	Pull out at the time with the wire and the tool in a right picture with the tool inserted.	

"Note" Please surely lock the terminal pushing the lance of the housing when you install the terminal again after pulling out.