

# Production Guide



## USB 3.1 Type C

ANE009 // FABIAN ALTENBRUNN

### 1. Introduction

---

USB-C now offers different connector variants ranging from USB 2.0 in Type-C housing to Type-C for a 10 GBit data rate. The housing variants have also become more diverse. From the horizontal hybrid type to vertical variants and the mid-mount type, which is placed in a PCB cutout. All these types have their special characteristics, which in many cases may already have to be taken into account in the layout to ensure problem-free manufacturing is possible afterwards. We would like to shed light on these points and identify ways of dealing with the challenges. The PCB itself and its manufacture cannot be left out of the equation either, as it has certain limitations that should be taken into account in order to achieve the best possible result. Once all this has been done, it is a matter of controlling the manufacturing process in its various steps from stencil printing to the soldering oven and optimizing the parameters, so that the slender type-C connectors can also be processed in a way suitable for series production.

### 2. Process parameters for the USB-C connectors

---

The USB-C product portfolio from Würth Elektronik eiSos GmbH & Co. KG includes the plug, receptacle connectors, fastening elements (spacers) as well as USB-C cable without eMarker labeling. The aim of this Production Guide is to show the relevant process parameters and to depict the ideal production process by means of practical recommendations. The respective connectors have different requirements for the production materials as well as for the production process itself.

To illustrate this, let's start with the parameter table. It provides an overview of the product portfolio and the relevant process parameters. In the following sections, each product family is examined in more detail. Here, dimensioned stencil drawings are displayed and the production process is described step by step.

At the end of the document in the appendix you will find the basis for calculation and formulas for the THR (through-hole reflow) process. This information helps you calculate your stencil opening, for example, if you cannot make use of the parameters recommended to us. This may be true if you have certain keepout zones around the component on account of your PCB design, and thus require modified stencil openings. Likewise, changing the PCB thickness inevitably leads to a change in the volume of solder paste required. Here we support you with our THR stencil calculation tool to make quick calculations.

# Production Guide



## USB 3.1 Type C

2.1. Product family	2.2. Plug		2.3. Receptacle		
Product name	WR-COM USB 3.1 Type C Plug Horizontal SMT 0.8 mm	WR-COM USB 3.1 Type C Plug Horizontal 0.8 mm	WR-COM USB 3.1 Type C Receptacle Horizontal THR / SMT	WR-COM USB 3.1 Type C Receptacle Horizontal Mid-Mount THR / SMT 1.6 mm	WR-COM USB 3.1 Type C Receptacle Vertical SMT 1.0 mm
Product image					
Article no.	632712000011	632712000112	632723100011 632723300011	632723130112	632722110112
Pins	22	24	24	24	24
PCB thickness	0.8 mm	0.8 mm	1.00 / 1.60 mm	1.60 mm	-
Mounting	SMT	SMT	SMT / THR	SMT / THR	SMT
<b>Stencil parameters</b>					
Stencil thickness	100 µm	100 µm	100 µm	100 µm	100 µm
Electropolished	yes	yes	yes	yes	yes
Nano-coated	no	no	yes	yes	no
Stencil recommendation	Fig. 1	Fig. 1	Figs. 4-7	Figs. 4-7	Fig. 12
<b>Print parameters</b>					
Grain size solder paste	4	4	5	5	4
Print speed	40 mm/s	40 mm/s	20 mm/s	20 mm/s	40 mm/s
Squeegee force	50 N	50 N	70 N	70 N	50 N
Squeegee angle	60-67°	60-67°	45°	45°	60-67°
Squeegee type	Metal	Metal	Plastic	Plastic	Metal
Print cycles	1	1	2	2	1
Additional solder depot	no	no	yes	yes	yes
<b>Assembly parameters</b>					
Assembly speed	Standard	Standard	Reduced to minimum	Reduced to minimum	Standard
Automatic assembly	Partially automated	Partially automated	yes	yes	yes
<b>Soldering parameters</b>					
Solder profile	IPC / JEDEC J-STD-020E				
Flow direction	-	-	Connector face or pins first	Connector face or pins first	-
Inspection of solder joints	AOI	AOI	AOI / XRAY	AOI / XRAY	AOI

# Production Guide



## USB 3.1 Type C

### 3. Processing the USB-C plug

The USB-C plug connector is not a classic connector assembled onto the PCB, but this component is shifted to the edge of the PCB. As a result, its component pads are located both on the underside and on the topside of the PCB. This poses a major challenge for effective and cost-effective process design. In order to achieve this, some adaptations are required in the stencil design as well as the production of a solder deposit on the underside of the PCB. The exact sequence of tasks required is listed below.

#### 3.1. Stencil recommendation:

##### Underside of the PCB:

- Reduce the stencil opening by 4% circumferentially relative to the pad (as an oblong opening)
- Create a solder depot on the underside of the PCB with this first process step

##### Topside of the PCB:

- Reduce the stencil opening (shown in blue in Fig. 1) in the pad area to a width of 0.20 mm (pad width 0.30 mm is shown in red in Fig. 1)
- Place the stencil opening to the back by 1/3 of the pad length relative to the start of the pad (overprinting on the solder resist is intended and is important for the soldering process)
- The reduction in width and the shift of the stencil opening prevents excessive extrusion of paste during the assembly process. The risk of short-circuiting is thus significantly reduced.




Figure 1: Stencil recommendation of the USB-C Plug for the topside of the PCB

# Production Guide



## USB 3.1 Type C

### 3.2. Assembly process:

1. If possible: Carry out solder paste printing on the underside of the PCB. With this process step, a solder deposit can be created (according to stencil recommendation for the underside of PCB in section 3.1).
2. Reflow soldering of the underside of the PCB.
3. Solder paste printing of the topside of the PCB using the stencil recommendation shown in Figure 1.
4. Assembly of the USB-C plug (whether automatic or manual assembly is possible depends on the production equipment).
5. During the reflow soldering process, it is important that the USB-C enters the reflow oven with the connector face or pin row first. This prevents the USB-C from bending. This bending can occur if the solder paste of the pin row does not melt simultaneously.
6. AOI (automatic optical inspection) (see Figure 2 and 3)

### Topside




Figure 2: IPC-compliant soldered component connections on the topside of the PCB

### Underside




Figure 3: IPC-compliant soldered component connections on the underside of the PCB

## 4. Processing the USB-C receptacle hybrid

In USB-C hybrid variants, the 24 contacts are made up of twelve SMT and twelve THR contacts. In addition, there are four more housing pins in THR design. The mix of SMT and THR contacts confers significant mechanical advantages. The most decisive factors here are significantly higher retention forces on the PCB compared to a fully SMT design and minimization of soldering problems as a result of insufficient coplanarity of the consecutive rows of pins. The pin mix and the very compact design of the USB-C hybrid type means it is a challenge to get enough solder paste around the THR pad as well as into its hole. The required process parameters as well as the exact stencil drawings (see Figs. 4 to 7) are listed in the following bullet points.

# Production Guide



## USB 3.1 Type C

### 4.1. Solder paste print parameters:

- Use solder paste with a grain size of 5.
- Implementation of a second printing process (i.e. a second printing cycle immediately follows the first without lifting the stencil from the PCB). This favors greater penetration of the solder paste into the depth of the hole.
- Reduce printing speed to 20 mm/s (typically 40 mm/s).
- Increase squeegee force to 70 N (typically 50 N).
- Please do not use a standard squeegee with an angle between 60-67°, but a squeegee with a 45° angle. This is necessary to transport the maximum amount of solder paste into the depth of the hole. If possible, a plastic squeegee is also recommended here (this has the property of preloading the stencil a little more).

### 4.2. Stencil recommendations:

Underside of the PCB




Figure 4: USB-C hybrid shown as Altium element incl. stencil recommendation for the underside of the PCB




Figure 5: Dimensioned stencil openings of the underside of the PCB

# Production Guide



## USB 3.1 Type C

Topside of the PCB




Figure 6: USB-C hybrid shown as Altium element incl. stencil recommendation for the topside of the PCB




Figure 7: Dimensioned stencil openings of the topside of the PCB

### 4.3. Assembly process:

1. If possible: Provide for solder paste printing on the underside of the PCB. Please use the stencil recommendation shown in Figs. 4 and 5. This process step can be used to create a solder deposit on the underside of the PCB. However, it must be ensured that no solder paste enters the hole. This would make it difficult or even impossible to assemble the USB-C later in the process.
2. Reflow soldering of the underside of the PCB.
3. Solder paste printing of the topside of the PCB using the stencil recommendation shown in Figs. 6 and 7. It is recommended to carry out a print check for prototypes, initial series and production starts. The solder paste print is optically inspected and measured. The filling level of the paste after the printing process is particularly important for the USB-C soldering process. This should ideally correspond to approx. 75% of the hole depth.
4. Carry out the assembly of the USB-C using a pick and place machine. The component 632723100011 can be used up to a PCB thickness of 1.3 mm. Please reduce the settling speed here too. The slower this is selected, the less likely it is to push or punch the paste out of the hole. This inevitably leads to a deterioration of the soldering result.

# Production Guide



## USB 3.1 Type C

5. During the reflow soldering process, it is recommended that the USB-C enters the reflow oven with the connector face or pin row first (see Figure 8). This prevents the USB-C from bending. This bending can occur if the solder paste of the pin row does not melt simultaneously.




Figure 8: Recommended flow direction of the USB-C hybrid during reflow soldering

6. Perform AOI for the visible pins. The hidden pins can be checked and the filling level determined by X-ray.

# Production Guide



## USB 3.1 Type C

### 5. Layout tips for the USB-C mid-mount

To facilitate the routing of the differential pairs B2/B3 and B10/B11, it is possible to increase the distance to the milled edge in deviation from the layout recommendation. Assuming a milling cutter with a diameter of 0.50 mm and a resulting radius of 0.25 mm, which is common in PCB production, the distance from the center of the lowest row of pins to the center of the milling contour can be changed as follows:

According to the data sheet, a distance of 0.80 mm is specified for this. This results in a distance of 0.55 mm from the center of the row of pins to the milled edge. Thus, the width available for routing is only 225 µm. The area between the pad rest-ring and the milling contour can be increased by 200 µm by increasing the distance from the center of the lowest pin row to the center of the milling contour to 1.00 mm. Figures 9 to 11 show the dimensioned displacement of the milled edge. The 425 µm now available is sufficient for routing the differential pairs (125 µm per track).

Contrary to the data sheet, the oblong holes B1 and B12 can also be designed as drilled holes similar to B2 to B11. This simplifies the PCB manufacturing process.




Figure 9: Comparison of the two footprint variants of the USB-C mid-mount




Figure 10: Dimensioned original footprint




Figure 11: Dimensioned optimized footprint

Caution: The displacement of the milling contour must be discussed with the assembler (EMS). As the milling contour is now moved closer to the component as shown in Figures 9, 10 and 11, higher positioning accuracy is required of the pick-and-place machines. Assembly/placement accuracy of +/- 50 µm is recommended here.



# Production Guide



## USB 3.1 Type C




Figure 12: 3D representation of the shifted milled edge (left: original / right: optimized)

### 6. Processing the USB-C receptacle vertical

With the USB-C receptacle vertical, the component connections are implemented with two SMT pin rows aligned parallel to each other. This greatly simplifies stencil design as well as the soldering process. The four shield lances on the housing are nevertheless implemented as THR pins for mechanical stabilization.

When designing the stencil, make sure to select a 100  $\mu\text{m}$  thick stencil and to design the stencil openings as oblongs, in contrast to the pads. These should also be 4% smaller than the original pads all round. Excessive overprinting around the shield lances is not necessary, since the relatively large hole opening allows sufficient solder paste to be pressed into the hole. The exact opening dimensions of the stencil can be found in our Altium component libraries and in Figure 13.




Figure 13: Stencil recommendation for the USB-C vertical

# Production Guide



## USB 3.1 Type C

### 7. Use of the SMD spacer for cable fixation

Würth Elektronik offers SMD spacers in addition to the existing USB-C connectors and cables. These allow screwable USB-C cables to be integrated into the system. There are two types of locking, cables that are fixed with a central screw and cables that are fixed with two screws along the edge. The layout excerpt in Figure 14 shows the placement of these spacers in relation to the USB-C connector. The two SMD spacers for lateral two-screw locking are shown in red and the one SMD spacer for centric one-screw locking is shown in blue. Solder bridges may occur when locking the cable with the two lateral screws, due to the very small distance between the USB-C shield lances and the SMD spacer. However, these do not adversely affect the system functionality (same potential) and do not necessarily have to be corrected / reworked.




Figure 14: Positioning of the SMD spacers in relation to the USB-C

#### 7.1. Locking types:




Figure 15: Centric one-screw locking

Figure 16: USB-C cable with centric screw

# Production Guide



## USB 3.1 Type C





Figure 18: USB-C cable with two lateral screw



Figure 17: Lateral two-screw fixation

### 7.2. Types of installation:

#### Integration of the PCB into a housing:

- The spacers must be positioned at the edge of the PCB (solder pads of the spacer are located 0.40 mm behind the edge of the PCB and therefore do not interfere with PCB manufacture or the assembly and soldering process) (see layout Figure 14 & Figure 19 after assembly).
- The USB-C connector is placed up to the front edge of the housing and thus beyond the edge of the PCB.




Figure 19: 3D representation of the USB-C hybrid with the lateral SMD spacers

# Production Guide



## USB 3.1 Type C

### Assembly without housing:

- The spacers must be positioned at the edge of the PCB.
- Caution: For centric one-screw fixation, the USB-C connector must be placed at the PCB edge, contrary to the layout recommendation. Otherwise, the cable connector may bend when tightening the screw. As a result, mechanical and electrical damage can occur to the component as well as to the entire device.
- This mechanical torsion cannot occur with the two-screw system. This allows the USB-C connector to be placed both at the edge of the PCB and beyond.




Figure 20: 3D representation of the USB-C hybrid with the centric SMD spacer

# Production Guide



## USB 3.1 Type C

### Appendix: Basis of calculation of the THR process

#### Layout suggestion and volume calculation of the PCB (drilled hole)

- The volume calculation for the drilled hole
 
$$V_{pcb} = \pi \frac{Dh^2}{4} \times T_b$$
- $T_b$ : PCB thickness
- $Dh$ : Hole diameter = pin diameter + 0.3 mm for round pins
  - (0.25 mm for rectangular pins)
- $D_{sp}$ : Solder pad diameter =  $Dh$  (+0.6 to 0.8 mm)





Figure 21: Volume calculation for the drilled hole

#### Volume calculation for the pin

- $V_{pin} = \pi \times \text{pin radius}^2 \times \text{PCB thickness}$
- For round pins: Pin radius =  $\frac{Wp}{2}$
- For rectangular pins: Pin radius =  $\sqrt{\frac{AxB}{\pi}}$




Free volume for solder paste  
Figure 22: Volume calculation for the pin hole

#### Volume calculation for the fillet according to the Pappus-Guldin formula

- $V_{fillet} = 0.215 \times C^2 \times (0.2334 \times C + \text{pin radius}) \times 2 \pi$
- For round pins: pin radius =  $\frac{Wp}{2}$
- For rectangular pins: pin radius =  $\sqrt{\frac{AxB}{\pi}}$
- $C = \frac{\text{solder pad diameter} - \text{pin diameter}}{2}$

#### Calculation for the solder paste volume and the stencil opening

- Volume of solder paste =  $V_{paste} = (2 \times V_{fillet} + V_{pcb} - V_{pin}) \times 2$
- The total volume is taken x2, as standard solder pastes have a metallic content of 50%.
- Stencil opening (mm<sup>2</sup>) =  $\frac{V_{paste}}{T_s \text{ (stencil thickness)}}$
- Caution: How deep the paste is pressed into the hole
  - depends on the diameter and height of the stencil.
  - This is also influenced by the printing parameters: print cycles, force, speed and the squeegee angle.



Free stencil aperture  
Figure 23: Stencil opening




Figure 24: Filling level of the solder paste print

# Production Guide



## USB 3.1 Type C

- Our THR stencil calculator (Figure 25): Please ask your responsible sales team

more than you expect

### THR (trough hole reflow) stencil calculation

Fill in grey fields

#### for circular pin

solder pad diameter "s"	2,60 [mm]
plated hole diameter "D"	1,10 [mm]
pin diameter "d"	0,70 [mm]
board thickness "t"	1,50 [mm]
paste reduction factor	0,50
stencil height "h"	0,17 [mm]

V <sub>pin</sub>	0,58 [mm <sup>3</sup> ]
V <sub>hole</sub>	1,43 [mm <sup>3</sup> ]
V <sub>fillets</sub>	1,37 [mm <sup>3</sup> ]
V <sub>total</sub>	2,22 [mm <sup>3</sup> ]
V <sub>paste</sub>	4,44 [mm <sup>3</sup> ]

stencil aperture area	26,11 [mm <sup>2</sup> ]
if rounded --> diameter is:	5,77 [mm]
if square --> plain is:	5,11 [mm]

if rectangular: enter first plain	4,00 [mm]
second plain is:	6,53 [mm]

#### for rectangular pin

solder pad diameter "s"	2,10 [mm]
plated hole diameter "D"	1,10 [mm]
pin width "w"	0,70 [mm]
pin length "l"	0,55 [mm]
board thickness "t"	1,10 [mm]
paste reduction factor	0,70
stencil height "h"	0,15 [mm]

V <sub>pin</sub>	0,42 [mm <sup>3</sup> ]
V <sub>hole</sub>	1,05 [mm <sup>3</sup> ]
V <sub>fillets</sub>	0,67 [mm <sup>3</sup> ]
V <sub>total</sub>	1,29 [mm <sup>3</sup> ]
V <sub>paste</sub>	1,85 [mm <sup>3</sup> ]

stencil aperture area	12,31 [mm <sup>2</sup> ]
if rounded --> diameter is:	3,96 [mm]
if square --> plain is:	3,51 [mm]

if rectangular: enter first plain	4,00 [mm]
second plain is:	3,08 [mm]

Figure 25: THR stencil calculator

# Production Guide



## USB 3.1 Type C

- Typical examples of stencil openings




Figure 26: Examples of stencil opening

- Screen printing / solder paste printing




Figure 27: Positioning of the stencil




Figure 28: Applying the solder paste to the hole




Figure 29: Solder paste fills the hole and solder pad




Figure 30: Assembling the component




Figure 31: Reflow soldering




Figure 32: Soldered component

# Production Guide



## USB 3.1 Type C

- Quality requirements according to IPC-A-610




Figure 33: Ideal case - 100% filling level




Figure 34: Minimum - 75% filling level





Figure 35:  
Micrograph of the soldered THR pin



# Production Guide



## USB 3.1 Type C

### IMPORTANT NOTICE

The Application Note is based on our current knowledge and experience and serves as general information and is not as an assurance from Würth Elektronik eiSos GmbH & Co. KG of the suitability of the product for customer applications. The Application Note is subject to change without prior notice. This document and parts thereof may not be reproduced or copied without written permission. Würth Elektronik eiSos GmbH & Co. KG and/or its partners and affiliates (hereinafter collectively referred to as "WE") are not liable for application-related support of any nature. Customers are entitled to use the support and product recommendations from WE for their own applications and designs. The customer always bears sole responsibility for applicability and use of WE products in a particular design. As a result of this, it is the customer's task to initiate investigations and to decide whether the device is admissible or not for the respective customer application with the specific product features described in the product specification.

The technical data are specified in the current data sheet for the product. The customer therefore has to use the data sheets and is explicitly referred to the fact that they have to verify that the data sheets are up to date. The current data sheets can be downloaded from [www.we-online.com](http://www.we-online.com). The customer must strictly observe product-specific remarks and warnings. WE reserves the right to undertake corrections, modifications, extensions, improvements, and other changes to its products and services. Licenses and other rights of whatever type, especially patents, utility models, brands, copyrights, and other industrial property rights, are neither granted nor does a corresponding obligation arise to grant such rights. By publishing information on products or services from third parties, WE neither grants a license for the use of such products or services nor a guarantee or endorsement of these.

The use of WE products in safety-critical applications or those in which a product failure could lead to serious personal injury or death, are not permitted. Furthermore, WE products are neither designed nor intended for use in fields such as military technology, aerospace, nuclear control, marine, transportation (control of cars, trains or ships), traffic control installations, emergency management, medical technology, public information networks, etc. The customer must inform WE of intending such use prior to the start of the planning phase (design-in phase). In case of customer applications that require a high degree of safety and which can represent a risk to life and limb in the event of malfunctions or failure of an electronic component, the customer has to ensure that they have the required specialist knowledge of safety and legal implications of their applications. The customer confirms and agrees that irrespective of all application-related information and support provided by WE, they bear the overall responsibility for all legal, regulatory and safety-related requirements in conjunction with their products and the use of WE products in such safety-critical applications.

The customer indemnifies and holds WE harmless in all damage claims that arise through such safety-critical customer applications.

### USEFUL LINKS

Application Notes:

[www.we-online.de/appnotes](http://www.we-online.de/appnotes)

REDEXPERT Design Platform:

[www.we-online.de/redexpert](http://www.we-online.de/redexpert)

Toolbox:

[www.we-online.de/toolbox](http://www.we-online.de/toolbox)

Product catalog:

[www.we-online.de/produkte](http://www.we-online.de/produkte)

### CONTACT INFORMATION

Würth Elektronik eiSos GmbH & Co. KG

Max-Eyth-Str. 1 · 74638 Waldenburg · Germany

Tel. +49-7942-945-0 · Fax +49-7942-945-5000

[appnotes@we-online.de](mailto:appnotes@we-online.de) · [www.we-online.de](http://www.we-online.de)