

TPS48111Q1EVM: Evaluation Module for Smart High-Side Driver TPS48111-Q1



ABSTRACT

This user's guide describes the evaluation module (EVM) for the TPS48111-Q1 smart high-side driver. The document provides EVM configuration information and test setup details for evaluating the TPS48111-Q1 device. The EVM schematic, board layout, and bill of materials (BOM) are also included.


| | | |
|---|----------------|--|
|  | <p>Caution</p> | <p>Caution Hot surface. Contact may cause burns. Do not touch!</p> |
|---|----------------|--|

Table of Contents

| | |
|---|----|
| 1 Introduction | 2 |
| 2 Description | 2 |
| 3 Schematic | 3 |
| 4 General Configurations | 4 |
| 5 Test Setup and Procedures | 5 |
| 6 EVAL Board Assembly Drawings | 11 |
| 7 Bill Of Materials (BoM) | 13 |
| 8 Revision History | 16 |

List of Figures

| | |
|--|----|
| Figure 3-1. TPS48111Q1EVM: Evaluation Module Schematic..... | 3 |
| Figure 5-1. TPS48111Q1EVM Setup with Test Equipment..... | 5 |
| Figure 5-2. Pre-charge Profile of the Output Capacitance (VIN = 48 V, COUT = 440 μ F, No-load)..... | 6 |
| Figure 5-3. Start-Up Profile of Bootstrap Voltage for INP = GND..... | 7 |
| Figure 5-4. Start-Up Profile of Bootstrap Voltage for INP = HIGH..... | 7 |
| Figure 5-5. Turn-ON Response of TPS48111-Q1 for INP -> LOW to HIGH..... | 8 |
| Figure 5-6. Turn-OFF Response of TPS48111-Q1 for INP -> HIGH to LOW..... | 8 |
| Figure 5-7. Overcurrent Response of TPS48111-Q1 for a Load Step from 2 A to 8 A With 5-A Overcurrent Protection Setting..... | 9 |
| Figure 5-8. Auto-Retry Response of TPS48111-Q1 for an Overcurrent Fault..... | 9 |
| Figure 5-9. Output Hot-Short Response of TPS48111-Q1 Device..... | 10 |
| Figure 6-1. TPS48111Q1EVM Board (a) Top Assembly (b) Bottom Assembly..... | 11 |
| Figure 6-2. TPS48111Q1EVM Board (a) Top Layer (b) Bottom Layer..... | 11 |
| Figure 6-3. TPS48111Q1EVM Board (a) Inner Signal Layer (b) Inner Routing Layer..... | 12 |

List of Tables

| | |
|---|----|
| Table 2-1. TPS48111Q1EVM Evaluation Board Options and Setting..... | 2 |
| Table 4-1. Input and Output Connector Functionality..... | 4 |
| Table 4-2. Test Points Description..... | 4 |
| Table 4-3. Jumper and LED Descriptions..... | 4 |
| Table 5-1. Default Jumper Setting for TPS48111Q1EVM Evaluation Board..... | 5 |
| Table 7-1. TPS48111Q1EVM Bill Of Materials..... | 13 |

Trademarks

All trademarks are the property of their respective owners.

1 Introduction

The TPS48111Q1EVM allows reference circuit evaluation of TI's smart high-side driver TPS48111-Q1. The TPS48111-Q1 has an operating range of 3.5 V–80 V and has strong gate drive strength of 4 A to enable switching parallel MOSFETs in high current designs. The controller TPS48111-Q1 can drive back-to-back N-channel MOSFETs and also has a separate pre-charge driver (G) with independent control input (INP_G) to drive large capacitive loads. The device provides two-level adjustable overcurrent protection with adjustable circuit breaker timer, fast short-circuit protection, accurate analog current monitor output, and remote overtemperature protection.

1.1 EVM Features

General TPS48111Q1EVM features include:

- 24-V to 60-V (typical) operation
- 5-A to 50-A adjustable overcurrent protection using on-board jumpers
- Programmable circuit breaker timer
- Bi-directional current flow capability
- Load current monitoring output
- Programmable auto-retry and latch options
- LED status indication for overcurrent and overtemperature faults

1.2 EVM Applications

This EVM can be used for the following applications:

- Circuit breaker and safety disconnect switch
- Power distribution unit
- e-relay
- HVAC compressor module

2 Description

The TPS48111Q1EVM evaluation board enables evaluation of TPS48111-Q1 driver from TPS4811x-Q1 family. The input power is applied between connectors T1 and T4 while T2 and T3 provide an output connection to the load, Refer to the schematic in [Figure 3-1](#) and EVM test setup in [Figure 5-1](#).

D4 and D5 provide the fault indication output for the overcurrent and overtemperature faults respectively. Scaled current of the load can be monitored at TP10.

Table 2-1. TPS48111Q1EVM Evaluation Board Options and Setting

| Part Number | EVM Function | Vin Range | Vin UVLO | ENABLE (EN/UVLO) | Overcurrent Protection | | Features |
|---------------|--|--------------|----------|------------------|------------------------|------------|--|
| | | | | | Low Setting | Hi Setting | |
| TPS48111Q1EVM | Smart high-side driver with protection and diagnostics | 24 V to 60 V | 24 V | Active high | 5 A | 50 A | Pre-charging the output overload protection with auto-retry and latch response |

3 Schematic

Figure 3-1 illustrates the EVM schematic.




Figure 3-1. TPS48111Q1EVM: Evaluation Module Schematic

4 General Configurations

4.1 Physical Access

Table 4-1 lists the TPS48111Q1EVM Evaluation Board input and output connector functionality. Table 4-2 and Table 4-3 describe the test point availability and the jumper functionality.

Table 4-1. Input and Output Connector Functionality

| Connector | Label | Description |
|-----------|-------|--|
| T1 | VIN | Power input connector to the positive rail of the input power supply |
| T4 | PGND | Ground connection for the power supply |
| T2 | VOUT | Power output connector to the positive side of the load |
| T3 | PGND | Ground connection for the load |

Table 4-2. Test Points Description

| Test Points | Label | Description |
|---------------------------|---------|---|
| TP1 | VIN | Input power supply to the EVM |
| TP2 | VOUT | Output from the EVM |
| TP3 | EN/UVLO | Enable control (active high) and undervoltage input |
| TP5 | GATE | GATE of the external main MOSFET |
| TP6 | INP | Control input of main MOSFET |
| TP7 | INP/ | Inversion of control input for main MOSFET |
| TP8 | TMR | Fault timer voltage |
| TP9 | VAUX | Auxiliary supply to bias fault LEDs |
| TP10 | IMON | Load current monitor |
| TP11 | FLT_I/ | Overcurrent fault output |
| TP12 | FLT_T/ | Overtemperature fault output |
| TP13 | RS+ | Positive terminal of current sense input |
| TP14 | RS- | Negative terminal of current sense input |
| TP15, TP16, TP17, TP18 | GND | GND |
| TP24 | INP_G | Control input of pre-charge MOSFET |
| TP25 | G | GATE of the pre-charge MOSFET |
| TP26 | INP_G/ | Inversion of control input for pre-charge MOSFET |

Table 4-3. Jumper and LED Descriptions

| Jumper | Label | Description |
|-------------------|-------|--|
| J1 | TMR | Fault timer setting 1-2 position sets 15-ms delay 3-4 position sets 150-ms delay 5-6 position sets the controller in latch-off mode |
| J2 | IMON | Current scale setting 1-2 position sets 0.09 V/A 3-4 position sets 0.034 V/A |
| J3 | IWRN | Overcurrent protection threshold setting 1-2 position sets R_{IWRN} to short and disables the overcurrent protection 3-4 position sets 5 A 5-6 position sets 15 A 7-8 position sets 50 A |
| D4 (RED – LED) | D4 | Fault indicator. LED turns on for overcurrent fault. |
| D5 (RED – LED) | D5 | Fault indicator. LED turns on for overtemperature fault. |

4.2 Test Equipment and Setup

4.2.1 Power Supplies

One adjustable power supply with 0-V to 60V- output and 0-A to 50-A output current limit.

4.2.2 Meters

One DMM minimum needed.

4.2.3 Oscilloscope

A DPO2024 or equivalent, three 10 times voltage probes, and a DC current probe.

4.2.4 Loads

One resistive load or equivalent that can tolerate up to 50-A DC load at 60 V and capable of the output short.

5 Test Setup and Procedures

Make sure the evaluation board has default jumper settings as shown in [Table 5-1](#).

Table 5-1. Default Jumper Setting for TPS48111Q1EVM Evaluation Board

| J1 | J2 | J3 |
|-----|-----|-----|
| 1-2 | 1-2 | 3-4 |




Figure 5-1. TPS48111Q1EVM Setup with Test Equipment

Follow the below instructions before starting any test and repeat again before moving to next test.

- Set the power supply output (VIN) to zero volts.
- Turn ON the power supply and set the power supply output (VIN) to 48 V, current limit = 50 A.
- Turn OFF the power supply.
- Set the jumper setting on EVM to default position as shown in [Table 5-1](#).

5.1 Pre-charging Functional Test

Use the following instructions to capture the pre-charging current profile:

1. First, disable both the Main MOSFETs and pre-charge FET by connecting INP (TP6) and INP_G (TP24) to ground.
2. Set the jumper setting on EVM to default position as shown in [Table 5-1](#).
3. Set the input supply voltage VIN to 48 V and current limit of 10 A.
4. Enable the power supply.
5. Enable the control input (INP_G at TP24) of the pre-charge MOSFET by releasing the ground connection.
6. Observe the waveform at SRC. That is, VOUT (TP2) with an oscilloscope.

Figure 5-2 shows an example of pre-charging current profile captured on the TPS48111Q1EVM Evaluation Board.




Figure 5-2. Pre-charge Profile of the Output Capacitance (VIN = 48 V, COUT = 440 μ F, No-load)

5.2 Power-Up With EN Control

Use the following instructions to verify the power-up profile of TPS48111-Q1:

1. Remove the output capacitors of 440 μF from the board.
2. Disable the pre-charge path by connecting INP_G (TP24) to ground.
3. Connect the EN/UVLO pin (TP3) to ground and INP (TP6) to ground.
4. Set the input supply voltage VIN to 48 V and current limit of 10 A.
5. Enable the power supply.
6. Now, enable the EN/UVLO to HIGH to observe the start-up profile of BST, GATE and SRC when INP = GND as shown in [Figure 5-3](#).
7. Now, disable the controller by making EN/UVLO = LOW.
8. Connect INP (TP6) to VAUX to set INP as HIGH.
9. Now again, enable the EN/UVLO to HIGH to observe the start-up profile of BST, GATE and SRC when INP = HIGH as shown in [Figure 5-4](#).




Figure 5-3. Start-Up Profile of Bootstrap Voltage for INP = GND




Figure 5-4. Start-Up Profile of Bootstrap Voltage for INP = HIGH

5.3 ON and OFF Control With INP Input

Use the following instructions to verify ON and OFF control of TPS48111-Q1:

1. Remove the output capacitors of 440 μF from the board.
2. Disable the pre-charge path by connecting INP_G (TP24) to ground.
3. Connect the INP (TP6) to ground.
4. Set the input supply voltage VIN to 48 V and current limit of 10 A.
5. Enable the power supply.
6. Now, toggle the INP to HIGH and then LOW to verify the turn-ON and turn-OFF response of PU/PD of TPS48111-Q1.

Figure 5-5 and Figure 5-6 show the turn-ON and turn-OFF responses on the TPS48111Q1EVM Evaluation Board.




Figure 5-5. Turn-ON Response of TPS48111-Q1 for INP -> LOW to HIGH




Figure 5-6. Turn-OFF Response of TPS48111-Q1 for INP -> HIGH to LOW

5.4 Overcurrent Protection Test

Use the following instructions to perform the overcurrent test on the TPS48111Q1EVM:

1. Pre-charge the output voltage by following the steps in [Pre-charging Functional Test](#).
2. Now, enable the control input INP (TP6) of the main MOSFETS.
3. Disable the pre-charge FET by connecting INP_G (TP24) to ground.
4. By default, the EVM is configured for 5-A overcurrent protection.
5. Now, load the output with rheostat or electronic load and gradually increase the load current to observe the overload behavior of TPS48111-Q1.
6. Place jumper J3 at other settings to test at various overcurrent limits.

Figure 5-7 and Figure 5-8 show test waveforms for an overcurrent fault.




Figure 5-7. Overcurrent Response of TPS48111-Q1 for a Load Step from 2 A to 8 A With 5-A Overcurrent Protection Setting




Figure 5-8. Auto-Retry Response of TPS48111-Q1 for an Overcurrent Fault

5.5 Output Hot-Short Test

Use the following instructions to perform output the hot-short test:

1. Pre-charge the output voltage by following the steps in [Pre-charging Functional Test](#).
2. Now, enable the control input INP (TP6) of the main MOSFETS.
3. Disable the pre-charge FET by connecting INP_G (TP24) to ground.
4. Now, short the output, That is, VOUT to GND with a shorter cable and observe the short-circuit response of TPS48111-Q1 using an oscilloscope.

Figure 5-9 shows hot-short response of TPS48111-Q1 on TPS48111Q1EVM Evaluation Board.




Figure 5-9. Output Hot-Short Response of TPS48111-Q1 Device

6 EVAL Board Assembly Drawings

6.1 PCB Drawings

Figure 6-1 shows component placement of the EVAL Board, and Figure 6-2 and Figure 6-3 show PCB layout images.




Figure 6-1. TPS48111Q1EVM Board (a) Top Assembly (b) Bottom Assembly




Figure 6-2. TPS48111Q1EVM Board (a) Top Layer (b) Bottom Layer




Figure 6-3. TPS48111Q1EVM Board (a) Inner Signal Layer (b) Inner Routing Layer

7 Bill Of Materials (BoM)

Table 7-1 lists the EVM BoM.

Table 7-1. TPS48111Q1EVM Bill Of Materials

| Designator | Quantity | Description | Part Number | Manufacturer |
|----------------|----------|---|----------------------|-----------------------------|
| !PCB1 | 1 | Printed Circuit Board | PSIL180 | Any |
| C2, C15 | 2 | CAP, AL, 220 uF, 100 V, +/- 20%, 0.153 ohm, AEC-Q200 Grade 2, SMD | EEV-FK2A221M | Panasonic |
| C3, C4 | 2 | CAP, CERM, 0.1 uF, 100 V, +/- 10%, X7R, AEC-Q200 Grade 1, 0805 | CGA4J2X7R2A104K125AA | TDK |
| C6 | 1 | CAP, CERM, 0.47 uF, 25 V, +/- 10%, X7R, AEC-Q200 Grade 1, 0603 | CGA3E3X7R1E474K080AB | TDK |
| C8 | 1 | CAP, CERM, 1000 pF, 50 V, +/- 5%, X7R, 0805 | C0805C102J5RACTU | Kemet |
| C11 | 1 | CAP, CERM, 1000 pF, 10 V, +/- 10%, X7R, 0402 | 0402ZC102KAT2A | AVX |
| C12 | 1 | CAP, CERM, 2.2 uF, 25 V, +/- 10%, X7R, AEC-Q200 Grade 1, 0805 | GCM21BR71E225KA73L | MuRata |
| C13 | 1 | CAP, CERM, 0.068 uF, 100 V, +/- 10%, X7R, 0805 | C0805C683K1RACTU | Kemet |
| C14 | 1 | CAP, CERM, 0.68 uF, 50 V, +/- 10%, X7R, 0805 | C0805C684K5RACTU | Kemet |
| C16 | 1 | CAP, AL, 47 uF, 100 V, +/- 20%, 0.32 ohm, AEC-Q200 Grade 2, SMD, SMT Radial H13 | EEV-FK2A470Q | Panasonic |
| C17, C18 | 2 | CAP, CERM, 1 uF, 100 V, +/- 10%, X7R, 1812 | C4532X7R2A105K230KA | TDK |
| C21 | 1 | CAP, CERM, 10 uF, 100 V, +/- 20%, X7R, 2220 | 22201C106MAT2A | AVX |
| D2 | 1 | Diode, Schottky, 100 V, 2 A, SMB | SS2H10-E3/5BT | Vishay-Semiconductor |
| D3 | 1 | LED, 0805, Green, SMD | LTST-C170KGKT | Lite-On |
| D4, D5 | 2 | LED, Red, 0805, SMD | LTST-C170KRKT | Lite-On |
| D6 | 1 | Diode, Zener, 5.6 V, 300 mW, AEC-Q101, SOD-323 | SZMM3Z5V6ST1G | ON Semiconductor |
| D10, D11 | 2 | Diode, Schottky, 100 V, 0.25 A, SOD-123F | BAT46WH,115 | Nexperia |
| H1, H2, H3, H4 | 4 | Machine Screw, Round, #4-40 x 1/4, Nylon, Philips panhead | NY PMS 440 0025 PH | B&F Fastener Supply |
| H5, H6, H7, H8 | 4 | Standoff | 1902C | Keystone |
| J1 | 1 | Header, 100mil, 3x2 3x2, Tin, TH | PEC03DAAN | Sullins Connector Solutions |
| J2 | 1 | Header, 100mil, 2x2, Tin, TH | PEC02DAAN | Sullins Connector Solutions |
| J3 | 1 | Header, 100mil, 4x2, Tin, TH | PEC04DAAN | Sullins Connector Solutions |

Table 7-1. TPS48111Q1EVM Bill Of Materials (continued)

| Designator | Quantity | Description | Part Number | Manufacturer |
|---------------------|----------|--|-----------------------|-----------------------------|
| Q1, Q2, Q12, Q14 | 4 | N-Channel 80V 300A (Tc) 375W (Tc) Surface Mount PG-HSOG-8-1 | IAUS300N08S5N012ATMA1 | Infineon |
| Q4, Q16 | 2 | MOSFET, N-CH, 60 V, 0.115 A, SOT-323 | 2N7002W-7-F | Diodes Inc. |
| Q5 | 1 | Transistor, NPN, 160 V, 0.3 A, SOT-23 | PMBT5551,215 | Nexperia |
| Q6 | 1 | Transistor, NPN, 40 V, 0.2 A, SOT-23 | MMBT3904 | Fairchild Semiconductor |
| Q15 | 1 | MOSFET, N-CH, 100 V, 1.4 A, SOT-23 | DMN10H220L-7 | Diodes Inc. |
| R1 | 1 | Res Metal Strip 3921 0.0005 Ohm 1% 3W ±175ppm/°C Molded SMD SMD Embossed, 3921 Plastic T/R | WSL3921L5000FEA | Vishay Dale |
| R4, R7 | 2 | RES, 220, 1%, 1 W, AEC-Q200 Grade 0, 2512 | CRCW2512220RFKEG | Vishay-Dale |
| R5 | 1 | RES, 100, 1%, 0.125 W, AEC-Q200 Grade 0, 0805 | CRCW0805100RFKEA | Vishay-Dale |
| R6, R8, R41, R45 | 4 | RES, 2.21, 1%, 0.1 W, 0603 | RC0603FR-072R21L | Yageo |
| R9 | 1 | RES, 0, 5%, 0.1 W, AEC-Q200 Grade 0, 0603 | CRCW06030000Z0EA | Vishay-Dale |
| R10 | 1 | RES, 10.0, 1%, 0.25 W, AEC-Q200 Grade 0, 0603 | CRCW060310R0FKEAHP | Vishay-Dale |
| R11, R17, R30, R49 | 4 | RES, 9.53 k, 1%, 0.1 W, 0603 | RC0603FR-079K53L | Yageo |
| R12, R21, R22, R47 | 4 | RES, 3.16 k, 1%, 0.1 W, AEC-Q200 Grade 0, 0603 | CRCW06033K16FKEA | Vishay-Dale |
| R14 | 1 | RES, 1.47 k, 0.1%, 0.1 W, 0603 | RT0603BRD071K47L | Yageo America |
| R18, R19, R20 | 3 | RES, 10.0 k, 1%, 0.125 W, AEC-Q200 Grade 0, 0805 | ERJ-6ENF1002V | Panasonic |
| R23 | 1 | RES, 100 k, 1%, 0.1 W, AEC-Q200 Grade 0, 0603 | CRCW0603100KFKEA | Vishay-Dale |
| R24 | 1 | RES, 41.2 k, 1%, 0.1 W, 0603 | RC0603FR-0741K2L | Yageo |
| R25 | 1 | RES, 20.0 k, 0.5%, 0.1 W, 0603 | RT0603DRE0720KL | Yageo America |
| R26, R48 | 2 | RES, 0, 5%, 0.1 W, 0603 | ERJ-3GEY0R00V | Panasonic |
| R27 | 1 | RES, 475 k, 1%, 0.1 W, 0603 | RC0603FR-07475KL | Yageo |
| R28 | 1 | RES, 158 k, 1%, 0.1 W, AEC-Q200 Grade 0, 0603 | CRCW0603158KFKEA | Vishay-Dale |
| R29 | 1 | RES, 47.0 k, 1%, 0.1 W, AEC-Q200 Grade 0, 0603 | CRCW060347K0FKEA | Vishay-Dale |
| R42 | 1 | RES, 470 k, 1%, 0.1 W, 0603 | RC0603FR-07470KL | Yageo |
| R44 | 1 | RES, 24.9 k, 1%, 0.125 W, AEC-Q200 Grade 0, 0805 | CRCW080524K9FKEA | Vishay-Dale |
| SH-J1, SH-J2, SH-J3 | 3 | Shunt, 100mil, Flash Gold, Black | SPC02SYAN | Sullins Connector Solutions |
| T1, T2, T3, T4 | 4 | Terminal 90A Lug | CB70-14-CY | Panduit |

Table 7-1. TPS48111Q1EVM Bill Of Materials (continued)

| Designator | Quantity | Description | Part Number | Manufacturer |
|--|----------|--|-----------------------|-------------------|
| TP1, TP2, TP9 | 3 | Test Point, Multipurpose, Red, TH | 5010 | Keystone |
| TP3, TP5, TP6, TP8, TP10, TP11, TP12, TP13, TP14, TP24, TP25 | 11 | Test Point, Multipurpose, White, TH | 5012 | Keystone |
| TP7, TP26 | 2 | Test Point, Multipurpose, Orange, TH | 5013 | Keystone |
| TP15, TP16, TP17, TP18 | 4 | Test Point, Multipurpose, Black, TH | 5011 | Keystone |
| U2 | 1 | 100V Smart High Side controller with Protection and Diagnostics | PTPS48111-Q1 | Texas Instruments |
| C1 | 0 | CAP, CERM, 0.01 uF, 100 V, +/- 10%, X7R, 1206 | 12061C103KAT2A | AVX |
| C5, C9, C20 | 0 | CAP, CERM, 0.1 uF, 100 V, +/- 10%, X7R, AEC-Q200 Grade 1, 0805 | CGA4J2X7R2A104K125AA | TDK |
| C7 | 0 | CAP, CERM, 0.47 uF, 25 V, +/- 10%, X7R, AEC-Q200 Grade 1, 0603 | CGA3E3X7R1E474K080AB | TDK |
| C10 | 0 | CAP, CERM, 330 pF, 50 V, +/- 10%, X7R, 0402 | GRM155R71H331KA01D | MuRata |
| C19 | 0 | CAP, CERM, 0.01 uF, 100 V, +/- 5%, X7R, 0805 | 08051C103JAT2A | AVX |
| D1 | 0 | Diode, TVS, Uni, 70 V, 113 Vc, SMC | SMCJ70A | Littelfuse |
| FID1, FID2, FID3, FID4, FID5, FID6 | 0 | Fiducial mark. There is nothing to buy or mount. | N/A | N/A |
| Q3, Q13 | 0 | N-Channel 80V 300A (Tc) 375W (Tc) Surface Mount PG-HSOG-8-1 | IAUS300N08S5N012ATMA1 | Infineon |
| R2 | 0 | Res Metal Strip 3921 0.0005 Ohm 1% 3W ±175ppm/°C Molded SMD SMD Embossed Plastic T/R | WSL3921L5000FEA | Vishay Dale |
| R3 | 0 | RES, 100, 1%, 0.5 W, AEC-Q200 Grade 0, 1206 | CRCW1206100RFKEAHP | Vishay-Dale |
| R13, R43 | 0 | RES, 0, 5%, 0.1 W, AEC-Q200 Grade 0, 0603 | CRCW06030000Z0EA | Vishay-Dale |
| R15 | 0 | RES, 10.0, 1%, 0.125 W, 0805 | RC0805FR-0710RL | Yageo America |
| R16 | 0 | RES, 470 k, 1%, 0.1 W, 0603 | RC0603FR-07470KL | Yageo |
| R31 | 0 | RES, 9.53 k, 1%, 0.1 W, 0603 | RC0603FR-079K53L | Yageo |

8 Revision History

NOTE: Page numbers for previous revisions may differ from page numbers in the current version.

| Changes from Revision * (June 2022) to Revision A (December 2022) | Page |
|--|-------------------|
| • Updated TPS48111Q1EVM: Evaluation Module Schematic..... | 3 |
| • Updated TPS48111Q1EVM Setup with Test Equipment..... | 5 |

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATA SHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, regulatory or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to [TI's Terms of Sale](#) or other applicable terms available either on ti.com or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

TI objects to and rejects any additional or different terms you may have proposed.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2022, Texas Instruments Incorporated